

Gearmulator MD × Ableton Push 3

CHEAT SHEET

Play the emulated Machinedrum from Push 3 in User Mode. Press User to switch between Live and the MD.

github.com/raphaelshklarek/gearmulator-md-mm

PADS 8 × 8 grid, top row = row 8



PATTERNS 1-16

Shown while a bank is selected. Tap to pick a pattern.

MUTES 1-16

Tap to mute / unmute. Red = playing, dark = muted.

TRACKS 1-16

Tap to select a track. Red = selected / playing.

TRIGS 1-16

Sequencer steps in grid record or Accent / Swing.

Select a pattern

Tap or hold a bank button (lower row 1-4): the top rows show its patterns. Tap one to pick it. It blinks red until the switch (MD countdown). Hot Swap toggles banks A-D / E-H.

SETUP

1. Connect Push 3 over USB (standalone models: Control mode) and load Gearmulator MD - one instance only.
2. Live > Settings > Link, Tempo & MIDI: turn Track and Remote off for the "Ableton Push 3 User Port" input.
3. Press User on Push. Buttons glow when mapped, brighten while held. Press User again to return to Live.

The Push display stays with Live while Live is running. Monomachine: pads, knobs and buttons work; function shortcuts are Machinedrum only.

KNOBS & WHEELS

Encoders 1-8	Data entry A-H
Left jog wheel	Level, fine
Touch strip	Level, fast slide
Right jog wheel	Track select

TRANSPORT

Play	Play
Stop	Stop
Record	Grid record
Capture	Live record
Tap Tempo	Tempo

PAGES

Double Loop	Next trig page
Upper row 1-4	Page lights 1-4

Upper / lower row = the 8 buttons above / below the display.

NAVIGATION

Shift	Function
D-pad arrows	Arrow buttons
D-pad centre	Enter / Yes
Master	Exit / No
Select	Synth / FX / Routing
Note	Kit

BANKS

Lower row 1-4	Bank A-D
Hot Swap	Bank group A-D/E-H

FUNCTION SHORTCUTS

Mute	Mute mode
Accent	Accent
Quantize	Swing
Gear (Setup)	Global