









# **Basics of induction Motors**

Commissioning of SIMOCODE with TIA portal






#### SIMOCODE PRACTICE:


TASK: Basic Configuration of SIMOCODE Pro V with TIA portal.

Step 1: Open TIA portal, create a project with project name and path.






**Step 2:** Select the available SIMOCODE with correct version.








Step 3: Select the required application.















**Step 5:** Select the communication type either ProfiBus DP or USB for SIMOCODE Pro V then complie and download the program.





Step 6: Go to Control/Status information and click Online,








**Step 7:** Now, before pressing 'ON' botton the motor is in 'OFF' as shown below, now, click 'ON' and the motor starts running.





**Step 8:** Check whether the control status is indicating 'ON' or not? If it is 'ON' it shows that the motor is running.



- ➤ Basic commissioning of SIMOCODE Pro V with TIA portal is done with direct starter as the control.
- To complete this, one should have basic understanding of TIA portal.

#### Other tasks which we can perform on SIMOCODE Pro V with TIA Portal software are:

- Over Load/Unbalance Protection.
- Stalled Protection.





- ➤ Upper/Lower current limit violation
- ➤ Indicating LEDs.
- Flashing and Flickering.Timer, Counter, Truth Table and Calculator.
- ➤ Limit Violation.
- > Parameter Recording.

