

Bambu Lab Telegram Monitor

Complete Setup Guide

Raspberry Pi 4 / 5 • macOS

This guide walks you through every step — from zero to receiving Telegram notifications for every print job on your Bambu Lab printer.

🕒 Estimated total time: about 30 minutes

Part A — Setting up Telegram

1 Create a new Telegram bot

Your Telegram bot is created through an official Telegram service called BotFather.

- a. Open Telegram on your phone or desktop.
- b. In the search bar, search for @BotFather and tap it (it has a blue verified checkmark).
- c. Send it this message:

```
/newbot
```

- d. It will ask for a display name — type anything you like, e.g. My Bambu Bot.
- e. It will ask for a username — must end in bot, e.g. mybambuprinter_bot

BotFather will reply with a Token that looks like this:

```
1234567890:ABCDfGhIjKlMnOpQrStUvWxYz
```

Save this Token — you will need it later.

2

Find your Chat ID

The bot needs your Chat ID so it knows where to send messages.

- a. Search in Telegram for @userinfobot.
- b. Send it any message (e.g. hello).
- c. It will reply with your details — copy the number next to Id:

It looks like this:

Id: 123456789

Save this number too — you will need it later.

3

Send your bot a first message

Do this now so that the bot is allowed to write to you later:

- a. Search Telegram for the bot you just created (use the username you chose).
- b. Tap Start or send /start.

The bot can now send you messages.

Part B — Collecting your printer details

4

Find your printer's IP address

The IP address is your printer's address on your home network.

Via the printer screen:

1. Tap the WiFi icon or go to Network Settings.
2. You will see an address like 192.168.1.55 — that is the IP.

Via your Router (alternative):

Open your router's admin page in a browser (usually 192.168.1.1 or 10.0.0.1). Find the list of connected devices and look for Bambu.

Tip: consider setting a static (fixed) IP for your printer in the router settings so the address never changes.

5 Find your Serial Number and Access Code

Both of these are found on the printer's touchscreen:

Access Code (8 characters):

Printer screen → Settings → WLAN → scroll to the bottom → you will see Access Code.

Serial Number:

Printer screen → Settings → Device → Serial Number.

It looks like this: 01P00A123456789

Write both down — you will need them in the next section.

6 Your Bambu Lab account credentials

The bot uses your Bambu Lab account to connect to the cloud.

These are the email address and password you used to register at bambulab.com or in the Bambu Handy app.

If you don't have an account yet, create one for free at bambulab.com.

Part C — Installing on the Raspberry Pi

7 Open Terminal on your Mac

All work on the Pi is done through the Terminal app on your Mac.

1. Press Command + Space on your keyboard to open Spotlight search.
2. Type Terminal and press Enter.
3. A black window with a command prompt will open — this is Terminal.

Keep it open for the steps below.

8

Find your Pi's name on the network

Before connecting you need to know your Pi's address on the network.

Option A — Network name (easiest):

On most Raspberry Pi setups the default name is: raspberrypi.local

If you renamed your Pi during setup, use that name instead.

Option B — IP address:

Log in to your router's admin panel in a browser and look for the Pi in the list of connected devices. Its address looks like: 192.168.1.XX

The steps below use raspberrypi.local. If that doesn't work, replace it with the actual IP address.

9

Connect to your Pi via SSH

SSH lets you control the Pi from your Mac, as if you were typing directly on it.

In Terminal, type the following and press Enter:

```
ssh pi@raspberrypi.local
```

If your Pi username is different from pi, replace it:

```
ssh YOUR_PI_USERNAME@raspberrypi.local
```

The first time you connect, you will see this message:

```
Are you sure you want to continue connecting (yes/no)?
```

Type yes and press Enter.

Then it will ask for your Pi's password. Type it and press Enter (nothing is shown while you type — that is normal).

When you see a prompt starting with pi@ you are inside the Pi!

10 Transfer the install file to your Pi

Now we copy `install.sh` from your Mac to the Pi. This requires a second Terminal window.

Step 1 — Open a new Terminal window on your Mac:

Press `Command+Space`, type `Terminal` and press `Enter`.

Important: this is a new window — not the one connected to the Pi.

Step 2 — Confirm `install.sh` is in your Downloads folder:

```
ls ~/Downloads/install.sh
```

If the filename appears, you are good. If not, move the file to Downloads first.

Step 3 — Send the file to your Pi:

```
scp ~/Downloads/install.sh pi@raspberrypi.local:~/
```

It will ask for your Pi password — type it and press `Enter`.

When you see **100%** and the filename, the transfer is complete.

11 Run the installation script

Switch back to the Terminal window that is connected to the Pi (the prompt starts with `pi@`).

Run this command:

```
chmod +x ~/install.sh && ~/install.sh
```

The script will automatically:

- Install Python and all required packages
- Create the folder `~/bambu_monitor/`
- Set up a service that starts automatically every time the Pi boots

Installation takes about 2-5 minutes. Text will scroll by — that is normal, just wait.

12

Enter your printer and Telegram details

This is the most important step. You will now fill in all the details you collected in Parts A and B.

In the Pi Terminal, run:

```
nano ~/bambu_monitor/config.py
```

A text editor will open inside Terminal. Use the arrow keys to move around — the mouse does not work here.

Each line looks like this:

```
PRINTER_IP = "YOUR_PRINTER_IP"
```

Delete the placeholder text between the quotes and type your real value. Example:

```
PRINTER_IP = "192.168.1.55"
```

Fill in all seven fields:

```
PRINTER_IP = "..." # IP address shown on the printer screen
```

```
PRINTER_SERIAL = "..." # Serial Number (Settings > Device)
```

```
PRINTER_PASSWORD = "..." # Access Code (Settings > WLAN) – 8 characters
```

```
BAMBU_USERNAME = "..." # Your Bambu Lab account email
```

```
BAMBU_PASSWORD = "..." # Your Bambu Lab account password
```

```
TELEGRAM_TOKEN = "..." # Token from BotFather
```

```
TELEGRAM_CHAT_ID = "..." # Your Chat ID from userinfobot
```

To save and exit:

1. Press Ctrl + X
2. Press Y (yes, save)
3. Press Enter (confirm filename)

If you make a typing mistake, use Backspace to delete, just like any text editor.

13 Start the bot and verify

Start the bot:

```
~/bambu_monitor/manage.sh start
```

Check that it is running:

```
~/bambu_monitor/manage.sh status
```

If everything is correct you will receive a Telegram message saying the bot is connected and running.

To watch live logs (useful for troubleshooting):

```
~/bambu_monitor/manage.sh logs
```

The bot now starts automatically every time the Pi is powered on. Nothing else needs to be done!

Part D — Troubleshooting

Bot not sending messages	Check that TELEGRAM_TOKEN and TELEGRAM_CHAT_ID are correct. Make sure you sent /start to your bot in Telegram.
MQTT / connection error	Check that the printer IP is correct and that the Access Code is exactly 8 characters. On firmware above 01.07 the bot automatically switches to cloud MQTT.
Bot does not start after Pi reboot	Run: <code>sudo systemctl enable bambu-monitor</code>
No notifications for print jobs	Make sure the Serial Number is exactly correct — upper and lower case matter.
Cannot SSH into the Pi	Make sure SSH is enabled on the Pi (<code>raspi-config > Interface Options > SSH</code>). Try using the IP address instead of <code>raspberrypi.local</code> .

Quick-reference commands

Start	<code>~/bambu_monitor/manage.sh start</code>
Stop	<code>~/bambu_monitor/manage.sh stop</code>
Restart	<code>~/bambu_monitor/manage.sh restart</code>

Status	<code>~/bambu_monitor/manage.sh status</code>
Live logs	<code>~/bambu_monitor/manage.sh logs</code>
Edit settings	<code>nano ~/bambu_monitor/config.py</code>

The bot starts automatically with the Pi — no action needed after initial setup. Good luck!