

SECTION 1: DEAERATOR (DA) SYSTEM SOP

Purpose: Maintain appropriate pressure and temperature in the DA tank to eliminate dissolved oxygen and prevent internal corrosion.

Procedures:

- Confirm that the make-up water supply valve is open.
- Check the tank pressure gauge (target range: 5–15 psig).
- Ensure spray valve and steam inlet valve function properly.
- Monitor water level indicators—keep within safe operational range.
- Record temperature (ideal: ~227°F at 5 psig).
- Ensure the overflow/vent pipe is unobstructed.
- Inspect for leaks or abnormal steam release.
- Log all pressure, level, and temperature readings.

Notes:

A pressure drop may indicate vent control or steam trap failure. Automatic fill shutoff alarms should trigger if levels exceed safety limits.