

SECTION 4: PRESSURE RELIEF VALVES (PRVs) & SAFETY VALVES SOP

Purpose: Prevent overpressure events through regular inspection and testing of all relief and safety valves.

Procedures:

- Check valve certification tag and confirm test date.
- Test lifting mechanism or lever (if code allows).
- Inspect for corrosion, seat damage, or cracking.
- Ensure discharge piping is clear and unrestricted.
- Look for signs of weeping or chattering.
- Confirm drain lines are properly routed.
- Record system operating pressure and valve setpoints.

Notes:

- Schedule annual third-party valve testing.
- Re-certify any valve that has lifted during operation.