

SECTION 5: LOW WATER FUEL CUTOFF (LWFCO) SOP

Purpose: Guarantee automatic shutdown of the boiler in the event of low water conditions to prevent equipment damage and hazards.

Procedures:

Blow down float-type LWFCOs to eliminate sediment.
Test probe-type LWFCO functionality through control panel.
Simulate low water conditions under controlled settings.
Confirm system shutdown and alarm activation.
Manually reset and log time of test.

Notes:

Weekly testing is required by most state codes.
If LWFCO fails to trip, immediately lockout system and begin repairs.