

Troubleshooting Guide

Problem:

Device does not turn on.

Solution:

- Check if the battery is charged.
- Ensure the charger is connected properly.
- Hold the power button for 5 seconds.

Problem:

Cannot connect to Wi-Fi.

Solution:

- Restart your router.
- Ensure the device is within Wi-Fi range.
- Verify the Wi-Fi password.

Problem:

Mobile app cannot detect the device.

Solution:

- Enable Bluetooth.
- Restart the mobile application.
- Reset the device.

Problem:

Voice assistant is not responding.

Solution:

- Check internet connectivity.
- Update device firmware.
- Restart the device.

Problem:

Device overheats.

Solution:

- Turn off the device.
- Allow it to cool.
- Contact support if overheating continues.