PA-32RT-300 Preflight Checklist

Master Switch On

	Interior and Exterior Lights
	Stall Warning Horn
	Pitot Heat
Walk Around	
	Control Surfaces and Cables
	Drain Fuel Tank Sumps
	• Remove all water and sediment; verify proper fuel.
	Drain Fuel Tank Strainer
	 Move the selector OFF position, left, then right, while draining the strainer sump.
	Propeller
	Air Inlets and Alternator Belt Tension
	Oil Level (10-12 quarts)
	No Obvious Oil or Fuel Leaks
Landing Gear	
	Strut Exposure (≥ 4.0" / ≥ 2.6")
	Visual Inspection of Tires
	Visual Inspection of Brake Blocks
Finishing Up	
	Clean Windshield
	Prep Cockpit
Ш	Engine Times and Stratus