LISTA DE APN's:

AVANTEL: Ite.avantel.com.co

MOVISTAR: internet.movistar.com.co

 ${\sf TIGO: web.colombiamovil.com.co}$

CLARO: internet.comcel.com.co

VIRGIN: web.vmc.net.co

WOM: Internet

Comandos de configuracion:

COBAN:

clear123456

reset123456

begin123456

apn123456 APN_SEGUN_OPERADOR

dns123456 sudominio.com 5001

distance123456 0050

Fix010s010s***n123456 (Para que comience a transmitir rápido por primera vez)

Fix030s060m***n123456 (Una vez transmita por primera vez se pone este comando)

gprs123456

imei123456

time zone123456 -5

protocol123456 18

suppress123456

TK909:

reset123456

begin123456

apn123456 APN_SEGUN_OPERADOR

adminip123456 IP_DEL_SERVIDOR 5093

distance123456 0010

fix010s***n123456

gprs123456

time zone123456 -5

sleep123456 off

sleep123456 shock

TK906:

reset123456

begin123456

apn123456 APN_SEGUN_OPERADOR

adminip123456 IP_DEL_SERVIDOR 5093

distance123456 0010

fix010s***n123456

gprs123456

time zone123456 -5

sleep123456 off

sleep123456 shock

CONCOX:

FACTORY#

APN,APN_SEGUN_OPERADOR#

SERVER,1,sudominio.com,5023,0#

DISTANCE,050#

TIMER,30,3600#

ACCREP#

VERSION#

GMT,W,5,0#

CONCOX VL03:

FACTORY#

APN,APN_SEGUN_OPERADOR#

SERVER,1,sudominio.com,5023,0#

DISTANCE,050#

TIMER,30,3600#

ACCREP#

VERSION#

GMT,W,5,0#

VT03C:

FACTORY#

APN,APN_SEGUN_OPERADOR#

SERVER,1,sudominio.com,5023,0#

DISTANCE,050#

TIMER,30,3600#

ACCREP#

VERSION#

GMT,W,5,0#

CANTRACK:

reset123456

begin123456

apn123456 APN_SEGUN_OPERADOR

adminip123456 sudominio.com O IP 5013

distance123456 0010

fix010s***n123456

gprs123456 1

time zone123456 -5

GPS-201/BN-201:

clear123456

reset123456

begin123456

apn123456 APN_SEGUN_OPERADOR

dns123456 sudominio.com 5001

distance123456 0050

Fix010s010s***n123456

gprs123456

imei123456

time zone123456 -5

LK209C:

CXZT (Para ver los parámetros del dispositivo, entre ellos el parámetro "ID" (número de 10 dígitos normalmente comienza con 702) este es el equivalente al IMEI y es el que se pone en la plataforma. Importante: NO USAR EL IMEI

CQ (Para reiniciar el dispositivo)

FORMAT (Para formatear el dispositivo a los parámetros de fábrica)

APN123456,APN_SEGUN_OPERADOR

IP IP_DEL_SERVIDOR 5013

FREQ,123456,30 (Frecuenta en segundos de rastreo)

CXZT (Para ver los parámetros del dispositivo, verificar que la ip y el apn sean los correctos)