



Online guide

Filler cap

0000 350 0533

Bin **T0** | 2 spares per kit | **AS1** supervision

MS 462 — fuel tank

Fuel filler cap; includes seal (item 6). The same part is used on the oil tank.

Item 5 | Qty listed: 1

MS 462 C-M Z spare-parts list, 10/29/2024. Drawing p. 23; parts table p. 24.

MS 462 — oil tank

Oil filler cap in the crankcase; includes seal (item 9). Also listed in crankcase section B, table p. 7.

Item 8 | Qty listed: 1

MS 462 C-M Z spare-parts list, 10/29/2024. Drawing p. 3; parts table p. 4.

