

CHANNEL					VALUE	FUNCTION
40ch Framing	31ch F-Wash	31ch Spot	22ch Wash	30ch BSW		
1	1	1	1	1	000-255	PAN 0°→540°
2	2	2	2	2	000-255	PAN FINE
3	3	3	3	3	000-255	TILT 0°→260°
4	4	4	4	4	000-255	TILT FINE
5	5	5	5	5	000-255	PAN/TILT SPEED Fast to Slow
6	6	6	6	6	000-255	CYAN 0%→100%
7	7	7	7	7	000-255	MAGENTA 0%→100%
8	8	8	8	8	000-255	YELLOW 0%→100%
9	9	9	9	9	000-255	CTO 0%→100%
10	10	10	10	10	000-007	COLOR WHEEL Open Color 1 Color 2 Color 3 Color 4 Color 5 Open Open + Color 1 Color 1 Color 1 + Color 2 Color 2 Color 2 + Color 3 Color 3 Color 3 + Color 4 Color 4 Color 4 + Color 5 Color 5 Color 5 + CRI CRI CRI + CTB
					008-018	
					019-029	
					030-040	
					041-051	
					052-063	
					064-066	
					067-069	
					070-072	
					073-075	
					076-078	
					079-081	
					082-084	
					085-087	
					088-090	
					091-093	
					094-096	
					097-099	
					100-102	
					103-105	

					106-108 109-111 112-127 128-189 190-193 194-255	CTB CTB + Open Open Counter-Clockwise Rotation, Fast to Slow Stop Clockwise Rotation, Slow to Fast
11		11		11	000-007 008-014 015-021 022-028 029-035 036-042 043-049 050-056 057-063 064-071 072-079 080-087 088-095 096-103 104-111 112-119 120-127 128-189 190-193 194-255	GOBO WHEEL 1 Open Gobo 1 Gobo 2 Gobo 3 Gobo 4 Gobo 5 Gobo 6 Gobo 7 Gobo 8 Gobo 1 Shaking, Slow to Fast Gobo 2 Shaking, Slow to Fast Gobo 3 Shaking, Slow to Fast Gobo 4 Shaking, Slow to Fast Gobo 5 Shaking, Slow to Fast Gobo 6 Shaking, Slow to Fast Gobo 7 Shaking, Slow to Fast Gobo 8 Shaking, Slow to Fast Counter-Clockwise Rotation, Fast to Slow Stop Clockwise Rotation, Slow to Fast
12		12		12	000-127 128-189 190-193 194-255	R-GOBO WHEEL 1 Index 0°→360° Counter-Clockwise Rotation, Fast to Slow Stop Clockwise Rotation, Slow to Fast
13		13		13	000-255	R-GOBO WHEEL 1 FINE 0%→100%
14		14		14	000-007 008-013 014-019 020-025 026-031 032-037 038-043 044-049 050-055	GOBO WHEEL 2 Open Gobo 1 Gobo 2 Gobo 3 Gobo 4 Gobo 5 Gobo 6 Gobo 7 Gobo 8

					056-063 064-070 071-077 078-084 085-091 092-098 099-105 106-112 113-119 120-127 128-189 190-193 194-255	Gobo 9 Gobo 1 Shaking, Slow to Fast Gobo 2 Shaking, Slow to Fast Gobo 3 Shaking, Slow to Fast Gobo 4 Shaking, Slow to Fast Gobo 5 Shaking, Slow to Fast Gobo 6 Shaking, Slow to Fast Gobo 7 Shaking, Slow to Fast Gobo 8 Shaking, Slow to Fast Gobo 9 Shaking, Slow to Fast Clockwise Rotation, Fast to Slow Stop Counter-Clockwise Rotation, Slow to Fast
15		15		15	000-007 008-129 130-133 134-255	ANIMATION Open Counter-Clockwise Rotation, Fast to Slow Stop Clockwise Rotation, Slow to Fast
16	11	16	11		000-255	IRIS 100%→0%
17		17		16	000-007 008-255	PRISM 1 (4-facet circular prism) Close Open
18		18		17	000-127 128-189 190-193 194-255	R-PRISM 1 Index 0°→360° Counter-Clockwise Rotation, Fast to Slow Stop Clockwise Rotation, Slow to Fast
19		19		18	000-007 008-255	PRISM 2 (4-facet linear prism) Close Open
20		20		19	000-127 128-189 190-193 194-255	R-PRISM 2 Index 0°→360° Counter-Clockwise Rotation, Fast to Slow Stop Clockwise Rotation, Slow to Fast
21	12	21	12	20	000-007 008-255	CRI Close Open
22	13	22	13	21	000-255	FROST 1 (1°) 0%→100%
23	14	23	14	22	000-255	FROST 2 (5°) 0%→100%

24	15	24	15	23	000-255	ZOOM Wide→Narrow
25	16	25	16	24	000-255	ZOOM FINE
26	17	26	17	25	000-255	FOCUS 0%→100%
27	18	27	18	26	000-255	FOCUS FINE
28	19	28	19	27	000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE Close Open Strobe from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Random Strobe from Slow to Fast Open
29	20	29	20	28	000-255	DIMMER 0%→100%
30	21	30	21	29	000-255	DIMMER FINE
31	22				000-255	BLADE 0°→180°
32	23				000-255	BLADE DW 1 0%→100%
33	24				000-255	BLADE DW 2 0%→100%
34	25				000-255	BLADE UP 1 0%→100%
35	26				000-255	BLADE UP 2 0%→100%
36	27				000-255	BLADE LF 1 0%→100%
37	28				000-255	BLADE LF 2 0%→100%
38	29				000-255	BLADE RG 1 0%→100%
39	30				000-255	BLADE RG 2 0%→100%
40	31	31	22	30		FUNCTION (To activate following functions, stop in DMX value for at least 3 seconds.)

				000-005	Null
				006-007	Null
				008-009	Null
				010-019	Blade Mode: Mode 1 (Not available on 31 (Spot) ch & 22ch & 30ch)
				020-029	Blade Mode: Mode 2 (Not available on 31 (Spot) ch & 22ch & 30ch)
				030-039	Dimmer Curve Square Law
				040-049	Dimmer Curve Inv Square Law
				050-059	Dimmer Curve Linear
				060-069	Dimmer Curve S
				070-079	Fan Mode Auto
				080-089	Fan Mode Quiet
				090-099	Null
				100-109	LED Frequency Setting Enable
				110-119	LED Frequency Setting Disable
				120-122	Null
				123	900Hz
				124	1000Hz
				125	1100Hz
				126	1200Hz
				127	1300Hz
				128	1400Hz
				129	1500Hz
				130	2500Hz
				131	4000Hz
				132	5000Hz
				133	6000Hz
				134	10KHz
				135	15KHz
				136	20KHz
				137	25KHz
				138-139	Null
				140-149	Reset Pan/Tilt
				150-159	Reset Effect
				160-199	Null
				200-209	Reset All
				210-219	Dimmer Speed: Fast
				220-229	Dimmer Speed: Smooth
				230-231	Gobo Short Cut: Enable (Not available on 31 (F-Wash) ch & 22ch)
				232-233	Gobo Short Cut: Disable (Not available on 31 (F-Wash) ch & 22ch)

					234-235	Color Short Cut: Enable
					236-237	Color Short Cut: Disable
					238-239	CTB Compensate: Enable
					240-241	CTB Compensate: Disable
					242-255	Null