

JUKEBOX USER GUIDE



While Powered On		
Turn	Press	Hold
Volume	Mode selection: Music Player → Streaming → Remote Mode →	Power off
Select letter	Play/Stop	Toggle shuffle
Select number	Next track	Previous track



While Powered Off		
Turn	Press	Hold
-	Power on	-
-	Announce IP address	Reconnect WiFi / Re-enable AP
Select music folder (after press)	Start/finalize music folder selection	(Hold for 5 seconds) Delete static IP and WiFi AP password

JUKEBOX USER GUIDE



LOU'S CAFE
HILL AND MAIN
HILL VALLEY, CALIFORNIA

Commands from TCD	
Switch to Music Player mode	5020
Switch to Streaming mode	5021
Switch to Remote Mode	5022
Select volume level (00 - 20)	53xx
Play / Stop	5005
Previous track/stream	5002
Next track/stream	5008
Select music folder (A-K:50-59, 1-10:60-69)	5050-5069
Shuffle off	5222
Shuffle on	5555
Go to track A-1	5888
Go to track L-N (L:01-10, N:01-10)	588LLNN
Go to track T (T:000-099)	5888TTT
Announce current IP address	5090
Restart	5064738
Delete static IP address & WiFi AP password	5123456

Control through TCD requires BTTFN connection.