



Button Modes			
9 10 4C	Light	9 10 4C	Operation
9 10 4C	Music Player	9 10 4C	Admin

Operation	Press	Hold
9	Time Travel	Display mode: Pushwheel value
10	Play "key3.mp3"	Display mode: Temperature
4C	Play "key6.mp3"	Display mode: Speed

Music Player	Press	Hold
9	Previous track	Go to track #0
10	Play / Stop	Enable shuffle mode
4C	Next track	Disable shuffle mode

Admin	Press	Hold
9	Volume up	Toggle Car Mode
10	Volume down	Re-activate or connect WiFi
4C	Display IP address	Delete static IP and AP password



Commands from TCD/HA	
Select pushwheel display mode	8010
Select temperature display mode	8011
Select speed display mode	8012
Select volume level (00 - 20)	83xx
Set brightness level (00 - 15)	84xx
Music Player : Play / Stop	8005
Music Player : Previous/Next track	8002/8008
Music Player : Select music folder	805x
Music Player : Shuffle off/on	8222/8555
Music Player : Go to track 000	8888
Music Player : Go to track xxx	8888xxx
Play "keyX.mp3" (X = 1, 3, 4, 6, 7, 9)	800x
Play "keyX.mp3" (X = 1 - 9)	850x
Display current IP address	8090
Disable/Enable Car Mode *	8990/8991
Restart*	8064738
Delete static IP address*	8123456

Control through TCD requires BTTFN connection.

* Not through HA/MQTT-INJECT