




Goulds Pumps

Quick Disconnect Control Boxes For 4", 1Ø, 3-Wire Submersible Motors



FEATURES

- Voltage Relays for installer convenience
- 115 and 230 volt models
- 208 volt relays available for low voltage applications
- Start Capacitors
- NEMA 3R enclosure for indoor or outdoor mounting
- Quick disconnect cover design will retrofit with F.E. Q-D control boxes
- Multiple knockouts
- Two grounding lugs

AGENCY LISTINGS



Listed to UL778 Standard by Underwriters Laboratories Inc. File No. E83318



CSA certified to C22.2, No. 108 Standard by Canadian Standards Association, File No. LR38549

Goulds Pumps is ISO 9001 Registered.



Goulds Pumps is a brand of ITT Residential and Commercial Water.

www.goulds.com

Engineered for life



GOULDS PUMPS Residential Water

GOULDS PUMPS ORDER NUMBERS

Control Box Order Number	НР	KW	Volts	Replaces old GP #	Replaces FE #	Standard Circuit Breaker	Standard Fuse	Dual Element Time Delay Fuse	Enclosure Dimensions W x D x H (in)	Shipping Wt. (lbs)
CB05411G	.5	.37	115	00043GP	280 104 49	30 A	35 A	20 A	4.8 x 2.9 x 8.4	4
CB05412G	.5	.37	230	00044GP	280 105 49	15 A	20 A	10 A	4.8 x 2.9 x 8.4	4
CB07412G	.75	.55	230	00054GP	280 107 49	20 A	25 A	15 A	4.8 x 2.9 x 8.4	4
CB10412G	1	.75	230	00064GP	280 108 49	25 A	30 A	20 A	4.8 x 2.9 x 8.4	4

Note: 208 Volt starting relay, 9K461, is available for 200-208 volt power supplies.

"K" REPAIR PARTS FOR QUICK DISCONNECT STYLE CONTROL BOXES*

Goulds Pumps Order Number	Old Order Number	НР	Volts	Capacitor Order Number	Start Capacitor Mfd	Capacitor Voltage	Capacitor Quantity	Start Relay Order No.	Supplier Number	
CB05411G	00043 (GP)	.5	115	9K450	250 - 300	125	1	9K457	RVA7AA (6L) (or KL)	
CB05412G	00044 (GP)	.5	230	9K448	59 - 71	220	1		RVA2AL (6L) (or KL)	
CB07412G	00054 (GP)	.75	230	9K449	86 - 103	220	1	9K462		
CB10412G	00064 (GP)	1	230	9K447	105 - 126	220	1			
Special 208 V Relay for .5 - 1 HP operating on 200 or 208 volt power supplies Order No. 9K461.										

^{*} Repair parts above will work in new voltage relay control boxes as well as in control boxes shown in "Replaces Column" above.









GOULDS PUMPS Residential Water

INSTALLING A PumpSaver® INSIDER

- 1. Remove the cover from the front of the 3-wire Goulds Pumps control box.
- 2. Remove the yellow wire from the terminal strip at L2.
- 3. Remove the black wire from L1 to the capacitor.
- 4. Press the PumpSaver onto the L1 and L2 terminals.
- 5. Reconnect the yellow wire to L2 on the PumpSaver.
- 6. Connect the blue wire attached to the PumpSaver to the dual-lug terminal (with the black wire) of the capacitor.








Residential Water

WIRING DIAGRAM





Goulds Pumps, CentriPro and the ITT Engineered Blocks Symbol are registered trademarks and tradenames of ITT Corporation.

PumpSaver is a registered trademark of SymCom, Inc.

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.

BGQD September, 2006 © 2006 ITT Corporation

Engineered for life