Standard IR codes

*C: Canada model, U: USA model

Function			Device				
Group	Name			Zone	FullCode(ID1)	RX-A730	RX-A830
POWER	RECEIVER POWER	ON/OFF	RECEIVER	MAIN	7E81-2AD5	YES	YES
				ZONE2	7A85-453A	YES	YES
				ZONE3	7A85-4639	NO	NO
				ZONE4	7A85-6F10	NO	NO
	SOURCE POWER	TOGGLE	RECEIVER	MAIN	7F01-50AF	NO	NO
				ZONE2	7F01-708F	NO	NO
				ZONE3	7F01-906F	NO	NO
				ZONE4	7F01-B04F	NO	NO
	SLEEP	TOGGLE	RECEIVER	MAIN	7A85-30CF	YES	YES
				ZONE2	7A85-31CE	YES	YES
				ZONE3	7A85-32CD	NO	NO
				ZONE4	7A85-33CC	NO	NO
INPUT	HDMI- 1		RECEIVER	MAIN	7A85-4738	YES	YES
				ZONE2	7A85-4837	NO	NO
				ZONE3	7A85-4936	NO	NO
	HDMI- 2		RECEIVER	MAIN	7A85-4A35	YES	YES
				ZONE2	7A85-4B34	NO	NO
				ZONE3	7A85-4C33	NO	NO
	HDMI- 3		RECEIVER	MAIN	7A85-4D32	YES	YES
				ZONE2	7A85-4E31	NO	NO
				ZONE3	7A85-4F30	NO	NO
	HDMI- 4		RECEIVER	MAIN	7A85-502F	YES	YES
				ZONE2	7A85-512E	NO	NO
				ZONE3	7A85-522D	NO	NO
	HDMI- 5		RECEIVER	MAIN	7A85-700F	YES	YES
				ZONE2	7A85-710E	NO	NO
				ZONE3	7A85-720D	NO	NO
	HDMI- 6		RECEIVER	MAIN	7A85-730C	NO	YES
				ZONE2	7A85-740B	NO	NO
				ZONE3	7A85-750A	NO	NO
	HDMI- 7		RECEIVER	MAIN	7A85-98E7	NO	YES
				ZONE2	7A85-99E6	NO	NO
				ZONE3	7A85-9AE5	NO	NO
	AV- 1		RECEIVER	MAIN	7A85-532C	YES	YES
				ZONE2	7A85-542B	NO	NO
				ZONE3	7A85-552A	NO	NO
				ZONE4	7A85-84FB	NO	NO
	AV- 2		RECEIVER	MAIN	7A85-5629	YES	YES
				ZONE2	7A85-5728	NO	NO
				ZONE3	7A85-5827	NO	NO
				ZONE4	7A85-85FA	NO	NO
	AV- 3		RECEIVER	MAIN	7A85-5926	YES	YES
				ZONE2	7A85-5A25	NO	NO
				ZONE3	7A85-5B24	NO	NO
				ZONE4	7A85-86F9	NO	NO
	AV- 4		RECEIVER	MAIN	7A85-5C23	YES	YES
				ZONE2	7A85-5D22	NO	NO
				ZONE3	7A85-5E21	NO	NO
				ZONE4	7A85-87F8	NO	NO
	AV- 5		RECEIVER	MAIN	7A85-5F20	YES	YES
				ZONE2	7A85-601F	YES	YES
				ZONE3	7A85-611E	NO	NO
				ZONE4	7A85-88F7	NO	NO
	AV- 6		RECEIVER	MAIN	7A85-621D	YES	YES
				ZONE2	7A85-631C	YES	YES
				ZONE3	7A85-641B	NO	NO
				ZONE4	7A85-89F6	NO	NO
	AV- 7		RECEIVER	MAIN	7A85-7609	NO	NO
				ZONE2	7A85-7708	NO	NO
				ZONE3	7A85-7807	NO	NO
				ZONE4	7A85-8AF5	NO	NO
	AUDIO- 1 (AUDIO)		RECEIVER	MAIN	7A85-651A	YES	YES
				ZONE2	7A85-6619	YES	YES
				ZONE3	7A85-6718	NO	NO
				ZONE4	7A85-8CF3	NO	NO
	AUDIO- 2		RECEIVER	MAIN	7A85-6817	YES	YES
				ZONE2	7A85-6916	YES	YES
				ZONE3	7A85-6A15	NO	NO
				ZONE4	7A85-8DF2	NO	NO
	AUDIO- 3		RECEIVER	MAIN	7A85-7C03	NO	NO
				ZONE2	7A85-7D02	NO	NO
				ZONE3	7A85-7E01	NO	NO
				ZONE4	7A85-8EF1	NO	NO
	AUDIO- 4		RECEIVER	MAIN	7A85-7F00	NO	NO
				ZONE2	7A85-80FF	NO	NO
				ZONE3	7A85-81FE	NO	NO
				ZONE4	7A85-8FF0	NO	NO
	V-AUX		RECEIVER	MAIN	7A85-55AA	YES	YES
				ZONE2	7A85-D827	NO	YES
				ZONE3	7A85-F00F	NO	NO
				ZONE4	7A85-7D82	NO	NO
	PHONO		RECEIVER	MAIN	7A85-14EB	NO	YES*except UC
				ZONE2	7A85-D02F	NO	YES*except UC
				ZONE3	7A85-F10E	NO	NO
				ZONE4	7A85-7E81	NO	NO
	USB		RECEIVER	MAIN	7F01-720D	YES	YES
				ZONE2	7F01-730C	YES	YES
				ZONE3	7F01-740B	NO	NO
				ZONE4	7F01-7A05	NO	NO
	NET	TOGGLE	RECEIVER	MAIN	7F01-3FC0	YES	YES
				ZONE2	7F01-40BF	YES	YES
				ZONE3	7F01-41BE	NO	NO
				ZONE4	7F01-49B6	NO	NO
	TUNER		RECEIVER	MAIN	7A85-16E9	YES	YES
				ZONE2	7A85-D22D	YES	YES
				ZONE3	7A85-F30C	NO	NO
				ZONE4	7A85-20DF	NO	NO
	MULTI CH IN		RECEIVER	MAIN	7A85-8778	NO	NO
	UP		RECEIVER	MAIN	7A85-1F60	YES	YES
				ZONE2	7A85-205F	YES	YES
				ZONE3	7A85-215E	NO	NO
				ZONE4	7A85-225D	NO	NO
	DOWN		RECEIVER	MAIN	7A85-235C	YES	YES
				ZONE2	7A85-245B	YES	YES
				ZONE3	7A85-255A	NO	NO
				ZONE4	7A85-2659	NO	NO
	NET/USB	TOGGLE	RECEIVER	MAIN	7A85-A8D7	YES	YES
				ZONE2	7A85-A9D6	YES	YES
				ZONE3	7A85-AAD5	NO	NO
				ZONE4	7A85-ABD4	NO	NO
OUTPUT	HDMI OUT	TOGGLE	RECEIVER	MAIN	7A85-35CA	YES*No key	YES
				ZONE2	7A85-B4CB	NO	NO
				ZONE3	7A85-B5CA	NO	NO
				ZONE4	7A85-B6C9	NO	NO
	SPEAKER	ZONE A	RECEIVER	MAIN	7A85-9A65	NO	NO
		ZONE B	RECEIVER	MAIN	7A85-9B64	NO	NO
PROGRAM	MOVIE	TOGGLE	RECEIVER	MAIN	7A85-8877	YES	YES
	MUSIC	TOGGLE	RECEIVER	MAIN	7A85-8976	YES	YES
	ENHANCER	TOGGLE	RECEIVER	MAIN	7A85-946B	YES	YES
	STRAIGHT	TOGGLE	RECEIVER	MAIN	7A85-56A9	YES	YES
	PURE DIRECT or DIRECT	TOGGLE	RECEIVER	MAIN	7A85-DD22	YES	YES
	SUR. DECODE	TOGGLE	RECEIVER	MAIN	7A85-8D72	YES	YES
	CLASSICAL	TOGGLE	RECEIVER	MAIN	7A85-8A75	NO	NO
	LIVE/CLUB	TOGGLE	RECEIVER	MAIN	7A85-8B74	NO	NO
	ENTERTAIN	TOGGLE	RECEIVER	MAIN	7A85-8C73	NO	NO
	MOVIE	TOGGLE	RECEIVER	MAIN	7A85-8E71	NO	NO
	STEREO	TOGGLE	RECEIVER	MAIN	7A85-8F70	NO	NO
	PROGRAM	UP	RECEIVER	MAIN	7A85-58A7	YES	YES
		DOWN	RECEIVER	MAIN	7A85-59A6	YES	YES
MEMORY	SCENE	1 BD/DVD	RECEIVER	MAIN	7A85-007F	YES	YES
				ZONE2	7A85-017E	NO	NO
				ZONE3	7A85-027D	NO	NO
				ZONE4	7A85-1867	NO	NO
		2 TV	RECEIVER	MAIN	7A85-037C	YES	YES
				ZONE2	7A85-047B	NO	NO
				ZONE3	7A85-057A	NO	NO
				ZONE4	7A85-1966	NO	NO
		3 CD or NET	RECEIVER	MAIN	7A85-0679	YES	YES
				ZONE2	7A85-0778	NO	NO
				ZONE3	7A85-0877	NO	NO
				ZONE4	7A85-1A65	NO	NO
		4 RADIO	RECEIVER	MAIN	7A85-0976	YES	YES
				ZONE2	7A85-0A75	NO	NO
				ZONE3	7A85-0B74	NO	NO
				ZONE4	7A85-1B64	NO	NO
	MEMORY		RECEIVER	MAIN	7F01-6718	NO	NO
				ZONE2	7F01-6817	NO	NO
				ZONE3	7F01-6916	NO	NO
				ZONE4	7F01-80FF	NO	NO
MENU	ON SCREEN or SETUP	TOGGLE	RECEIVER	MAIN	7A85-847B	YES	YES
				ZONE2	7A85-3B44	NO	NO
				ZONE3	7A85-443B	NO	NO
				ZONE4	7A85-413E	NO	NO
	OPTION	TOGGLE	RECEIVER	MAIN	7A85-6B14	YES	YES
				ZONE2	7A85-6C13	NO	NO
				ZONE3	7A85-6D12	NO	NO

				ZONE4	7A85-6E11	NO	NO
	TOP MENU	TOGGLE	RECEIVER	MAIN	7A85-A0DF	YES	YES
				ZONE2	7A85-A1DE	NO	NO
				ZONE3	7A85-A2DD	NO	NO
				ZONE4	7A85-A3DC	NO	NO
	POP-UP MENU	TOGGLE	RECEIVER	MAIN	7A85-A4DB	YES	YES
				ZONE2	7A85-A5DA	NO	NO
				ZONE3	7A85-A6D9	NO	NO
				ZONE4	7A85-A7D8	NO	NO
	CURSOR	UP	RECEIVER	MAIN	7A85-9D62	YES	YES
				ZONE2	7A85-2B54	NO	NO
				ZONE3	7A85-304F	NO	NO
				ZONE4	7A85-354A	NO	NO
		DOWN	RECEIVER	MAIN	7A85-9C63	YES	YES
				ZONE2	7A85-2C53	NO	NO
				ZONE3	7A85-314E	NO	NO
				ZONE4	7A85-3649	NO	NO
		LEFT	RECEIVER	MAIN	7A85-9F60	YES	YES
				ZONE2	7A85-2D52	NO	NO
				ZONE3	7A85-324D	NO	NO
				ZONE4	7A85-3748	NO	NO
		RIGHT	RECEIVER	MAIN	7A85-9E61	YES	YES
				ZONE2	7A85-2E51	NO	NO
				ZONE3	7A85-334C	NO	NO
				ZONE4	7A85-3847	NO	NO
	ENTER		RECEIVER	MAIN	7A85-DE21	YES	YES
				ZONE2	7A85-2F50	YES	YES
				ZONE3	7A85-344B	NO	NO
				ZONE4	7A85-3946	NO	NO
	RETURN		RECEIVER	MAIN	7A85-AA55	YES	YES
				ZONE2	7A85-3C43	NO	NO
				ZONE3	7A85-3F40	NO	NO
				ZONE4	7A85-423D	NO	NO
	LEVEL	TOGGLE	RECEIVER	MAIN	7A85-8679	NO	NO
VOLUME	VOLUME	UP	RECEIVER	MAIN	7A85-1AE5	YES	YES
				ZONE2	7A85-DA25	YES	YES
				ZONE3	7A85-FD02	NO	NO
				ZONE4	7A85-2BD4	NO	NO
		DOWN	RECEIVER	MAIN	7A85-1BE4	YES	YES
				ZONE2	7A85-DB24	YES	YES
				ZONE3	7A85-FE01	NO	NO
				ZONE4	7A85-2CD3	NO	NO
	MUTE	TOGGLE	RECEIVER	MAIN	7A85-1CE3	YES	YES
				ZONE2	7A85-DC23	YES	YES
				ZONE3	7A85-FF00	NO	NO
				ZONE4	7A85-2DD2	NO	NO
ZONE CONTROL	PARTY	TOGGLE	RECEIVER	ALL	7A85-34CB	NO	YES
DISPLAY	DISPLAY	TOGGLE	RECEIVER	MAIN	7F01-609F	YES	YES
				ZONE2	7F01-807F	NO	NO
				ZONE3	7F01-A05F	NO	NO
				ZONE4	7F01-C03F	NO	NO
	INFO	TOGGLE	RECEIVER	MAIN	7A85-2758	YES	YES
				ZONE2	7A85-2857	NO	NO
				ZONE3	7A85-2956	NO	NO
				ZONE4	7A85-2A55	NO	NO
OPERATION	MODE	TOGGLE	RECEIVER	MAIN	7F01-6699	YES	YES
				ZONE2	7F01-8679	NO	NO
				ZONE3	7F01-A659	NO	NO
				ZONE4	7F01-C639	NO	NO
	STOP		RECEIVER	MAIN	7F01-6996	YES	YES
				ZONE2	7F01-8976	YES	YES
				ZONE3	7F01-A956	NO	NO
				ZONE4	7F01-C936	NO	NO
	PAUSE		RECEIVER	MAIN	7F01-6798	YES	YES
				ZONE2	7F01-8778	YES	YES
				ZONE3	7F01-A758	NO	NO
				ZONE4	7F01-C738	NO	NO
	PLAY or BAND		RECEIVER	MAIN	7F01-6897	YES	YES
				ZONE2	7F01-8877	YES	YES
				ZONE3	7F01-A857	NO	NO
				ZONE4	7F01-C837	NO	NO
	SEARCH or TUNING	SEARCH- or TUNING-	RECEIVER	MAIN	7F01-6A95	YES	YES
				ZONE2	7F01-8A75	YES	YES
				ZONE3	7F01-AA55	NO	NO
				ZONE4	7F01-CA35	NO	NO
		SEARCH+ or TUNING+	RECEIVER	MAIN	7F01-6B94	YES	YES
				ZONE2	7F01-8B74	YES	YES
				ZONE3	7F01-AB54	NO	NO
				ZONE4	7F01-CB34	NO	NO
	SKIP or PRESET	SKIP- or PRESET-	RECEIVER	MAIN	7F01-6C93	YES	YES
				ZONE2	7F01-8C73	YES	YES
				ZONE3	7F01-AC53	NO	NO
				ZONE4	7F01-CC33	NO	NO
		SKIP+ or PRESET+	RECEIVER	MAIN	7F01-6D92	YES	YES
				ZONE2	7F01-8D72	YES	YES
				ZONE3	7F01-AD52	NO	NO
				ZONE4	7F01-CD32	NO	NO
	PRESET	PRESET-	RECEIVER	MAIN	7F01-5E21	NO	NO
				ZONE2	7F01-5F20	NO	NO
				ZONE3	7F01-601F	NO	NO
				ZONE4	7F01-6B14	NO	NO
		PRESET+	RECEIVER	MAIN	7F01-5B24	NO	NO
				ZONE2	7F01-5C23	NO	NO
				ZONE3	7F01-5D22	NO	NO
				ZONE4	7F01-6A15	NO	NO
	CATEGORY/BAND	FM	RECEIVER	MAIN	7F01-5827	NO	NO
				ZONE2	7F01-5926	NO	NO
				ZONE3	7F01-5A25	NO	NO
				ZONE4	7F01-7D02	NO	NO
		AM (DAB: DAB model)	RECEIVER	MAIN	7F01-552A	NO	NO
				ZONE2	7F01-5629	NO	NO
				ZONE3	7F01-5728	NO	NO
				ZONE4	7F01-7C03	NO	NO
	TUNING/CH	TUNING-	RECEIVER	MAIN	7F01-641B	NO	NO
				ZONE2	7F01-651A	NO	NO
				ZONE3	7F01-6619	NO	NO
				ZONE4	7F01-7F00	NO	NO
		TUNING+	RECEIVER	MAIN	7F01-611E	NO	NO
				ZONE2	7F01-621D	NO	NO
				ZONE3	7F01-631C	NO	NO
				ZONE4	7F01-7E01	NO	NO
NUMBER/CHARACTER	1		RECEIVER	MAIN	7F01-51AE	YES	YES
				ZONE2	7F01-718E	YES	YES
				ZONE3	7F01-916E	NO	NO
				ZONE4	7F01-B14E	NO	NO
	2		RECEIVER	MAIN	7F01-52AD	YES	YES
				ZONE2	7F01-728D	YES	YES
				ZONE3	7F01-926D	NO	NO
				ZONE4	7F01-B24D	NO	NO
	3		RECEIVER	MAIN	7F01-53AC	YES	YES
				ZONE2	7F01-738C	YES	YES
				ZONE3	7F01-936C	NO	NO
				ZONE4	7F01-B34C	NO	NO
	4		RECEIVER	MAIN	7F01-54AB	YES	YES
				ZONE2	7F01-748B	YES	YES
				ZONE3	7F01-946B	NO	NO
				ZONE4	7F01-B44B	NO	NO
	5		RECEIVER	MAIN	7F01-55AA	YES	YES
				ZONE2	7F01-758A	YES	YES
				ZONE3	7F01-956A	NO	NO
				ZONE4	7F01-B54A	NO	NO
	6		RECEIVER	MAIN	7F01-56A9	YES	YES
				ZONE2	7F01-7689	YES	YES
				ZONE3	7F01-9669	NO	NO
				ZONE4	7F01-B649	NO	NO
	7		RECEIVER	MAIN	7F01-57A8	YES	YES
				ZONE2	7F01-7788	YES	YES
				ZONE3	7F01-9768	NO	NO
				ZONE4	7F01-B748	NO	NO
	8		RECEIVER	MAIN	7F01-58A7	YES	YES
				ZONE2	7F01-7887	YES	YES
				ZONE3	7F01-9867	NO	NO
				ZONE4	7F01-B847	NO	NO
	9		RECEIVER	MAIN	7F01-59A6	YES	YES
				ZONE2	7F01-7986	YES	YES
				ZONE3	7F01-9966	NO	NO
				ZONE4	7F01-B946	NO	NO
	0		RECEIVER	MAIN	7F01-5AA5	YES	YES
				ZONE2	7F01-7A85	YES	YES
				ZONE3	7F01-9A65	NO	NO
				ZONE4	7F01-BA45	NO	NO
	+10 or MEMORY		RECEIVER	MAIN	7F01-5BA4	YES(MEMORY)	YES(MEMORY)
				ZONE2	7F01-7B84	NO	NO
				ZONE3	7F01-9B64	NO	NO
				ZONE4	7F01-BB44	NO	NO
	ENT		RECEIVER	MAIN	7F01-5CA3	YES	YES
				ZONE2	7F01-7C83	YES	YES
				ZONE3	7F01-9C63	NO	NO
				ZONE4	7F01-BC43	NO	NO