# Extended IR codes for RX-V375 - V775

*A: Australia model, C: Canada model, E: Europe model, J: Japan Model, T: China model, U: USA model

| Function | | | Device | | Code | Code | RX-V375 | RX-V475, V500D | RX-V575 | RX-V675 | RX-V775 |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Group | Name | | | Zone | (ID1) | (ID2) | HTR-2866, 3066 | HTR-4066 | HTR-5066 | HTR-6066 | |
| POWER | POWER | ON | RECEIVER | MAIN | 7E-7E | 7E-7E80 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-BA | 7E-BA44 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7A-ED | 7A-ED13 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7A-7B | 7A-7B85 | NO | NO | NO | NO | NO |
| | | | | ALL | 7A-1D | 7A-1DE3 | YES | YES | YES | YES | YES |
| | STANDBY | OFF | RECEIVER | MAIN | 7E-7F | 7E-7F81 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-BB | 7E-BB45 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7A-EE | 7A-EE10 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7A-7C | 7A-7C82 | NO | NO | NO | NO | NO |
| | | | | ALL | 7A-1E | 7A-1EE0 | YES | YES | YES | YES | YES |
| | SLEEP | TOGGLE | RECEIVER | ALL | 7A-57 | 7A-57A9 | NO | NO | NO | YES | YES |
| | | ON | RECEIVER | MAIN | 7E-1669 | 7E-1668 | NO | NO | NO | YES | YES |
| | | | | ZONE2 | 7E-1768 | 7E-1769 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-1867 | 7E-1866 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-1966 | 7E-1967 | NO | NO | NO | NO | NO |
| | | | | ALL | 7E-1A65 | 7E-1A64 | NO | NO | NO | YES | YES |
| | | OFF | RECEIVER | MAIN | 7E-1B64 | 7E-1B65 | NO | NO | NO | YES | YES |
| | | | | ZONE2 | 7E-1C63 | 7E-1C62 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-1D62 | 7E-1D63 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-1E61 | 7E-1E60 | NO | NO | NO | NO | NO |
| | | | | ALL | 7E-B3 | 7E-B34D | YES | YES | YES | YES | YES |
| | | 120min | RECEIVER | ALL | 7E-B4 | 7E-B44A | YES | YES | YES | YES | YES |
| | | 90min | RECEIVER | ALL | 7E-B5 | 7E-B54B | YES | YES | YES | YES | YES |
| | | 60min | RECEIVER | ALL | 7E-B6 | 7E-B648 | YES | YES | YES | YES | YES |
| | | 30min | RECEIVER | ALL | 7E-B7 | 7E-B749 | YES | YES | YES | YES | YES |
| INPUT | AUDIO SEL | AUTO | RECEIVER | MAIN | 7E-A6 | 7E-A658 | NO | NO | NO | NO | NO |
| | | HDMI | RECEIVER | MAIN | 7E-DA | 7E-DA24 | NO | NO | NO | NO | NO |
| | | COAX/OPT | RECEIVER | MAIN | 7E-A9 | 7E-A957 | NO | NO | NO | NO | NO |
| | | ANALOG | RECEIVER | MAIN | 7E-AA | 7E-AA54 | NO | NO | NO | NO | NO |
| | SUB INPUT | PC/MCX | RECEIVER | MAIN | 7F01-6C13 | 7F01-6C12 | NO | YES | YES | YES | YES |
| | | | | ZONE2 | 7F01-6D12 | 7F01-6D13 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7F01-6E11 | 7F01-6E10 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7F01-7807 | 7F01-7806 | NO | NO | NO | NO | NO |
| | | NET RADIO | RECEIVER | MAIN | 7F01-6F10 | 7F01-6F11 | NO | YES | YES | YES | YES |
| | | | | ZONE2 | 7F01-700F | 7F01-700E | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7F01-710E | 7F01-710F | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7F01-7906 | 7F01-7907 | NO | NO | NO | NO | NO |
| | | Rhapsody<br>Napster | RECEIVER | MAIN | 7F01-750A | 7F01-750B | NO | NO | NO | YES*U | YES*U |
| | | | | ZONE2 | 7F01-7609 | 7F01-7608 | NO | NO | NO | YES*U | YES*U |
| | | | | ZONE3 | 7F01-7708 | 7F01-7709 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7F01-7B04 | 7F01-7B05 | NO | NO | NO | NO | NO |
| | | Pandora | RECEIVER | MAIN | 7F01-85FA | 7F01-85FB | NO | NO | NO | YES*U | YES*U |
| | | | | ZONE2 | 7F01-86F9 | 7F01-86F8 | NO | NO | NO | YES*U | YES*U |
| | | | | ZONE3 | 7F01-87F8 | 7F01-87F9 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7F01-88F7 | 7F01-88F6 | NO | NO | NO | NO | NO |
| | | Napster | RECEIVER | MAIN | 7F01-89F6 | 7F01-89F7 | NO | NO | NO | NO | NO |
| | | | | ZONE2 | 7F01-8AF5 | 7F01-8AF4 | NO | NO | NO | NO | NO |
| | | | | ZONE3 | 7F01-8BF4 | 7F01-8BF5 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7F01-8CF3 | 7F01-8CF2 | NO | NO | NO | NO | NO |
| | | AirPlay | RECEIVER | MAIN | 7F01-91EE | 7F01-91EF | NO | NO | NO | YES | YES |
| | | | | ZONE2 | 7F01-92ED | 7F01-92EC | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7F01-93EC | 7F01-93ED | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7F01-94EB | 7F01-94EA | NO | NO | NO | NO | NO |
| OUTPUT | HDMI OUT 1 | ON | RECEIVER | ALL | 7E-205F | 7E-205E | YES | YES | YES | YES | YES |
| | | OFF | RECEIVER | ALL | 7E-B0CF | 7E-B0CE | YES | YES | YES | YES | YES |
| | HDMI OUT 2 | ON | RECEIVER | ALL | 7E-215E | 7E-215F | NO | NO | NO | NO | YES |
| | | OFF | RECEIVER | ALL | 7E-B1CE | 7E-B1CF | NO | NO | NO | NO | YES |
| VOLUME | MUTE | ON<br>(FULL) | RECEIVER | MAIN | 7E-A2 | 7E-A25C | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-A0 | 7E-A05E | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-26 | 7E-26D8 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-0C73 | 7E-0C72 | NO | NO | NO | NO | NO |
| | | | | ALL | 7E-2758 | 7E-2759 | NO | NO | NO | NO | NO |
| | | ON<br>(-40dB) | RECEIVER | MAIN | 7E-631C | 7E-631D | NO | NO | NO | YES | YES |
| | | | | ZONE2 | 7E-641B | 7E-641A | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-651A | 7E-651B | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-6619 | 7E-6618 | NO | NO | NO | NO | NO |
| | | | | ALL | 7E-6718 | 7E-6719 | NO | NO | NO | NO | NO |
| | | ON<br>(-20dB) | RECEIVER | MAIN | 7E-DF | 7E-DF21 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-2956 | 7E-2957 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-2A55 | 7E-2A54 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-2B54 | 7E-2B55 | NO | NO | NO | NO | NO |
| | | | | ALL | 7E-2C53 | 7E-2C52 | NO | NO | NO | NO | NO |
| | | OFF | RECEIVER | MAIN | 7E-A3 | 7E-A35D | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-A1 | 7E-A15F | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-66 | 7E-6698 | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-0D72 | 7E-0D73 | NO | NO | NO | NO | NO |
| | | | | ALL | 7E-2857 | 7E-2856 | NO | NO | NO | NO | NO |
| DISPLAY | SMART ZOOM | ON | RECEIVER | MAIN | 7E-225D | 7E-225C | NO | NO | NO | NO | NO |
| | | OFF (THROUGH) | RECEIVER | MAIN | 7E-235C | 7E-235D | NO | NO | NO | NO | NO |
| PROGRAM | PURE DIRECT<br>or DIRECT | ON | RECEIVER | MAIN | 7E-80 | 7E-807E | NO | YES | YES | YES | YES |
| | | OFF | RECEIVER | MAIN | 7E-82 | 7E-827C | NO | YES | YES | YES | YES |
| | STRAIGHT | ON | RECEIVER | MAIN | 7E-E0 | 7E-E01E | YES | YES | YES | YES | YES |
| | | OFF | RECEIVER | MAIN | 7E-27 | 7E-27D9 | YES | YES | YES | YES | YES |
| | PROGRAM | Hall in Munich A | RECEIVER | MAIN | 7E-E1 | 7E-E11F | YES | YES | YES | YES | YES |
| | | Hall in Munich B | RECEIVER | MAIN | 7E-E2 | 7E-E21C | NO | NO | NO | NO | NO |
| | | Hall in Frankfurt | RECEIVER | MAIN | 7E-E3 | 7E-E31D | NO | NO | NO | NO | NO |
| | | Hall in Stuttgart | RECEIVER | MAIN | 7E-E4 | 7E-E41A | NO | NO | NO | NO | NO |
| | | Hall in Vienna | RECEIVER | MAIN | 7E-E5 | 7E-E51B | YES | YES | YES | YES | YES |
| | | Hall in Amsterdam | RECEIVER | MAIN | 7E-E6 | 7E-E618 | NO | NO | NO | NO | NO |
| | | Hall in USA A | RECEIVER | MAIN | 7E-C4 | 7E-C43A | NO | NO | NO | NO | NO |
| | | Hall in USA B | RECEIVER | MAIN | 7E-C5 | 7E-C53B | NO | NO | NO | NO | NO |
| | | Church in Tokyo | RECEIVER | MAIN | 7E-E7 | 7E-E719 | NO | NO | NO | NO | NO |
| | | Church in Freiburg | RECEIVER | MAIN | 7E-E8 | 7E-E816 | NO | NO | NO | NO | NO |
| | | Church in Royaumont | RECEIVER | MAIN | 7E-E9 | 7E-E917 | NO | NO | NO | NO | NO |
| | | Chamber | RECEIVER | MAIN | 7E-AF | 7E-AF51 | YES | YES | YES | YES | YES |
| | | Village Gate | RECEIVER | MAIN | 7E-EA | 7E-EA14 | NO | NO | NO | NO | NO |
| | | Village Vanguard | RECEIVER | MAIN | 7E-EB | 7E-EB15 | NO | NO | NO | NO | NO |
| | | Warehouse Loft | RECEIVER | MAIN | 7E-EE | 7E-EE10 | NO | NO | NO | NO | NO |
| | | Cellar Club | RECEIVER | MAIN | 7E-CD | 7E-CD33 | YES | YES | YES | YES | YES |
| | | The Roxy Theatre | RECEIVER | MAIN | 7E-ED | 7E-ED13 | YES | YES | YES | YES | YES |
| | | The Bottom Line | RECEIVER | MAIN | 7E-EC | 7E-EC12 | YES | YES | YES | YES | YES |
| | | Arena | RECEIVER | MAIN | 7E-EF | 7E-EF11 | YES | YES | YES | YES | YES |
| | | Sports | RECEIVER | MAIN | 7E-F8 | 7E-F806 | YES | YES | YES | YES | YES |
| | | Action Game | RECEIVER | MAIN | 7E-F2 | 7E-F20C | YES | YES | YES | YES | YES |
| | | Roleplaying Game | RECEIVER | MAIN | 7E-CE | 7E-CE30 | YES | YES | YES | YES | YES |
| | | Music Video | RECEIVER | MAIN | 7E-F3 | 7E-F30D | YES | YES | YES | YES | YES |
| | | Recital/Opera | RECEIVER | MAIN | 7E-F5 | 7E-F50B | NO | NO | NO | NO | NO |
| | | Pavilion | RECEIVER | MAIN | 7E-F6 | 7E-F608 | NO | NO | NO | NO | NO |
| | | Disco | RECEIVER | MAIN | 7E-F0 | 7E-F00E | NO | NO | NO | NO | NO |
| | | Standard | RECEIVER | MAIN | 7E-FE | 7E-FE00 | YES | YES | YES | YES | YES |
| | | Spectacle | RECEIVER | MAIN | 7E-F9 | 7E-F907 | YES | YES | YES | YES | YES |
| | | Sci-Fi | RECEIVER | MAIN | 7E-FA | 7E-FA04 | YES | YES | YES | YES | YES |
| | | Adventure | RECEIVER | MAIN | 7E-FB | 7E-FB05 | YES | YES | YES | YES | YES |
| | | Drama | RECEIVER | MAIN | 7E-FC | 7E-FC02 | YES | YES | YES | YES | YES |
| | | Mono Movie | RECEIVER | MAIN | 7E-F7 | 7E-F709 | YES | YES | YES | YES | YES |
| | | 2ch Stereo | RECEIVER | MAIN | 7E-C0 | 7E-C03E | YES | YES | YES | YES | YES |
| | | Xch Stereo | RECEIVER | MAIN | 7E-FF | 7E-FF01 | YES | YES | YES | YES | YES |

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | SUR. DECODE | ON | RECEIVER | MAIN | 7E-FD | 7E-FD03 | YES | YES | YES | YES | YES |
| | ENHANCER | AUTO | RECEIVER | MAIN | 7E-D8 | 7E-D826 | YES | YES | YES | YES | YES |
| | | OFF | RECEIVER | MAIN | 7E-D9 | 7E-D927 | YES | YES | YES | YES | YES |
| | TONE CONTROL | BASS + | RECEIVER | ZONE2 | 7A-73 | 7A-738D | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE3 | 7A-77 | 7A-7789 | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE4 | 7E-433C | 7E-433D | NO | NO | NO | NO | NO |
| | | BASS - | RECEIVER | ZONE2 | 7A-74 | 7A-748A | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE3 | 7A-78 | 7A-7886 | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE4 | 7E-443B | 7E-443A | NO | NO | NO | NO | NO |
| | | TREBLE + | RECEIVER | ZONE2 | 7A-75 | 7A-758B | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE3 | 7A-79 | 7A-7987 | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE4 | 7E-453A | 7E-453B | NO | NO | NO | NO | NO |
| | | TREBLE - | RECEIVER | ZONE2 | 7A-76 | 7A-7688 | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE3 | 7A-7A | 7A-7A84 | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE4 | 7E-4639 | 7E-4638 | NO | NO | NO | NO | NO |
| | BALANCE | LEFT | RECEIVER | ZONE2 | 7E-D4 | 7E-D42A | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE3 | 7E-D6 | 7E-D628 | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE4 | 7E-4738 | 7E-4739 | NO | NO | NO | NO | NO |
| | | RIGHT | RECEIVER | ZONE2 | 7E-D5 | 7E-D52B | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE3 | 7E-D7 | 7E-D729 | NO | NO | NO | NO | NO |
| | | | RECEIVER | ZONE4 | 7E-4837 | 7E-4836 | NO | NO | NO | NO | NO |
| MENU | SUR. DECODE | PLII(IIx) MOVIE | RECEIVER | MAIN | 7E-67 | 7E-6799 | YES | YES | YES | YES | YES |
| | | PLII(IIx) MUSIC | RECEIVER | MAIN | 7E-68 | 7E-6896 | YES | YES | YES | YES | YES |
| | | PLII(IIx) GAME | RECEIVER | MAIN | 7E-C7 | 7E-C739 | YES | YES | YES | YES | YES |
| | | NEO:6 CINEMA | RECEIVER | MAIN | 7E-69 | 7E-6997 | YES | YES | YES | YES | YES |
| | | NEO:6 MUSIC | RECEIVER | MAIN | 7E-6A | 7E-6A94 | YES | YES | YES | YES | YES |
| | | Prologic | RECEIVER | MAIN | 7E-C9 | 7E-C937 | YES | YES | YES | YES | YES |
| | EXTED SURROUND | AUTO | RECEIVER | MAIN | 7E-7C | 7E-7C82 | NO | NO | YES | YES | YES |
| | | PLIIx MOVIE | RECEIVER | MAIN | 7E-DD | 7E-DD23 | NO | NO | YES | YES | YES |
| | | PLIIx MUSIC | RECEIVER | MAIN | 7E-DE | 7E-DE20 | NO | NO | YES | YES | YES |
| | | ON(EX/ES) | RECEIVER | MAIN | 7E-B8 | 7E-B846 | NO | NO | YES | YES | YES |
| | | OFF | RECEIVER | MAIN | 7E-B9 | 7E-B947 | NO | NO | YES | YES | YES |
| | HDMI Auto Lipsync | ON | RECEIVER | MAIN | 7E-83FC | 7E-83FD | YES | YES | YES | YES | YES |
| | | OFF(MANUAL) | RECEIVER | MAIN | 7E-84FB | 7E-84FA | YES | YES | YES | YES | YES |
| | DUAL MONO | MAIN | RECEIVER | MAIN | 7E-93 | 7E-936D | YES*J | YES*J | YES*J | YES*J | YES*J |
| | | SUB | RECEIVER | MAIN | 7E-94 | 7E-946A | YES*J | YES*J | YES*J | YES*J | YES*J |
| | | ALL | RECEIVER | MAIN | 7E-95 | 7E-956B | YES*J | YES*J | YES*J | YES*J | YES*J |
| | ADAPTIVE DRC | ON | RECEIVER | MAIN | 7E-740B | 7E-740A | YES | YES | YES | YES | YES |
| | | OFF | RECEIVER | MAIN | 7E-750A | 7E-750B | YES | YES | YES | YES | YES |
| | ADAPTIVE DSP | ON | RECEIVER | MAIN | 7E-7609 | 7E-7608 | YES | YES | YES | YES | YES |
| | | OFF | RECEIVER | MAIN | 7E-7708 | 7E-7709 | YES | YES | YES | YES | YES |
| | TRIGGER 1 | MANUAL ON | RECEIVER | ALL | 7E-3F40 | 7E-3F41 | NO | NO | NO | YES | YES |
| | | MANUAL OFF | RECEIVER | ALL | 7E-403F | 7E-403E | NO | NO | NO | YES | YES |
| | TRIGGER 2 | MANUAL ON | RECEIVER | ALL | 7E-413E | 7E-413F | NO | NO | NO | NO | NO |
| | | MANUAL OFF | RECEIVER | ALL | 7E-423D | 7E-423C | NO | NO | NO | NO | NO |
| | DIALOGUE LEVEL | 0 | RECEIVER | MAIN | 7E-B4CB | 7E-B4CA | NO | NO | NO | YES | YES |
| | | 1 | RECEIVER | MAIN | 7E-B5CA | 7E-B5CB | NO | NO | NO | YES | YES |
| | | 2 | RECEIVER | MAIN | 7E-B6C9 | 7E-B6C8 | NO | NO | NO | YES | YES |
| | | 3 | RECEIVER | MAIN | 7E-B7C8 | 7E-B7C9 | NO | NO | NO | YES | YES |
| MEMORY | SCENE | 5 | RECEIVER | MAIN | 7A-90EF | 7A-90EE | NO | NO | NO | NO | NO |
| | | 6 | RECEIVER | MAIN | 7A-91EE | 7A-91EF | NO | NO | NO | NO | NO |
| | | 7 | RECEIVER | MAIN | 7A-92ED | 7A-92EC | NO | NO | NO | NO | NO |
| | | 8 | RECEIVER | MAIN | 7A-93EC | 7A-93ED | NO | NO | NO | NO | NO |
| | | 9 | RECEIVER | MAIN | 7A-94EB | 7A-94EA | NO | NO | NO | NO | NO |
| | | 10 | RECEIVER | MAIN | 7A-95EA | 7A-95EB | NO | NO | NO | NO | NO |
| | | 11 | RECEIVER | MAIN | 7A-96E9 | 7A-96E8 | NO | NO | NO | NO | NO |
| | | 12 | RECEIVER | MAIN | 7A-97E8 | 7A-97E9 | NO | NO | NO | NO | NO |
| | VOLUME MEMORY | 1 | RECEIVER | MAIN | 7E-6B | 7E-6B95 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-87 | 7E-8779 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-20 | 7E-20DE | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-007F | 7E-007E | NO | NO | NO | NO | NO |
| | | 2 | RECEIVER | MAIN | 7E-6C | 7E-6C92 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-88 | 7E-8876 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-21 | 7E-21DF | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-017E | 7E-017F | NO | NO | NO | NO | NO |
| | | 3 | RECEIVER | MAIN | 7E-6D | 7E-6D93 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-89 | 7E-8977 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-22 | 7E-22DC | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-027D | 7E-027C | NO | NO | NO | NO | NO |
| | | 4 | RECEIVER | MAIN | 7E-6E | 7E-6E90 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-8A | 7E-8A74 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-23 | 7E-23DD | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-037C | 7E-037D | NO | NO | NO | NO | NO |
| | | 5 | RECEIVER | MAIN | 7E-6F | 7E-6F91 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-8B | 7E-8B75 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-24 | 7E-24DA | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-047B | 7E-047A | NO | NO | NO | NO | NO |
| | | 6 | RECEIVER | MAIN | 7E-70 | 7E-708E | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-8C | 7E-8C72 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-25 | 7E-25DB | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-057A | 7E-057B | NO | NO | NO | NO | NO |
| | VOLUME RECALL | 1 | RECEIVER | MAIN | 7E-75 | 7E-758B | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-8D | 7E-8D73 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-60 | 7E-609E | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-0679 | 7E-0678 | NO | NO | NO | NO | NO |
| | | 2 | RECEIVER | MAIN | 7E-76 | 7E-7688 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-8E | 7E-8E70 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-61 | 7E-619F | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-0778 | 7E-0779 | NO | NO | NO | NO | NO |
| | | 3 | RECEIVER | MAIN | 7E-77 | 7E-7789 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-8F | 7E-8F71 | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-62 | 7E-629C | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-0877 | 7E-0876 | NO | NO | NO | NO | NO |
| | | 4 | RECEIVER | MAIN | 7E-78 | 7E-7886 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-90 | 7E-906E | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-63 | 7E-639D | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-0976 | 7E-0977 | NO | NO | NO | NO | NO |
| | | 5 | RECEIVER | MAIN | 7E-79 | 7E-7987 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-91 | 7E-916F | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-64 | 7E-649A | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-0A75 | 7E-0A74 | NO | NO | NO | NO | NO |
| | | 6 | RECEIVER | MAIN | 7E-7A | 7E-7A84 | YES | YES | YES | YES | YES |
| | | | | ZONE2 | 7E-92 | 7E-926C | NO | NO | NO | YES | YES |
| | | | | ZONE3 | 7E-65 | 7E-659B | NO | NO | NO | NO | NO |
| | | | | ZONE4 | 7E-0B74 | 7E-0B75 | NO | NO | NO | NO | NO |
| | VIDEO PRESET | 1 | RECEIVER | MAIN | 7E-A4DB | 7E-A4DA | NO | NO | NO | NO | NO |
| | | 2 | RECEIVER | MAIN | 7E-A5DA | 7E-A5DB | NO | NO | NO | NO | NO |
| | | 3 | RECEIVER | MAIN | 7E-A6D9 | 7E-A6D8 | NO | NO | NO | NO | NO |
| | | 4 | RECEIVER | MAIN | 7E-A7D8 | 7E-A7D9 | NO | NO | NO | NO | NO |
| | | 5 | RECEIVER | MAIN | 7E-A8D7 | 7E-A8D6 | NO | NO | NO | NO | NO |
| | | 6 | RECEIVER | MAIN | 7E-A9D6 | 7E-A9D7 | NO | NO | NO | NO | NO |
| ZONE CONTROL | PARTY | ON | RECEIVER | ALL | 7E-354A | 7E-354B | NO | NO | NO | NO | YES |
| | | OFF | RECEIVER | ALL | 7E-3649 | 7E-3648 | NO | NO | NO | NO | YES |
| MENU | SRCH MODE | PRESET | TUNER | ALL | 7F01-FD | 7F01-FD03 | YES | YES | YES | YES | YES |
| | | MANUAL | HD-Radio | | 7F01-FE | 7F01-FE00 | YES | YES | YES | YES | YES |
| | | TOGGLE | | | 7A-AB | 7A-AB55 | YES | YES | YES | YES | YES |
| INPUT | BAND | FM | | | 7E-BC | 7E-BC42 | YES | YES | YES | YES | YES |
| | | AM | | | 7E-BD | 7E-BD43 | YES | YES | YES | YES | YES |
| OPERATION | AUTO TUNING | UP | | | 7E-BE | 7E-BE40 | YES | YES | YES | YES | YES |
| | | DOWN | | | 7E-BF | 7E-BF41 | YES | YES | YES | YES | YES |
| | TUNING/ PRESET No. | UP | | | 7A-10 | 7A-10EE | YES | YES | YES | YES | YES |
| | | DOWN | | | 7A-11 | 7A-11EF | YES | YES | YES | YES | YES |