Standard IR codes for RX-V375 - V775

*A: Australia model, C: Canada model, E: Europe model, J: Japan Model, T: China model, U: USA model

Function			Device		Code	Code	RX-V375	RX-V475, V500D	RX-V575	RX-V675	RX-V775
Group	Name			Zone	(ID1)	(ID2)	HTR-2866, 3066	HTR-4066	HTR-5066	HTR-6066	
POWER	RECEIVER POWER	ON/OFF	RECEIVER	MAIN	7E-2A	7E-2AD4	YES	YES	YES	YES	YES
				ZONE2	7A-453A	7A-453B	NO	NO	NO	YES	YES
				ZONE3	7A-4639	7A-4638	NO	NO	NO	NO	NO
				ZONE4	7A-6F10	7A-6F11	NO	NO	NO	NO	NO
	SOURCE POWER	TOGGLE	RECEIVER	MAIN	7F01-50	7F01-50AE	NO	NO	NO	NO	NO
				ZONE2	7F01-70	7F01-708E	NO	NO	NO	NO	NO
				ZONE3	7F01-90	7F01-906E	NO	NO	NO	NO	NO
				ZONE4	7F01-B0	7F01-B04E	NO	NO	NO	NO	NO
	SLEEP	TOGGLE	RECEIVER	MAIN	7A-30	7A-30CE	YES	YES	YES	YES	YES
				ZONE2	7A-31	7A-31CF	NO	NO	NO	YES	YES
				ZONE3	7A-32	7A-32CC	NO	NO	NO	NO	NO
				ZONE4	7A-33	7A-33CD	NO	NO	NO	NO	NO
INPUT	HDMI- 1		RECEIVER	MAIN	7A-4738	7A-4739	YES	YES	YES	YES	YES
				ZONE2	7A-4837	7A-4836	NO	NO	NO	NO	NO
				ZONE3	7A-4936	7A-4937	NO	NO	NO	NO	NO
	HDMI- 2		RECEIVER	MAIN	7A-4A35	7A-4A34	YES	YES	YES	YES	YES
				ZONE2	7A-4B34	7A-4B35	NO	NO	NO	NO	NO
				ZONE3	7A-4C33	7A-4C32	NO	NO	NO	NO	NO
	HDMI- 3		RECEIVER	MAIN	7A-4D32	7A-4D33	YES	YES	YES	YES	YES
				ZONE2	7A-4E31	7A-4E30	NO	NO	NO	NO	NO
				ZONE3	7A-4F30	7A-4F31	NO	NO	NO	NO	NO
	HDMI- 4		RECEIVER	MAIN	7A-502F	7A-502E	YES	YES	YES	YES	YES
				ZONE2	7A-512E	7A-512F	NO	NO	NO	NO	NO
				ZONE3	7A-522D	7A-522C	NO	NO	NO	NO	NO
	HDMI- 5		RECEIVER	MAIN	7A-700F	7A-700E	NO	YES	YES	YES	YES
				ZONE2	7A-710E	7A-710F	NO	NO	NO	NO	NO
				ZONE3	7A-720D	7A-720C	NO	NO	NO	NO	NO
	HDMI- 6		RECEIVER	MAIN	7A-730C	7A-730D	NO	NO	NO	NO	NO
				ZONE2	7A-740B	7A-740A	NO	NO	NO	NO	NO
				ZONE3	7A-750A	7A-750B	NO	NO	NO	NO	NO
	HDMI- 7		RECEIVER	MAIN	7A-98E7	7A-98E6	NO	NO	NO	NO	NO
				ZONE2	7A-99E6	7A-99E7	NO	NO	NO	NO	NO
				ZONE3	7A-9AE5	7A-9AE4	NO	NO	NO	NO	NO
	AV- 1		RECEIVER	MAIN	7A-532C	7A-532D	YES	YES	YES	YES	YES
				ZONE2	7A-542B	7A-542A	NO	NO	NO	NO	NO
				ZONE3	7A-552A	7A-552B	NO	NO	NO	NO	NO
				ZONE4	7A-84FB	7A-84FA	NO	NO	NO	NO	NO
	AV- 2		RECEIVER	MAIN	7A-5629	7A-5628	YES	YES	YES	YES	YES
				ZONE2	7A-5728	7A-5729	NO	NO	NO	NO	NO
				ZONE3	7A-5827	7A-5826	NO	NO	NO	NO	NO
				ZONE4	7A-85FA	7A-85FB	NO	NO	NO	NO	NO
	AV- 3		RECEIVER	MAIN	7A-5926	7A-5927	YES	YES	YES	YES	YES
				ZONE2	7A-5A25	7A-5A24	NO	NO	NO	NO	NO
				ZONE3	7A-5B24	7A-5B25	NO	NO	NO	NO	NO
				ZONE4	7A-86F9	7A-86F8	NO	NO	NO	NO	NO
	AV- 4		RECEIVER	MAIN	7A-5C23	7A-5C22	YES	YES	YES	YES	YES
				ZONE2	7A-5D22	7A-5D23	NO	NO	NO	NO	NO
				ZONE3	7A-5E21	7A-5E20	NO	NO	NO	NO	NO
				ZONE4	7A-87F8	7A-87F9	NO	NO	NO	NO	NO
	AV- 5		RECEIVER	MAIN	7A-5F20	7A-5F21	YES	YES	YES	YES	YES
				ZONE2	7A-601F	7A-601E	NO	NO	NO	YES	YES
				ZONE3	7A-611E	7A-611F	NO	NO	NO	NO	NO
				ZONE4	7A-88F7	7A-88F6	NO	NO	NO	NO	NO
	AV- 6		RECEIVER	MAIN	7A-621D	7A-621C	NO	YES	YES	YES	YES
				ZONE2	7A-631C	7A-631D	NO	NO	NO	YES	YES
				ZONE3	7A-641B	7A-641A	NO	NO	NO	NO	NO
				ZONE4	7A-89F6	7A-89F7	NO	NO	NO	NO	NO
	AV- 7		RECEIVER	MAIN	7A-7609	7A-7608	NO	NO	NO	NO	NO
				ZONE2	7A-7708	7A-7709	NO	NO	NO	NO	NO
				ZONE3	7A-7807	7A-7806	NO	NO	NO	NO	NO
				ZONE4	7A-8AF5	7A-8AF4	NO	NO	NO	NO	NO
	AUDIO- 1 (AUDIO)		RECEIVER	MAIN	7A-651A	7A-651B	YES	YES(AUDIO)	YES(AUDIO)	YES	YES
				ZONE2	7A-6619	7A-6618	NO	NO	NO	YES	YES
				ZONE3	7A-6718	7A-6719	NO	NO	NO	NO	NO
				ZONE4	7A-8CF3	7A-8CF2	NO	NO	NO	NO	NO
	AUDIO- 2		RECEIVER	MAIN	7A-6817	7A-6816	YES	NO	NO	YES	YES
				ZONE2	7A-6916	7A-6917	NO	NO	NO	YES	YES
				ZONE3	7A-6A15	7A-6A14	NO	NO	NO	NO	NO
				ZONE4	7A-8DF2	7A-8DF3	NO	NO	NO	NO	NO
	AUDIO- 3		RECEIVER	MAIN	7A-7C03	7A-7C02	NO	NO	NO	NO	NO
				ZONE2	7A-7D02	7A-7D03	NO	NO	NO	NO	NO
				ZONE3	7A-7E01	7A-7E00	NO	NO	NO	NO	NO
				ZONE4	7A-8EF1	7A-8EF0	NO	NO	NO	NO	NO
	AUDIO- 4		RECEIVER	MAIN	7A-7F00	7A-7F01	NO	NO	NO	NO	NO
				ZONE2	7A-80FF	7A-80FE	NO	NO	NO	NO	NO
				ZONE3	7A-81FE	7A-81FF	NO	NO	NO	NO	NO
				ZONE4	7A-8FF0	7A-8FF1	NO	NO	NO	NO	NO
	V-AUX		RECEIVER	MAIN	7A-55	7A-55AB	YES	YES	YES	YES	YES
				ZONE2	7A-D8	7A-D826	NO	NO	NO	NO	NO
				ZONE3	7A-F0	7A-F00E	NO	NO	NO	NO	NO
				ZONE4	7A-7D	7A-7D83	NO	NO	NO	NO	NO
	PHONO		RECEIVER	MAIN	7A-14	7A-14EA	NO	NO	NO	NO	YES*except UC
				ZONE2	7A-D0	7A-D02E	NO	NO	NO	NO	YES*except UC
				ZONE3	7A-F1	7A-F10F	NO	NO	NO	NO	NO
				ZONE4	7A-7E	7A-7E80	NO	NO	NO	NO	NO
	USB		RECEIVER	MAIN	7F01-720D	7F01-720C	YES*except T	YES	YES	YES	YES
				ZONE2	7F01-730C	7F01-730D	NO	NO	NO	YES	YES
				ZONE3	7F01-740B	7F01-740A	NO	NO	NO	NO	NO
				ZONE4	7F01-7A05	7F01-7A04	NO	NO	NO	NO	NO
	NET	TOGGLE	RECEIVER	MAIN	7F01-3F	7F01-3FC1	NO	YES	YES	YES	YES
				ZONE2	7F01-40	7F01-40BE	NO	NO	NO	YES	YES
				ZONE3	7F01-41	7F01-41BF	NO	NO	NO	NO	NO
				ZONE4	7F01-49	7F01-49B7	NO	NO	NO	NO	NO
	TUNER		RECEIVER	MAIN	7A-16	7A-16E8	YES*No key	YES*No key	YES*No key	YES	YES
				ZONE2	7A-D2	7A-D22C	NO	NO	NO	YES	YES
				ZONE3	7A-F3	7A-F30D	NO	NO	NO	NO	NO
				ZONE4	7A-20	7A-20DE	NO	NO	NO	NO	NO
	MULTI CH IN		RECEIVER	MAIN	7A-87	7A-8779	NO	NO	NO	NO	NO
	UP		RECEIVER	MAIN	7A-1F60	7A-1F61	NO	NO	NO	YES	YES
				ZONE2	7A-205F	7A-205E	NO	NO	NO	YES	YES
				ZONE3	7A-215E	7A-215F	NO	NO	NO	NO	NO
				ZONE4	7A-225D	7A-225C	NO	NO	NO	NO	NO
	DOWN		RECEIVER	MAIN	7A-235C	7A-235D	NO	NO	NO	YES	YES
				ZONE2	7A-245B	7A-245A	NO	NO	NO	YES	YES
				ZONE3	7A-255A	7A-255B	NO	NO	NO	NO	NO
				ZONE4	7A-2659	7A-2658	NO	NO	NO	NO	NO
	NET/USB	TOGGLE	RECEIVER	MAIN	7A-A8D7	7A-A8D6	NO	NO	NO	YES	YES
				ZONE2	7A-A9D6	7A-A9D7	NO	NO	NO	YES	YES
				ZONE3	7A-AAD5	7A-AAD4	NO	NO	NO	NO	NO
				ZONE4	7A-ABD4	7A-ABD5	NO	NO	NO	NO	NO
OUTPUT	HDMI OUT	TOGGLE	RECEIVER	MAIN	7A-35	7A-35CB	YES*No key	YES*No key	YES*No key	YES*No key	YES
				ZONE2	7A-B4CB	7A-B4CA	NO	NO	NO	NO	NO
				ZONE3	7A-B5CA	7A-B5CB	NO	NO	NO	NO	NO
				ZONE4	7A-B6C9	7A-B6C8	NO	NO	NO	NO	NO
	SPEAKER	ZONE A	RECEIVER	MAIN	7A-9A	7A-9A64	NO	NO	YES	NO	NO
		ZONE B	RECEIVER	MAIN	7A-9B	7A-9B65	NO	NO	YES	NO	NO
PROGRAM	MOVIE	TOGGLE	RECEIVER	MAIN	7A-88	7A-8876	YES	YES	YES	YES	YES
	MUSIC	TOGGLE	RECEIVER	MAIN	7A-89	7A-8977	YES	YES	YES	YES	YES
	ENHANCER	TOGGLE	RECEIVER	MAIN	7A-94	7A-946A	YES	YES	YES	YES	YES
	STRAIGHT	TOGGLE	RECEIVER	MAIN	7A-56	7A-56A8	YES	YES	YES	YES	YES
	PURE DIRECT or DIRECT	TOGGLE	RECEIVER	MAIN	7A-DD	7A-DD23	NO	YES	YES	YES	YES
	SUR. DECODE	TOGGLE	RECEIVER	MAIN	7A-8D	7A-8D73	YES	YES	YES	YES	YES
	CLASSICAL	TOGGLE	RECEIVER	MAIN	7A-8A	7A-8A74	NO	NO	NO	NO	NO
	LIVE/CLUB	TOGGLE	RECEIVER	MAIN	7A-8B	7A-8B75	NO	NO	NO	NO	NO
	ENTERTAIN	TOGGLE	RECEIVER	MAIN	7A-8C	7A-8C72	NO	NO	NO	NO	NO
	MOVIE	TOGGLE	RECEIVER	MAIN	7A-8E	7A-8E70	NO	NO	NO	NO	NO
	STEREO	TOGGLE	RECEIVER	MAIN	7A-8F	7A-8F71	NO	NO	NO	NO	NO
	PROGRAM	UP	RECEIVER	MAIN	7A-58	7A-58A6	NO	NO	NO	YES	YES
		DOWN	RECEIVER	MAIN	7A-59	7A-59A7	NO	NO	NO	YES	YES
MEMORY	SCENE	1 BD/DVD	RECEIVER	MAIN	7A-007F	7A-007E	YES	YES	YES	YES	YES
				ZONE2	7A-017E	7A-017F	NO	NO	NO	NO	NO
				ZONE3	7A-027D	7A-027C	NO	NO	NO	NO	NO
				ZONE4	7A-1867	7A-1866	NO	NO	NO	NO	NO
		2 TV	RECEIVER	MAIN	7A-037C	7A-037D	YES	YES	YES	YES	YES
				ZONE2	7A-047B	7A-047A	NO	NO	NO	NO	NO
				ZONE3	7A-057A	7A-057B	NO	NO	NO	NO	NO
				ZONE4	7A-1966	7A-1967	NO	NO	NO	NO	NO
		3 CD or NET	RECEIVER	MAIN	7A-0679	7A-0678	YES	YES	YES	YES	YES
				ZONE2	7A-0778	7A-0779	NO	NO	NO	NO	NO
				ZONE3	7A-0877	7A-0876	NO	NO	NO	NO	NO
				ZONE4	7A-1A65	7A-1A64	NO	NO	NO	NO	NO
		4 RADIO	RECEIVER	MAIN	7A-0976	7A-0977	YES	YES	YES	YES	YES
				ZONE2	7A-0A75	7A-0A74	NO	NO	NO	NO	NO
				ZONE3	7A-0B74	7A-0B75	NO	NO	NO	NO	NO
				ZONE4	7A-1B64	7A-1B65	NO	NO	NO	NO	NO
	MEMORY		RECEIVER	MAIN	7F01-6718	7F01-6719	YES	YES	YES	NO	NO
				ZONE2	7F01-6817	7F01-6816	NO	NO	NO	NO	NO
				ZONE3	7F01-6916	7F01-6917	NO	NO	NO	NO	NO
				ZONE4	7F01-80FF	7F01-80FE	NO	NO	NO	NO	NO
MENU	ON SCREEN or SETUP	TOGGLE	RECEIVER	MAIN	7A-84	7A-847A	YES	YES	YES	YES	YES
				ZONE2	7A-3B44	7A-3B45	NO	NO	NO	NO	NO
				ZONE3	7A-443B	7A-443A	NO	NO	NO	NO	NO
				ZONE4	7A-413E	7A-413F	NO	NO	NO	NO	NO
	OPTION	TOGGLE	RECEIVER	MAIN	7A-6B14	7A-6B15	YES	YES	YES	YES	YES

				ZONE2	7A-6C13	7A-6C12	NO	NO	NO	NO	NO
				ZONE3	7A-6D12	7A-6D13	NO	NO	NO	NO	NO
				ZONE4	7A-6E11	7A-6E10	NO	NO	NO	NO	NO
	TOP MENU	TOGGLE	RECEIVER	MAIN	7A-A0DF	7A-A0DE	YES*except T	YES	YES	YES	YES
				ZONE2	7A-A1DE	7A-A1DF	NO	NO	NO	NO	NO
				ZONE3	7A-A2DD	7A-A2DC	NO	NO	NO	NO	NO
				ZONE4	7A-A3DC	7A-A3DD	NO	NO	NO	NO	NO
	POP-UP MENU	TOGGLE	RECEIVER	MAIN	7A-A4DB	7A-A4DA	YES*except T	YES	YES	YES	YES
				ZONE2	7A-A5DA	7A-A5DB	NO	NO	NO	NO	NO
				ZONE3	7A-A6D9	7A-A6D8	NO	NO	NO	NO	NO
				ZONE4	7A-A7D8	7A-A7D9	NO	NO	NO	NO	NO
	CURSOR	UP	RECEIVER	MAIN	7A-9D	7A-9D63	YES	YES	YES	YES	YES
				ZONE2	7A-2B54	7A-2B55	NO	NO	NO	NO	NO
				ZONE3	7A-304F	7A-304E	NO	NO	NO	NO	NO
				ZONE4	7A-354A	7A-354B	NO	NO	NO	NO	NO
		DOWN	RECEIVER	MAIN	7A-9C	7A-9C62	YES	YES	YES	YES	YES
				ZONE2	7A-2C53	7A-2C52	NO	NO	NO	NO	NO
				ZONE3	7A-314E	7A-314F	NO	NO	NO	NO	NO
				ZONE4	7A-3649	7A-3648	NO	NO	NO	NO	NO
		LEFT	RECEIVER	MAIN	7A-9F	7A-9F61	YES	YES	YES	YES	YES
				ZONE2	7A-2D52	7A-2D53	NO	NO	NO	NO	NO
				ZONE3	7A-324D	7A-324C	NO	NO	NO	NO	NO
				ZONE4	7A-3748	7A-3749	NO	NO	NO	NO	NO
		RIGHT	RECEIVER	MAIN	7A-9E	7A-9E60	YES	YES	YES	YES	YES
				ZONE2	7A-2E51	7A-2E50	NO	NO	NO	NO	NO
				ZONE3	7A-334C	7A-334D	NO	NO	NO	NO	NO
				ZONE4	7A-3847	7A-3846	NO	NO	NO	NO	NO
	ENTER		RECEIVER	MAIN	7A-DE	7A-DE20	YES	YES	YES	YES	YES
				ZONE2	7A-2F50	7A-2F51	NO	NO	NO	YES	YES
				ZONE3	7A-344B	7A-344A	NO	NO	NO	NO	NO
				ZONE4	7A-3946	7A-3947	NO	NO	NO	NO	NO
	RETURN		RECEIVER	MAIN	7A-AA	7A-AA54	YES	YES	YES	YES	YES
				ZONE2	7A-3C43	7A-3C42	NO	NO	NO	NO	NO
				ZONE3	7A-3F40	7A-3F41	NO	NO	NO	NO	NO
				ZONE4	7A-423D	7A-423C	NO	NO	NO	NO	NO
	LEVEL	TOGGLE	RECEIVER	MAIN	7A-86	7A-8678	NO	NO	NO	NO	NO
VOLUME	VOLUME	UP	RECEIVER	MAIN	7A-1A	7A-1AE4	YES	YES	YES	YES	YES
				ZONE2	7A-DA	7A-DA24	NO	NO	NO	YES	YES
				ZONE3	7A-FD	7A-FD03	NO	NO	NO	NO	NO
				ZONE4	7A-2B	7A-2BD5	NO	NO	NO	NO	NO
		DOWN	RECEIVER	MAIN	7A-1B	7A-1BE5	YES	YES	YES	YES	YES
				ZONE2	7A-DB	7A-DB25	NO	NO	NO	YES	YES
				ZONE3	7A-FE	7A-FE00	NO	NO	NO	NO	NO
				ZONE4	7A-2C	7A-2CD2	NO	NO	NO	NO	NO
	MUTE	TOGGLE	RECEIVER	MAIN	7A-1C	7A-1CE2	YES	YES	YES	YES	YES
				ZONE2	7A-DC	7A-DC22	NO	NO	NO	YES	YES
				ZONE3	7A-FF	7A-FF01	NO	NO	NO	NO	NO
				ZONE4	7A-2D	7A-2DD3	NO	NO	NO	NO	NO
ZONE CONTROL	PARTY	TOGGLE	RECEIVER	ALL	7A-34	7A-34CA	NO	NO	NO	NO	YES
DISPLAY	DISPLAY	TOGGLE	RECEIVER	MAIN	7F01-60	7F01-609E	NO	NO	NO	YES	YES
				ZONE2	7F01-80	7F01-807E	NO	NO	NO	NO	NO
				ZONE3	7F01-A0	7F01-A05E	NO	NO	NO	NO	NO
				ZONE4	7F01-C0	7F01-C03E	NO	NO	NO	NO	NO
	INFO	TOGGLE	RECEIVER	MAIN	7A-2758	7A-2759	YES	YES	YES	YES	YES
				ZONE2	7A-2857	7A-2856	NO	NO	NO	NO	NO
				ZONE3	7A-2956	7A-2957	NO	NO	NO	NO	NO
				ZONE4	7A-2A55	7A-2A54	NO	NO	NO	NO	NO
OPERATION	MODE	TOGGLE	RECEIVER	MAIN	7F01-66	7F01-6698	YES	YES	YES	YES	YES
				ZONE2	7F01-86	7F01-8678	NO	NO	NO	NO	NO
				ZONE3	7F01-A6	7F01-A658	NO	NO	NO	NO	NO
				ZONE4	7F01-C6	7F01-C638	NO	NO	NO	NO	NO
	STOP		RECEIVER	MAIN	7F01-69	7F01-6997	YES*except T	YES	YES	YES	YES
				ZONE2	7F01-89	7F01-8977	NO	NO	NO	YES	YES
				ZONE3	7F01-A9	7F01-A957	NO	NO	NO	NO	NO
				ZONE4	7F01-C9	7F01-C937	NO	NO	NO	NO	NO
	PAUSE		RECEIVER	MAIN	7F01-67	7F01-6799	YES*except T	YES	YES	YES	YES
				ZONE2	7F01-87	7F01-8779	NO	NO	NO	YES	YES
				ZONE3	7F01-A7	7F01-A759	NO	NO	NO	NO	NO
				ZONE4	7F01-C7	7F01-C739	NO	NO	NO	NO	NO
	PLAY or BAND		RECEIVER	MAIN	7F01-68	7F01-6896	YES(PLAY)*except T	YES(PLAY)	YES(PLAY)	YES	YES
				ZONE2	7F01-88	7F01-8876	NO	NO	NO	YES	YES
				ZONE3	7F01-A8	7F01-A856	NO	NO	NO	NO	NO
				ZONE4	7F01-C8	7F01-C836	NO	NO	NO	NO	NO
	SEARCH or TUNING	SEARCH- or TUNING-	RECEIVER	MAIN	7F01-6A	7F01-6A94	YES(SEARCH-)*except T	YES(SEARCH-)	YES(SEARCH-)	YES	YES
				ZONE2	7F01-8A	7F01-8A74	NO	NO	NO	YES	YES
				ZONE3	7F01-AA	7F01-AA54	NO	NO	NO	NO	NO
				ZONE4	7F01-CA	7F01-CA34	NO	NO	NO	NO	NO
		SEARCH+ or TUNING+	RECEIVER	MAIN	7F01-6B	7F01-6B95	YES(SEARCH+)*except T	YES(SEARCH+)	YES(SEARCH+)	YES	YES
				ZONE2	7F01-8B	7F01-8B75	NO	NO	NO	YES	YES
				ZONE3	7F01-AB	7F01-AB55	NO	NO	NO	NO	NO
				ZONE4	7F01-CB	7F01-CB35	NO	NO	NO	NO	NO
	SKIP or PRESET	SKIP- or PRESET-	RECEIVER	MAIN	7F01-6C	7F01-6C92	YES(SKIP-)*except T	YES(SKIP-)	YES(SKIP-)	YES	YES
				ZONE2	7F01-8C	7F01-8C72	NO	NO	NO	YES	YES
				ZONE3	7F01-AC	7F01-AC52	NO	NO	NO	NO	NO
				ZONE4	7F01-CC	7F01-CC32	NO	NO	NO	NO	NO
		SKIP+ or PRESET+	RECEIVER	MAIN	7F01-6D	7F01-6D93	YES(SKIP+)*except T	YES(SKIP+)	YES(SKIP+)	YES	YES
				ZONE2	7F01-8D	7F01-8D73	NO	NO	NO	YES	YES
				ZONE3	7F01-AD	7F01-AD53	NO	NO	NO	NO	NO
				ZONE4	7F01-CD	7F01-CD33	NO	NO	NO	NO	NO
	PRESET	PRESET-	RECEIVER	MAIN	7F01-5E21	7F01-5E20	YES	YES	YES	NO	NO
				ZONE2	7F01-5F20	7F01-5F21	NO	NO	NO	NO	NO
				ZONE3	7F01-601F	7F01-601E	NO	NO	NO	NO	NO
				ZONE4	7F01-6B14	7F01-6B15	NO	NO	NO	NO	NO
		PRESET+	RECEIVER	MAIN	7F01-5B24	7F01-5B25	YES	YES	YES	NO	NO
				ZONE2	7F01-5C23	7F01-5C22	NO	NO	NO	NO	NO
				ZONE3	7F01-5D22	7F01-5D23	NO	NO	NO	NO	NO
				ZONE4	7F01-6A15	7F01-6A14	NO	NO	NO	NO	NO
	CATEGORY/BAND	FM	RECEIVER	MAIN	7F01-5827	7F01-5826	YES	YES	YES	NO	NO
				ZONE2	7F01-5926	7F01-5927	NO	NO	NO	NO	NO
				ZONE3	7F01-5A25	7F01-5A24	NO	NO	NO	NO	NO
				ZONE4	7F01-7D02	7F01-7D03	NO	NO	NO	NO	NO
		AM (DAB: DAB model)	RECEIVER	MAIN	7F01-552A	7F01-552B	YES	YES	YES	NO	NO
				ZONE2	7F01-5629	7F01-5628	NO	NO	NO	NO	NO
				ZONE3	7F01-5728	7F01-5729	NO	NO	NO	NO	NO
				ZONE4	7F01-7C03	7F01-7C02	NO	NO	NO	NO	NO
	TUNING/CH	TUNING-	RECEIVER	MAIN	7F01-641B	7F01-641A	YES	YES	YES	NO	NO
				ZONE2	7F01-651A	7F01-651B	NO	NO	NO	NO	NO
				ZONE3	7F01-6619	7F01-6618	NO	NO	NO	NO	NO
				ZONE4	7F01-7F00	7F01-7F01	NO	NO	NO	NO	NO
		TUNING+	RECEIVER	MAIN	7F01-611E	7F01-611F	YES	YES	YES	NO	NO
				ZONE2	7F01-621D	7F01-621C	NO	NO	NO	NO	NO
				ZONE3	7F01-631C	7F01-631D	NO	NO	NO	NO	NO
				ZONE4	7F01-7E01	7F01-7E00	NO	NO	NO	NO	NO
NUMBER/CHARACTER	1		RECEIVER	MAIN	7F01-51	7F01-51AF	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-71	7F01-718F	NO	NO	NO	YES	YES
				ZONE3	7F01-91	7F01-916F	NO	NO	NO	NO	NO
				ZONE4	7F01-B1	7F01-B14F	NO	NO	NO	NO	NO
	2		RECEIVER	MAIN	7F01-52	7F01-52AC	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-72	7F01-728C	NO	NO	NO	YES	YES
				ZONE3	7F01-92	7F01-926C	NO	NO	NO	NO	NO
				ZONE4	7F01-B2	7F01-B24C	NO	NO	NO	NO	NO
	3		RECEIVER	MAIN	7F01-53	7F01-53AD	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-73	7F01-738D	NO	NO	NO	YES	YES
				ZONE3	7F01-93	7F01-936D	NO	NO	NO	NO	NO
				ZONE4	7F01-B3	7F01-B34D	NO	NO	NO	NO	NO
	4		RECEIVER	MAIN	7F01-54	7F01-54AA	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-74	7F01-748A	NO	NO	NO	YES	YES
				ZONE3	7F01-94	7F01-946A	NO	NO	NO	NO	NO
				ZONE4	7F01-B4	7F01-B44A	NO	NO	NO	NO	NO
	5		RECEIVER	MAIN	7F01-55	7F01-55AB	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-75	7F01-758B	NO	NO	NO	YES	YES
				ZONE3	7F01-95	7F01-956B	NO	NO	NO	NO	NO
				ZONE4	7F01-B5	7F01-B54B	NO	NO	NO	NO	NO
	6		RECEIVER	MAIN	7F01-56	7F01-56A8	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-76	7F01-7688	NO	NO	NO	YES	YES
				ZONE3	7F01-96	7F01-9668	NO	NO	NO	NO	NO
				ZONE4	7F01-B6	7F01-B648	NO	NO	NO	NO	NO
	7		RECEIVER	MAIN	7F01-57	7F01-57A9	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-77	7F01-7789	NO	NO	NO	YES	YES
				ZONE3	7F01-97	7F01-9769	NO	NO	NO	NO	NO
				ZONE4	7F01-B7	7F01-B749	NO	NO	NO	NO	NO
	8		RECEIVER	MAIN	7F01-58	7F01-58A6	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-78	7F01-7886	NO	NO	NO	YES	YES
				ZONE3	7F01-98	7F01-9866	NO	NO	NO	NO	NO
				ZONE4	7F01-B8	7F01-B846	NO	NO	NO	NO	NO
	9		RECEIVER	MAIN	7F01-59	7F01-59A7	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-79	7F01-7987	NO	NO	NO	YES	YES
				ZONE3	7F01-99	7F01-9967	NO	NO	NO	NO	NO
				ZONE4	7F01-B9	7F01-B947	NO	NO	NO	NO	NO
	0		RECEIVER	MAIN	7F01-5A	7F01-5AA4	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-7A	7F01-7A84	NO	NO	NO	YES	YES
				ZONE3	7F01-9A	7F01-9A64	NO	NO	NO	NO	NO
				ZONE4	7F01-BA	7F01-BA44	NO	NO	NO	NO	NO
	+10 or MEMORY		RECEIVER	MAIN	7F01-5B	7F01-5BA5	NO	NO	NO	YES(MEMORY)	YES(MEMORY)
				ZONE2	7F01-7B	7F01-7B85	NO	NO	NO	NO	NO
				ZONE3	7F01-9B	7F01-9B65	NO	NO	NO	NO	NO
				ZONE4	7F01-BB	7F01-BB45	NO	NO	NO	NO	NO
	ENT		RECEIVER	MAIN	7F01-5C	7F01-5CA2	YES*except A No key	YES	YES	YES	YES
				ZONE2	7F01-7C	7F01-7C82	NO	NO	NO	YES	YES
				ZONE3	7F01-9C	7F01-9C62	NO	NO	NO	NO	NO
				ZONE4	7F01-BC	7F01-BC42	NO	NO	NO	NO	NO