CYRUS AV5 REMOTE CODES

RC5 REMOTE SYSTEM 19

Code	RC5 Amplifier 2 (19)	Cyrus AV5 & AV8
0	0	
1	1	Input 1*
2	2	Input 2*
3	3	Input 3*
4	4	Input 4*
5	5	Input 5*
6	6	Input 6*
7	7	Input 7*
8	8	Input 8*
9	9	Input 9*
10	GEQ L	
11	GEQ R	
12	Standby	Standby
13	Mute/Demute	Mute
14	Personal preference	
15	Display	Display off**
16	Volume +	Volume up
17	Volume -	Volume down
18	Brightness +	
19	Brightness -	
20	Colour Sat +	
21	Colour Sat -	
22	Bass +	
23	Bass -	
24	Treble +	
25	Treble -	
26	Balance Right	
27	Balance Left	
28	GEQ L+R	
29	Loudness	
30	High tone filter	
31	Low tone filter	
32	Up	Next input
33	Down	Prev input
34	Signal path scroll	
35	Speaker select	
36		
37	Surround mode	Stereo
38	Sleeptimer	
39	Balance rear	
40	Balance front	
41	T-P-S	
42	Timer set	
43	Timer up	
44	Timer down	
45	Timer memo	
46	Acoustic memory	
47	Select acoustic memory	
48	Pause	
49	Erase (Correct/clear entry)	
50	Rewind/Fast run reverse	
51	Go to	
52	Wind/Fast run forward	
53	Play	
54	Stop	
55	Recording	
56	Connect (External 1)	
57	Disconnect (External 2)	
58		
59		Power off
60	Dynamic range	
61	System standby	
62		Power on
63	System select	

Code	RC5 Amplifier 2 (19)	Cyrus AV5 & AV8
64		
65		
66		
67		
68		
69		
70		
71		
72		
73		
74		
75		
76		
77		
78		
79		
80		Adjust up
81		Adjust down
82		
83		Exit
84		
85		
86		
87		
88		Noise setup
89		
90		
91		Left front select
92		Centre select
93		Right front select
94		
95		
96		
97		
98		Left surround select
99		
100		Right surround select
101		
102		
103		
104		
105		
106		
107		
108		
109		
110		Inputs setup
111		Mode setup
112		
113		
114		
115		
116		
117		
118		Subwoofer select
119		
120		
121		
122		
123		
124		
125		
126		
127		

NOTE:- Codes marked * are available for all AV8 or AV5 from software version 1.2 only.
NOTE:- Codes marked ** are available for AV8 only from software version 1.2.