AMPLIFIER REMOTE CODE TABLE

Code	RC5 Amplifier 1 (16)	Cyrus 3i
0	0	
1	1	
2	2	
3	3	
4	4	
5	5	
6	6	
7	7	
8	8	
9	9	
10	GEQ L	
11	GEQ R	
12	Standby	Standby
13	Mute/Demute	Mute
14	Personal preference	
15	Display	
16	Volume +	Volume +
17	Volume -	Volume -
18	Brightness +	
19	Brightness -	
20	Colour Sat +	
21	Colour Sat -	
22	Bass +	
23	Bass -	
24	Treble +	Input inc
25	Treble -	Input dec
26	Balance Right	
27	Balance Left	
28	GEQ L+R	
29	Loudness	
30	High tone filter	
31	Low tone filter	
32	Up	
33	Down	
34	Signal path scroll	
35	Speaker select	
36		
37	Surround mode	
38	Sleeptimer	
39	Balance rear	
40	Balance front	Balance select
41	T-P-S	
42	Timer set	
43	Timer up	
44	Timer down	
45	Timer memo	
46	Acoustic memory	
47	Select acoustic memory	
48	Pause	Phono
49	Erase (Correct/clear entry)	CD
50	Rewind/Fast run reverse	Tuner
51	Go to	Video
52	Wind/Fast run forward	Aux
53	Play	SP
54	Stop	Tape monitor
55	Recording	
56	Connect (External 1)	
57	Disconnect (External 2)	
58		
59		Power on
60	Dynamic range	
61	System standby	
62		Power off (standby)
63	System select	