AMPLIFIER REMOTE CODE TABLE

SYSTEM ADDRESS 16

Code	Philips RC5 Amplifier 1	Cyrus FM7/FM7.5
0	0	0
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	GEQ L	
11	GEQ R	
12	Standby	
13	Mute/Demute	
14	Personal preference	Fine
15	Display	Display
16	Volume +	
17	Volume -	
18	Brightness +	
19	Brightness -	
20	Colour Sat +	
21	Colour Sat -	
22	Bass +	
23	Bass -	
24	Treble +	
25	Treble -	
26	Balance Right	
27	Balance Left	
28	GEQ L+R	
29	Loudness	
30	High tone filter	Seek>
31	Low tone filter	<Seek
32	Up	Next preset
33	Down	Prev preset
34	Signal path scroll	
35	Speaker select	
36		
37	Surround mode	
38	Sleeptimer	
39	Balance rear	
40	Balance front	
41	T-P-S	Store
42	Timer set	
43	Timer up	
44	Timer down	
45	Timer memo	
46	Acoustic memory	
47	Select acoustic memory	
48	Pause	
49	Erase (Correct/clear entry)	
50	Rewind/Fast run reverse	*Power on*
51	Go to	
52	Wind/Fast run forward	
53	Play	
54	Stop	
55	Recording	
56	Connect (External 1)	
57	Disconnect (External 2)	Standby
58		Mono
59		
60	Dynamic range	
61	System standby	
62		Power off (standby)
63	System select	