PHLIPS RC5 DEVICE SYSTEM 19

Code	RC5 Amplifier 2 (19)	Cyrus AV master
0	0	Preset 0
1	1	Preset 1
2	2	Preset 2
3	3	Preset 3
4	4	Preset 4
5	5	Preset 5
6	6	Preset 6
7	7	Preset 7
8	8	Preset 8
9	9	Preset 9
10	GEQ L	
11	GEQ R	
12	Standby	Standby
13	Mute/Demute	Mute
14	Personal preference	
15	Display	Display
16	Volume +	Master volume +
17	Volume -	Master volume -
18	Brightness +	Centre level +
19	Brightness -	Centre level -
20	Colour Sat +	Rear level +
21	Colour Sat -	Rear level -
22	Bass +	Sub bass level +
23	Bass -	Sub bass level -
24	Treble +	Input inc
25	Treble -	Input dec
26	Balance Right	
27	Balance Left	
28	GEQ L+R	
29	Loudness	
30	High tone filter	Preset inc
31	Low tone filter	Preset dec
32	Up	Next dolby mode
33	Down	Previous dolby mode
34	Signal path scroll	
35	Speaker select	Centre select
36		Rear select
37	Surround mode	Subwoofer select
38	Sleeptimer	
39	Balance rear	
40	Balance front	Balance front
41	T-P-S	Store
42	Timer set	
43	Timer up	
44	Timer down	
45	Timer memo	
46	Acoustic memory	
47	Select acoustic memory	
48	Pause	No longer used
49	Erase (Correct/clear entry)	
50	Rewind/Fast run reverse	Decrement time delay
51	Go to	
52	Wind/Fast run forward	Increment time delay
53	Play	No longer used
54	Stop	Input inc
55	Recording	
56	Connect (External 1)	
57	Disconnect (External 2)	
58		
59		Power on
60	Dynamic range	
61	System standby	
62		Power off
63	System select	