CD PLAYER REMOTE CODE TABLE

Code	RC5 CD (20)	Cyrus CD
0	0	0
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	Cursor scroll	
11	Display scroll	Track/time
12	Standby	Standby
13	Mute/Demute	
14	Personal preference	
15	Display	Display on/off
16	Volume +	
17	Volume -	
18	Brightness +	
19	Brightness -	
20	Colour Sat +	
21	Colour Sat -	
22	Bass +	
23	Bass -	
24	Treble +	
25	Treble -	
26	Balance Right	
27	Balance Left	
28	Repeat once	
29	Repeat continuous	Repeat
30	Select +	
31	Select -	
32	Next	Next
33	Previous	Previous
34	Index next	
35	Index previous	
36	Play/program	
37	Speed nominal	
38	Speed +	
39	Speed -	
40		Phase
41	Store execute	Store
42		
43	Scan forward	
44		
45	Open/Close	
46		Power on
47	Fast	
48	Pause	Pause
49	Erase (Correct/clear entry)	
50	Rewind/Fast run reverse	<Fast search(X1)
51	Go to	
52	Wind/Fast run forward	Fast search(X1)>
53	Play	Play
54	Stop	Stop
55	Recording	
56	Connect (External 1)	
57	Disconnect (External 2)	
58	Clear all memories	
59	Repeat (A/B program)	
60	Dynamic range expand	
61	System standby	
62	Dynamic range compress	Power off (standby)
63	System select	