Code	RC5 Combi systems (21)	Cyrus Quattro, quattro mode
0	0	0
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10		
11	Display scroll	
12	Standby	Standby
13	Mute/Demute	Mute
14		
15	Display	
16	Volume +	Volume +
17	Volume -	Volume -
18	Brightness +	
19	Brightness -	
20		
21		
22	Bass +	
23	Bass -	
24	Treble +	
25	Treble -	
26	Balance Right	
27	Balance Left	
28	TSP/repeat once	
29	Repeat continuous	Repeat
30	Select +	
31	Select -	
32	Next	Next
33	Previous	Previous
34	Index next	
35	Index previous	
36		
37	Stereo/mono	
38	Sleep timer	
39		
40	Synchro start	
41	Store execute	Store preset
42		
43	Scan forward	
44		
45	Open/Close	
46	Waveband scroll	FM select/mono toggle
47	Alarm on/off	
48	Pause	
49	se (Correct/clear entry)	
50		<Fast search(X1)
51		
52		Fast search(X1)>
53	Play	Play/pause
54	Stop	Stop (not open!)
55		CD select
56		Aux select
57		Tape select
58	Clear all memories	
59	Repeat (A/B program)	
60		
61		
62		
63	System select	