Extended IR codes

*A: Australia model, C: Canada model, E: Europe model, J: Japan Model, U: USA model

Function			Device		FullCode(ID1)	RX-A730	RX-A830
Group	Name			Zone			
POWER	POWER	ON	RECEIVER	MAIN	7E81-7E81	YES	YES
				ZONE2	7E81-BA45	YES	YES
				ZONE3	7A85-ED12	NO	NO
				ZONE4	7A85-7B84	NO	NO
				ALL	7A85-1DE2	YES	YES
	STANDBY	OFF	RECEIVER	MAIN	7E81-7F80	YES	YES
				ZONE2	7E81-BB44	YES	YES
				ZONE3	7A85-EE11	NO	NO
				ZONE4	7A85-7C83	NO	NO
				ALL	7A85-1EE1	YES	YES
	SLEEP	TOGGLE	RECEIVER	ALL	7A85-57A8	YES	YES
		ON	RECEIVER	MAIN	7E81-1669	YES	YES
				ZONE2	7E81-1768	YES	YES
				ZONE3	7E81-1867	NO	NO
				ZONE4	7E81-1966	NO	NO
				ALL	7E81-1A65	YES	YES
		OFF	RECEIVER	MAIN	7E81-1B64	YES	YES
				ZONE2	7E81-1C63	YES	YES
				ZONE3	7E81-1D62	NO	NO
				ZONE4	7E81-1E61	NO	NO
				ALL	7E81-B34C	YES	YES
		120min	RECEIVER	ALL	7E81-B44B	YES	YES
		90min	RECEIVER	ALL	7E81-B54A	YES	YES
		60min	RECEIVER	ALL	7E81-B649	YES	YES
		30min	RECEIVER	ALL	7E81-B748	YES	YES
INPUT	AUDIO SEL	AUTO	RECEIVER	MAIN	7E81-A659	NO	NO
		HDMI	RECEIVER	MAIN	7E81-DA25	NO	NO
		COAX/OPT	RECEIVER	MAIN	7E81-A956	NO	NO
		ANALOG	RECEIVER	MAIN	7E81-AA55	NO	NO
	SUB INPUT	PC/MCX	RECEIVER	MAIN	7F01-6C13	YES	YES
				ZONE2	7F01-6D12	YES	YES
				ZONE3	7F01-6E11	NO	NO
				ZONE4	7F01-7807	NO	NO
		NET RADIO	RECEIVER	MAIN	7F01-6F10	YES	YES
				ZONE2	7F01-700F	YES	YES
				ZONE3	7F01-710E	NO	NO
				ZONE4	7F01-7906	NO	NO
		Rhapsody Napster	RECEIVER	MAIN	7F01-750A	YES*UCE	YES*UCE
				ZONE2	7F01-7609	YES*UCE	YES*UCE
				ZONE3	7F01-7708	NO	NO
				ZONE4	7F01-7B04	NO	NO
		Pandora	RECEIVER	MAIN	7F01-85FA	YES*UCA	YES*UCA
				ZONE2	7F01-86F9	YES*UCA	YES*UCA
				ZONE3	7F01-87F8	NO	NO
				ZONE4	7F01-88F7	NO	NO
		Sirius Internet Radio	RECEIVER	MAIN	7F01-81FE	YES*UC	YES*UC
				ZONE2	7F01-82FD	YES*UC	YES*UC
				ZONE3	7F01-83FC	NO	NO
				ZONE4	7F01-84FB	NO	NO
		AirPlay	RECEIVER	MAIN	7F01-91EE	YES	YES
				ZONE2	7F01-92ED	YES	YES
				ZONE3	7F01-93EC	NO	NO
				ZONE4	7F01-94EB	NO	NO
OUTPUT	HDMI OUT 1	ON	RECEIVER	ALL	7E81-205F	YES	YES
		OFF	RECEIVER	ALL	7E81-B0CF	YES	YES
	HDMI OUT 2	ON	RECEIVER	ALL	7E81-215E	NO	YES
		OFF	RECEIVER	ALL	7E81-B1CE	NO	YES
VOLUME	MUTE	ON (FULL)	RECEIVER	MAIN	7E81-A25D	YES	YES
				ZONE2	7E81-A05F	YES	YES
				ZONE3	7E81-26D9	NO	NO
				ZONE4	7E81-0C73	NO	NO
				ALL	7E81-2758	NO	NO
		ON (-40dB)	RECEIVER	MAIN	7E81-631C	YES	YES
				ZONE2	7E81-641B	YES	YES
				ZONE3	7E81-651A	NO	NO
				ZONE4	7E81-6619	NO	NO
				ALL	7E81-6718	NO	NO
		ON (-20dB)	RECEIVER	MAIN	7E81-DF20	YES	YES
				ZONE2	7E81-2956	YES	YES
				ZONE3	7E81-2A55	NO	NO
				ZONE4	7E81-2B54	NO	NO
				ALL	7E81-2C53	NO	NO
		OFF	RECEIVER	MAIN	7E81-A35C	YES	YES
				ZONE2	7E81-A15E	YES	YES
				ZONE3	7E81-6699	NO	NO
				ZONE4	7E81-0D72	NO	NO
				ALL	7E81-2857	NO	NO
DISPLAY	SMART ZOOM	ON	RECEIVER	MAIN	7E81-225D	NO	NO
		OFF (THROUGH)	RECEIVER	MAIN	7E81-235C	NO	NO
PROGRAM	PURE DIRECT or DIRECT	ON	RECEIVER	MAIN	7E81-807F	YES	YES
		OFF	RECEIVER	MAIN	7E81-827D	YES	YES
	STRAIGHT	ON	RECEIVER	MAIN	7E81-E01F	YES	YES
		OFF	RECEIVER	MAIN	7E81-27D8	YES	YES
	PROGRAM	Hall in Munich (A)	RECEIVER	MAIN	7E81-E11E	YES	YES
		Hall in Munich B	RECEIVER	MAIN	7E81-E21D	NO	NO
		Hall in Frankfurt	RECEIVER	MAIN	7E81-E31C	NO	NO
		Hall in Stuttgart	RECEIVER	MAIN	7E81-E41B	NO	NO
		Hall in Vienna	RECEIVER	MAIN	7E81-E51A	YES	YES
		Hall in Amsterdam	RECEIVER	MAIN	7E81-E619	NO	NO
		Hall in USA A	RECEIVER	MAIN	7E81-C43B	NO	NO
		Hall in USA B	RECEIVER	MAIN	7E81-C53A	NO	NO
		Church in Tokyo	RECEIVER	MAIN	7E81-E718	NO	NO
		Church in Freiburg	RECEIVER	MAIN	7E81-E817	NO	NO
		Church in Royaumont	RECEIVER	MAIN	7E81-E916	NO	NO
		Chamber	RECEIVER	MAIN	7E81-AF50	YES	YES
		Village Gate	RECEIVER	MAIN	7E81-EA15	NO	NO
		Village Vanguard	RECEIVER	MAIN	7E81-EB14	NO	NO
		Warehouse Loft	RECEIVER	MAIN	7E81-EE11	NO	NO
		Cellar Club	RECEIVER	MAIN	7E81-CD32	YES	YES
		The Roxy Theatre	RECEIVER	MAIN	7E81-ED12	YES	YES
		The Bottom Line	RECEIVER	MAIN	7E81-EC13	YES	YES
		Arena	RECEIVER	MAIN	7E81-EF10	YES	YES
		Sports	RECEIVER	MAIN	7E81-F807	YES	YES
		Action Game	RECEIVER	MAIN	7E81-F20D	YES	YES
		Roleplaying Game	RECEIVER	MAIN	7E81-CE31	YES	YES
		Music Video	RECEIVER	MAIN	7E81-F30C	YES	YES
		Recital/Opera	RECEIVER	MAIN	7E81-F50A	NO	NO
		Pavilion	RECEIVER	MAIN	7E81-F609	NO	NO
		Disco	RECEIVER	MAIN	7E81-F00F	NO	NO
		Standard	RECEIVER	MAIN	7E81-FE01	YES	YES
		Spectacle	RECEIVER	MAIN	7E81-F906	YES	YES
		Sci-Fi	RECEIVER	MAIN	7E81-FA05	YES	YES
		Adventure	RECEIVER	MAIN	7E81-FB04	YES	YES
		Drama	RECEIVER	MAIN	7E81-FC03	YES	YES
		Mono Movie	RECEIVER	MAIN	7E81-F708	YES	YES
		2ch Stereo	RECEIVER	MAIN	7E81-C03F	YES	YES

		Xch Stereo	RECEIVER	MAIN	7E81-FF00	YES	YES
	SUR. DECODE	ON	RECEIVER	MAIN	7E81-FD02	YES	YES
	ENHANCER	AUTO	RECEIVER	MAIN	7E81-D827	YES	YES
		OFF	RECEIVER	MAIN	7E81-D926	YES	YES
	TONE CONTROL	BASS +	RECEIVER	ZONE2	7A85-738C	NO	NO
			RECEIVER	ZONE3	7A85-7788	NO	NO
			RECEIVER	ZONE4	7E81-433C	NO	NO
		BASS −	RECEIVER	ZONE2	7A85-748B	NO	NO
			RECEIVER	ZONE3	7A85-7887	NO	NO
			RECEIVER	ZONE4	7E81-443B	NO	NO
		TREBLE +	RECEIVER	ZONE2	7A85-758A	NO	NO
			RECEIVER	ZONE3	7A85-7986	NO	NO
			RECEIVER	ZONE4	7E81-453A	NO	NO
		TREBLE −	RECEIVER	ZONE2	7A85-7689	NO	NO
			RECEIVER	ZONE3	7A85-7A85	NO	NO
			RECEIVER	ZONE4	7E81-4639	NO	NO
	BALANCE	LEFT	RECEIVER	ZONE2	7E81-D42B	NO	NO
			RECEIVER	ZONE3	7E81-D629	NO	NO
			RECEIVER	ZONE4	7E81-4738	NO	NO
		RIGHT	RECEIVER	ZONE2	7E81-D52A	NO	NO
			RECEIVER	ZONE3	7E81-D728	NO	NO
			RECEIVER	ZONE4	7E81-4837	NO	NO
MENU	SUR. DECODE	PLII(IIx) MOVIE	RECEIVER	MAIN	7E81-6798	YES	YES
		PLII(IIx) MUSIC	RECEIVER	MAIN	7E81-6897	YES	YES
		PLII(IIx) GAME	RECEIVER	MAIN	7E81-C738	YES	YES
		NEO:6 CINEMA	RECEIVER	MAIN	7E81-6996	YES	YES
		NEO:6 MUSIC	RECEIVER	MAIN	7E81-6A95	YES	YES
		Prologic	RECEIVER	MAIN	7E81-C936	YES	YES
	EXTED SURROUND	AUTO	RECEIVER	MAIN	7E81-7C83	YES	YES
		PLIIx MOVIE	RECEIVER	MAIN	7E81-DD22	YES	YES
		PLIIx MUSIC	RECEIVER	MAIN	7E81-DE21	YES	YES
		ON(EX/ES)	RECEIVER	MAIN	7E81-B847	YES	YES
		OFF	RECEIVER	MAIN	7E81-B946	YES	YES
	HDMI Auto Lipsync	ON	RECEIVER	MAIN	7E81-83FC	YES	YES
		OFF(MANUAL)	RECEIVER	MAIN	7E81-84FB	YES	YES
	DUAL MONO	MAIN	RECEIVER	MAIN	7E81-936C	YES*J	YES*J
		SUB	RECEIVER	MAIN	7E81-946B	YES*J	YES*J
		ALL	RECEIVER	MAIN	7E81-956A	YES*J	YES*J
	ADAPTIVE DRC	ON	RECEIVER	MAIN	7E81-740B	YES	YES
		OFF	RECEIVER	MAIN	7E81-750A	YES	YES
	ADAPTIVE DSP	ON	RECEIVER	MAIN	7E81-7609	YES	YES
		OFF	RECEIVER	MAIN	7E81-7708	YES	YES
	TRIGGER 1	MANUAL ON	RECEIVER	ALL	7E81-3F40	YES	YES
		MANUAL OFF	RECEIVER	ALL	7E81-403F	YES	YES
	TRIGGER 2	MANUAL ON	RECEIVER	ALL	7E81-413E	NO	NO
		MANUAL OFF	RECEIVER	ALL	7E81-423D	NO	NO
	DIALOGUE LEVEL	0	RECEIVER	MAIN	7E81-B4CB	YES	YES
		1	RECEIVER	MAIN	7E81-B5CA	YES	YES
		2	RECEIVER	MAIN	7E81-B6C9	YES	YES
		3	RECEIVER	MAIN	7E81-B7C8	YES	YES
MEMORY	SCENE	5	RECEIVER	MAIN	7A85-90EF	NO	NO
		6	RECEIVER	MAIN	7A85-91EE	NO	NO
		7	RECEIVER	MAIN	7A85-92ED	NO	NO
		8	RECEIVER	MAIN	7A85-93EC	NO	NO
		9	RECEIVER	MAIN	7A85-94EB	NO	NO
		10	RECEIVER	MAIN	7A85-95EA	NO	NO
		11	RECEIVER	MAIN	7A85-96E9	NO	NO
		12	RECEIVER	MAIN	7A85-97E8	NO	NO
	VOLUME MEMORY	1	RECEIVER	MAIN	7E81-6B94	YES	YES
				ZONE2	7E81-8778	YES	YES
				ZONE3	7E81-20DF	NO	NO
				ZONE4	7E81-007F	NO	NO
		2	RECEIVER	MAIN	7E81-6C93	YES	YES
				ZONE2	7E81-8877	YES	YES
				ZONE3	7E81-21DE	NO	NO
				ZONE4	7E81-017E	NO	NO
		3	RECEIVER	MAIN	7E81-6D92	YES	YES
				ZONE2	7E81-8976	YES	YES
				ZONE3	7E81-22DD	NO	NO
				ZONE4	7E81-027D	NO	NO
		4	RECEIVER	MAIN	7E81-6E91	YES	YES
				ZONE2	7E81-8A75	YES	YES
				ZONE3	7E81-23DC	NO	NO
				ZONE4	7E81-037C	NO	NO
		5	RECEIVER	MAIN	7E81-6F90	YES	YES
				ZONE2	7E81-8B74	YES	YES
				ZONE3	7E81-24DB	NO	NO
				ZONE4	7E81-047B	NO	NO
		6	RECEIVER	MAIN	7E81-708F	YES	YES
				ZONE2	7E81-8C73	YES	YES
				ZONE3	7E81-25DA	NO	NO
				ZONE4	7E81-057A	NO	NO
	VOLUME RECALL	1	RECEIVER	MAIN	7E81-758A	YES	YES
				ZONE2	7E81-8D72	YES	YES
				ZONE3	7E81-609F	NO	NO
				ZONE4	7E81-0679	NO	NO
		2	RECEIVER	MAIN	7E81-7689	YES	YES
				ZONE2	7E81-8E71	YES	YES
				ZONE3	7E81-619E	NO	NO
				ZONE4	7E81-0778	NO	NO
		3	RECEIVER	MAIN	7E81-7788	YES	YES
				ZONE2	7E81-8F70	YES	YES
				ZONE3	7E81-629D	NO	NO
				ZONE4	7E81-0877	NO	NO
		4	RECEIVER	MAIN	7E81-7887	YES	YES
				ZONE2	7E81-906F	YES	YES
				ZONE3	7E81-639C	NO	NO
				ZONE4	7E81-0976	NO	NO
		5	RECEIVER	MAIN	7E81-7986	YES	YES
				ZONE2	7E81-916E	YES	YES
				ZONE3	7E81-649B	NO	NO
				ZONE4	7E81-0A75	NO	NO
		6	RECEIVER	MAIN	7E81-7A85	YES	YES
				ZONE2	7E81-926D	YES	YES
				ZONE3	7E81-659A	NO	NO
				ZONE4	7E81-0B74	NO	NO
	VIDEO PRESET	1	RECEIVER	MAIN	7E81-A4DB	NO	NO
		2	RECEIVER	MAIN	7E81-A5DA	NO	NO
		3	RECEIVER	MAIN	7E81-A6D9	NO	NO
		4	RECEIVER	MAIN	7E81-A7D8	NO	NO
		5	RECEIVER	MAIN	7E81-A8D7	NO	NO
		6	RECEIVER	MAIN	7E81-A9D6	NO	NO
ZONE CONTROL	PARTY	ON	RECEIVER	ALL	7E81-354A	NO	YES
		OFF	RECEIVER	ALL	7E81-3649	NO	YES
MENU	SRCH MODE	PRESET	TUNER HD-Radio	ALL	7F01-FD02	YES	YES
		MANUAL			7F01-FE01	YES	YES
		TOGGLE			7A85-AB54	YES	YES
INPUT	BAND	FM			7E81-BC43	YES	YES
		AM			7E81-BD42	YES	YES
OPERATION	AUTO TUNING	UP			7E81-BE41	YES	YES
		DOWN			7E81-BF40	YES	YES
	TUNING/ PRESET No.	UP			7A85-10EF	YES	YES
		DOWN			7A85-11EE	YES	YES