

NORMAL PROCEDURES

DA62

BEFORE START

In reach / PLB	CLIPPED
Pre flight / Walk around	DONE
Tow bar	REMOVED
Chocks / Tie downs	REMOVED
Covers (pitot / engine...)	REMOVED
Fuel caps	CLOSED FORWARD
Passengers	BRIEFED
Doors	UNLOCKED / CLOSED
Seats	UPRIGHT
Seat belts	FASTENED
Landing gear	DOWN
Alternate air	CLOSED
Alternate static	CLOSED
A/C Alternator	OFF
Switches	ALL OFF
Anti icing	OFF
ELT	ARMED
ECU	AUTO
Alternators	ON

PREPARE PANEL

Navigation DB	CHECK CURRENT
Transponder	SET FLT ID
Fuel totalizer	SET
Time in service	NOTE
Gear warning	TEST

ENGINES START

Current time	NOTE
Strobe / position lights	ON

REPEAT LEFT AND RIGHT

Prop area	CLEAR
Engine master	ON
Glow	WAIT
Starter	ENGAGE
Oil pressure	CHECK
Alternator	CHECK ONLINE
CAS Alerts	NONE

AFTER BOTH ENGINES STARTED

Avionics	ON
AP self test	VERIFY
Circuit breakers	ALL IN
Fuel selectors	CROSS FEED
Intercom	CHECK

TAXI CHECKLIST

iPad Bluetooth	CONNECTED
ATIS	GET
Clearance	REQUEST
Flight plan	LOADED
Pitot heat	TEST
Autopilot	TEST
Flight director	OFF
Electric trim	TEST UP/DOWN
Trim	TAKEOFF
Rudder trim	CENTERED
HSI	MATCH w/ COMPASS
AHRS	BOTH LEVEL
MFD	TAXI MAP
Terrain display	AS REQD
Fuel selectors	NORMAL
Flaps	CYCLE / TO
Taxi instructions	REQUEST

BEFORE TAKEOFF

Engines	WARM UP
Transponder	CODE / FLT ID
Seat belts	ON
Doors	CLOSED
Windows	CLOSED
Baggage doors	CLOSED
Fuel selectors	NORMAL
Circuit breakers	ALL IN
Lights	ALL ON
Expected power	BRIEF
Fuel levels	BALANCED
Flaps	T/O
Trim	TAKEOFF
Hdg ALT Bugs	SET
Climb power altitude	SET
Altimeter	CHECK BOTH
Flight director	FLC 95 + Lateral
Departure alternate	BRIEF
Takeoff briefing	DO
O2 Cannulas	AS REQD
Fuel pumps	OFF
Temperatures	GREEN
ECU	CYCLE A/B/AUTO
ECU Test	HOLD
CAS Alerts	CHECK
Fuel pumps	ON
Flight controls	FREE

CLEARED FOR TAKEOFF

Wind	CHECK
Pitot heat	AS REQD
Anti icing	AS REQD
Alternate air	AS REQD
Radar	AS REQD
Flow	TRIM PUMPS GEAR FLAPS LIGHTS

CLIMB

Landing gear	UP / LIGHTS OFF
Flaps	UP
Pumps	OFF
Power	MCT
Alternate air	AS REQD
Pitot heat	AS REQD
LNAV	CHECK

CRUISE

Power	75% MAX
Alternate air	AS REQD
Air conditioning	AS REQD
Lights	AS REQD
Fuel	BALANCED
Radar	AS REQD
Aux tanks	PREPARE
Guard 121.5	MONITOR
iPad	CHARGING
LNAV	CHECK
VNAV	SET

DESCENT

ATIS	GET
COM2	TWR GND
Lights	ALL ON
Gear warning	TEST
LNAV	CHECK
VNAV	CHECK
Parking brake	RELEASE
Brakes	PUMP
Tanks	BALANCED
Aux tanks	EMPTY
Seat belts	FASTENED
Approach	LOADED / BRIEFED
Minimums	VERIFY
Alternate air	AS REQD
Anti icing	AS REQD
Radar	AS REQD
A/C	AS REQD
Taxi layout	BRIEF

LANDING

Alternate air	AS REQD
Rudder trim	AS REQD

FINAL CHECK

Flow	PUMPS GEAR FLAPS LIGHTS AP
------	----------------------------

AFTER LANDING

Alternate air	CLOSED
Pitot heat	OFF
Flaps	UP
Fuel pumps	OFF
Lights	AS REQD
Anti icing	OFF
Flight plan	CLOSE

SHUTDOWN

Oxygen	CLOSED
A/C Alternator	OFF
Parking brake	AS REQD
Power	MAX 10% 1 MIN
ELT	NOT ACTIVE
Lights	ONLY STROBE
Internal lights	ALL OFF
Avionics	OFF
Engine masters	BOTH OFF
Strobes	OFF

Wait for Xs on both engines

Current time	NOTE
Transponder	CHK FLT ID
Time in service	NOTE
MASTER OFF - GOOD BYE	

EMERGENCY PROCEDURES

DA62

ENGINE TROUBLESHOOTING

Power lever **IDLE 1 SECOND**
Power lever

..... **SLOWLY TO 1975 RPM**

If engine fails again, maintain maximum possible power

Circuit breakers **CHECK**

ECU Voter **CYCLE / AUTO**

Above 10,000' **FUEL PUMP ON**

Fuel selector **CROSS FEED**

Alternate air **OPEN**

ENGINE FAILURE

Power good engine **AS REQD**

Airspeed **> BLUE LINE**

Landing gear **UP**

Flaps **UP**

Failed engine **VERIFY / SECURE**

Alternator failed engine **OFF**

Fuel pump failed engine **OFF**

Fuel selector failed engine **OFF**

Fuel balance **MONITOR**

Transponder **7700**

Emergency **DECLARE**

LNAV **DIVERT**

ENGINES OUT LANDING

Engine masters **OFF**

Speed **BLUE LINE**

Transponder **7700**

Mayday mayday **DECLARE**

Alternators **OFF**

Fuel pumps **OFF**

Fuel selectors **OFF**

Seat belts **TIGHT**

Flaps **AS REQD**

GEAR UP

Electric master **KEEP ON**

GEAR DOWN

Landing gear **DOWN / LOCKED**

DITCHING

Landing gear **UP**

Engine masters **OFF**

Transponder **7700**

Mayday mayday **DECLARE**

HEAVY SWELL

Ditch parallel to swell

HEAVY WIND

Ditch into the wind

Touch down pitch level

Do not flare

RPM PROBLEMS

Power lever **SWEEP**

ECU Voter **CYCLE / AUTO**

Expect engine failure

ENGINE FIRE

Cabin heat / defrost **OFF**

Windows **OPEN**

Power lever **IDLE**

Engine master **OFF**

Fuel selector **OFF**

Alternator **OFF**

Fuel pump **OFF**