

EMERGENCY PROCEDURES

DA62

ENGINE TROUBLESHOOTING

Power lever	IDLE 1 SECOND
Power lever	SLOWLY TO 1975 RPM
<i>If engine fails again, maintain maximum possible power</i>	
Circuit breakers	CHECK
ECU Voter	CYCLE / AUTO
Above 10,000'	FUEL PUMP ON
Fuel selector	CROSS FEED
Alternate air	OPEN

ENGINE FAILURE

Power good engine	AS REQD
Airspeed	> BLUE LINE
Landing gear	UP
Flaps	UP
Failed engine	VERIFY / SECURE
Alternator failed engine	OFF
Fuel pump failed engine	OFF
Fuel selector failed engine	OFF
Fuel balance	MONITOR
Transponder	7700
Emergency	DECLARE
LNAV	DIVERT

ENGINES OUT LANDING

Engine masters	OFF
Speed	BLUE LINE
Transponder	7700
Mayday mayday	DECLARE
Alternators	OFF
Fuel pumps	OFF
Fuel selectors	OFF
Seat belts	TIGHT
Flaps	AS REQD

GEAR UP

Electric master	KEEP ON
-----------------------	----------------

GEAR DOWN

Landing gear	DOWN / LOCKED
--------------------	----------------------

EMERGENCY PROCEDURES (cont.)

DA62 (continued)

DITCHING

Landing gear	UP
Engine masters	OFF
Transponder	7700
Mayday mayday	DECLARE

HEAVY SWELL

Ditch parallel to swell

HEAVY WIND

*Ditch into the wind***Touch down pitch level****Do not flare**

RPM PROBLEMS

Power lever	SWEEP
ECU Voter	CYCLE / AUTO

Expect engine failure

ENGINE FIRE

Cabin heat / defrost	OFF
Windows	OPEN
Power lever	IDLE
Engine master	OFF
Fuel selector	OFF
Alternator	OFF
Fuel pump	OFF