

1. Make sure your static IP script is created and executable

vi /etc/init.d/set-static-ip

1.1 Paste this content

```
#!/bin/sh

### BEGIN INIT INFO
# Provides:      set-static-ip
# Required-Start: $network
# Default-Start: S
# Default-Stop:
# Short-Description: Set static IP for eth0

### END INIT INFO

ip addr flush dev eth0
ip addr add 192.168.1.100/24 dev eth0
ip link set dev eth0 up
ip route add default via 192.168.1.1
```

1.2 Make it executable:

```
chmod +x /etc/init.d/set-static-ip
```

2 Create a systemd unit:

vi /etc/systemd/system/set-static-ip.service

2.1 Paste this content

[Unit]

Description=Set static IP at boot

After=network-pre.target

Before=network.target

[Service]

ExecStart=/etc/init.d/set-static-ip

Type=oneshot

RemainAfterExit=yes

[Install]

WantedBy=multi-user.target

2.2 Enable and reload the service:

```
chmod +x /etc/systemd/system/set-static-ip.service
```

```
systemctl daemon-reload
```

```
systemctl enable set-static-ip.service
```

3 Reboot

4 Verify

```
ip addr show eth0
```

This should show the correct ip address for eth0

Try to ping the G2I board from your laptop.