


RMD10.5XS Error & warning codes - Troubleshooting

Errors are reset by pressing and holding the power button for 2 seconds until beep.

CODE	FAULT AREA	POTENTIAL SOLUTION
	Not cooling in AC mode	- Code reset - Check AC element - Check that RV is level - Check if unit cools OK in other energy mode – possible cooling unit fault
	Not cooling in DC mode	- Code reset - Check DC element NOTE: DC usage is designed for travel point A to B - not for stationary/campsite usage – performance reduced.
	Not cooling in gas mode This error needs to be reset manually by pushing and holding the power button for 2 seconds until a beep occurs	- Code reset - Check gas turned on and bottle not empty - Check RV is level - Check proper gas flame at burner - Check if unit cools OK in other energy mode – possible cooling unit fault
	AC power is not connected	- Check AC is switched on and plug is properly inserted - Poorly regulated voltage < 190 volts
	Fuel tank stop mode When running from DC and DC is lost the unit assumes you have stopped at a fuel station so will not try to ignite	Allow at least 15 minutes for auto reset
	Gas lockout after 3 unsuccessful attempts to ignite	- Check bottle is not empty - Check regulator providing gas to refrigerator - Check for blocked burner/jet - Check gas valve
	DC power unavailable to element	- Check that tow vehicle wiring is connected - Wiring direct to DC element not connected - No voltage at D+ signal wire
	DC overvoltage (>16 volts)	Check solar regulator and house batteries
	Gas valve check error	- Reset error - Check gas valve solenoid
	Internal communication error	- Reset error - Check wiring loom/connections
	Gas lock – internal error in power module/PCB	- Reset error - Replace power module/PCB

Continued next page

CODE	FAULT AREA	POTENTIAL SOLUTION
	Ground contact – Gas valve	- Reset code - Check gas valve solenoid - Check for shorts
	Ground contact – Ignition electrode	- Reset code - Check electrode - Check for shorts
	Internal refrigerator Batteries dead when using standalone on gas with no house DC power	Replace or recharge the internal batteries (Not used in Australia normally – if internal batteries are fitted the refrigerator is designed to ONLY work on gas.)
	Faulty temperature sensor	Replace temperature sensor
Audible beep & 	Door open > 2 minutes	Close the door properly
	No connection between power module and display PCB This error needs to be reset manually by pushing and holding the power button for 2 seconds until a beep occurs	Check wiring loom

Note: most errors/warnings reset automatically when the symptom has been solved. To manually cancel an error push and hold the power button for 2 seconds until a “beep” is heard. That will clear nuisance errors, but the error alarm may return if service is required. Servicing should be carried out by a suitably qualified and in some cases licenced person.