plmc

A minimal PL/M compiler for the Motorola 6809 – user manual

plm09 project

October 2026

Contents

1 Introduction **3**

2 Building and quick start **3**

3 Command-line usage **4**

4 The language **5**

4.1 Lexical rules . . . 6
4.2 Program structure . . . 6
4.3 INCLUDE . . . 7
4.4 Declarations . . . 7
4.5 LITERALLY . . . 7
4.6 Arrays . . . 8
4.7 INITIAL and DATA . . . 9
4.8 Structures . . . 10
4.9 BASED variables and the dot operator . . . 11
4.10 AT . . . 12
4.11 Procedures . . . 12
4.12 Statements . . . 15
4.13 Labels and GOTO . . . 16
4.14 Iterative DO . . . 17
4.15 DO CASE . . . 18
4.16 Expressions . . . 18
4.17 Types and conversions . . . 21
4.18 Conditions . . . 22
4.19 Unsupported features . . . 22

5 Diagnostics **23**

6 Hooks **27**

6.1 How targets are selected . . . 27

6.2 What a hooks file must define . . . 27

6.3 Calling convention for EXTERNAL procedures . . . 27

6.4 Hooks provided . . . 28

6.5 Writing hooks for a new machine . . . 29

7 Object files and lwlink **29**

7.1 An example . . . 29

7.2 The main module and the others . . . 30

7.3 Rules and limits . . . 31

8 OS-9 modules **31**

8.1 What `--os9` changes . . . 31

8.2 Module names . . . 32

8.3 The OS-9 hooks . . . 33

9 Running on a Color Computer **33**

10 FLEX **34**

11 Simon6809 **36**

12 Wichit Sirichote's 6809 Microprocessor Kit **36**

13 Grant Searle's 6809 SBC **37**

14 Generated code **38**

14.1 Layout . . . 38

14.2 Example . . . 38

14.3 Conventions . . . 39

15 Inspecting the compiler's view **42**

16 Testing **42**

17 Source code **44**

1 Introduction

`plmc` compiles programs written in a small subset of PL/M-80, Intel's systems programming language of the late 1970s, into assembly source for the Motorola 6809. Its output is meant for **lwasm**, the assembler in the lwtools package (version 4.24 or later). lwasm then produces whatever binary format the target needs: S-records, Disk BASIC `.BIN` files, raw images and so on.

The compiler is not tied to any particular machine. Everything that depends on the hardware lives in a small **hooks file** that lwasm includes, chosen with an include path. Eight hooks files come with plmc:

Hooks	Target
`runtime/sim/`	sim6809, the headless simulator used by the test suite
`runtime/coco/`	the Tandy Color Computer 1, 2 and 3 under Color BASIC
`runtime/os9/`	OS-9 and NitrOS-9 (Level 1 and 2), for modules built with `--os9`
`runtime/flex/`	the FLEX 9 disk operating system, for `.CMD` commands made by `srec2flex`
`runtime/simon6809/`	the Simon6809 board, under its BUGGY monitor
`runtime/kswichit/`	Wichit Sirichote's 6809 Microprocessor Kit, under its monitor
`runtime/searle6809/`	Grant Searle's 6809 SBC (and boards built from it), under ASSIST09 or BASIC
`runtime/example/`	a template for a board with an MC6850 ACIA serial port

Main features

- BYTE (8-bit) and ADDRESS (16-bit) unsigned variables, arrays and structures, with PL/M-80's rules for mixing the two types, and the built-ins `LENGTH`, `LAST`, `SIZE`, `HIGH`, `LOW`, `DOUBLE`, `SHL`, `SHR`, `ROL` and `ROR`.
- All PL/M arithmetic, logical and relational operators, with PL/M precedence.
- `LITERALLY` macros, scoped like other declarations.
- Pointers: `BASED` variables and the address-of (dot) operator `.X`.
- `INITIAL` and `DATA` initializations, including strings of any length up to 255 characters, and `(*)` dimensions.
- `IF`/`THEN`/`ELSE`, `DO` blocks with their own declarations, `DO WHILE` and iterative `DO I = ... TO ... BY ...` loops, `DO CASE`, labels and `GOTO`, `HALT`.
- Procedures: typed and untyped, with parameters, nested inside each other, and `EXTERNAL` procedures written in assembly.
- Error messages that give the file, line and column. Every unsupported PL/M feature is rejected with a clear message rather than misread.
- Readable output: each source statement appears as a comment above the code generated for it.
- With `--os9`, position-independent, reentrant OS-9 program modules that run under OS-9 and NitrOS-9.

2 Building and quick start

`plmc` is plain C11. From the top of the plm09 tree:

```
make            # builds build/plmc
```

```
make test       # runs every test suite
make install    # copies plmc to BINDIR
```

The tests, and the examples in this manual, run programs in `sim6809` and make FLEX commands with `srec2flex`. Both come from the separate sim6809 project (they were part of plm09 until version 0.5.0); `make test` finds them on PATH, or takes `SIM6809=` and `SREC2FLEX=`.

`BINDIR` defaults to `$(PREFIX)/bin`, and `PREFIX` to `/usr/local`; for example `make install BINDIR=~/bin`. `DESTDIR` is put in front for staged installs. The man page `plmc(1)` (from `docs/man/`) goes to `MANDIR/man1`, `MANDIR` defaulting to `$(PREFIX)/share/man`, so `man plmc` summarizes the options.

The runtime and hooks files go to `DATADIR/plm09/runtime` (`DATADIR` defaults to `$(PREFIX)/share`): with an installed plmc, write `-I /usr/local/share/plm09/runtime -I /usr/local/share/plm09/runtime/sim` wherever this manual has `-I runtime -I runtime/sim`.

`make rpm` builds a Fedora RPM from `plm09.spec` (from the release tag, or the committed tree before the version is tagged, into `build/rpm`), which installs in `/usr`, so the runtime is in `/usr/share/plm09/runtime`; its documentation is patched to use that directory in its commands. `plmc --version` prints the version.

A first program:

```
SUM: DO;
PUTDEC: PROCEDURE (N) EXTERNAL; DECLARE N ADDRESS; END PUTDEC;
DECLARE I BYTE, TOTAL ADDRESS;
TOTAL = 0;
I = 1;
DO WHILE I <= 10;
    TOTAL = TOTAL + I;
    I = I + 1;
END;
CALL PUTDEC(TOTAL);
END SUM;
```

Compile it, assemble it, and run it in the simulator:

```
$ build/plmc -o sum.asm sum.plm
$ lwasm -9 -f srec -I runtime -I runtime/sim -o sum.s19 sum.asm
$ sim6809 sum.s19
55
```

`make run F=sum.plm` does all three steps. Always pass `-9` to lwasm (or rely on the `PRAGMA 6809` that plmc emits). By default lwasm accepts the Hitachi 6309's extra instructions, which a 6809 doesn't have.

3 Command-line usage

```
plmc [options] file.plm
```

Option	Meaning
`-o FILE`	Write the assembly to *FILE*. The default is standard output.

Option	Meaning
`--obj`	Write a module for `lwasm -f obj`, to be linked with other modules by lwlink. See Object files and lwlink.
`-I DIR`	Also look for `$INCLUDE` files in *DIR*, after the including file's directory. May be given more than once; the directories are searched in order. See INCLUDE.
`--org ADDR`	Address where the program is loaded and starts. The default is `$0100`.
`--vectors`	Also emit `ORG $FFFE` / `FDB RT_START`, setting the 6809 reset vector, for programs that run from ROM or straight from reset, and the IRQ, FIRQ and NMI vectors of any INTERRUPT procedures.
`--os9`	Generate a position-independent OS-9 program module instead of a program for a fixed address. See OS-9 modules.
`--stack N`	With `--os9`: bytes of stack to reserve in the module's data area (default 256, at least 32).
`--memory N`	With `--os9`: bytes of the data area for the predeclared array `MEMORY` (default 0); see MEMORY and STACKPTR.
`--name NAME`	With `--os9`: the module name (default: the PL/M program's name).
`--tokens`	Print the token stream and stop. See Inspecting the compiler's view.
`--ast`	Print the syntax tree and stop.
`-h`, `--help`	Print a usage summary and exit.
`--version`	Print `plmc (plm09)` and the version, and exit.

The `--org` address and `--stack` size can be written as decimal (`8192`), `0x2000`, `$2000` (quote it for the shell) or PL/M style `2000H`, and must fit in 16 bits. `--org` and `--vectors` can't be combined with `--os9`, and `--stack` and `--name` need `--os9`; violations are reported as errors.

Exit status

Status	Meaning
0	Success. Any warnings are still printed.
1	Compilation error, or a file couldn't be read or written. If `-o` was given and writing failed, the partial output file is removed.
2	Bad usage, for example no input file or an unknown option.

4 The language

plmc accepts a **subset** of PL/M-80. Anything outside the subset is rejected with an error (see Unsupported features), so a program that compiles means what PL/M-80 says it means.

4.1 Lexical rules

- **Case:** case doesn't matter. `Total`, `TOTAL` and `total` are the same name, and keywords may be written in any case.
- **The `$` character:** ignored inside names and numbers, so you can use it as a separator: `MAX$COUNT`, `1$000`, `0FF$FFH`.
- **Names:** start with a letter and continue with letters, digits and `$`. The underscore is **not** allowed (as in PL/M-80). This is what keeps compiler-generated labels from ever colliding with your names.
- **Comments:** `/* ... */`. They may span several lines but don't nest.
- **Control lines:** a line with `$` in column 1 holds compiler controls; only `$INCLUDE(file)` has an effect, and the others are ignored with a warning. See INCLUDE.
- **Numbers:** must start with a digit and fit in 16 bits (0 to 65535). An optional suffix gives the base:

Suffix	Base	Example	Value
none or `D`	decimal	`255`, `255D`	255
`H`	hexadecimal	`0FFH`	255
`O` or `Q`	octal	`377Q`	255
`B`	binary	`1111$1111B`	255

  A hexadecimal number has to start with a digit, so write `0FFH`, not `FFH` (`FFH` is a name).

- **Strings:** a one-character string such as `'A'` is a BYTE constant (65). A two-character string such as `'AB'` is an ADDRESS constant (`'A'`× 256 + `'B'`). Write a quote character as `''`, as in `''''`. A longer string, up to 255 characters, can't be a number. As in PL/M-80 it can be used in three places:
  - an `INITIAL` or `DATA` list, as in `DECLARE MSG (*) BYTE DATA ('HELLO')`
  - a constant list, `.('HELLO', 0)`, which gives its address
  - the text of a `LITERALLY`

  Used as a value anywhere else, it is an error.
- **Reserved words:** all PL/M-80 reserved words, including ones for features plmc doesn't implement, so they can't be used as names: `ADDRESS AND AT BASED BY BYTE CALL CASE DATA DECLARE DISABLE DO ELSE ENABLE END EOF EXTERNAL GO GOTO HALT IF INITIAL INTERRUPT LABEL LITERALLY MINUS MOD NOT OR PLUS PROCEDURE PUBLIC REENTRANT RETURN STRUCTURE THEN TO WHILE XOR`.

4.2 Program structure

A program is one labeled block:

```
NAME: DO;
    declarations
    statements
END NAME;
```

The name after `END` is optional, but if present it must match. The block may optionally be followed by the keyword `EOF`. Within any block, **all declarations must come before the first statement.**

4.3 INCLUDE

A line with `$` in its first column is a *control line*, as in Intel's compiler. The one control plmc implements is `INCLUDE` (abbreviated `IC`, in either case), which reads another file in place of the line:

```
UTIL: DO;
$INCLUDE(:F1:HOOKS.PLM)
DECLARE I BYTE;
    ...
END UTIL;
```

- **Where the text goes:** the file's text is compiled as if it stood where the control line is, so it must fit there: declarations among the declarations, statements among the statements. An INCLUDE file may itself contain INCLUDE lines, up to 16 deep.
- **Finding the file:** the name is looked for first in the directory of the file that contains the control line, then in each `-I` directory in order. Each place is tried with the name as written, then in lower case, so the upper-case names of ISIS sources find lower-case files. An ISIS drive prefix (`:F0:` to `:F9:`) is dropped, and an absolute path is used as it is.
- **The line:** INCLUDE must be the last control on its line, and the file name is everything between the parentheses, without surrounding blanks.
- **Diagnostics** in an INCLUDE file name that file and its own line numbers, and so do the source comments in the generated assembly (`; inc/defs.plm:3: RETURN N + N;`).
- **Other controls** (`$NOLIST`, `$TITLE('...')`, `$PAGEWIDTH(120)`, `$OPTIMIZE`, and the rest) concern Intel's listing and object files. plmc ignores each one, with any parenthesized argument, and warns: `warning: control NOLIST ignored (only INCLUDE has an effect)`. Several may share a line, also before an INCLUDE (`$NOLIST INCLUDE(DEFS.PLM)`).

4.4 Declarations

```
DECLARE COUNT BYTE;
DECLARE (X, Y, Z) ADDRESS;
DECLARE FLAG BYTE, LIMIT ADDRESS, (LO, HI) BYTE;
```

- **Types:** `BYTE` is an unsigned 8-bit value (0 to 255) and `ADDRESS` an unsigned 16-bit value (0 to 65535).
- **Order and scope:** names must be declared before they are used. A name declared in an inner block or procedure hides the same name from an outer one. Declaring a name twice in the same block is an error.
- **Initial values:** a variable has no initial value unless it is declared with `INITIAL` or `DATA` (see INITIAL and DATA). Otherwise it starts with whatever is in memory, which is `$A5` in the simulator so that the mistake shows up.

4.5 LITERALLY

```
DECLARE TRUE LITERALLY '0FFH', FALSE LITERALLY '0';
DECLARE BUFFER$SIZE LITERALLY '32';
DECLARE DCL LITERALLY 'DECLARE', PROC LITERALLY 'PROCEDURE';

DCL PRINT$BUFFER(BUFFER$SIZE) BYTE;
```

`DECLARE name LITERALLY 'text'` defines a parameterless macro. Every later occurrence of *name* is replaced by the tokens of *text*, before parsing, so a literal can stand for anything:

- a constant (`TRUE`, `BUFFER$SIZE`), including where only a number is allowed, such as an array dimension
- a keyword (`DCL`, `PROC`)
- part of an expression
- a whole statement (`INCR LITERALLY 'N = N + 1'`, then `INCR;`)

The rules:

- **Text:** up to 255 characters. Write a quote inside it as `''`, so `QUOTE LITERALLY '''A'''` stands for `'A'`.
- **Nesting:** a literal's text may use other literals, which are expanded in turn. A literal that expands to itself is reported as `literal X expands recursively`.
- **Scope:** literals follow block scope like any other declaration.
  - A literal declared in a procedure or a `DO` block is visible only there, from its declaration on.
  - An inner block can declare its own literal, or a variable or procedure, with the same name, which hides the outer literal until that block's `END`.
  - Declaring the same name twice in one block is an error.
- **Names being defined are not expanded:** declared names, procedure names, parameters, labels and the name after `END`.
- **Textual substitution:** the text is substituted *as text*, so precedence can surprise you. After `DECLARE TWO LITERALLY '1 + 1'`, the expression `TWO * 3` means `1 + 1 * 3`, which is 4. Put parentheses in the literal (`'(1 + 1)'`) when it is an expression.
- **Form:** a LITERALLY can't be factored (`DECLARE (A, B) LITERALLY ...`) or have a dimension, but it can be mixed with other items in one `DECLARE`.
- **Seeing the result:** `--ast` shows the program *after* substitution, which is the easiest way to check what a literal turned into.

4.6 Arrays

```
DECLARE BUF(80) BYTE;
DECLARE (XS, YS)(10) ADDRESS;
DECLARE COUNT BYTE, TABLE(16) ADDRESS;
```

- **Declaring:** a dimension in parentheses makes an array. `BUF(80)` has the 80 elements `BUF(0)` to `BUF(79)`. The dimension must be a number from 1 to 65535, and the array must fit in 64 KB.
- **Element type:** the elements are BYTE or ADDRESS, and an element behaves exactly like a variable of that type in expressions and conversions.
- **Using an element:** `BUF(I)` is an element wherever a variable can appear: in expressions and as an assignment target, including multiple assignment (`BUF(I), BUF(J), N = 0;`).
- **Subscripts:** any expression, BYTE or ADDRESS. A BYTE subscript is zero-extended. **Subscripts are not checked:** as in PL/M-80, `BUF(80)` silently reads or writes the memory after the array.
- **Unsubscripted name:** a plain `BUF` means `BUF(0)`.
- **Not allowed:** arrays can't be parameters, and procedures can't return them. Pass an element (its value), or keep the array global, or in an outer procedure that the procedure can see.
- **Built-ins:** three PL/M-80 functions describe a variable, as constants worked out by the compiler:
  - `LENGTH(A)`: the number of elements
  - `LAST(A)`: the highest subscript, `LENGTH(A) - 1`
  - `SIZE(X)`: the number of bytes

`LENGTH` and `LAST` are **BYTE** when the value is 255 or less and ADDRESS otherwise, as in PL/M-80. Arithmetic with them follows the BYTE rules: if `LENGTH(B)` is 10, then `LENGTH(B) + 250` wraps to 4. `SIZE` is always an ADDRESS.

For a scalar, `LENGTH` and `LAST` give 1 and 0. The built-ins are only used when you haven't declared a procedure or variable with the same name yourself. They also accept structure references; see Structures.

```
I = 0;
DO WHILE I < LENGTH(BUF);
    BUF(I) = ' ';
    I = I + 1;
END;
```

4.7 INITIAL and DATA

```
DECLARE THRESHOLD BYTE INITIAL (48);
DECLARE (COUNTER, LIMIT, INCR) ADDRESS INITIAL (0, 1024, 2);
DECLARE GREETING (*) BYTE INITIAL ('HELLO, WORLD', 0);
DECLARE DAYS (*) BYTE DATA (31, 28, 31, 30, 31, 30, 31, 31, 30, 31, 30, 31);
DECLARE MESSAGES (*) ADDRESS INITIAL (.GREETING, .('BYE', 0));
```

An `INITIAL (...)` or `DATA (...)` list after the type gives a declaration initial values (PL/M-80 manual 6.2.9).

Values. The list fills the declaration's **scalars in storage order**:

- array elements from 0 up
- a structure's members in order, including member arrays, and each structure of an array of structures in turn
- across all the names of a factored declaration: `INITIAL (0, 1024, 2)` above sets COUNTER, LIMIT and INCR

Each value is one of these:

Value	Fills
a number, as in `48`, `0FFH` or `'A'`	one scalar; a BYTE needs 0 to 255
a string, `'HELLO'`	one character per BYTE, two per ADDRESS (`'ABC'` fills two ADDRESS scalars with `'AB'` and `'C'`)
a location reference plus or minus numbers, as in `.BUF`, `.TABLE(2) - 2`, `.('TEXT', 0)` or `.PROC`	one ADDRESS scalar with that address. Subscripts must be constants, the variable must be declared earlier and not BASED

Length of the list. The list may be shorter than the declaration, and the remaining scalars are then left uninitialized. It may not be longer.

Implicit dimensions. `(*)` in place of a dimension makes the array exactly as long as its list. `FAREWELL (*) BYTE INITIAL ('GOODBYE, NOW')` has 12 elements, and `LENGTH(FAREWELL)` is 12. `(*)` can't be used in a factored declaration, for an array of structures, or for a member.

INITIAL or DATA:

- `INITIAL` gives a variable its value when the program is **loaded**. The program can change it afterwards; it isn't reset on a restart. `INITIAL` is allowed only at the **outer level of the main program**.

- `DATA` stores the values **with the program code**, so they could be in ROM. A DATA variable is a constant table, and the compiler rejects assignments to it. `DATA` is allowed at any level, including inside procedures.
- **Not allowed:** a BASED variable or a parameter can't be initialized.

4.8 Structures

```
DECLARE AIRPLANE (20) STRUCTURE (SPEED BYTE, ALTITUDE ADDRESS);
DECLARE PAYROLL (100) STRUCTURE (
    LAST$NAME (15) BYTE,
    FIRST$NAME (15) BYTE,
    DOLLARS ADDRESS);

AIRPLANE(17).ALTITUDE = 9000;
PAYROLL(N).FIRST$NAME(K) = 'A';
```

A **structure** groups members of different types under one name. `STRUCTURE (member, ...)` is a type, written where `BYTE` or `ADDRESS` would be, so it can be combined with the other parts of a declaration:

- **Forms:**
  - a single structure: `DECLARE POINT STRUCTURE (X BYTE, Y BYTE);`
  - an array of structures: `DECLARE AIRPLANE (20) STRUCTURE (...)`
  - factored: `DECLARE (A, B) STRUCTURE (...)`, which gives both the same members
  - BASED: `DECLARE ITEM BASED P STRUCTURE (...)`
- **Members:** each is `name [(dimension)] BYTE` or `ADDRESS`.
  - A member can be an array.
  - A member can't be factored, BASED, or itself a structure; structures don't nest.
  - Member names belong to their structure, so different structures can use the same names, and a member name never clashes with a variable.
- **Layout:** the members are stored one after another in the order written, so `SIZE` of a structure is the sum of its members' sizes. An array of structures stores whole structures one after another.

References. A member is referenced as `X.M`, `X(i).M`, `X.M(j)` or `X(i).M(j)`. Each subscript can be any expression, and each is **unchecked**, as for arrays. A member reference can be used anywhere a variable can: in expressions, as an assignment target, and with `..` An unsubscripted member array (`POINT.COORD`) means its element 0.

A whole structure (`POINT`, or `AIRPLANE(3)`) is not a value. It can only be used in these places:

Reference	Meaning
`.POINT`, `.AIRPLANE(3)`, `.AIRPLANE`	the address of the structure (of element 0 for an array)
`.PAYROLL(5).FIRST$NAME`	the address of a member array
`LENGTH(AIRPLANE)`, `LAST(AIRPLANE)`	the number of structures in an array of structures, and the last subscript
`SIZE(POINT)`, `SIZE(AIRPLANE)`, `SIZE(AIRPLANE(3))`	bytes in a structure, the whole array, or one element
`LENGTH(PAYROLL(5).FIRST$NAME)`, `SIZE(...)`	a member array's length and size

The built-in shorthand. A member of an *array* of structures normally needs the array's subscript (`AIRPLANE.SPEED` is an error). The built-ins are the exception, because every element's member array has the same size: `LENGTH(PAYROLL.FIRST$NAME)` is 15.

Pointers. Structures combine naturally with BASED variables and the dot operator. For example, a procedure can take a structure's address and look at it through a BASED structure:

```
TOTAL: PROCEDURE (Q) ADDRESS;
    DECLARE Q ADDRESS, R BASED Q STRUCTURE (KEY BYTE, INFO (3) ADDRESS);
    ...  R.INFO(K) ...
END TOTAL;

X = TOTAL(.RECORD);
```

A linked list can be built in an array of structures with an ADDRESS member holding `.NODE(i)`, and walked with a BASED structure.

Not allowed: structures can't be parameters, values, or iterative DO indexes. Pass `.X` and use a BASED structure instead.

4.9 BASED variables and the dot operator

```
DECLARE (NORTH$ERROR, EAST$ERROR) BYTE;
DECLARE ERROR$POINTER ADDRESS;
DECLARE ERROR BASED ERROR$POINTER BYTE;

ERROR$POINTER = .NORTH$ERROR;
ERROR = 0;                          /* clears NORTH$ERROR */
```

A **BASED variable** has no storage of its own. Each reference to it uses the memory whose address is, *at that moment*, in its **base**.

- **Declaring:** `BASED base` must come right after the variable's name:
  - `DECLARE ITEM BASED PTR BYTE;`
  - `DECLARE (A BASED P, B BASED Q) ADDRESS;`
  - `DECLARE (LIST BASED LP) (100) ADDRESS;` (the parentheses are optional)
- **The base:** an ADDRESS scalar declared earlier. It can't be an array, an element, or itself BASED. Parameters and locals make good bases.
- **Arrays:** a BASED array's element `A(i)` is at `base + i` (BYTE) or `base + 2*i` (ADDRESS), and `A` alone means `A(0)`. As with ordinary arrays nothing is range-checked, so `DECLARE (BUF BASED P) (1) BYTE` can index any amount of memory.
- **Not allowed:** a BASED variable can't be a parameter or the index of an iterative DO.

The **dot operator** gives an ADDRESS value:

Form	Value
`.X`	the address of variable `X` (of element 0 if `X` is an array)
`.A(i)`	the address of element `A(i)`
`.B` for a BASED `B`	the current value of its base (plus the offset for `.B(i)`)

Form	Value
`.P`	the entry address of procedure `P`. `P` must be declared at the outer level, and is written without arguments
`.(constants)`	the address of the listed bytes, stored with the program: numbers from 0 to 255 and strings of any length up to 255, as in `.('HELLO', 13, 0)`

Together they give PL/M its pointers: pass `.BUF` to a procedure whose parameter is the base of a BASED array, walk a string by adding 1 to a base, or keep tables of addresses. The 6809 stores ADDRESS values high byte first, so a BYTE BASED on an ADDRESS variable sees its high byte.

In an `--os9` module, `.X` gives the variable's actual run-time address inside the process's data area, and constant lists live in the module.

4.10 AT

```
DECLARE BUFFER (3) BYTE;
DECLARE (CHAR$A, CHAR$B, CHAR$C) BYTE AT (.BUFFER);
DECLARE STATUS BYTE AT (0FF00H);
```

`AT (address)` places a variable at an address of your choosing instead of giving it storage of its own (PL/M-80 manual 6.2.8).

- **Placement:** the first name of the declaration is at the address, and any others follow it in order, so `CHAR$A`, `CHAR$B` and `CHAR$C` above are `BUFFER(0)`, `BUFFER(1)` and `BUFFER(2)`. `AT` goes after the type and before any `INITIAL`.
- **The address** is a restricted expression, as for `INITIAL`:
  - a number, as in `AT (0FF00H)`: the variable is at that fixed address, for example a memory-mapped I/O register. Plus or minus numbers is allowed.
  - the location of a variable declared earlier, plus or minus numbers: `AT (.BUFFER)`, `AT (.TABLE(3) - 2)`, `AT (.REC.VAL(1) + 1)`. The new variable is an **alias**: it shares that variable's storage, wherever that is. Subscripts must be constants.
- **Byte order:** the 6809 is big-endian, so `DECLARE ITEM BYTE AT (.DATUM)`, where `DATUM` is an ADDRESS, is the *high-order* byte of `DATUM` (on the 8080 it would be the low-order byte). Use `AT (.DATUM + 1)` for the low-order byte.
- **Any type:** scalars, arrays and structures can be declared `AT`, in procedures as well as in the main program.
- **With INITIAL:** the values are stored at the address, as part of the load image (`ORG` to the address, then `FCB`/`FDB`). In an `--os9` module they are copied there at start-up.
- **Not allowed:** `AT` with `BASED`, with `DATA`, for a parameter, or with the address of a procedure, of a constant list or of a BASED variable.
- **In `--os9` modules:** an alias stays in the data area (`,U`) or, if it is AT a DATA variable, in the module (`,PCR`). A variable AT a number is used at that absolute address, which is fine for I/O registers but leaves the program's own memory.

4.11 Procedures

```
NAME: PROCEDURE [(PARAM, ...)] [BYTE | ADDRESS] [EXTERNAL | REENTRANT]
                [INTERRUPT n];
    declarations
```

```
    statements
END [NAME];
```

- **Parameters:** each one must be declared, with its type, in the procedure's own declarations.
- **Typed and untyped:**
  - A typed procedure (`BYTE` or `ADDRESS`) returns a value with `RETURN expression;` and is used inside expressions.
  - An untyped procedure is invoked with `CALL` and may use a bare `RETURN;`.
  - Using one kind where the other is expected is an error.
- **No arguments:** a typed procedure with no parameters is called just by writing its name: `X = NEXTCHAR;`.
- **Nesting:** procedures may be nested. An inner procedure can use the parameters and variables of the procedures around it, and of the program.
- **Argument conversion:** arguments are converted to the parameter's declared type, and `RETURN` values to the procedure's type. See Types and conversions.
- **Reaching `END`:** an untyped procedure just returns. A typed procedure that might reach its `END` without a `RETURN` gets a warning, and the value it returns is then undefined.
- **Static storage:** as in classic PL/M-80, the parameters and local variables of an ordinary procedure live at fixed memory locations, not on the stack. Such a procedure must not call itself, directly or through other procedures, unless it is `REENTRANT`. plmc reports both cases:

  ```
  error: procedure A is recursive (A -> B -> A) but not REENTRANT
  ```

4.11.1 REENTRANT procedures

```
SUM$ARRAY: PROCEDURE (PTR, N) BYTE REENTRANT;
    DECLARE PTR ADDRESS,
        ARRAY BASED PTR (1) BYTE,
        N BYTE;
    IF N=0 THEN RETURN ARRAY(0);
    ELSE RETURN ARRAY(N) + SUM$ARRAY(PTR, N-1);
END SUM$ARRAY;
```

A `REENTRANT` procedure keeps its parameters and variables on the stack, so every activation has its own (PL/M-80 manual 8.1.7). It may call itself, directly or through other procedures, and it may be called from an interrupt procedure while it is running.

- **Calling ahead:** inside a REENTRANT procedure, a REENTRANT procedure may be called (or have its address taken) before it is declared. That allows indirect recursion: `IS$EVEN` can call `IS$ODD`, declared after it, which calls `IS$EVEN`. Anywhere else, names must be declared first.
- **Cycles:** every procedure on a cycle of calls must be REENTRANT.
- **What is on the stack:** the parameters, and the variables declared in the procedure and in its `DO` blocks, including arrays and structures. Exceptions: `DATA` (read-only, kept with the code), and variables `AT` a number or `AT` a variable that is not on the stack.
- **Rules:**
  - only at the outer level of the main program;
  - no procedure declarations inside it;

  - not `EXTERNAL`;
  - its variables take at most 32767 bytes.

- **Stack use:** each activation needs its variables, its arguments and 4 bytes, plus room for intermediate results. Deep recursion needs a big enough stack; with `--os9`, raise `--stack` (default 256 bytes).
- **Pointers:** `.X` of a variable on the stack is its address in the current activation, valid until the procedure returns.

4.11.2 INTERRUPT procedures, ENABLE and DISABLE

```
DECLARE PIA0B BYTE AT (0FF02H);
TICK: PROCEDURE INTERRUPT 0;
    DECLARE ACK BYTE;
    ACK = PIA0B;                    /* acknowledge the device */
    TICKS = TICKS + 1;
END TICK;
```

`INTERRUPT n` makes a procedure run when interrupt n occurs (PL/M-80 manual 8.1.6). The 8080's numbers are RST levels; on the 6809 they are:

n	Interrupt	Vector	Registers stacked by the CPU
0	IRQ	`$FFF8`	all
1	FIRQ	`$FFF6`	PC and CC (plmc's entry code saves the others)
2	NMI	`$FFFC`	all

- **What happens:** the CPU masks interrupts (IRQ sets I; FIRQ and NMI set I and F) and enters the procedure through a small entry routine, `RT_INTn`, which sets DP = 0 and calls it. When the procedure returns (`RETURN` or `END`), `RTI` restores the interrupted program's registers, including CC, so interrupts are enabled again.
- **Acknowledge the device:** IRQ and FIRQ stay asserted until the device that raised them is serviced. The procedure must do that (typically by reading or writing a device register, declared `AT` its address), or it will be entered again as soon as it returns.
- **Installation:** at start-up the program calls the hooks' `PLM_SETINT` for each INTERRUPT procedure, which points that interrupt at `RT_INTn`. The simulator's hooks store the vector; the CoCo's patch BASIC's RAM vector (and `PLM_EXIT` puts it back). For a ROM-based system, `--vectors` also writes `RT_INTn` into the vector table.
- **`ENABLE;` and `DISABLE;`** clear and set both the I and F masks (`ANDCC #$AF`, `ORCC #$50`). NMI can't be disabled. Programs start with interrupts as the hooks leave them: masked after a reset (and in the simulator), enabled under Color BASIC.
- **CALL:** an interrupt procedure may also be called like any untyped procedure. Interrupts aren't masked for such a call, and when it returns they are enabled, as by `ENABLE`.
- **GOTO out:** an interrupt procedure may `GOTO` a label at the outer level of the main program. Control never returns to the interrupted code, and interrupts stay masked until `ENABLE`.
- **HALT** enables interrupts before it stops the program, as in PL/M-80.
- **Shared procedures:** a procedure that might be running when an interrupt procedure calls it again must be `REENTRANT` (its static variables would otherwise be overwritten). The runtime routines (`RT_MUL16`, `RT_DIV16`) use only the stack and are safe.
- **Rules:**
  - untyped, with no parameters;
  - only at the outer level of the main program;
  - not `EXTERNAL`;
  - each number at most once, and only 0, 1 and 2;
  - not in `--os9` modules (OS-9 owns the interrupts), and neither are `ENABLE` and `DISABLE`.

4.11.3 EXTERNAL procedures

An `EXTERNAL` procedure is written in assembly language, usually in the hooks file. Its PL/M declaration gives only the parameters and their types:

```
PUTCH: PROCEDURE (C) EXTERNAL;
    DECLARE C BYTE;
END PUTCH;
```

The body may contain only the parameter declarations. In the assembly the procedure is called by its exact PL/M name, so it must not be a 6809 register name (`A`, `B`, `D`, `X`, `Y`, `U`, `S`, `PC`, `CC`, `DP`, `PCR`). The calling convention is described under Hooks. An EXTERNAL procedure can also be a PUBLIC procedure of another PL/M module; see Object files and lwlink.

4.11.4 PUBLIC procedures

`PUBLIC` makes a procedure callable from outside its module, by its own name:

```
GCD: PROCEDURE (A, B) ADDRESS PUBLIC;
    DECLARE (A, B, T) ADDRESS;
    ...
END GCD;
```

- **Inside the module** it is an ordinary procedure, called as usual.
- **From outside** it is called with the EXTERNAL convention (see Calling convention for EXTERNAL procedures): every argument pushed as a 16-bit word, the last one also in D, `JSR GCD`, the result in B or D. So another PL/M module calls it through an `EXTERNAL` declaration, and assembly code (hooks, say) can call it too. plmc puts an entry for this under the procedure's name, next to its code; see Generated code.
- **Rules:** PUBLIC procedures are declared at the outer level of their module, and can't also be EXTERNAL. As for EXTERNAL, the name must not be a register name. PUBLIC may be combined with REENTRANT (the entry passes the arguments on in the procedure's own convention) and INTERRUPT.
- In a program of one module, PUBLIC only adds that entry. It is meant for programs of several modules, built as object files: see Object files and lwlink.

4.12 Statements

Statement	Form
Assignment	`X = expression;` or `A(i) = expression;`
Multiple assignment	`X, A(i), Z = expression;` (evaluated once, converted for each target)
Call	`CALL NAME;` or `CALL NAME(arg, ...);` (untyped procedures only)
Conditional	`IF condition THEN statement; [ELSE statement;]`
Block	`[LABEL:] DO; declarations statements END [LABEL];`
Loop	`[LABEL:] DO WHILE condition; statements END [LABEL];`

Statement	Form
Counted loop	`[LABEL:] DO I = start TO limit [BY step]; statements END [LABEL];` (see Iterative DO)
Case	`[LABEL:] DO CASE expression; statement-0; statement-1; ... END [LABEL];` (see DO CASE)
Return	`RETURN;` or `RETURN expression;` (inside procedures only)
Halt	`HALT;` stops the program through the hooks' `PLM_HALT` (enabling interrupts first if the program has INTERRUPT procedures)
Interrupt masks	`ENABLE;` and `DISABLE;` (see INTERRUPT procedures, ENABLE and DISABLE)
Empty	`;`
Jump	`GOTO label;` or `GO TO label;` (see Labels and GOTO)

- **ELSE:** an `ELSE` belongs to the nearest `IF` that doesn't already have one. To put several statements under `THEN` or `ELSE`, wrap them in `DO; ... END;`.
- **Labels:** any executable statement may carry labels, `L1: L2: stmt.` `END name` after a `DO` block must match one of the DO's labels. See Labels and GOTO.
- **Loop and case blocks:** `DO WHILE`, iterative `DO` and `DO CASE` blocks may not contain declarations at their top level. A simple `DO` block inside them may.

4.13 Labels and GOTO

```
        I = 0;
AGAIN:  I = I + 1;
        IF I < 10 THEN GOTO AGAIN;

        DO WHILE 1;
            IF DONE THEN GOTO FINISHED;     /* leave the loop */
            ...
        END;
FINISHED: ;
```

Labels (PL/M-80 manual 5.3, 9.3):

- **Where:** a label can be put on any executable statement, and a statement can have several (`L1: L2: N = 0;`). A labeled null statement `L: ;` marks a place, for example just before an `END`. Declarations and procedures can't be labeled.
- **Scope:** a label belongs to the **smallest block** that contains it. Every `DO` block counts as a block (simple, WHILE, iterative and CASE), and so does every procedure, but an `IF` does not.
  - A label may be used **before** it is defined.
  - The same name can be a label in two different blocks.
  - A label shares the block's names with its variables and procedures, so a clash is an error.
- **Labels on a DO:** a label on a `DO` statement belongs to the enclosing block, not to the DO's own block. So `GOTO L` to the label of `L: DO; ... END;` runs the whole block again.
- **The program's name:** the label on the program's first `DO` is outside every block, and can't be a GOTO target.

GOTO transfers control to a label that is visible from where the GOTO is:

- **Allowed:** a label in the same block, or in any block that encloses it. This lets you leave loops, `DO CASE` blocks and nested blocks early.
- **Not allowed:** jumping **into** a block. Its labels aren't visible from outside, so this is reported as `L is not declared`.
- **Leaving a procedure:** a GOTO in a procedure may jump out of it, even through several nested calls, but **only to a label at the outer level of the main program**. Anything else is an error. plmc then discards everything those calls left on the stack, which is safe because procedures keep their parameters and locals in fixed storage.

`GO TO`, written as two words, is the same as `GOTO`.

4.13.1 LABEL declarations

```
DECLARE (AGAIN, DONE) LABEL;
DECLARE RESTART LABEL PUBLIC;
DECLARE MONITOR LABEL EXTERNAL;
```

A label is normally declared just by labeling a statement. A LABEL declaration (PL/M-80 manual 6.3) declares it explicitly at the start of a block, before the statements (a procedure's body, a simple `DO`, or the program), and can give it an attribute.

- **Definition:** the declared label must label a statement at the **outer level of the same block**. A statement with that label inside a nested block is a different label, implicitly declared in that block.
- **Undefined labels:** a declared label that no statement has is an error if a GOTO uses it (or it is PUBLIC); otherwise it only gets a warning.
- **Factoring:** `DECLARE (A, B) LABEL PUBLIC;` declares each name, with the attribute.
- **`PUBLIC`:** the label is also exported under its own name, as `RESTART EQU G_RESTART`, so assembly code (your hooks) can jump to it.
- **`EXTERNAL`:** the label is an assembly-language label with exactly that name, for example an entry point in the hooks or a ROM monitor; `GOTO MONITOR` becomes `LBRA MONITOR`. It can't label a PL/M statement. A GOTO to it from inside a procedure resets the stack first, as for a GOTO out of a procedure.
- **Rules:**
  - no dimension, `BASED`, type or initialization;
  - PUBLIC and EXTERNAL labels only at the outer level of the main program;
  - their names can't be 6809 register names, and must not clash with other labels in the assembly (such as hook entry points).

4.14 Iterative DO

```
DO I = 1 TO 10;
    TOTAL = TOTAL + I;
END;

DO I = 1 TO 2 * N - 1 BY 2;     /* odd numbers */
    PROD = PROD * I;
END;
```

The index `I` must be a scalar variable, BYTE or ADDRESS (not an array element). The loop works exactly as described in the PL/M-80 manual:

1. **Start:** `start` is evaluated **once**, converted to the index's type, and assigned to the index.

2. **Test:** `limit` is evaluated and converted to the index's type. If the index is **greater than** the limit, the loop ends.
3. **Body:** the statements in the block run.
4. **Step:** `step` (1 if there's no `BY`) is evaluated and converted to the index's type, and added to the index. If the addition **wraps around** past 255 (BYTE) or 65535 (ADDRESS), the loop ends. Otherwise it goes back to step 2.

Things that follow from these rules:

- **Re-evaluation:** the limit and the step are evaluated on *every* pass, so changing a variable they use inside the body changes the loop.
- **Final value:** after a normal exit the index is the first value past the limit. `DO I = 1 TO 10` leaves `I` = 11.
- **Wrap-around:** a BYTE loop `DO I = 0 TO 255` runs 256 times and ends because the increment wraps, leaving `I` = 0. Without the wrap rule it would never end.
- **Conversions:** these can surprise you. With a BYTE index, a limit of 300 becomes 44.
- **No counting down:** arithmetic is unsigned, so `BY -1` on a BYTE index means `BY 255`, and a start above the limit runs the body zero times.
- **Step of zero:** this gives an endless loop unless the limit is passed some other way.

4.15 DO CASE

```
DO CASE SCORE;
    ;                              /* 0: nothing */
    CONVERSIONS = CONVERSIONS + 1;  /* 1 */
    SAFETIES = SAFETIES + 1;        /* 2 */
    DO;                             /* 3: several statements */
        FIELDGOALS = FIELDGOALS + 1;
        POINTS = POINTS + 3;
    END;
END;
```

- **Choosing a case:** the selector expression is evaluated once, and statement number *selector* runs, counting from **0**. Exactly one statement runs, then control continues after `END`.
- **Null and grouped cases:** a null statement `;` is a case that does nothing. Use a `DO; ... END;` block to make one case of several statements.
- **Out of range:** a selector of the number of cases or more is undefined in PL/M. **plmc runs no case**: it range-checks the selector and skips the block.

4.16 Expressions

Operators, from highest to lowest precedence:

Precedence	Operators	Notes
1 (highest)	`( )`	grouping
2	unary `-`, unary `+`	negation (two's complement)
3	`* / MOD`	multiply, divide, remainder
4	`+ - PLUS MINUS`	add, subtract; add with carry, subtract with borrow
5	`= <> < > <= >=`	comparisons
6	`NOT`	bitwise complement

Precedence	Operators	Notes
7	`AND`	bitwise and
8 (lowest)	`OR XOR`	bitwise or, exclusive or

- **Grouping:** operators of equal precedence group left to right, so `A - B - C` is `(A - B) - C`. Comparisons do too: `A < B = C` compares the result of `A < B` with `C`.
- **Low precedence of `NOT`:** `NOT` binds more loosely than the comparisons, so `NOT A < B` means `NOT (A < B)`.
- **Evaluation order:** the order in which operands are evaluated is not defined, as in PL/M. Avoid expressions where a procedure call changes a variable used elsewhere in the same expression. (plmc evaluates the right operand of a binary operator before the left one; only PLUS and MINUS can tell the difference without calls, see below.)

4.16.1 PLUS and MINUS

```
DECLARE (AL, AH, BL, BH, SL, SH) ADDRESS;     /* 32-bit numbers AH:AL ... */
SL = AL + BL;
SH = AH PLUS BH;                              /* SH:SL = AH:AL + BH:BL */
```

`A PLUS B` is `A + B + carry`, and `A MINUS B` is `A - B - borrow` (PL/M-80 manual 12.2). They have the precedence and the result types of `+` and `-`, and are meant for arithmetic on numbers wider than 16 bits, low part first.

On the 8080 the carry is the CPU's flag, so the manual warns that the result can't be predicted. plmc defines it instead, as described in The flags: the carry is the one out of the last `+`, `-`, `PLUS`, `MINUS`, `SCL`, `SCR` or `DEC` executed, and nothing else changes it.

4.16.2 HIGH, LOW, DOUBLE, SHL, SHR, ROL and ROR

These PL/M-80 built-in procedures (manual 11.1.3 and 11.1.4) are used in expressions:

Call	Type	Value
`HIGH(x)`	BYTE	the high byte of an ADDRESS; 0 for a BYTE
`LOW(x)`	BYTE	the low byte of an ADDRESS; a BYTE unchanged
`DOUBLE(x)`	ADDRESS	a BYTE zero-extended; an ADDRESS unchanged
`SHL(p, n)`, `SHR(p, n)`	the type of `p`	`p` shifted left or right by `n` bits, zeros shifted in
`ROL(p, n)`, `ROR(p, n)`	BYTE	`p`, converted to BYTE, rotated left or right by `n` bits

- **Examples** from the manual: `ROR(10011101B, 1)` is `11001110B`, and `ROL(10011101B, 2)` is `01110110B`.
- **The count `n`** is any expression, converted to BYTE. A count of 0 is undefined in PL/M-80; plmc returns `p` unchanged. Shifting by the width or more gives 0, and rotating by 8 gives `p` back.
- **Types matter:** `SHL(1, 8)` is 0, because the constant 1 is a BYTE; write `SHL(DOUBLE(1), 8)` for 256. Likewise `HIGH(W) + LOW(W)` is BYTE arithmetic.
- **Your own names win:** like `LENGTH`, these names are built-ins only where they aren't declared, so a program can still declare its own `HIGH` procedure or a variable called `LOW`.

- **On every target:** they compile to inline code (shifts, rotates and `TFR`s, with a short loop for a computed count), not to calls, so they need nothing from the hooks and work the same in `--os9` modules. They don't change the flags (see below).

4.16.3 The flags: CARRY, ZERO, SIGN, PARITY, SCL, SCR and DEC

```
S(0) = DEC(X(0) + Y(0));                /* BCD: two digits per BYTE */
S(1) = DEC(X(1) PLUS Y(1));
IF CARRY THEN CALL OVERFLOW;
```

PL/M-80's chapter 12 gives access to the 8080's flags, warning that the compiler's optimizations make them unpredictable. plmc keeps them in memory instead, so they are exact:

- **What sets them:** the last `+`, `-`, `PLUS`, `MINUS`, `SCL`, `SCR` or `DEC` executed, at its width (8 bits for a BYTE operation, 16 for an ADDRESS one). Before any of them the carry is 0 and the result 0.
- **Nothing else changes them:** not comparisons, `*`, `/`, `MOD`, logical operators, shifts, assignments, calls, loops (the `+` that steps an iterative `DO` doesn't count), or interrupt procedures (their entry code saves and restores them). They are kept across statements and procedure calls.
- **Within an expression,** the right operand is evaluated first (and a count before its pattern): in `(1 PLUS 1) PLUS (200 + 100)`, `200 + 100` sets the carry used by `1 PLUS 1`.
- **To test a value,** add 0 to it: `B = B + 0; IF PARITY THEN ...`.

Built-in	Type	Value
`CARRY`	BYTE	`0FFH` if the carry (or borrow) is set, else 0
`ZERO`	BYTE	`0FFH` if the result was 0
`SIGN`	BYTE	`0FFH` if the result's top bit (bit 7 of a BYTE, 15 of an ADDRESS) is set
`PARITY`	BYTE	`0FFH` if the result's low byte has an even number of 1 bits
`SCL(p, n)`, `SCR(p, n)`	the type of `p`	`p` rotated left or right `n` times *through the carry*: a 9-bit rotation for a BYTE, 17-bit for an ADDRESS. The carry goes in at one end, and the bit that leaves the other end becomes the carry
`DEC(x)`	BYTE	decimal adjust of `x` (converted to BYTE) after a BYTE addition of two BCD numbers, with the 6809's `DAA`, using that addition's carry and half carry. It sets the carry if the decimal result overflows

- **DEC** only makes sense right after a BYTE `+` or `PLUS`, as in `DEC(A + B)`: the half carry it needs is only kept for BYTE operations (after an ADDRESS one, or a subtraction, it is undefined).
- **SCL and SCR** with a count of 0 return `p` and leave the carry as it was; `SCL(W, 1)` followed by `SCL(V, 1)` shifts the 32-bit number V:W left.
- **Cost:** only programs that use these (or PLUS and MINUS) keep the flags, after each `+`, `-`, `PLUS`, `MINUS`, `SCL`, `SCR` and `DEC`: one `ROL` for the carry (two instructions instead for BYTE operations when `DEC` is used), and one or two stores of the result when `ZERO`, `SIGN` or `PARITY` is used.

4.16.4 INPUT and OUTPUT: not supported

PL/M-80's `INPUT(port)` and `OUTPUT(port)` use the 8080's `IN` and `OUT` instructions and its separate space of 256 I/O ports. The 6809 has no I/O instructions and no port space, only memory-mapped devices, so plmc doesn't provide them. A program that uses either without declaring it gets

```
INPUT is not supported: the 6809 has no I/O ports; declare a BYTE variable AT the device's address
```

Declare the device's registers AT their address instead, as a BYTE variable or array:

```
DECLARE IO(16) BYTE AT (0FF00H);    /* sim6809's I/O block */
IO(0) = 'A';                        /* print a character */
C = IO(1);                          /* read one */
```

Since they aren't built in, `INPUT` and `OUTPUT` are ordinary names that a program may declare for its own variables or procedures.

4.16.5 MOVE and TIME

- `CALL MOVE(count, source, destination);` copies `count` bytes from the address `source` to the address `destination`, first byte first. All three are ADDRESS values; a count of 0 copies nothing. If the areas overlap with the destination above the source, bytes are copied that have already been overwritten (the manual leaves overlap undefined).
- `CALL TIME(n);` waits `n` × 100 microseconds (`n` is converted to BYTE, so at most 25.5 ms). It is a loop timed in CPU cycles, from the hooks' `RT_CYCLES100` (cycles in 100 µs): 89 on a CoCo at 0.895 MHz, 179 for NitrOS-9's 1.79 MHz CoCo 3, 100 (1 MHz) for the example board. Each 100 µs step is a multiple of 8 cycles, the nearest one (88 cycles, 98 µs, on a CoCo). Interrupts make the wait longer. The simulator has no timing, so there `TIME` only runs the loop.

4.16.6 MEMORY and STACKPTR

- `MEMORY` is a BYTE array of unknown length: the memory after the program's own. `.MEMORY` is its address; `MEMORY(i)` can be read and written, with any subscript. `LENGTH`, `LAST` and `SIZE` can't be used on it.
  - In a normal program it starts right after the variables and constant lists (`RT_MEMORY EQU *`) and runs up to whatever comes next (on the simulator, the stack below `$FF00`; on a CoCo started as described in Running on a Color Computer, RAM up to `$7FFF`).
  - In an `--os9` module it is `--memory N` bytes of the data area (default 0), after the variables and before the stack.
- `STACKPTR` is an ADDRESS variable that is the S register: reading it gives S (`TFR S,D`) and assigning it sets S (`TFR D,S`). As the manual warns, moving the stack is at your own risk; a later `RETURN` uses the stack as it then is.
- Like the built-in procedures, these names can be declared by the program, which then hides them.

4.17 Types and conversions

The type of every expression is worked out at compile time:

Expression	Result type
constant 0–255	BYTE
constant 256–65535, or a two-character string	ADDRESS
variable, or array element	its declared type
structure member `X.M`, `X(i).M(j)`	the member's type
`LENGTH(A)`, `LAST(A)`	BYTE if 255 or less, otherwise ADDRESS
`HIGH(x)`, `LOW(x)`, `ROL(p, n)`, `ROR(p, n)`	BYTE
`DOUBLE(x)`	ADDRESS
`SHL(p, n)`, `SHR(p, n)`, `SCL(p, n)`, `SCR(p, n)`	the type of `p`
`DEC(x)`, `CARRY`, `ZERO`, `SIGN`, `PARITY`	BYTE
`STACKPTR`	ADDRESS
`SIZE(X)`	ADDRESS
typed procedure call	the procedure's type
`a + b`, `a - b`, `a PLUS b`, `a MINUS b`, `a MOD b`, `a AND b`, `a OR b`, `a XOR b`	BYTE if *both* operands are BYTE, otherwise ADDRESS
`a * b`, `a / b`	always ADDRESS
`a = b`, `a < b`, …	BYTE: `0FFH` for true, `0` for false
`-a`, `NOT a`	the type of `a`

Rules that follow from this table:

- **BYTE arithmetic wraps at 8 bits, before any widening.** If `B` is a BYTE holding 200, `B + 100` is 44, *even when the result is assigned to an ADDRESS*. When you need the full result, make one operand an ADDRESS, for example by copying `B` into an ADDRESS variable first: `W = B; W = W + 100;`.
- **A constant above 255 makes the operation 16-bit.** `B + 300` is ADDRESS arithmetic.
- **Multiplication never wraps at 8 bits.** `200 * 200` is 40000.
- **Unsigned only.** All arithmetic and comparisons are unsigned. `0FFFFH > 1` is true.
- **Assignment converts:** an ADDRESS stored in a BYTE keeps its low byte, and a BYTE stored in an ADDRESS is zero-extended. The same applies to arguments and `RETURN` values.
- **Division by zero** gives a quotient of `0FFFFH` and a remainder equal to the dividend. Programs should not rely on this.

4.18 Conditions

`IF` and `DO WHILE` test **only bit 0** of their condition. A comparison gives `0FFH` or `0`, so this works as expected for comparisons and for `AND`, `OR` and `NOT` applied to them. For other values it means `IF 2` is false and `IF 3` is true. `AND` and `OR` always evaluate both operands; they do not short-circuit.

4.19 Unsupported features

These parts of PL/M-80 are recognized and rejected with an error:

Feature	Error message
`PUBLIC` or `EXTERNAL` on a variable	`PUBLIC on a variable is not supported`, `EXTERNAL on a variable is not supported`
embedded assignment `:=`	`embedded assignment ':=' is not supported`
a string of three or more characters used as a value	`strings longer than 2 characters are not supported`

All of PL/M-80's built-in procedures (LENGTH, LAST, SIZE, HIGH, LOW, DOUBLE, SHL, SHR, ROL, ROR, SCL, SCR, DEC, CARRY, ZERO, SIGN, PARITY, MOVE, TIME) and predeclared variables (MEMORY, STACKPTR) are provided, except the 8080 port I/O INPUT and OUTPUT (see INPUT and OUTPUT: not supported).

5 Diagnostics

Errors and warnings go to standard error in the form `file:line:column: error: message`:

```
$ build/plmc e1.plm
e1.plm:3:5: error: Y is not declared
```

Compilation stops at the first error. Warnings don't stop compilation and don't change the exit status. Columns count from 1, and tabs advance to the next multiple of 8 plus 1.

Message	Cause
`expected X, found Y`	syntax error; *X* is what the parser needed at this point
`X is not declared`	name used before (or without) its declaration
`X is already declared at line N`	second declaration in the same scope
`parameter X of P is not declared`	parameter without a `DECLARE` in the procedure
`procedure P expects N arguments, got M`	wrong number of arguments
`X is not a procedure`	`CALL X` where X is a variable
`X is not a procedure or an array`	`X(...)` in an expression where X is a scalar variable
`X is not an array`	`X(i) = ...` where X is a scalar
`array A takes exactly one subscript` / `an array takes exactly one subscript`	`A(i, j)` in an expression / as a target
`array dimension must be from 1 to 65535, expected an array dimension (a number), found ...`	dimension 0, or not a number
`array X is too large (more than 65535 bytes)`	e.g. `DECLARE X(40000) ADDRESS`
`parameter X cannot be an array`	a parameter declared with a dimension
`LENGTH needs the name of a variable` (or `LAST`, `SIZE`)	argument isn't a declared variable
`HIGH takes one argument` (or `LOW`, `DOUBLE`, `DEC`, `TIME`), `SHL takes two arguments, a pattern and a count` (or `SHR`, `ROL`, `ROR`, `SCL`, `SCR`), `CARRY takes no arguments` (or `ZERO`, `SIGN`, `PARITY`), `MOVE takes three arguments, ...`	wrong number of arguments to a built-in
`built-in LOW returns a value and must be used in an expression, not CALLed`	`CALL` of a typed built-in
`built-in TIME is untyped, so it can't be used in an expression (use CALL TIME)`	`TIME` or `MOVE` in an expression
`INPUT is not supported: the 6809 has no I/O ports; declare a BYTE variable AT the device's address` (or `OUTPUT`)	an undeclared `INPUT` or `OUTPUT`
`LENGTH can't be used with MEMORY, whose size isn't known` (or `LAST`, `SIZE`; `STACKPTR`)	a built-in on a predeclared variable
`STACKPTR is not a procedure or an array`	`STACKPTR(...)`
`plmc: --memory is only used with --os9 ...`	`--memory` without `--os9`

Message	Cause
`structure X cannot be used as a value; select a member, as in X.M`	a whole structure, or a structure array's element, as a value or target
`X is not a structure, structure X has no member M`	bad member reference
`X is an array of structures: select one, as in X(i).M`	`X.M` without the array's subscript (outside the built-ins)
`X is not an array, X.M is not an array`	a subscript on something that isn't an array
`structures cannot be nested ..., structure members cannot be factored, a structure member cannot be BASED, member M is declared twice`	bad member list
`parameter X cannot be a structure`	a structure declared as a parameter
`a BASED variable cannot be declared AT, AT cannot be used with DATA, parameter X cannot be declared AT`	`AT` in the wrong place
`AT needs a number or the location of a variable`	e.g. `AT (.P)` for a procedure, or `AT (.(1, 2))`
`an AT address must be a number or a location reference plus or minus numbers, subscripts in an AT address must be constants, an AT address cannot use the address of a BASED variable`	e.g. `AT (2 * 100H)`, `AT (.B(I))`
`literal X expands recursively (more than 32 levels)`	a literal whose text uses itself
`a LITERALLY declaration cannot be factored, ... cannot have a dimension`	`DECLARE (A, B) LITERALLY ...`, `DECLARE A(3) LITERALLY ...`
`expected a string, found ...`	`LITERALLY` not followed by a string
`strings are limited to 255 characters`	a string over 255 characters
`strings longer than 2 characters are not supported`	a long string used as a value (it can be used in `INITIAL`/`DATA`, `.(...)` and `LITERALLY`)
`INITIAL is only allowed at the outer level of the main program (use DATA)`	`INITIAL` in a procedure or a `DO` block
`more initial values than scalars to initialize`	the list is longer than the declaration
`an initial value for a BYTE must be from 0 to 255, an address can only initialize an ADDRESS`	value doesn't fit its scalar
`an initial value must be a number, a string, or a location reference plus or minus numbers`	e.g. `INITIAL (X + 1)` or `INITIAL (2 * 3)`
`subscripts in an initial value must be constants, an initial value cannot use the address of a BASED variable`	bad location reference
`an implicit dimension (*) needs INITIAL or DATA, (*) cannot be used ...`	`(*)` without a list, factored, for a structure array or member
`X is DATA and cannot be assigned`	assignment to a DATA variable
`a BASED variable cannot be initialized, parameter X cannot be initialized`	initialization not allowed there
`DATA in an --os9 module cannot hold addresses (use INITIAL)`	see OS-9 modules
`the index of an iterative DO must be a scalar variable`	`DO A = ...` where A is an array, a procedure, BASED, or undeclared

Message	Cause
`L is not a label`	`GOTO X` where X is a variable or procedure
`label L is declared here but no statement at the outer level of this block has it`	a declared label used by a GOTO (or PUBLIC) but never defined
warning: `label L is declared but never used`	a declared label that is neither defined nor used
`L is declared LABEL EXTERNAL, so it cannot label a statement here`	definition of an EXTERNAL label
`PUBLIC and EXTERNAL labels must be declared at the outer level of the main program`, `a LABEL declaration cannot have a dimension`, `a LABEL declaration cannot be BASED`	LABEL in the wrong place or with the wrong options
`PUBLIC name X is also a 6809 register name`, `EXTERNAL name X is also a 6809 register name`	a label or procedure name the assembler would misread
`a PUBLIC procedure must be declared at the outer level of the module`, `a procedure cannot be both PUBLIC and EXTERNAL`	PUBLIC in the wrong place
`plmc: --obj cannot be combined with --os9, --org or --vectors ...`	`--obj` modules are placed by lwlink
`MEMORY cannot be used with --obj ...`, `INITIAL ... AT cannot be used with --obj ...`	not available in object modules
`an INTERRUPT procedure must be in the main module (the one with statements), which installs it`	INTERRUPT in a non-main `--obj` module
`a GOTO out of a procedure must go to a label at the outer level of the main program`	the target is in an enclosing procedure, or in a block of the main program
`a label must be followed by a statement (use 'L: ;')`	a label right before `END`
`L is a label, not a variable or procedure`, `cannot assign to label L`	a label used as a value
`P, the base of X, is not declared`	`BASED` names an undeclared base
`the base of a BASED variable must be an ADDRESS scalar that is not itself BASED`	base is BYTE, an array, a procedure, or BASED
`parameter X cannot be BASED`, `a LITERALLY declaration cannot be BASED`	`BASED` in the wrong place
`the dot operator needs a variable, an array element or a procedure`	e.g. `.LENGTH(A)`
`the address of a procedure needs a procedure declared at the outer level, written without arguments`	`.P` for a nested procedure, or `.P(1)`
`a number in a constant list must fit in a byte`, `expected a number or a string, ...`	bad item in `.(...)`
`typed procedure F must be used in an expression, not CALLed`	`CALL` of a BYTE or ADDRESS procedure
`untyped procedure P cannot be used in an expression`	value taken from an untyped procedure
`cannot assign to procedure P`	procedure name on the left of `=`
`RETURN outside a procedure`	`RETURN` in the main program
`untyped procedure P cannot return a value` / `RETURN in typed procedure F needs a value`	`RETURN` does not match the procedure's type
`procedure P is recursive (...) but not REENTRANT`	direct or indirect recursion through a procedure that is not REENTRANT

Message	Cause
X is not declared (only a REENTRANT procedure can use a REENTRANT procedure declared after it)	a REENTRANT procedure used before its declaration outside a REENTRANT procedure
a REENTRANT procedure must be declared at the outer level of the main program, REENTRANT procedure P cannot contain procedure declarations, an EXTERNAL procedure cannot be REENTRANT	REENTRANT in the wrong place
the variables of REENTRANT procedure P take more than 32767 bytes	too big a stack frame
INTERRUPT n: the 6809's interrupts are 0 (IRQ), 1 (FIRQ) and 2 (NMI), an INTERRUPT number must be from 0 to 255	bad interrupt number
INTERRUPT n is already used by procedure P	two procedures for one interrupt
INTERRUPT procedure P must be untyped and have no parameters, an INTERRUPT procedure must be declared at the outer level of the main program, an EXTERNAL procedure cannot be an INTERRUPT procedure	INTERRUPT in the wrong place
INTERRUPT procedures cannot be used in an --os9 module, ENABLE and DISABLE cannot be used in an --os9 module	see OS-9 modules
END X does not match ...	label after END differs from the block or procedure
declarations must come before statements	DECLARE or procedure after the first statement
declarations are only allowed in procedures and simple DO blocks	DECLARE inside DO WHILE
an EXTERNAL procedure may only declare its parameters / ... cannot have statements	body of an EXTERNAL procedure
EXTERNAL name X is also a 6809 register name	external called A, X, PC, …
invalid digit, invalid number, number ... does not fit in 16 bits	bad numeric constant
invalid character, unterminated comment, unterminated string, empty string	lexical errors
cannot find INCLUDE file 'X'	no such file in the including file's directory or a -I directory, as written or in lower case
INCLUDE needs a file name in parentheses, as in $INCLUDE(FILE.PLM), INCLUDE file name without a closing ')', INCLUDE needs a file name	a malformed $INCLUDE line
INCLUDE must be the last control on its line	text after $INCLUDE(...)
INCLUDE files nested more than 16 deep (does a file include itself?)	INCLUDE recursion
a control name is expected after '$'	a control line without a control name
control X without a closing ')'	an ignored control's argument runs to the end of the line
warning: control X ignored (only INCLUDE has an effect)	any control other than INCLUDE
warning: typed procedure F may reach its END without RETURN	last statement is not RETURN or HALT
plmc: --org and --vectors cannot be used with --os9 ...	OS-9 modules have no fixed address

Message	Cause
`plmc: --stack is only used with --os9, --name is only used with --os9`	option without `--os9`
`plmc: bad --stack size ..., bad --name ...`	stack below 32 bytes, or an invalid module name

6 Hooks

6.1 How targets are selected

The assembly plmc writes always ends with:

```
INCLUDE "plm_rt.asm"
INCLUDE "plm_hooks.asm"
```

lwasm searches its `-I` directories for these files. `plm_rt.asm` and `plm_crt0.asm` come from `runtime/`. Which `plm_hooks.asm` is used depends on which hooks directory is on the include path, so **the same `.asm` file can be assembled for different machines** without recompiling:

```
lwasm -9 -f srec -I runtime -I runtime/sim  -o prog.s19 prog.asm   # simulator
lwasm -9 -f decb -I runtime -I runtime/coco -o PROG.BIN prog.asm   # CoCo
```

6.2 What a hooks file must define

Symbol	Purpose
`RT_STACKTOP`	Initial stack pointer; the stack grows down from here. The value 0 means "keep the caller's stack".
`PLM_EXIT`	Jumped to when the program ends, with the exit status in B (0 for a normal end). Must not return.
`PLM_HALT`	Jumped to by `HALT`.
`RT_CYCLES100`	Only for programs that use `TIME`: CPU (E clock) cycles in 100 microseconds.
`PLM_SETINT`	Only for programs with INTERRUPT procedures: called at start-up with B = the interrupt number (0 IRQ, 1 FIRQ, 2 NMI) and X = the entry routine; it must make that interrupt go to X. May change any register but S.
each `EXTERNAL`	A label with the procedure's PL/M name in upper case.

The startup code saves the stack pointer it was entered with in `RT_ENTRYS`. A hooks file that sets `RT_STACKTOP` to 0 can therefore return to whatever started the program (BASIC, a monitor or an operating system) with `LDS RT_ENTRYS` / `RTS`. The CoCo hooks do this.

6.3 Calling convention for EXTERNAL procedures

- **Arguments:** each one is pushed as a **16-bit word**, from left to right. BYTE values are zero-extended first.

- **Where to find them:** on entry, the last argument is at `2,S`, just above the return address, the one before it at `4,S`, and so on. The last argument is **also in D**, so most one-argument hooks never need to touch the stack.
- **Cleanup:** the caller removes the arguments after the call (`LEAS 2n,S`).
- **Results:** a BYTE result is returned in **B** and an ADDRESS result in **D**.
- **Registers:** a hook may change A, B, X, Y, U, DP and CC. Only S must be preserved. (Y is the frame pointer of REENTRANT procedures, so in a program that has any, every call of an EXTERNAL procedure is wrapped in `PSHS Y` / `PULS Y`. The arguments are still at `2,S` and up.) Keep DP at 0 if the hook calls code that relies on it. **In `--os9` modules, U must be preserved too**, because it points at the data area, and hooks must themselves be position-independent (see OS-9 modules).
- **Runtime routines:** hooks are assembled after `plm_rt.asm`, so they may call `RT_MUL16` and `RT_DIV16`.

Example: a two-argument hook `POKE(ADDR, VALUE)`:

```
; POKE: PROCEDURE (ADDR, VALUE) EXTERNAL; DECLARE ADDR ADDRESS, VALUE BYTE;
POKE    LDX     4,S         ; first argument: ADDR
        STB     ,X          ; last argument: VALUE, also in D (B = low byte)
        RTS
```

6.4 Hooks provided

All five hooks files implement the same procedures, so a program that uses only these runs unchanged on any of the targets (the table below covers four of them; for FLEX see FLEX):

```
PUTCH:  PROCEDURE (C) EXTERNAL;    DECLARE C BYTE;    END PUTCH;
PUTDEC: PROCEDURE (N) EXTERNAL;    DECLARE N ADDRESS; END PUTDEC;
GETCH:  PROCEDURE BYTE EXTERNAL;                      END GETCH;
EXIT:   PROCEDURE (CODE) EXTERNAL; DECLARE CODE BYTE; END EXIT;
```

`PUTDEC` prints a number in decimal followed by a newline. The hooks in the `sim`, `coco`, `os9` and `example` directories of `runtime/` compared:

	`sim`	`coco`	`os9`	`example`
`PUTCH`	simulator I/O port	Color BASIC CHROUT; LF sent as CR	`I$Write` to path 1; LF sent as CR	MC6850 ACIA, waits until ready to send
`GETCH`	stdin; 0 at end of input	waits for a key (POLCAT); ENTER gives 13	`I$Read` from path 0; 0 at end of file	ACIA, waits for a character
`PUTDEC`	simulator decimal port	via `RT_DIV16` and CHROUT	via `RT_DIV16`, one `I$Write`, ends with CR	via `RT_DIV16`, ends with CR LF
`EXIT`, end of program	simulator exit status	back to BASIC (status discarded)	`F$Exit` with the status	stops in a loop
`HALT`	exit status 0	back to BASIC	`F$Exit` with status 0	stops in a loop

	sim	coco	os9	example
PLM_SETINT	stores the vector at $FFF8/$FFF6/$FFFC	patches BASIC's RAM vector (JMP at $010C/$010F/$0109); PLM_EXIT restores it	(not used)	does nothing: use --vectors
RT_CYCLES100 (TIME)	100 (no real timing)	89 (0.895 MHz)	179 (1.79 MHz CoCo 3)	100 (1 MHz); override with -D
extra		CLS clears the screen		
stack	$FF00	BASIC's	in the data area (--stack)	$8000

6.5 Writing hooks for a new machine

Copy `runtime/example/plm_hooks.asm` to a directory of your own, change the I/O routines and `RT_STACKTOP`, and assemble with `-I runtime -I yourdir`. Add any extra routines your programs need as further labels, and declare them in PL/M as `EXTERNAL`. The example file's `ACIA_BASE` and `RT_STACKTOP` are wrapped in `IFNDEF`, so they can also be overridden from the lwasm command line with `-D`.

7 Object files and lwlink

A program can be split into **modules** that are compiled and assembled separately, then linked: PL/M-80's way of building larger programs. plmc's `--obj` option writes a module for lwasm's object format (`-f obj`), and lwtools' linker, `lwlink`, joins the object files into one S-record file. Modules call each other's **PUBLIC** procedures through **EXTERNAL** declarations.

7.1 An example

Two modules: `main.plm` calls `GCD`, a PUBLIC procedure of `util.plm`, and `util.plm` calls back `SHOW`, a PUBLIC procedure of `main.plm`. Each module declares the procedures it uses from the other one as EXTERNAL. (These are also in the plm09 source tree, in `contrib/obj`, with a Makefile.)

```
/* main.plm: the main module, the one with statements */
MAIN: DO;
PUTDEC: PROCEDURE (N) EXTERNAL; DECLARE N ADDRESS; END PUTDEC;    /* a hook */
GCD: PROCEDURE (A, B) ADDRESS EXTERNAL;                           /* in util.plm */
    DECLARE (A, B) ADDRESS;
END GCD;
SHOW: PROCEDURE (N) PUBLIC;                                       /* used by util.plm */
    DECLARE N ADDRESS;
    CALL PUTDEC(N);
END SHOW;
CALL SHOW(GCD(1071, 462));
END MAIN;

/* util.plm: a module of declarations only */
UTIL: DO;
```

```
SHOW: PROCEDURE (N) EXTERNAL; DECLARE N ADDRESS; END SHOW;        /* in main.plm */
GCD: PROCEDURE (A, B) ADDRESS PUBLIC;
    DECLARE (A, B, T) ADDRESS;
    DO WHILE B <> 0;
        CALL SHOW(B);
        T = A MOD B;
        A = B;
        B = T;
    END;
    RETURN A;
END GCD;
END UTIL;
```

Compile each module with `--obj`, assemble each into an object file with `-f obj`, link the object files with plm09's link script, and run the result:

```
$ plmc --obj -o main.asm main.plm
$ plmc --obj -o util.asm util.plm
$ lwasm -9 -f obj -I runtime -I runtime/sim -o main.o main.asm
$ lwasm -9 -f obj -o util.o util.asm
$ lwlink -f srec -s runtime/plm09.link -o demo.s19 main.o util.o
$ sim6809 demo.s19
462
147
21
21
```

The main module is the only one that needs the hooks directory on lwasm's include path. Changing one module means compiling and assembling only that module again, and linking.

7.2 The main module and the others

As in PL/M-80, a module whose outer level has **statements** is the **main module**; there must be exactly one in a program. The others contain only declarations: procedures, variables, literals.

- **The main module** holds the startup code (`RT_START`, the program's entry point), the main program, and the runtime routines and hooks. These are exported, so the other modules use the same copies: their calls of `RT_MUL16`, `RT_DIV16`, `RT_COPY` (MOVE) and so on, and of hook procedures such as `PUTDEC` (declared EXTERNAL, as usual), are resolved by lwlink against the main module.
- **The other modules** hold only their procedures and variables, and include nothing; lwasm takes every name a module uses but doesn't define as an import (`PRAGMA undefextern`).
- **Exported names:** each module exports only its PUBLIC procedures (and the main module also `RT_START` and the runtime and hook symbols). All other names, such as `V_X` or `P_GCD`, are local to their object file, so modules may use the same names for their own variables and procedures.
- **Sections:** code and `DATA` go in section `code`, variables with `INITIAL` values in `data`, and the other variables in `bss`. `runtime/plm09.link` loads `code` at `$0100`, then `data`, then `bss`, and makes `RT_START` the entry point (the S9 record). `runtime/coco/plm09.link` does the same from `$0E00`, for the Color Computer (see Running on a Color Computer). For another load address, copy a script and change its `load` line; `lwlink -m map.txt` shows where everything went.

7.3 Rules and limits

- A module calls another module's PUBLIC procedure through an EXTERNAL declaration with the same parameters and type. Nothing checks that the two declarations agree, as with assembly-language EXTERNAL procedures.
- A PUBLIC procedure's name must not clash with another module's PUBLIC name, or with a runtime or hook symbol (`PUTDEC`, `RT_DIV16`, …); lwlink reports such a clash.
- `INITIAL` is allowed at the outer level of every module.
- **Not available with `--obj`:** `--org` and `--vectors` (lwlink places the program), `--os9`, `MEMORY` (the end of the linked program isn't known when a module is compiled) and `INITIAL ... AT`. INTERRUPT procedures must be in the main module, which installs them.
- **The flags are per module:** the carry and result that PLUS, MINUS, CARRY, ZERO, SIGN and PARITY use are those of the last `+ - PLUS MINUS SCL SCR DEC` executed *in the same module*.

8 OS-9 modules

With `--os9`, plmc produces an **OS-9 program module** for Microware OS-9 and NitrOS-9, Level 1 or Level 2. Like every OS-9 command, the module can be loaded at any address and shared by several processes at once.

```
build/plmc --os9 -o sum.asm sum.plm
lwasm -9 -f os9 -I runtime -I runtime/os9 -o sum sum.asm
```

`lwasm -f os9` writes the finished module, with its header parity and CRC. Copy it to the `CMDS` directory of an OS-9 disk (with toolshed: `os9 copy sum disk.dsk,CMDS/sum` and `os9 attr -e -pe disk.dsk,CMDS/sum`), then run it from the shell like any other command:

```
OS9: sum
55
OS9: sum >/d0/result
```

`sim6809 --os9 sum` runs the module without OS-9, by emulating the system calls the hooks use (see the sim6809 manual).

8.1 What `--os9` changes

Position-independent code. Calls are `LBSR` rather than `JSR`, and jumps are `LBRA` rather than `JMP`. Every other branch is already relative, so the module contains no absolute addresses.

Data in the process's data area. OS-9 gives each process its own data area and points U at it.

- **Variables:** declared as `RMB` offsets inside the module (which lwasm allocates in the data area, not the module), and every access is U-relative, as in `STB V_I,U`. Because the module never writes to itself, it is reentrant.
- **Order in the source:** variables come first, so lwasm knows their offsets and uses short indexed forms.
- **Hooks and stack:** the hooks' own buffers and the stack reserve follow the code.

Startup. `runtime/plm_crt0_os9.asm` keeps the stack, U and DP that OS-9 set up, calls the program, and ends with `F$Exit`.

Not available: INTERRUPT procedures, `ENABLE` and `DISABLE` (OS-9 owns the interrupts; a user program must not mask them), and `--org`/`--vectors`. Variables `AT` a number are used at that absolute address, outside the data area. REENTRANT procedures work, with their frames on the process's stack.

Module header.

Field	Value
type/language	`$11` (Prgrm+Objct)
attributes/revision	`$81` (ReEnt, revision 1)
edition	1
data size	variables + hook buffers + `--memory` + `--stack` bytes
name	the PL/M program name, or `--name`

The beginning of the `SUM` example compiled with `--os9`:

```
        PRAGMA  6809
        MOD     RT_EOM,RT_NAME,$11,$81,RT_START,RT_SIZE

; variables (data area, U-relative)
V_I     RMB     1
V_TOTAL RMB     2

RT_NAME FCS     /SUM/
        FCB     1               ; edition
        INCLUDE "plm_crt0_os9.asm"

; program SUM
PLM_MAIN
; 4: TOTAL = 0;
        LDB     #$00
        CLRA
        STD     V_TOTAL,U
...
RT_MEMORY RMB   0               ; MEMORY (--memory)
RT_STACK RMB    256             ; stack space (--stack)
RT_SIZE EQU     .               ; data area size
        EMOD
RT_EOM  EQU     *
```

8.2 Module names

OS-9 finds a command by the **module name** inside the file, and expects it to match the file name in `CMDS`. By default plmc uses the PL/M program name.

- **Matching the file name:** use `--name` to give the module the name of the file you'll install, for example `--name sum`.
- **Avoiding clashes:** if a module with the same name is already in memory (or in the boot file), OS-9 runs *that* module instead. A PL/M program called `ECHO`, for instance, would run NitrOS-9's own `echo` command. Choose a program name, or `--name`, that doesn't clash.

Module names are 1 to 29 characters: a letter followed by letters, digits, `_`, `.` or `$`.

8.3 The OS-9 hooks

`runtime/os9/plm_hooks.asm` provides `PUTCH`, `GETCH`, `PUTDEC` and `EXIT`. They use these system calls:

Hook	System call
`PUTCH`, `PUTDEC`	`I$Write` on path 1 (standard output)
`GETCH`	`I$Read` on path 0 (standard input)
`EXIT`, end of program, `HALT`	`F$Exit`, which gives the shell the exit status

- **Newlines:** OS-9 ends lines with CR, so `PUTCH(10)` is sent as CR and `PUTDEC` ends its number with CR. Terminals add the line feed, and files get standard OS-9 text. Programs written for the simulator therefore print the same way under OS-9.
- **End of input:** `GETCH` returns 0 at end of file (`E$EOF`).
- **Errors:** any other I/O error ends the program with the OS-9 error code as its exit status, which the shell reports as `ERROR #nnn`.
- **Redirection:** standard input and output can be redirected as usual, for example `sum <data >/d0/out`.

INITIAL and DATA in modules.

- **DATA** is stored in the module, which is read-only and shared, and is read PC-relative (`V_X,PCR`). Its values can't include addresses, because those depend on where each process's data area is: use `INITIAL` for pointer tables.
- **INITIAL** variables live in the process's data area, which OS-9 creates fresh for every run. plmc stores their values in the module as a template. At start-up the program copies the template into the data area (the `RT_COPY` runtime routine) and then computes and stores any initial addresses, so they are right wherever the module and data area are.

Rules for your own OS-9 hooks:

- **Calls and jumps:** use only relative ones (`BSR`/`LBSR`/`BRA`/`LBRA`, or `JSR label,PCR`).
- **Data:** put it in `RMB` storage and address it through U (`LEAX buf,U`).
- **Registers:** preserve U and S.
- **System calls:** use `OS9 F$xxx`, which lwasm assembles as `SWI2` plus the function code.

9 Running on a Color Computer

```
build/plmc --org 3000H -o hello.asm hello.plm
lwasm -9 -f decb -I runtime -I runtime/coco -o HELLO.BIN hello.asm
```

Copy `HELLO.BIN` to a disk or disk image (for example with toolshed: `decb copy -2 -b HELLO.BIN disk.dsk,HELLO.BIN`), then in BASIC:

```
CLEAR 200,&H2FFF
LOADM"HELLO":EXEC
```

- **Load address:** always give `--org`. The default `$0100` would overwrite BASIC's RAM interrupt vectors. `CLEAR 200,&H2FFF` stops BASIC from using memory from `$3000` up.
- **Reset vector:** never use `--vectors` on a CoCo; `$FFFE` is in ROM.
- **Running and returning:** the program runs with DP = 0 on BASIC's own stack, and returns to BASIC when it ends, on `HALT`, or on `EXIT`.

- **Newlines:** Color BASIC ignores the LF character, so `PUTCH(10)` is sent as CR, the CoCo's newline. A program written for the simulator therefore prints the same way on the CoCo.
- **Lower case:** on a CoCo 1 or 2, lower-case letters appear as inverse video.
- **Interrupts:** an INTERRUPT procedure replaces BASIC's handler while the program runs, through the RAM vectors at `$0109`–`$0111`. The 60 Hz IRQ comes from PIA 0's field-sync input, which BASIC leaves enabled, and must be acknowledged by reading `$FF02` (`DECLARE PIA0B BYTE AT (0FF02H)`). BASIC's own IRQ work (`TIMER`, `PLAY`, the disk motor timeout) pauses until the program ends, when `PLM_EXIT` restores the vectors and returns to BASIC with IRQ enabled and FIRQ disabled.

Object files. A program of several modules (see Object files and lwlink) is linked for the CoCo with `runtime/coco/plm09.link`, which loads the code at `$0E00`, followed by the data and variables, and makes `RT_START` the entry point. lwlink writes the `.BIN` file itself:

```
plmc --obj -o main.asm main.plm
plmc --obj -o util.asm util.plm
lwasm -9 -f obj -I runtime -I runtime/coco -o main.o main.asm
lwasm -9 -f obj -o util.o util.asm
lwlink -f decb -s runtime/coco/plm09.link -o DEMO.BIN main.o util.o
```

and on the CoCo `LOADM"DEMO":EXEC`. Under Disk Extended Color BASIC, `$0E00` is where the four graphics pages reserved by default (PCLEAR 4) begin, and the BASIC program starts at `$2600`. A program that doesn't use PMODE graphics can live there without a `CLEAR`, as long as its code, data and variables end below `$2600`; `lwlink -m map.txt` shows where they end. List the main module first, so the code starts with `RT_START`.

The test suite checks these hooks in two ways. They run in the simulator against a stand-in for the BASIC ROM (also with an `--obj` program linked at `$0E00`). They also run on an emulated CoCo 2 under XRoar: each program is loaded from a disk image with `LOADM` and `EXEC`, and the text screen is compared with what's expected. That includes the `--obj` program, as the `.BIN` that `lwlink -f decb -s runtime/coco/plm09.link` writes, loaded at `$0E00` under Disk Extended Color BASIC 1.1.

10 FLEX

```
build/plmc -o hello.asm hello.plm
lwasm -9 -f srec -I runtime -I runtime/flex -o hello.s19 hello.asm
srec2flex hello.s19 HELLO.CMD
```

Copy `HELLO.CMD` to a FLEX disk and type `HELLO` at the `+++` prompt. `sim6809 --flex HELLO.CMD` runs it in the simulator instead.

- **Any FLEX 9 system:** the hooks use only the DOS entry points of FLEX's jump table at `$CD00`, which are the same on every 6809 FLEX (SWTPC, Gimix, CoCo, Dragon and others):

Hook	FLEX routine
`PUTCH`	`PUTCHR` (`$CD18`); LF (10) as `PCRLF` (`$CD24`), which also honors TTYSET's nulls and paging

Hook	FLEX routine
GETCH	GETCHR ($CD15): waits for a key, RETURN gives 13; most terminals echo it. When input is redirected to a file (FLEX's I command), the next byte is read with FMS ($D406) instead, so the end of the file gives 0 rather than FLEX's READ PAST END OF FILE error, which would end the program
PUTDEC	OUTDEC ($CD39) and PCRLF
EXIT, end of program, HALT	WARMS ($CD03), back to the +++ prompt; FLEX has no exit status
RT_CYCLES100 (TIME)	100, a 1 MHz CPU
stack	RT_STACKTOP = $C700, the top of FLEX's utility command area ($C100–$C6FF), which belongs to the running command. Not the top of user RAM: EXEC, print spoolers and other resident tools put themselves there (lowering the memory end at $CC2B), and a stack there would overwrite them

RT_CYCLES100 and RT_STACKTOP depend on the machine; give yours to lwasm with -D, for example -DRT_CYCLES100=200 for 2 MHz.

- **srec2flex** (from sim6809) turns lwasm's S-records into a FLEX binary file: $02 records (address, count, up to 252 bytes) for the loaded bytes, and a $16 transfer address record from the S9 entry address, which makes it a command. lwasm has no FLEX output format of its own.
- **Load address:** FLEX's user RAM is $0000–$BFFF, so the default --org ($0100) is fine. The program, its variables and MEMORY must stay below the memory end at $CC2B ($BFFF with nothing resident). FLEX's own commands run in the utility command area (--org C100H); a PL/M program can too, but then move the stack (-DRT_STACKTOP=...).
- **Not provided:** PLM_SETINT, since where a FLEX machine's interrupt vectors are, and what its drivers use them for, depends on the machine. A program with INTERRUPT procedures fails to assemble until you add one.

Two test suites check these hooks:

- **flex** runs every run program and 25 fuzz programs as commands in sim6809 --flex, which emulates FLEX's entry points and stops a program that writes into FLEX's memory.
- **dragonflex** runs the run programs on real FLEX: Compusense FLEX for the Dragon 64 (System v1.3.2, whose FLEX_1.3.2.VDK matches MAME's dragon_flex software list), booted from DragonDOS under XRoar.
  - The disk image comes from $FLEX_DISK (default ~/coco/flex/FLEX_1.3.2.VDK); the suite is skipped without it or XRoar. tools/flexdisk.py lists, reads and writes files on FLEX disk images.
  - On a copy of the disk, each program becomes Tnn.CMD, and STARTUP EXECs a command file that runs P,MARK (a separator line) and P,Tnn for each, then DONE. P sends a command's output to the printer, which XRoar appends to a file (-lp-file); DONE, at $C600, is where XRoar traps and quits.
  - This FLEX asks for the date when it boots, and XRoar's -type only reaches BASIC's keyboard routine, not FLEX's driver. So the copy's boot image (the FLEX that DragonDOS loads, from track 1 sector 1) is patched not to ask: its JSR to the prompt becomes NOPs.
  - Programs that read input are skipped: FLEX's I command resets the printer output that P set up. FLEX has no exit status, so statuses aren't compared.

11 Simon6809

```
build/plmc --org 0400H -o hello.asm hello.plm
lwasm -9 -f srec -I runtime -I runtime/simon6809 -o hello.s19 hello.asm
```

The Simon6809 is Erturk Kocalar's 6809 board of 2007 (github.com/drpeker/simon6809-ROM-Monitor): a 6809 at 1 MHz, 32 KB of RAM, an FT245RL USB FIFO as the console, and the BUGGY monitor (Lennart Benschop's sbc09 monitor, ported) in ROM at `$E000`.

- **Loading and running:** at the monitor's `.` prompt, send the S1 and S9 lines of `hello.s19` (the monitor rejects the S0 and S5 records that lwasm also writes, harmlessly), then type `G400`. When the program ends it returns to the monitor, which shows the registers (B is the exit status) and prompts again.
- **Load address:** always `--org 0400H`. The monitor uses `$0000`–`$03FF`; RAM ends at `$7FFF`, where the stack starts.
- **Console:** `PUTCH`, `GETCH` and `PUTDEC` use the monitor's I/O vectors in RAM (`getchar` at `$001B`, `putchar` at `$001E`, `putcr` at `$0027`). LF is sent as the monitor's CR LF; RETURN gives 13; `GETCH` waits for a character.
- **Return to the monitor:** `SWI`, which the monitor takes as a breakpoint, so this works whether the program was started with `G` or `J`.
- **Interrupts:** `PLM_SETINT` points the monitor's RAM vectors (JMPs at `$0009` IRQ, `$0006` FIRQ, `$000F` NMI) at the INTERRUPT procedures and puts them back at the end. FIRQ is the console's "data available" interrupt: a program that takes it over shouldn't use `GETCH`.
- **Other values:** `RT_CYCLES100` = 100 (a 4 MHz crystal, 1 MHz E clock).

The `simon6809` test suite runs every `run` program on the board's real monitor ROM, in `sim6809` with an FT245 at `$D000` (`--ft245`) and working `SWI` (`--swi`): each program is typed into the monitor as S1/S9 records, started with `G400`, and given its input file; its output is what the console shows before the monitor's register display, whose B is compared with the expected exit status. The ROM comes from `$SIMON_ROM` (default `~/coco/simon6809/simon09.rom.s19`, from the board's repository); the suite is skipped without it. A test of its own checks an IRQ procedure through the monitor's vector.

12 Wichit Sirichote's 6809 Microprocessor Kit

```
build/plmc --org 0200H -o hello.asm hello.plm
lwasm -9 -f srec -I runtime -I runtime/kswichit -o hello.s19 hello.asm
```

Wichit Sirichote's 6809 Microprocessor Kit (2017, kswichit.net/6809/6809.htm) is a trainer with a 68B09 (4.9152 MHz crystal, 1.2288 MHz E clock), 32 KB of RAM, a keypad and 7-segment display, an MC6850 ACIA serial port at 19200 bit/s, and a monitor in ROM from `$C000`.

- **Loading and running:** press LOAD and send `hello.s19` over the serial port (19200 bit/s, 8N1, with a 1 ms delay after each character, as the kit's manual says), then GO, which runs from `$0200`. When the program ends it returns to the monitor with `SWI`, which saves its registers as the user registers (B is the exit status).
- **Load address:** always `--org 0200H`, where user programs start. The stack starts at `$7000`, below the monitor's variables and stack (`$7000`–`$7FFF`).
- **Console:** the serial port. The hooks use the ACIA (`$A000` status, `$A001` data) directly rather than the monitor's routines, whose addresses change from one monitor version to the next. LF is sent as CR LF; `GETCH` waits for a character.

- **Interrupts:** the ROM's vectors point into RAM (`$7FF0` IRQ, `$7FF3` NMI, `$7FF6` FIRQ), where the monitor puts a JMP to its 10 ms tick counter and RTIs. `PLM_SETINT` puts a JMP to the INTERRUPT procedure there, and the monitor's instructions back at the end. The IRQ switch selects the 89C2051's 10 ms tick or the IRQ button.
- **Other values:** `RT_CYCLES100` = 123. The GPIO1 LEDs, keypad and display are at `$8000`–`$8003`; declare them AT those addresses.

The `kswichit` test suite runs every `run` program with these hooks in `sim6809` with an ACIA at `$A000` (`--acia`) and working `SWI` (`--swi`). The kit's monitor is driven from its keypad, so `tests/kswichit/fakemon.asm` stands in for it: it sets up the stack and the RAM vectors as the real ROM's reset does, runs the program at `$0200`, and on `SWI` checks that the vectors were put back and ends with B as the exit status. A test of its own checks IRQ and FIRQ procedures through the RAM vectors.

13 Grant Searle's 6809 SBC

```
build/plmc --org 1000H -o hello.asm hello.plm
lwasm -9 -f srec -I runtime -I runtime/searle6809 -o hello.s19 hello.asm
```

Grant Searle's 6809 single-board computer (searle.wales/6809/Simple6809.html) is a minimal board: a 68B09 with a 7.3728 MHz crystal (1.8432 MHz E clock), 32 KB of RAM, a 6850 ACIA at `$A000` (115200 bit/s), and a 16 KB ROM at `$C000`. Jeff Tranter's PCB (github.com/jefftranter/6809) is built from it. Two ROMs are common, and the hooks work with both:

- **Jeff Tranter's "combined" ROM** (the ASSIST09 monitor, Microsoft BASIC, a disassembler and trace): at the `>` prompt type `L`, send the S1/S9 lines of `hello.s19`, then `C 1000`, which calls the program as a subroutine. When it ends, ASSIST09 shows the registers (B is the exit status). Use `C`, not `G`: the program returns with RTS.
- **Grant Searle's BASIC ROM** (his serial port of Extended Color BASIC): it can't load machine code itself, so the program has to get into RAM some other way. Then `CLEAR 200,&HFFF` keeps BASIC below `$1000` and `EXEC &H1000` runs it; it returns to BASIC.

More details:

- **Load address:** `--org 1000H`, above BASIC's variables (`$0000`– `$0178`) and its program text. The stack starts at `$6FD0`, below the combined ROM's monitor RAM (`$6FD0`–`$7051`); under BASIC that is free memory below BASIC's stack and strings.
- **Console:** the ACIA, used directly, so the hooks don't depend on the ROM. LF is sent as CR LF; `GETCH` waits for a character.
- **Interrupts:** the two ROMs route them differently. ASSIST09's CPU vectors lead to `JMP [n,PCR]` instructions that read the handler's address from its RAM vector table (at `$70C2`); Grant's BASIC points them at JMPs in RAM (`$00A7` IRQ, `$00AA` FIRQ, `$00A4` NMI). `PLM_SETINT` follows the CPU vector and handles either: it stores the handler's address in the table, or puts a JMP at the RAM vector. The bytes it changes are put back when the program ends.
- **Other values:** `RT_CYCLES100` = 184.

The `searle6809` test suite runs every `run` program twice in `sim6809`, with an ACIA at `$A000` (`--acia --stop-at-end`) and the ROM read-only (`--rom 0xC000`), on the real ROMs: under the combined ROM, typed in with ASSIST09's `L` and run with `C 1000` (output up to the register display, whose B is compared with the exit status); and under Grant's BASIC ROM, loaded together with it and run with `EXEC &H1000` (output up to BASIC's `OK`). The ROMs come from `$SEARLE_ROM` (default `~/coco/searle6809/combined.s19`) and `$SEARLE_BASIC` (default `~/coco/searle6809/ExBasROM.hex`); either is skipped if missing. An interrupt test checks that IRQ and FIRQ procedures work under both ROMs and that the vectors are the same before and after the program.

14 Generated code

14.1 Layout

```
        PRAGMA  6809
        ORG     $0100                ; --org
        INCLUDE "plm_crt0.asm"       ; RT_START: set S and DP, call PLM_MAIN
PLM_MAIN                             ; main program statements
        ...
        RTS
P_PROC1                              ; each procedure
        ...
        INCLUDE "plm_rt.asm"         ; RT_MUL16, RT_DIV16
        INCLUDE "plm_hooks.asm"      ; target-specific hooks
V_X     RMB     1                    ; variables, parameters, locals
L12     FCB     ...                  ; constant lists
RT_MEMORY EQU   *                    ; MEMORY
        END     RT_START
```

- **Startup:** execution starts at `RT_START`, at the `--org` address. It sets the stack (unless `RT_STACKTOP` is 0) and DP = 0, calls `PLM_MAIN`, and jumps to `PLM_EXIT` with status 0.
- **Variables** come last and are reserved with `RMB`, so they add nothing to S-record or `.BIN` files.
- **Total size:** for a typical small program, the code is a few hundred bytes and the runtime about 70 bytes.

With `--os9` the layout is that of an OS-9 module instead; see What `--os9` changes.

14.2 Example

The program from Building and quick start compiles to (in part):

```
; 6: DO WHILE I <= 10;
L1
        LDB     V_I
        CMPB    #$0A
        LBHI    L2
; 7: TOTAL = TOTAL + I;
        LDB     V_I
        CLRA
        PSHS    D
        LDD     V_TOTAL
        ADDD    ,S++
        STD     V_TOTAL
; 8: I = I + 1;
        LDB     V_I
        ADDB    #$01
        STB     V_I
        LBRA    L1
L2
```

Each statement is preceded by its source line as a comment, which makes the listing and simulator traces easy to follow.

14.3 Conventions

- **Registers:** a BYTE value is computed in B and an ADDRESS value in D. A BYTE is widened with `CLRA` only where a 16-bit value is needed.
- **Binary operators:** the right operand is evaluated first and pushed, then the left one, then they're combined with `op ,S+` or `op ,S++`. When the right operand is a constant or a variable of the right size, it's used directly as the instruction operand (`ADDB V_I`, `CMPB #$0A`).
- **Comparisons:** these use the unsigned branches `BLO`, `BHS`, `BHI`, `BLS`, `BEQ` and `BNE`.
  - In an `IF` or `WHILE`, the code branches straight on the comparison.
  - As a value, a comparison produces `$FF` or `$00` in B.
  - Statement-level control flow uses long branches, so there's no limit on the size of a block.
- **Iterative DO:**
  - The start value is stored in the index.
  - At the top of the loop the index is compared with the limit, which is re-evaluated there (`LBHI`/`LBLO` to the exit).
  - After the body the step is added with `ADDB`/`ADDD`, and the result stored. `LBCC` goes back to the top; a carry means the addition wrapped, and the loop ends.
- **DO CASE:**
  - The selector is range-checked (`CMPD #n` / `LBHS` past the block), then doubled.
  - `LEAX table,PCR` / `LDD D,X` / `JMP D,X` jumps through a table of `FDB case-table` *offsets*. Offsets rather than addresses keep the code position-independent, so the same sequence works in `--os9` modules.
  - Each case ends with `LBRA` past the block.
- **GOTO:**
  - Every statement leaves the stack as it found it, so a GOTO within a procedure, or within the main program, is just `LBRA`.
  - If any GOTO leaves a procedure, `PLM_MAIN` saves its stack pointer in `RT_MAINS` on entry (`STS RT_MAINS`). Such a GOTO is `LDS RT_MAINS` / `LBRA label`, which discards the return addresses and intermediate values of the calls it leaves.
- **BASED variables:**
  - The base is loaded into X (`LDX P`, or `LDX P,U`), and the variable is used as `,X` or `k,X`, so a store needs no extra registers.
  - Computed subscripts use the same `D,X` sequence as ordinary arrays, with the base's value as X.
- **Dot operator:**
  - Normally `LDD #V_X`. In `--os9` modules it is `LEAX V_X,U` / `TFR X,D` for a variable, and `LEAX P_X,PCR` / `TFR X,D` for a procedure, so the code stays position-independent.
  - Constant lists become `FCB` data after the procedures.
- **INITIAL and DATA:**
  - In a normal program, INITIAL variables are emitted as `FCB`/`FDB` in the data section, so the values are part of the load image. The rest of a partly initialized variable is `RMB`.
  - DATA variables are emitted the same way, among the code.
  - Addresses become label expressions such as `FDB V_TABLE+2`.

  - In `--os9` modules, see OS-9 modules.

- **AT:** a variable declared `AT` gets no storage: its label is an `EQU`, `M_X EQU $FF00` for a fixed address or `V_X EQU V_BUFFER+1` for an alias. `M_X` is used as a plain absolute operand even in `--os9` modules.

- **Structures:**

  - A member reference whose subscripts are all constants is a fixed location, `V_X+offset` (structure subscript × structure size + member offset + member subscript × member size), and is used directly as an operand.
  - Computed subscripts are scaled with shifts when the size is a power of two, and with `RT_MUL16` otherwise. Two computed subscripts are added on the stack.
  - BASED structures and the dot operator use the same paths as arrays.

- **Array elements:**

  - *Constant subscript:* the element is an ordinary operand, `V_A+6` (or `V_A+6,U` in an OS-9 module).
  - *Computed subscript:* the subscript is computed into D and doubled for ADDRESS arrays. The array's address goes into X (`LDX #V_A`, or `LEAX V_A,U`), and the element is loaded with `LDB D,X` / `LDD D,X`.
  - *Storing to a computed element:* the value is pushed first, then the address is formed with `LEAX D,X`, and the value is pulled and stored through X.

- **HIGH, LOW, DOUBLE:** `LOW` is just its argument (the low byte is in B), `HIGH` is `TFR A,B` (or `CLRB` for a BYTE), `DOUBLE` is `CLRA` for a BYTE.

- **SHL, SHR, ROL, ROR:** a constant count gives straight-line code: `LSLB` (+`ROLA`) or `LSRB` (`LSRA`+`RORB`) per bit, a whole byte moved with `TFR` when a 16-bit count is 8 or more, and a rotate as `TFR B,A` / `LSLA` / `ROLB` (or `LSRA` / `RORB`), going the shorter way round. A computed count is pushed and counted down with `DEC ,S`.

- **The flags:** when a program uses them, every `+`, `-`, `PLUS`, `MINUS`, `SCL`, `SCR` and `DEC` is followed by `ROL RT_CC`, which shifts the carry into bit 0 of that byte without touching A or B (for a BYTE operation in a program that uses `DEC`: `TFR CC,A` / `STA RT_CC`, keeping the half carry in bit 5 too), and, if `ZERO`, `SIGN` or `PARITY` is used, by a store of the result in `RT_RES` (a BYTE twice).

  - PLUS is `LSR RT_CC` (the carry back into C) and `ADCB`, plus `ADCA` on the high bytes for ADDRESS (the 6809 has no 16-bit add with carry); MINUS uses `SBCB`/`SBCA`.
  - SCL and SCR are `LSR RT_CC` and then `ROLB`(+`ROLA`) or (`RORA`+)`RORB` per bit, as a loop for a computed count.
  - DEC puts the kept carry and half carry into CC, leaving I and F alone, and uses `DAA`.
  - `CARRY` is `LDB RT_CC` / `ANDB #1` / `NEGB`, `ZERO` a `CMPD #1` of `RT_RES`, `SIGN` a `SEX` of its high byte, and `PARITY` a call of `RT_PARITY`.

- **Other built-ins:** `STACKPTR` is `TFR S,D` / `TFR D,S`, `MOVE` calls `RT_COPY` (D bytes from X to Y; Y is saved around it if the program has REENTRANT procedures), and `TIME` calls `RT_TIME`. `RT_COPY`, `RT_TIME` and `RT_PARITY` are assembled only when used (`RT_NEED_COPY`, …).

- **Multiplication and division:** BYTE × BYTE uses the 6809's `MUL`. All other multiplications and all divisions call `RT_MUL16` or `RT_DIV16` (left operand in X, right in D).

- **REENTRANT procedures:**

  - The caller pushes the arguments, first to last, each in its declared width (BYTE 1 byte, ADDRESS 2), calls the procedure, and removes them with `LEAS n,S`.
  - The procedure starts with `PSHS Y`, `LEAS -n,S` for its variables and `TFR S,Y`, and returns with `LEAS n,Y` and `PULS Y,PC` (B and D, the result, are untouched).

  - Its parameters and variables are then at fixed offsets from Y, emitted as `EQU`s before the procedure (`V2_N EQU 4`) and used as `V2_N,Y`:

Offset from Y	Contents
0 and up	variables, in declaration order
n	the caller's Y
n+2	return address
n+4 and up	arguments, the last one first

  - Y belongs to the running REENTRANT procedure. Ordinary procedures and the runtime don't use it, REENTRANT procedures restore it, and EXTERNAL calls save it.

- **INTERRUPT procedures:** `PLM_MAIN` starts with `LDX #RT_INTn` / `LDB #n` / `JSR PLM_SETINT` for each one. The entry routine `RT_INTn` follows the procedures: `CLRA`, `TFR A,DP`, `JSR P_X`, `RTI`, with `PSHS U,Y,X,DP,D` / `PULS D,DP,X,Y,U` around it for FIRQ. `ENABLE` is `ANDCC #$AF`, `DISABLE` is `ORCC #$50`, and a `CALL` of an interrupt procedure is followed by `ANDCC #$AF`.

- **Procedure calls:** arguments are stored in the procedure's fixed parameter locations and the procedure is called with `JSR`. If an argument itself contains a call, all arguments are evaluated and pushed first, then stored. That makes `F(1, F(2, 3))` work even though `F` has only one set of parameter locations.

- **Label names:** PL/M names can't contain `_`, so these labels never clash with yours:

Label	Meaning
`V_X`	variable `X` of the program
`Vn_X`	variable or parameter `X` of nested scope n
`M_X`, `Mn_X`	variable `X` declared `AT` a fixed address
`P_X`, `Pn_X`	procedure `X`
`G_X`, `Gn_X`	statement label `X` (in scope n)
`Lnnn`	compiler-generated label
`RT_*`	runtime routine or data
`PLM_*`	entry point the hooks provide
`X`	`EXTERNAL` procedure `X`, or the EXTERNAL-style entry of `PUBLIC` procedure `X`

- **PUBLIC entries:** after a PUBLIC procedure's code, plmc writes an entry under its name that takes EXTERNAL-style arguments (words on the stack, the last one 2 bytes above the return address) and passes them on. For an ordinary procedure it stores them in the parameters and jumps to the procedure, whose `RTS` returns to the caller (comments added):

```
; PUBLIC ADD3: called by its name with the EXTERNAL convention
ADD3
        LDB     7,S             ; A (BYTE), the first argument
        STB     V2_A
        LDD     4,S             ; B (ADDRESS)
        STD     V2_B
        LDB     3,S             ; C (BYTE), the last
        STB     V2_C
        JMP     P_ADD3
```

  For a REENTRANT procedure it pushes them again in their declared widths, calls it, and removes them.

- **`--obj` modules** have the same code, in `SECTION code` (with `DATA`), `data` (INITIAL values) and `bss` (other variables), behind `PRAGMA undefextern`, with an `EXPORT` for each PUBLIC procedure. The main module INCLUDEs the startup code first and the runtime and hooks last, between `PRAGMA export` and `PRAGMA noexport`, with every optional runtime routine (`RT_NEED_COPY`, …) assembled; `RT_OBJ` tells the startup code to leave out its `SETDP`, which object files don't allow.

15 Inspecting the compiler's view

`--tokens` prints each token with its line and column. Numbers are shown with their value, which is useful for checking how a constant was read. Strings are printed as `STRING 'text'`, with the value of one- and two-character strings. `--tokens` shows the source as written; LITERALLY names are expanded later, by the parser.

```
2:1 IDENT X
2:3 PUNCT =
2:5 NUMBER 255
2:10 PUNCT +
```

`--ast` prints the syntax tree after parsing, and after LITERALLY substitution, with expressions written as prefix lists. It shows exactly how precedence was applied:

```
PROGRAM SUM
  PROCEDURE PUTDEC (N) EXTERNAL
    DECLARE N ADDRESS
  DECLARE I BYTE
  DECLARE TOTAL ADDRESS
  ASSIGN TOTAL = 0
  ASSIGN I = 1
  DO WHILE (<= I 10)
    ASSIGN TOTAL = (+ TOTAL I)
    ASSIGN I = (+ I 1)
  CALL (CALL PUTDEC TOTAL)
```

To follow a program at run time, assemble with a listing (`lwasm ... --list=prog.lst`) and run `sim6809 -t`. The trace addresses match the listing, and the listing shows the PL/M source line for each group of instructions.

16 Testing

`make test` runs all of these suites:

Suite	What it checks
`lex`, `parse`	`--tokens` and `--ast` output for every number form, every keyword, precedence, dangling `ELSE` and nested procedures, against golden files
`err`	211 programs that must fail, each with the expected message and position

Suite	What it checks
`run`	complete programs compiled, assembled and run in `sim6809`; output and exit status compared. They cover every operator and conversion rule, control flow including iterative DO (wrap-around, re-evaluated limit and step, conversions) and DO CASE, input, procedures (including nested calls), arrays (a sieve, a sort, edge cases), structures (the manual's AIRPLANE, PAYROLL, POINT and 100×100 examples, built-ins on every reference form, BASED structures, a linked list), BASED variables and the dot operator (the manual's examples, BASED arrays and parameters, constant lists), INITIAL and DATA (the manual's examples, `(*)`, strings in BYTE and ADDRESS arrays, pointer tables, DATA in a procedure), PLUS and MINUS (32- and 24-bit arithmetic, and under interrupts), the built-ins HIGH, LOW, DOUBLE, SHL, SHR, ROL and ROR (the manual's examples, constant and computed counts, a declared HIGH hiding the built-in), the flags (BCD arithmetic with DEC, SCL/SCR through the carry, CARRY/ZERO/SIGN/PARITY), MOVE, MEMORY, STACKPTR and TIME, device registers AT sim6809's I/O block in place of INPUT and OUTPUT, and INPUT and OUTPUT as ordinary names, PUBLIC procedures (ordinary, REENTRANT and untyped, whose entries must assemble in every mode), labels and GOTO (out of loops, blocks and nested procedure calls; LABEL declarations, PUBLIC and EXTERNAL labels; 10000 jumps out of three calls to check the stack is reset), AT (aliases, and variables at sim6809's I/O ports), REENTRANT procedures (the manual's $SUMARRAY, indirectrecursion, localarraysandstructures, Ackerm$ $org`and` -$ $-vectors`||`obj`|programsofseveralmodules(`tests/obj/*$ $/`), eachmodulecompiledwith` -$ $-obj`andassembledwith`lwasm -$ $fobj`, linkedbylwlinkwith`runtime/plm09.link`, andrunin`sim6809`$ $PUBLICprocedureswithBYTEandADDRESSargumentsandresul$ $mainmoduleusinghooks, runtimeroutines, INITIALandDATA, ach$ $bytestructures, whosesubscriptsneedamultiply; HIGH, LOW, DOU$ $-PLUSMINUSSCLSCRDEC`andreadsof`CARRYZEROSIGN$ $testN =$ $2000`runsmore||`coco`,`xroar`|theColorComputerhooks, inthesimul$ $ins, TIME(onXRoar, 40 \times`$ $TIME(250)`musttakeonesecondoffield -$ $syncinterrupts)andINTERRUPTprocedures(theRAMvectors, rest$ $syncIRQs)(the`xroar`suiteisskippedifXRoar, theROMsortoolshed$ $-os9`andrunby`sim6809 -$ $-os9`(programsthatneedcompileroptions, suchasfixedaddresses, ar$ $recordsandstartedwith`G400`; outputsandexitstatusescompared.Us$ `skipped without it. See [Simon6809] |` `|searle6809|` `therunprograms (except those needing compiler options) on Grant Searle's 6809 SBC insim6809, under both its real ROMs (ASSIST09L/C, and BASICEXEC). Uses`$SEARLE_ROM$`and`SEARLE_BASIC; skipped without them. See [Grant Searle's`

17 Source code

File	Contents
`src/main.c`	command line, file handling
`src/lexer.c`	tokens, numbers, strings, comments
`src/parser.c`, `ast.c`	recursive-descent parser, syntax tree, `--ast`
`src/symtab.c`, `sema.c`	scopes, name resolution, types, call checks, recursion detection
`src/codegen.c`	assembly output
`runtime/plm_crt0.asm`, `plm_crt0_os9.asm`, `plm_rt.asm`	startup code (normal and OS-9), 16-bit multiply and divide
`runtime/*/plm_hooks.asm`	hooks for the simulator, the CoCo, OS-9, and the ACIA template