

WanWay G19S Server Settings

This guide provides detailed instructions for configuring the server settings of your WanWay G19S device.

1. Domain Server Setting

This section outlines how to configure the device to connect to your server using a domain name.

Format:

```
SERVER,1,DOMAIN,PORT,0#
```

Explanation:

- **SERVER:** This is the fixed command keyword for server settings.
- **1:** This signifies Domain Mode. The device will attempt to resolve the provided domain name to an IP address.
- **DOMAIN:** Replace `DOMAIN` with your server's fully qualified domain name (e.g., `myserver.example.com`).
- **PORT:** Replace `PORT` with the port number your server is listening on (e.g., `7700`).
- **0:** This indicates the TCP Protocol. This is the default and recommended protocol for the G19S.

Example:

To connect to a server located at `myserver.example.com` on port `7700` using TCP, you would send the following command:

```
SERVER,1,myserver.example.com,7700,0#
```

2. IP Server Setting

This section explains how to configure the device to connect to your server directly using its public IP address.

Format:

```
SERVER,0,IP,PORT,0#
```

Explanation:

- SERVER: This is the fixed command keyword for server settings.
- 0: This signifies IP Mode. The device will use the provided IP address directly for connection.
- IP: Replace IP with your server's public IPv4 address (e.g., 123.45.67.89).
- PORT: Replace PORT with the port number your server is listening on (e.g., 7700).
- 0: This indicates the TCP Protocol. This is the default and recommended protocol for the G19S.

Example:

To connect to a server located at the IP address 123.45.67.89 on port 7700 using TCP, you would send the following command:

```
SERVER,0,123.45.67.89,7700,0#
```

TCP Protocol Flag (Final '0')

The final parameter in the SERVER command dictates the network protocol used for communication.

- 0 = TCP (default and recommended): This is the standard and most reliable protocol for data transmission with the WanWay G19S. It ensures data integrity through error checking and retransmission.

- 1 = UDP: Some devices might support UDP. However, the WanWay G19S series primarily operates using TCP only. Using '1' may result in unreliable communication or no connection at all.

Therefore, it is strongly recommended to always use `0` for the TCP protocol flag.

Quick Reference

- Server Mode Selection:
 - Use `"1"` for Domain Mode.
 - Use `"0"` for IP Mode.
 - Protocol Selection:
 - Always end your `SERVER` command with `",0#"` to ensure TCP protocol is used.
-

If you require a comprehensive command pack that includes settings for APN, GPRS, timers, timezone, and reboot commands, please let me know, and I can generate a separate PDF document for that purpose.