



GDS-STD-P7012
Waveguide Adapters

GDS-AMP-P7012
25 JUN 2026

SI No	SYNERGY PART No	DESCRIPTION	Global Code
1	STK5661701265001	WR650 Waveguide-to-Waveguide Adapter	WR650
2	STK5661701265002	WR650 Waveguide-to-Coaxial Adapter	WR650
3	STK5661701265003	WR650 Size Transition Adapter	WR650
4	STK5661701265004	WR650 Frequency Band Transition Adapter	WR650
5	STK5661701265005	WR650 Flange Transition Adapter	WR650
6	STK5661701265006	WR650 Right-Angle Adapter	WR650
7	STK5661701265007	WR650 Straight Adapter	WR650
8	STK5661701265008	WR650 Twist Adapter	WR650
9	STK5661701265009	WR650 Offset Adapter	WR650
10	STK5661701265010	WR650 Pressure-Sealed Adapter	WR650
11	STK5661701265011	WR650 High-Power Adapter	WR650
12	STK5661701265012	WR650 Precision Instrumentation Adapter	WR650
13	STK5661701265013	WR650 Rotary Interface Adapter	WR650
14	STK5661701265014	WR650 Mission-Specific Adapter	WR650
15	STK5661701243001	WR430 Waveguide-to-Waveguide Adapter	WR430
16	STK5661701243002	WR430 Waveguide-to-Coaxial Adapter	WR430
17	STK5661701243003	WR430 Size Transition Adapter	WR430
18	STK5661701243004	WR430 Frequency Band Transition Adapter	WR430
19	STK5661701243005	WR430 Flange Transition Adapter	WR430
20	STK5661701243006	WR430 Right-Angle Adapter	WR430
21	STK5661701243007	WR430 Straight Adapter	WR430
22	STK5661701243008	WR430 Twist Adapter	WR430
23	STK5661701243009	WR430 Offset Adapter	WR430
24	STK5661701243010	WR430 Pressure-Sealed Adapter	WR430
25	STK5661701243011	WR430 High-Power Adapter	WR430
26	STK5661701243012	WR430 Precision Instrumentation Adapter	WR430
27	STK5661701243013	WR430 Rotary Interface Adapter	WR430
28	STK5661701243014	WR430 Mission-Specific Adapter	WR430
29	STK5661701234001	WR340 Waveguide-to-Waveguide Adapter	WR340
30	STK5661701234002	WR340 Waveguide-to-Coaxial Adapter	WR340
31	STK5661701234003	WR340 Size Transition Adapter	WR340
32	STK5661701234004	WR340 Frequency Band Transition Adapter	WR340
33	STK5661701234005	WR340 Flange Transition Adapter	WR340
34	STK5661701234006	WR340 Right-Angle Adapter	WR340
35	STK5661701234007	WR340 Straight Adapter	WR340
36	STK5661701234008	WR340 Twist Adapter	WR340
37	STK5661701234009	WR340 Offset Adapter	WR340
38	STK5661701234010	WR340 Pressure-Sealed Adapter	WR340
39	STK5661701234011	WR340 High-Power Adapter	WR340
40	STK5661701234012	WR340 Precision Instrumentation Adapter	WR340
41	STK5661701234013	WR340 Rotary Interface Adapter	WR340
42	STK5661701234014	WR340 Mission-Specific Adapter	WR340
43	STK5661701228401	WR284 Waveguide-to-Waveguide Adapter	WR284



GDS-STD-P7012
Waveguide Adapters

GDS-AMP-P7012
25 JUN 2026

SI No	SYNERGY PART No	DESCRIPTION	Global Code
44	STK5661701228402	WR284 Waveguide-to-Coaxial Adapter	WR284
45	STK5661701228403	WR284 Size Transition Adapter	WR284
46	STK5661701228404	WR284 Frequency Band Transition Adapter	WR284
47	STK5661701228405	WR284 Flange Transition Adapter	WR284
48	STK5661701228406	WR284 Right-Angle Adapter	WR284
49	STK5661701228407	WR284 Straight Adapter	WR284
50	STK5661701228408	WR284 Twist Adapter	WR284
51	STK5661701228409	WR284 Offset Adapter	WR284
52	STK5661701228410	WR284 Pressure-Sealed Adapter	WR284
53	STK5661701228411	WR284 High-Power Adapter	WR284
54	STK5661701228412	WR284 Precision Instrumentation Adapter	WR284
55	STK5661701228413	WR284 Rotary Interface Adapter	WR284
56	STK5661701228414	WR284 Mission-Specific Adapter	WR284
57	STK5661701222901	WR229 Waveguide-to-Waveguide Adapter	WR229
58	STK5661701222902	WR229 Waveguide-to-Coaxial Adapter	WR229
59	STK5661701222903	WR229 Size Transition Adapter	WR229
60	STK5661701222904	WR229 Frequency Band Transition Adapter	WR229
61	STK5661701222905	WR229 Flange Transition Adapter	WR229
62	STK5661701222906	WR229 Right-Angle Adapter	WR229
63	STK5661701222907	WR229 Straight Adapter	WR229
64	STK5661701222908	WR229 Twist Adapter	WR229
65	STK5661701222909	WR229 Offset Adapter	WR229
66	STK5661701222910	WR229 Pressure-Sealed Adapter	WR229
67	STK5661701222911	WR229 High-Power Adapter	WR229
68	STK5661701222912	WR229 Precision Instrumentation Adapter	WR229
69	STK5661701222913	WR229 Rotary Interface Adapter	WR229
70	STK5661701222914	WR229 Mission-Specific Adapter	WR229
71	STK5661701218701	WR187 Waveguide-to-Waveguide Adapter	WR187
72	STK5661701218702	WR187 Waveguide-to-Coaxial Adapter	WR187
73	STK5661701218703	WR187 Size Transition Adapter	WR187
74	STK5661701218704	WR187 Frequency Band Transition Adapter	WR187
75	STK5661701218705	WR187 Flange Transition Adapter	WR187
76	STK5661701218706	WR187 Right-Angle Adapter	WR187
77	STK5661701218707	WR187 Straight Adapter	WR187
78	STK5661701218708	WR187 Twist Adapter	WR187
79	STK5661701218709	WR187 Offset Adapter	WR187
80	STK5661701218710	WR187 Pressure-Sealed Adapter	WR187
81	STK5661701218711	WR187 High-Power Adapter	WR187
82	STK5661701218712	WR187 Precision Instrumentation Adapter	WR187
83	STK5661701218713	WR187 Rotary Interface Adapter	WR187
84	STK5661701218714	WR187 Mission-Specific Adapter	WR187
85	STK5661701215901	WR159 Waveguide-to-Waveguide Adapter	WR159
86	STK5661701215902	WR159 Waveguide-to-Coaxial Adapter	WR159



GDS-STD-P7012
Waveguide Adapters

GDS-AMP-P7012
25 JUN 2026

SI No	SYNERGY PART No	DESCRIPTION	Global Code
87	STK5661701215903	WR159 Size Transition Adapter	WR159
88	STK5661701215904	WR159 Frequency Band Transition Adapter	WR159
89	STK5661701215905	WR159 Flange Transition Adapter	WR159
90	STK5661701215906	WR159 Right-Angle Adapter	WR159
91	STK5661701215907	WR159 Straight Adapter	WR159
92	STK5661701215908	WR159 Twist Adapter	WR159
93	STK5661701215909	WR159 Offset Adapter	WR159
94	STK5661701215910	WR159 Pressure-Sealed Adapter	WR159
95	STK5661701215911	WR159 High-Power Adapter	WR159
96	STK5661701215912	WR159 Precision Instrumentation Adapter	WR159
97	STK5661701215913	WR159 Rotary Interface Adapter	WR159
98	STK5661701215914	WR159 Mission-Specific Adapter	WR159
99	STK5661701213701	WR137 Waveguide-to-Waveguide Adapter	WR137
100	STK5661701213702	WR137 Waveguide-to-Coaxial Adapter	WR137
101	STK5661701213703	WR137 Size Transition Adapter	WR137
102	STK5661701213704	WR137 Frequency Band Transition Adapter	WR137
103	STK5661701213705	WR137 Flange Transition Adapter	WR137
104	STK5661701213706	WR137 Right-Angle Adapter	WR137
105	STK5661701213707	WR137 Straight Adapter	WR137
106	STK5661701213708	WR137 Twist Adapter	WR137
107	STK5661701213709	WR137 Offset Adapter	WR137
108	STK5661701213710	WR137 Pressure-Sealed Adapter	WR137
109	STK5661701213711	WR137 High-Power Adapter	WR137
110	STK5661701213712	WR137 Precision Instrumentation Adapter	WR137
111	STK5661701213713	WR137 Rotary Interface Adapter	WR137
112	STK5661701213714	WR137 Mission-Specific Adapter	WR137
113	STK5661701211201	WR112 Waveguide-to-Waveguide Adapter	WR112
114	STK5661701211202	WR112 Waveguide-to-Coaxial Adapter	WR112
115	STK5661701211203	WR112 Size Transition Adapter	WR112
116	STK5661701211204	WR112 Frequency Band Transition Adapter	WR112
117	STK5661701211205	WR112 Flange Transition Adapter	WR112
118	STK5661701211206	WR112 Right-Angle Adapter	WR112
119	STK5661701211207	WR112 Straight Adapter	WR112
120	STK5661701211208	WR112 Twist Adapter	WR112
121	STK5661701211209	WR112 Offset Adapter	WR112
122	STK5661701211210	WR112 Pressure-Sealed Adapter	WR112
123	STK5661701211211	WR112 High-Power Adapter	WR112
124	STK5661701211212	WR112 Precision Instrumentation Adapter	WR112
125	STK5661701211213	WR112 Rotary Interface Adapter	WR112
126	STK5661701211214	WR112 Mission-Specific Adapter	WR112
127	STK5661701209001	WR90 Waveguide-to-Waveguide Adapter	WR90
128	STK5661701209002	WR90 Waveguide-to-Coaxial Adapter	WR90
129	STK5661701209003	WR90 Size Transition Adapter	WR90



GDS-STD-P7012
Waveguide Adapters

GDS-AMP-P7012
25 JUN 2026

SI No	SYNERGY PART No	DESCRIPTION	Global Code
130	STK5661701209004	WR90 Frequency Band Transition Adapter	WR90
131	STK5661701209005	WR90 Flange Transition Adapter	WR90
132	STK5661701209006	WR90 Right-Angle Adapter	WR90
133	STK5661701209007	WR90 Straight Adapter	WR90
134	STK5661701209008	WR90 Twist Adapter	WR90
135	STK5661701209009	WR90 Offset Adapter	WR90
136	STK5661701209010	WR90 Pressure-Sealed Adapter	WR90
137	STK5661701209011	WR90 High-Power Adapter	WR90
138	STK5661701209012	WR90 Precision Instrumentation Adapter	WR90
139	STK5661701209013	WR90 Rotary Interface Adapter	WR90
140	STK5661701209014	WR90 Mission-Specific Adapter	WR90
141	STK5661701207501	WR75 Waveguide-to-Waveguide Adapter	WR75
142	STK5661701207502	WR75 Waveguide-to-Coaxial Adapter	WR75
143	STK5661701207503	WR75 Size Transition Adapter	WR75
144	STK5661701207504	WR75 Frequency Band Transition Adapter	WR75
145	STK5661701207505	WR75 Flange Transition Adapter	WR75
146	STK5661701207506	WR75 Right-Angle Adapter	WR75
147	STK5661701207507	WR75 Straight Adapter	WR75
148	STK5661701207508	WR75 Twist Adapter	WR75
149	STK5661701207509	WR75 Offset Adapter	WR75
150	STK5661701207510	WR75 Pressure-Sealed Adapter	WR75
151	STK5661701207511	WR75 High-Power Adapter	WR75
152	STK5661701207512	WR75 Precision Instrumentation Adapter	WR75
153	STK5661701207513	WR75 Rotary Interface Adapter	WR75
154	STK5661701207514	WR75 Mission-Specific Adapter	WR75
155	STK5661701206201	WR62 Waveguide-to-Waveguide Adapter	WR62
156	STK5661701206202	WR62 Waveguide-to-Coaxial Adapter	WR62
157	STK5661701206203	WR62 Size Transition Adapter	WR62
158	STK5661701206204	WR62 Frequency Band Transition Adapter	WR62
159	STK5661701206205	WR62 Flange Transition Adapter	WR62
160	STK5661701206206	WR62 Right-Angle Adapter	WR62
161	STK5661701206207	WR62 Straight Adapter	WR62
162	STK5661701206208	WR62 Twist Adapter	WR62
163	STK5661701206209	WR62 Offset Adapter	WR62
164	STK5661701206210	WR62 Pressure-Sealed Adapter	WR62
165	STK5661701206211	WR62 High-Power Adapter	WR62
166	STK5661701206212	WR62 Precision Instrumentation Adapter	WR62
167	STK5661701206213	WR62 Rotary Interface Adapter	WR62
168	STK5661701206214	WR62 Mission-Specific Adapter	WR62
169	STK5661701205101	WR51 Waveguide-to-Waveguide Adapter	WR51
170	STK5661701205102	WR51 Waveguide-to-Coaxial Adapter	WR51
171	STK5661701205103	WR51 Size Transition Adapter	WR51
172	STK5661701205104	WR51 Frequency Band Transition Adapter	WR51



GDS-STD-P7012
Waveguide Adapters

GDS-AMP-P7012
25 JUN 2026

SI No	SYNERGY PART No	DESCRIPTION	Global Code
173	STK5661701205105	WR51 Flange Transition Adapter	WR51
174	STK5661701205106	WR51 Right-Angle Adapter	WR51
175	STK5661701205107	WR51 Straight Adapter	WR51
176	STK5661701205108	WR51 Twist Adapter	WR51
177	STK5661701205109	WR51 Offset Adapter	WR51
178	STK5661701205110	WR51 Pressure-Sealed Adapter	WR51
179	STK5661701205111	WR51 High-Power Adapter	WR51
180	STK5661701205112	WR51 Precision Instrumentation Adapter	WR51
181	STK5661701205113	WR51 Rotary Interface Adapter	WR51
182	STK5661701205114	WR51 Mission-Specific Adapter	WR51
183	STK5661701204201	WR42 Waveguide-to-Waveguide Adapter	WR42
184	STK5661701204202	WR42 Waveguide-to-Coaxial Adapter	WR42
185	STK5661701204203	WR42 Size Transition Adapter	WR42
186	STK5661701204204	WR42 Frequency Band Transition Adapter	WR42
187	STK5661701204205	WR42 Flange Transition Adapter	WR42
188	STK5661701204206	WR42 Right-Angle Adapter	WR42
189	STK5661701204207	WR42 Straight Adapter	WR42
190	STK5661701204208	WR42 Twist Adapter	WR42
191	STK5661701204209	WR42 Offset Adapter	WR42
192	STK5661701204210	WR42 Pressure-Sealed Adapter	WR42
193	STK5661701204211	WR42 High-Power Adapter	WR42
194	STK5661701204212	WR42 Precision Instrumentation Adapter	WR42
195	STK5661701204213	WR42 Rotary Interface Adapter	WR42
196	STK5661701204214	WR42 Mission-Specific Adapter	WR42
197	STK5661701203401	WR34 Waveguide-to-Waveguide Adapter	WR34
198	STK5661701203402	WR34 Waveguide-to-Coaxial Adapter	WR34
199	STK5661701203403	WR34 Size Transition Adapter	WR34
200	STK5661701203404	WR34 Frequency Band Transition Adapter	WR34
201	STK5661701203405	WR34 Flange Transition Adapter	WR34
202	STK5661701203406	WR34 Right-Angle Adapter	WR34
203	STK5661701203407	WR34 Straight Adapter	WR34
204	STK5661701203408	WR34 Twist Adapter	WR34
205	STK5661701203409	WR34 Offset Adapter	WR34
206	STK5661701203410	WR34 Pressure-Sealed Adapter	WR34
207	STK5661701203411	WR34 High-Power Adapter	WR34
208	STK5661701203412	WR34 Precision Instrumentation Adapter	WR34
209	STK5661701203413	WR34 Rotary Interface Adapter	WR34
210	STK5661701203414	WR34 Mission-Specific Adapter	WR34
211	STK5661701202801	WR28 Waveguide-to-Waveguide Adapter	WR28
212	STK5661701202802	WR28 Waveguide-to-Coaxial Adapter	WR28
213	STK5661701202803	WR28 Size Transition Adapter	WR28
214	STK5661701202804	WR28 Frequency Band Transition Adapter	WR28
215	STK5661701202805	WR28 Flange Transition Adapter	WR28



GDS-STD-P7012
Waveguide Adapters

GDS-AMP-P7012
25 JUN 2026

SI No	SYNERGY PART No	DESCRIPTION	Global Code
216	STK5661701202806	WR28 Right-Angle Adapter	WR28
217	STK5661701202807	WR28 Straight Adapter	WR28
218	STK5661701202808	WR28 Twist Adapter	WR28
219	STK5661701202809	WR28 Offset Adapter	WR28
220	STK5661701202810	WR28 Pressure-Sealed Adapter	WR28
221	STK5661701202811	WR28 High-Power Adapter	WR28
222	STK5661701202812	WR28 Precision Instrumentation Adapter	WR28
223	STK5661701202813	WR28 Rotary Interface Adapter	WR28
224	STK5661701202814	WR28 Mission-Specific Adapter	WR28
225	STK5661701202201	WR22 Waveguide-to-Waveguide Adapter	WR22
226	STK5661701202202	WR22 Waveguide-to-Coaxial Adapter	WR22
227	STK5661701202203	WR22 Size Transition Adapter	WR22
228	STK5661701202204	WR22 Frequency Band Transition Adapter	WR22
229	STK5661701202205	WR22 Flange Transition Adapter	WR22
230	STK5661701202206	WR22 Right-Angle Adapter	WR22
231	STK5661701202207	WR22 Straight Adapter	WR22
232	STK5661701202208	WR22 Twist Adapter	WR22
233	STK5661701202209	WR22 Offset Adapter	WR22
234	STK5661701202210	WR22 Pressure-Sealed Adapter	WR22
235	STK5661701202211	WR22 High-Power Adapter	WR22
236	STK5661701202212	WR22 Precision Instrumentation Adapter	WR22
237	STK5661701202213	WR22 Rotary Interface Adapter	WR22
238	STK5661701202214	WR22 Mission-Specific Adapter	WR22
239	STK5661701201901	WR19 Waveguide-to-Waveguide Adapter	WR19
240	STK5661701201902	WR19 Waveguide-to-Coaxial Adapter	WR19
241	STK5661701201903	WR19 Size Transition Adapter	WR19
242	STK5661701201904	WR19 Frequency Band Transition Adapter	WR19
243	STK5661701201905	WR19 Flange Transition Adapter	WR19
244	STK5661701201906	WR19 Right-Angle Adapter	WR19
245	STK5661701201907	WR19 Straight Adapter	WR19
246	STK5661701201908	WR19 Twist Adapter	WR19
247	STK5661701201909	WR19 Offset Adapter	WR19
248	STK5661701201910	WR19 Pressure-Sealed Adapter	WR19
249	STK5661701201911	WR19 High-Power Adapter	WR19
250	STK5661701201912	WR19 Precision Instrumentation Adapter	WR19
251	STK5661701201913	WR19 Rotary Interface Adapter	WR19
252	STK5661701201914	WR19 Mission-Specific Adapter	WR19
253	STK5661701201501	WR15 Waveguide-to-Waveguide Adapter	WR15
254	STK5661701201502	WR15 Waveguide-to-Coaxial Adapter	WR15
255	STK5661701201503	WR15 Size Transition Adapter	WR15
256	STK5661701201504	WR15 Frequency Band Transition Adapter	WR15
257	STK5661701201505	WR15 Flange Transition Adapter	WR15
258	STK5661701201506	WR15 Right-Angle Adapter	WR15



GDS-STD-P7012
Waveguide Adapters

GDS-AMP-P7012
25 JUN 2026

SI No	SYNERGY PART No	DESCRIPTION	Global Code
259	STK5661701201507	WR15 Straight Adapter	WR15
260	STK5661701201508	WR15 Twist Adapter	WR15
261	STK5661701201509	WR15 Offset Adapter	WR15
262	STK5661701201510	WR15 Pressure-Sealed Adapter	WR15
263	STK5661701201511	WR15 High-Power Adapter	WR15
264	STK5661701201512	WR15 Precision Instrumentation Adapter	WR15
265	STK5661701201513	WR15 Rotary Interface Adapter	WR15
266	STK5661701201514	WR15 Mission-Specific Adapter	WR15
267	STK5661701201201	WR12 Waveguide-to-Waveguide Adapter	WR12
268	STK5661701201202	WR12 Waveguide-to-Coaxial Adapter	WR12
269	STK5661701201203	WR12 Size Transition Adapter	WR12
270	STK5661701201204	WR12 Frequency Band Transition Adapter	WR12
271	STK5661701201205	WR12 Flange Transition Adapter	WR12
272	STK5661701201206	WR12 Right-Angle Adapter	WR12
273	STK5661701201207	WR12 Straight Adapter	WR12
274	STK5661701201208	WR12 Twist Adapter	WR12
275	STK5661701201209	WR12 Offset Adapter	WR12
276	STK5661701201210	WR12 Pressure-Sealed Adapter	WR12
277	STK5661701201211	WR12 High-Power Adapter	WR12
278	STK5661701201212	WR12 Precision Instrumentation Adapter	WR12
279	STK5661701201213	WR12 Rotary Interface Adapter	WR12
280	STK5661701201214	WR12 Mission-Specific Adapter	WR12
281	STK5661701201001	WR10 Waveguide-to-Waveguide Adapter	WR10
282	STK5661701201002	WR10 Waveguide-to-Coaxial Adapter	WR10
283	STK5661701201003	WR10 Size Transition Adapter	WR10
284	STK5661701201004	WR10 Frequency Band Transition Adapter	WR10
285	STK5661701201005	WR10 Flange Transition Adapter	WR10
286	STK5661701201006	WR10 Right-Angle Adapter	WR10
287	STK5661701201007	WR10 Straight Adapter	WR10
288	STK5661701201008	WR10 Twist Adapter	WR10
289	STK5661701201009	WR10 Offset Adapter	WR10
290	STK5661701201010	WR10 Pressure-Sealed Adapter	WR10
291	STK5661701201011	WR10 High-Power Adapter	WR10
292	STK5661701201012	WR10 Precision Instrumentation Adapter	WR10
293	STK5661701201013	WR10 Rotary Interface Adapter	WR10
294	STK5661701201014	WR10 Mission-Specific Adapter	WR10