

Raspberry PI 4B programmato in Codesys





In SSH:
sudo apt-get update
sudo apt-get upgrade
sudo raspi-config (abilitare i2c)
apt-get install -y i2c-tools
sudo i2cdetect -y 1

In Codesys:
Installare (Tools > Repository):
- libreria: I2C_PCF8574_3.library
- dispositivo: PCF8574.devdesc.xml

