17.10.2001/THe

KES PC Message description

GENERAL

Messages are ASCII mark lines and message always ends in line finishing mark ASCII 13 (<CR>).
Message is regognised from the first mark , sc. message type. (See the list of used message types later).
Serial port setup is

19200 bps, no parity, 8 data bits, 1 stop bit

MESSAGE TYPES

In following there are all different message types listed and all their forms. Form is told by giving information's definition and after that information's lenght is indicated by # - mark. Example. [Shooting lane##] means that in message shooting lane is with 2 marks -> 02 or 12

. Type 1: Beginning

Pressing shooting lane keyboard's "Yellow" button.
Attention! Time information is always 000000. Lane reserved for future use.
Form: [Type#][shootinglane##][hours##minutes##seconds##][prone=0 stand=1]
Example: 1010000000 <CR>

Type 2: Shooter's number

Number being fed for the shooter from keyboard and pressed "Enter" button.
Form: [Type#][Shooting lane##] [Shooter number###]
Example: 201001 <CR>

. Type 3: Hit or Miss

Target device has registered the hit or miss shot. Used in television graphics only.
Attention! Time information is always 000000. Place is reserved for the future use.
Form: [type#][Shooting lane##][hours##minutes##seconds##]
Example: 301000000 <CR>

. Type 4: Hit

Target device has registered the hit (flap fell down)
Form: [type#][Shooting lane##][flaps #####]
Example: 40100001 <CR>

. Type 5: Leave shooting place

"Blue" button being pressed on shooting lane's keyboard.
Attention! Time information is always 000000. Place is reserved for the future use.
Form: [Type#][shooting lane##][hours##minutes##seconds##][flaps#####]
Example: 50100000000001<CR>

. Type 6: Clear

"C" button being pressed in shooting lane's keyboard.
Form: [type#][shooting lane##]
Example: 610<CR>

. Type 7: Stop

"C" button being pressed in shooting lane's keyboard so many times that event is totally canceled.
Form: [type#][shooting lane##]
Example: 710<CR>

. Type 8: Connection test

Unless there's other messages on the line, connection test will be sent at least once in every three (3) seconds.
Form: [Type#]
Example: 8<CR

. Type 9: Miss

Target device has registered miss shot.
Form: [type#][shooting lane##][flaps#####]
Example: 91401011<CR