Gearbox - gear ratio - gear lever position - gear number

- max gear number
- break position to change gear lever
- RPM to increase gear number
- RPM to decrease gear number
- + Gearbox()
- + ~Gearbox()
- + GearLeverPosition() + GearNumberChange()
- + get gear ratio()
- + get gear lever position()
- + get_gear_number()

Engine

- eng sts
- eng rpm
- eng_ hp
- eng max rpm
- eng_idle_rpm - eng_min rpm
- rpm max dec
- rpm simulation constant
- + Engine()
- + Ignition() + RPM()
- + ActualRPM()
- + get eng rpm()
- + get eng sts()

-gearbox -engine

Vehicle

- tire diameter
- diff ratio
- weight
- vehicle speed
- + Vehicle()
- + RPMToSpeedFactor()
- + VehicleSpeed()
- + Run()