Ember 2 Camp Stove - Owner's Manual

Specifications

Item	Value
Burners	2
Output	10,000 BTU per burner
Fuel	16.4 oz propane canister
Weight	11.2 lb
Cooking surface	Fits two 10-inch pans

Approved fuel: 16.4 oz propane canisters only.

Safety

Never use the Ember 2 indoors, inside a tent, or in any enclosed space. The stove produces carbon monoxide, which can kill. Keep the stove at least 3 feet from tents, trees and other flammable objects.

Lighting the stove

1. Connect the regulator to the stove and screw in the propane canister by hand.
2. Open the lid and set the stove on a flat, stable surface.
3. Turn the burner knob to HIGH and press the igniter button until the burner lights.
4. Adjust the flame with the knob.

Troubleshooting

Weak or uneven flame: check that the regulator is fully tightened. In cold weather (below 40°F) propane pressure drops; keep the canister warm before use.

Igniter does not spark: wipe the igniter tip with a dry cloth. You can light the burner with a long match.

Cleaning

Let the stove cool completely. Clean burner ports with a soft brush. Do not use a pin or wire, which can enlarge the ports.