ShopSphere BX-900 4K Ultra HD Action Camera — User Manual

Model: BX-900 | Category: Electronics | Cameras & Photography

1. Product Overview

The ShopSphere BX-900 is an ultra-rugged 4K action camera designed for extreme sports, vlogging, and outdoor exploration. It features dual full-color displays and advanced 6-axis Electronic Image Stabilization (EIS 3.0) for stable footage.

- Video Resolution: Native 4K @ 60fps, 4K @ 30fps, 2.7K @ 60fps, 1080p @ 120fps (Super Slow Motion).
- Photo Resolution: 24 Megapixels with Sony IMX image sensor and RAW image capture option.
- Dual Displays: 2.0-inch rear high-sensitivity IPS touchscreen + 1.4-inch front color preview screen for selfies.
- Waterproof Capability: Waterproof up to 10 meters (33 ft) without external case; waterproof up to 40 meters (131 ft) inside the included IP68 dive housing.
- Lens: 170-degree ultra-wide angle 6G glass lens with digital distortion calibration.

2. Memory Card & Battery Guidelines

To ensure smooth 4K 60fps recording, verify memory card specifications:

- MicroSD Card Requirement: Class 10, UHS Speed Class 3 (U3), or V30 rated MicroSD card up to 256GB. Format inside camera before first use.
- Battery Life: Removable 1350 mAh Li-ion battery delivers approx. 90 minutes of continuous 4K 60fps recording (two batteries included in retail box).
- Operating Temperature: -10 degrees C to 40 degrees C (14 degrees F to 104 degrees F).

3. Modes & Remote App Connectivity

- Shooting Modes: Normal Video, Loop Recording (dashcam 3m/5m), Time Lapse Video, Slow Motion, Photo Burst (10 photos/sec), and Night Photo.
- Wi-Fi & Companion App: Download 'ShopSphere Action Cam' app on iOS or Android. Turn on camera Wi-Fi by long-pressing the Up button. Connect phone to camera Wi-Fi network (SSID: BX900_XXXX, Default Password: 12345678).
- HDMI Output: Micro-HDMI port allows direct 4K playback to external TV or monitor.

4. System Reset & Maintenance

Factory Reset: Swipe down on the main touchscreen -> tap Gear Icon (Settings) -> select 'System Reset' -> Confirm. Alternatively, hold Shutter button + Power button for 8 seconds.

Care: Rinse dive housing in clean fresh water after saltwater diving and dry thoroughly.