



## **NOTES:**

- 1 Enable Pin: Must apply 2.4V < VEN < VIN to enable
  - There is a 10k resistor to GND internally from the enable pin. Floating this pin will disable the converter.
  - To disable, apply 0 to 800mV to enable pin, or OPEN circuit.
- 2 Current monitor: Scale factor from 0 to 5V maps 0 to 100% of rated current.
  - Max current for this converter is 400uA
- 3 Voltage monitor is same scale as HV\_Set Scale. 0 --> 5V sets 0 to -10kV.
- 4 SIG\_GND and HV\_RTN are kept isolated from each other.
- 5 5V REF is referenced to V\_TELEM\_RTN

Sheet: /Main\_DCDC\_Converter/
File: Main\_DCDC\_Converter.kicad\_sch

Title:
Size: A3 Date: Rev:
KiCad E.D.A. 8.0.6 Id: 2/7









