
## SCHEMATIC



. Resistors are shown in Ohms k = 1,000 M = 1,000,000

- 2. Capacitors are shown in uF otherwise noted ?????
- 3. All resistors are ± 5% tolerance unless otherwise indicated

Replace components marked with safety symbol with identical type

C310 is not listed in the BOM in the service manual.

C717 is 100V, no space on the schematic to show.

C909 is listed in the BOM as 47uF, but marked on the schematic as upgraded to 100uF.

C931 is listed on the schematic as 47uF, in the BOM in service manual as 470uF.

L701 is listed on the schematic as "116F", in the BOM in service manual as 3.3uH

R616 is listed on the schematic as 470R, in service manual as 270R. R707 is illegible but looks like 8R or 18R, in service manual 81R is stated. VR702 Illegible text accompanies this trim pot.

which makes more sense.

specified parts be used for the critical components in the shaded areas of the schematic.

When servicing it is essential that only manufacturers

special features important for protection from

X-radiation, fire and electrical shock hazards.

(RP: Unfortunately, the scan does not have a shaded area)

Nov 6th, 1987 N. S. Lee - Handdrawn/written schematic. Aug 17th, 2024 R. M. Pel - Re-typed all text based on barely legible scan.