

This document provides additional assistance with wiring your Extron IP Link® Pro Series enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific Extron IP Link® Pro Series enabled product or the controlled device manufacturer supplied documentation.

## Device Specifications

Device Type: Audio Processor  
Manufacturer: ClockAudio  
Firmware Version: N/A  
Model(s): CDT100 MK3

## Tested on the Following Software and Firmware Versions

|                                        |                |
|----------------------------------------|----------------|
| GC (Plus, Pro) Version                 | 3.25.0.3       |
| IP Link Pro Control Processor Firmware | 3.18.0000-b001 |
| MediaLink Plus Controller Firmware     | 3.04.0000-b001 |
| HC 400 Series Firmware                 | 2.11.0001-b004 |
| TLC Pro Series Firmware                | 3.10.0000-b002 |

## Version History

| Driver Version | Date      | Notes                                                  |
|----------------|-----------|--------------------------------------------------------|
| 1_1_1          | 9/24/2024 | Added Asynchronous IP Address driver parameter.        |
| 1_1_0          | 6/25/2024 | Updated Switch Logic Status – Channel parameter names. |
| 1_0_1          | 9/27/2023 | Fixed Switch Logic Status.                             |
| 1_0_0          | 9/6/2022  | Initial Version                                        |

**Driver Notes**

- User Defined command takes a string parameter and sends the string out of the port.
- The Asynchronous IP Address driver parameter is used to set the IP address that the device will send unsolicited (unpolled) responses to.
  - It is only necessary when configuring Switch Logic Status. Otherwise, it may be left blank.
  - It should be configured to match the appropriate LAN (or AV LAN) IP address of the controller.

**Driver Timings**

- N/A

## Control Commands & States

|                      |         |       |      |
|----------------------|---------|-------|------|
| ARM-C                |         |       |      |
| Value                | On      | Off   |      |
| Load Preset          |         |       |      |
| Value                | None    |       |      |
| Phantom Power        |         |       |      |
| Channel              | 1 – 4   |       |      |
| Value                | On      | Off   |      |
| Phantom Power All    |         |       |      |
| Value                | On      | Off   |      |
| RGB                  |         |       |      |
| Channel              | 1 – 4   |       |      |
| Red                  | 0 – 255 |       |      |
| Green                | 0 – 255 |       |      |
| Blue                 | 0 – 255 |       |      |
| Value                | None    |       |      |
| Save Preset          |         |       |      |
| Value                | None    |       |      |
| TS Brightness        |         |       |      |
| Channel              | 1 – 4   | All   |      |
| Color                | Red     | Green | Blue |
| Value                | 10      | 20    | 30   |
|                      | 40      | 50    | 60   |
|                      | 70      | 80    | 90   |
|                      | 100     |       |      |
| TS State             |         |       |      |
| Channel              | 1 – 4   | All   |      |
| Color                | Red     | Green | Blue |
| Value                | On      | Off   |      |
| User Defined Command |         |       |      |
| Value                | None    |       |      |
| User Defined String  |         |       |      |
| Value                | String  |       |      |

## Status Available

|                                 |             |              |             |
|---------------------------------|-------------|--------------|-------------|
| ARM-C                           |             |              |             |
| Value                           | On          | Off          |             |
| Connection Status <sup>RP</sup> |             |              |             |
| Value                           | Connected   | Disconnected |             |
| Firmware                        |             |              |             |
| Value                           | String      |              |             |
| Phantom Power                   |             |              |             |
| Channel                         | 1 – 4       |              |             |
| Value                           | On          | Off          |             |
| Switch Logic Status             |             |              |             |
| Channel                         | TS 1 – 4 RS | TS 1 – 4 TS  | TS 1 – 4 US |
| Value                           | On          | Off          |             |
| User Defined String             |             |              |             |
| Value                           | String      |              |             |

<sup>RP</sup> Connection Status is based off of the following string: VERSION\r

---

## Network communication

When configuring the Ethernet driver, be sure device settings match that of the GCP configuration.

|                                       |                |
|---------------------------------------|----------------|
| <b>Port Type:</b>                     | Ethernet (UDP) |
| <b>Device Listen Port:</b>            | 49494          |
| <b>Device Reply Port:</b>             | 49494          |
| <b>Logon Credentials Supported:</b>   | No             |
| <b>Multi-Connection Capabilities:</b> | Undetermined   |
| <b>Listen Port Changeability:</b>     | No             |
| <b>Reply Port Changeability:</b>      | Yes            |

---

## Ethernet Driver Configuration Description

Please refer to user manual for settings and changes to the network communication.

When using multiple UDP drivers within the same configuration each driver should have a unique 'Reply on Port' number due to the nature of UDP communication. If you have a driver with a fixed 'Reply on Port' number, only one instance of the driver can be used within the configuration.

## Notes for the Device