

SIS Configuration and Control

The DTP3 CrossPoint 42 and DTP3 CrossPoint 42 USB matrix switchers can be remotely controlled, monitored, or configured with Simple Instruction Set (SIS) commands. This section describes the operation of the switchers via SIS commands, including:

- [Host Control Ports](#)
- [Host to Switcher Instructions](#)
- [Using the Command and Response Tables](#)
- [Switcher-initiated Unsolicited Messages](#)
- [Symbol Definitions](#)
- [Command and Response Table for SIS Commands](#)

Host Control Ports

Configure and control the DTP3 CrossPoint 42 series remotely via a host computer or other device (such as a control system) by connecting to the rear panel LAN port or the front panel USB Config port of the switcher via an SSH (Secure Shell) client on port 22023.

The rear panel LAN port and front panel Configuration port are independent of one another. The front panel USB-C port and the rear panel LAN port can be active at the same time.

Front Panel Configuration Port

The USB-C port is located on the front panel (see [figure 3](#), [B](#) on page 9). Connect to a host computer for configuration using SIS commands via an SSH client and IP address 203.0.113.22 and port 22023 (see [Establishing a Connection](#) to connect to an SSH client).

NOTE: The IP address for the USB-C port cannot be changed.

Ethernet (LAN) Port

The rear panel Ethernet port ([H](#)) on the DTP3 CP 42 series can be connected to an Ethernet LAN or WAN. Communications between the switcher and the controlling device are via an SSH client using port 22023.

The Ethernet cable can be terminated as a straight-through cable or a crossover cable and must be properly terminated for the application (see [RJ-45 Connectors](#) on page 12).

Establishing a Connection

Establish a network connection to a DTP3 CrossPoint matrix switcher via an SSH client:

1. Download the SSH client software to the PC connected to the LAN port.
2. Open the SSH software.
3. Enter the IP address of the matrix switcher in the **Host Name** or **IP address** field.

NOTES:

- If the local system administrators have not changed the value, see the table above for the factory-specified default IP addresses.
- If connecting via the front panel USB-C port, the IP address is 203.0.113.22.

4. Enter **22023** in the **Port** field.

5. The matrix switcher is password protected, so the appropriate administrator or user name and password must be entered.
 - a. Enter **admin** or **user** name.
 - b. Enter the password next to the **Password** prompt.
 - If the login and password are correct, the matrix switcher responds with a copyright message including the copyright year, the name of the product, firmware version, part number, and the current date and time.
 - If the login and password are incorrect, the login prompt returns. Enter the administrator or user name and password again.

NOTES:

- The matrix is shipped password-protected. The factory configured passwords for all accounts on this device have been set to the device serial number.
- In the event of a complete system reset, the passwords convert to the default, which is **extron**. New passwords must be configured to secure the device.
- On password-protected connections, there are two levels of protection: administrator and user. Administrators have full access to all switching capabilities and editing functions. Users can create ties, recall presets, set mutes, and view all settings with the exception of passwords.

Connection timeouts

The Ethernet link times out after a designated period of time of no communications. By default, this timeout value is set to five minutes.

NOTE: Extron recommends leaving the default timeout at 5 minutes and periodically issuing the SIS I command (see [Information Requests](#) on page 41) to keep the connection active. If there are long idle periods, Extron recommends disconnecting the socket and reopening the connection when another command must be sent.

Number of connections

A DTP3 CrossPoint 42 switchers can have multiple TCP connections, including HTTP sockets and Telnet connections. When the connection limit is reached, the switcher accepts no new connections until some have been closed. No error message or indication is given that the connection limit has been reached. To maximize performance of an IP device, the number of connections should stay low and unnecessary open sockets should be closed.

Using Verbose Mode

SSH connections to a DTP3 CrossPoint 42 switchers can be used to monitor for changes that occur on the switchers, such as SIS commands from other LAN sockets. For an SSH session to receive change notices from the switcher, the session must be in verbose mode 2 or 3 (see the SIS command [Verbose Mode](#) on page 39). In verbose modes 2 and 3, the socket reports changes in messages that resemble SIS command responses.

Host to Switcher Instructions

The switchers accept SIS commands through the USB-C config port and the LAN port. SIS commands consist of one or more characters per command field. They do not require any special characters to begin or end the command character sequence. When a command is valid, the unit executes it and sends a response to the host device. Each switcher response to an SIS command ends with a carriage return and a line feed (CR/LF = ↵), which signals the end of the response character string. A string is one or more characters.

Switcher-initiated Unsolicited Messages

When a local event such as a front panel operation occurs, the switcher responds by sending an unsolicited message to the host. The switcher does not expect a response from the host, but the host program might request a new status.

The switcher initiates the following messages (see [Symbol Definitions](#) starting on page 30 for the X variable definitions):

- (c) Copyright 20xx, Extron Electronics, DTP3 CrossPoint 42 [USB], Vx.xx, 60-1925-0x — Displays when the unit is first powered up on a newly connected internet protocol (IP) port.
 - 20xx is the release year of the firmware.
 - xxx is the version number of the DTP3 CrossPoint 42 or 42 USB.
 - Vx.xx is the firmware version number.
 - 60-1925-0x is the unit part number.
- Password: — Displays immediately after the copyright message when connected using TCP/IP and the switcher is password protected. The switcher requires an administrator or user password before allowing commands to be entered. The password message response repeats until a valid password is entered.
- Login Administrator or Login User — A correct password has been entered. If the user and administrator passwords are the same, the switcher defaults to administrator privileges.
- Qik — A front panel tie creation has occurred.
- Rprnn — A memory preset has been recalled from the front panel. nn is the preset number.
- Exen — The front panel security lockout (executive mode) has been toggled on or off. n is the executive mode: 0, 1, or 2.
- Reconfig — A change has occurred in the input frequency. Also displays during software installation and during a power cycle.
- Sig I [X18] — A change has occurred in input signal status.
- HdcpI [X1]*[X9] — A change has occurred in the input HDCP status.
- HdcpO [X3]*[X10] — A change has occurred in the output HDCP status.
- Sts05*[X1]*[X18] — A change has occurred in the audio input status.
- Rate [X3]*[X35] — The output resolution and refresh rate have changed.

Switcher Error Responses

When the switchers receive a valid SIS command, they perform the command and send a response to the host device. If a switcher receives an invalid command or a command that contains invalid parameters, it is unable to perform the command and returns an error response to the host. The error response codes are:

- E01 — Invalid input channel number (out of range)
- E10 — Invalid command
- E11 — Invalid preset number (out of range)
- E12 — Invalid output number (out of range)
- E13 — Invalid parameter
- E14 — Invalid command for this configuration
- E17 — Invalid command for signal type
- E18 — System or command timed out
- E22 — Busy
- E24 — Privilege violation (Ethernet and Extron software only).
Users have access to all view and read commands, and can create ties, recall presets, and set audio mutes) **Exception:** Users cannot read administrator passwords.
- E25 — Device not present
- E26 — Maximum number of connections exceeded
- E28 — Bad filename or file not found

NOTE: If the unit does not support or recognize the entered commands, no response is issued.

Using the Command and Response Tables

The [Command and Response Table for SIS Commands](#) starts on page 33. Symbols used in the table represent variables in the command and response fields. Command and response examples are shown throughout the table. The SIS commands are **not** case sensitive. The ASCII to HEX conversion table below is for use with the command and response table.

ASCII to Hex Conversion Table																Esc	1B	CR	0D	LF	0A
Space →	20	!	21	"	22	#	23	\$	24	%	25	&	26	'	27						
(	28	)	29	*	2A	+	2B	,	2C	-	2D	.	2E	/	2F						
0	30	1	31	2	32	3	33	4	34	5	35	6	36	7	37						
8	38	9	39	:	3A	;	3B	<	3C	=	3D	>	3E	?	3F						
@	40	A	41	B	42	C	43	D	44	E	45	F	46	G	47						
H	48	I	49	J	4A	K	4B	L	4C	M	4D	N	4E	O	4F						
P	50	Q	51	R	52	S	53	T	54	U	55	V	56	W	57						
X	58	Y	59	Z	5A	[	5B	\	5C	]	5D	^	5E	_	5F						
`	60	a	61	b	62	c	63	d	64	e	65	f	66	g	67						
h	68	i	69	j	6A	k	6B	l	6C	m	6D	n	6E	o	6F						
p	70	q	71	r	72	s	73	t	74	u	75	v	76	w	77						
x	78	y	79	z	7A	{	7B		7C	}	7D	~	7E	DEL	7F						

Special Characters

The switcher accepts all alpha-numeric characters except | and “space”, as the name of the switcher, passwords, or locally created file names.

- NOTES:**
- For commands and examples of computer or device responses used in this guide, the character “0” is the number zero and “O” is the capital letter “o.”
 - Only instances marked with a • character require a space. Any spaces between characters in the command and response tables are only inserted for ease of reading.
 - Unless stated otherwise, SIS commands are not case sensitive.

Symbol Definitions

↵ = Carriage return and line feed

← = Carriage return (no line feed)

| = Pipe (can be used interchangeably with the ← character)

• = Space

Esc = Escape key

W = Can be used interchangeably with the Esc character

X1 = Input number

00 to 04 (00 = untied input)

X2 = Host input number

00 to 03 (00 = untied host)

X3 = Output number

00 to 03 (00 = untied output)

X4 = Audio input number

00 to 04 (00 = untied input)

X5 = Device output number

00 to 04 (00 = untied device)

X6 = Audio output number

00 to 03 (00 = untied output)

X7 = Video mute status

0 = Unmute video

1 = Mute video

2 = Mute video and sync

X8 = Remote power setting

0 = Off (default)

1 = 12 V

2 = 48 V

X9 = HDCP input status

0 = No source connected

1 = Source is HDCP-compliant

2 = Source is not HDCP-compliant

X10 = HDCP output status

0 = No monitor connected

1 = Monitor connected, does not support HDCP.

2 = Monitor connected, supports HDCP but is not encrypted.

3 = Monitor connected: supports HDCP and is encrypted.

X11 = HDCP authentication

0 = Disable HDCP authentication

1 = Allow HDCP authentication (default)

X12 = DP Alt mode lane configuration

DisplayPort Alt mode setting

1 = Two lanes of DisplayPort video (default)

2 = Four lanes of DisplayPort video

X13 = Power Save modes

0 = Power Save off — Device runs at full power (default).

1 = Power Save on — Device enters a low power state in which everything is powered down, including DTP remote power.

2 = Power save on (partial) — Device enters a partial low power state, maintaining DTP and DTP3 remote power and Ethernet to RS-232 insertion communication. Front panel LEDs, scaler outputs, and over TP functions are also enabled.

This mode can be exited only by using the Esc 0 PSAV ← command (see

Power Save commands on page 36.

9 = Low power state due to high temperature (not settable, query and response only)

X14 = Audio mute status

0 = Unmute audio

1 = Mute audio

X15 = Executive mode

0 = Unlock the front panel (default)

1 = Mode 1 (complete front panel lockout)

2 = Mode 2 (tie configuration and preset management only)

X16 = Logo number

00 – 16 (00 = no logo, 0 = disable logo on selected output)

X17 = Unit name

Text string of up to 63 alphanumeric characters and hyphens (-)

• No spaces can be used.

• First character must be a letter.

• Last character cannot be a hyphen.

• Command does not distinguish between uppercase and lowercase letters.

Default unit name = **DTP3 - CrossPoint - 42 -xx-xx-xx**.

X18 = Input video signal status

0 = No video signal at input

1 = Input video signal detected

X19 = Product part number

X20 = IP address

X21 = Subnet mask

X22 = Prefix (subnet mask bits)

X23 = Gateway IP address

X24 = Global preset number

X25 = Verbose mode

Standard model: 60-1925-01

USB model: 60-1925-02

nnn.nnn.nnn.nnn

Leading zeros are optional in the four octets when setting values. They are suppressed in responses.

nnn.nnn.nnn.nnn (default = 255.255.255.0)

Leading zeros are optional in the four octets when setting values. They are suppressed in responses.

(For CISG commands) Default subnet mask 255.255.255.0 is represented as a prefix value of /24.)

nnn.nnn.nnn.nnn (0.0.0.0 = default)

0 - 16

0 = Current ties for the system in view

0 = Clear/None (Ethernet default)

1 = Verbose mode

2 = Tagged response for queries

3 = Verbose mode and tagged response for queries

Verbose mode reverts to default in the event of the following:

- A power cycle
- Disconnection from Ethernet

NOTES:

- In **verbose response** mode, the DTP3 CP 42 returns unsolicited responses for value and setting changes that may result from a signal change, or a setting adjustment made via another interface.

Example: The DTP3 CP 42 can send out a notice of a change in some setting without receiving a query via a PC or a control system. That change could have been a result of an internal process or a selection made via the PCS program. This is a verbose (wordy) relationship between the controller and a connected device.

- If **tagged responses** are enabled, all “view” commands return the command string plus the data, the same as in responses for setting a value.

For example, to view a video output tie:

Command: **X3**%

Response: Out**X3**•In**X1**•Vid← or **X1**← (untagged)

X26 = Ethernet port timeout

The number of seconds (each step is 10 seconds) before timeout on IP connections.

1 - 65000 (10 - 650,000 seconds)

If no data is received during the timeout period, the Ethernet connection closes.

X27 = Enable Telnet port 23

0 = Off (default)

23 = Telnet Port 23 enabled

X28 = Telnet port mapping

Response is five digits with leading zeros (Example: 00000 or 00023).

X29 = Global preset number

01 through 16

Up to 32 characters are permitted, including the following special characters:

- ! # \$ % ^ & * () _ + . /

The following characters are **not** supported: = ~ , @ [] { } ' " ; : | \ and ?

X30 = Image reset

0 = Execute an image reset (follows aspect setting)

1 = Image reset and fill the output raster

2 = Image reset and follow the input aspect ratio

X31 = Detected input audio format

0 = Not detected

1 = Digital

X32 = Detected video input color space format

0 = No input color space detected

1 = YUV

2 = RGB

X33 = Detected pixel clock

Response is four digits, padded with zeros. *Example:* 0297 = 297 MHz

0000 = No pixel clock detected

X34 = Detected input resolution and rate

Example: 3840x2160@59.9 Hz

0000x0000@000 Hz = No input resolution and refresh rate detected

X35 = Ethernet port echo

0 = Echo off

1 = Echo on (default)

X36 = Output scaler resolution and rate

3-digit response with 0 padding (see the Resolution Rate table.)

Resolution Rate Table for X36								
Resolution	23.98 Hz	24 Hz	25 Hz	29.97 Hz	30 Hz	50 Hz	59.94 Hz	60 Hz
640 x 480								10
800 x 600								11
1024 x 768								12
1280 x 768								13
1280 x 800								14
1280 x 1024								15
1360 x 768								16
1366 x 768								17
1440 x 900								18
1400 x 1050								19
1600 x 900								20
1680 x 1050								21
1600 x 1200								22
1920 x 1200								23
480p							24	25
576p						26		
720p			29	30	31	32	33	34
1080i						35	36	37
1080p	38	39	40	41	42	43	44	45*
2048 x 1080	46	47	48	49	50	51	52	53
2048 x 1200								54
2048 x 1536								55
2560 x 1080								56
2560 x 1440								57
2560 x 1600								58
3840 x 2160	59	60	61	62	63	64	65	66
4096 x 2160	69	70	71	72	73	74	75	76
Custom EDID/Output rate 1 (based on capture or uploaded EDID)								201
* = Default output resolution (1080p)								

X37 = Video freeze status

0 = Freeze disabled (default)

1 = Freeze enabled

X38 = Audio output volume

Volume adjustment range: 0 to -100 in 1 dB steps (0% to 100%)

Default = 0.

X39 = USB device port number

1 to number of device ports in the USB hub

X40 = USB device port status

0 = Device port enabled (default)

1 = Device port disabled

X41 = USB signal status

1 = USB enabled (default)

0 = USB disabled

Command and Response Table for SIS Commands

Command Function	SIS Command (Host to Unit)	Response (Unit to Host)	Additional Description
Output Switching and Ties			
NOTES: - Commands can be entered back-to-back in a string, with no spaces. For example: 1*1!02*03%02*03\$4*4!. - The quick multiple tie and tie input to all outputs commands activate all I/O switches simultaneously. - The matrix switcher supports 1- and 2-digit numeric entries (1*1 or 02*02). Responses are 2 digits with a leading zero. - Audio-only ties apply only to output 3.			
Tie an input to an output			
Tie an input to an output, audio and video	[X1] * [X3] !	Out[X3] • In[X1] • All←	Tie input [X1] to output [X3], all signals.
Tie an input to an output, video only	[X1] * [X3] %	Out[X3] • In[X1] • Vid←	Tie input [X1] to output [X3], video only.
Tie an input to an output, audio only	[X4] * 03 \$	Out03 • In[X4] • Aud←	Tie input [X4] to output 03, audio only.
Tie an input to all outputs			
Tie an input to all outputs, audio and video	[X1] * !	In[X1] • All←	Tie input [X1] video and audio to all outputs.
Tie a video input to all outputs	[X1] * %	In[X1] • Vid←	Tie input [X1] video to all outputs.
Tie an audio input to all outputs	[X4] * \$	In[X4] • Aud←	Tie audio input [X4] to all outputs.
Tie a host to all devices (USB only)	[X2] * ^	In[X2] • Usb←	Tie USB host [X2] to all USB devices.
Untie			
Untie all outputs	0 * !	In00 • All←	Untie all outputs from inputs.
Untie all USB outputs	0 * ^	In00 • Usb←	Untie all USB devices from USB hosts.
Untie an output	0 * [X3] !	Out[X3] • In00 • All←	Untie output [X3] from all inputs.
Untie all outputs, video	0 * %	In00 • All←	Untie all video outputs.
Untie an output, video	0 * [X3] %	Out[X3] • In00 • Vid←	Untie output [X3], video.
Untie an output, audio	0 * [X3] \$	Out[X3] • In00 • Aud←	Untie output [X3], audio.
Quick tie			
Quick multiple tie	[Esc]+Q[X1] * [X3] ! . . . [X1] * [X3] ! ←	Qik← or Qik14←	Make multiple ties with one command. Qik14 is the response when part of the command is invalid or incorrect.
NOTE: The Quick tie applies to all I/O or analog audio sections.			
KEY: [X1] = Input number 00 to 04 (00 = untied input) [X2] = USB host input number 00 to 03 (00 = untied host) [X3] = Output number 00 to 03 (00 = untied output) [X4] = Audio input number 00 to 04 (00 = untied input) [X5] = USB device output number 00 to 04 (00 = untied device)			

Command Function	SIS Command (Host to Unit)	Response (Unit to Host)	Additional Description
Output Switching and Ties (continued)			
View individual ties			
View follow-all tie	[X3]! <i>In verbose mode 2 or 3</i>	[X1] Out[X3]•In[X1]•All	View follow-all tie between input [X1] and output [X3].
NOTE: If the view follow-all tie command is sent to an output with a break-away tie, the switcher responds with an E13 error message.			
View video output tie	[X3]% <i>In verbose mode 2 or 3</i>	[X1] Out[X3]•In[X1]•Vid	Video input [X1] is tied to output [X3].
View audio output tie	[X6]\$ <i>In verbose mode 2 or 3</i>	[X4] Out[X6]•In[X4]•Aud	Audio input [X4] is tied to output [X6].
View USB tie	[X5]^ <i>In verbose mode 2 or 3</i>	[X2] Out[X5]•In[X2]•Usb	USB host [X2] is tied to USB device [X5].
View all ties			
View all video ties	[Esc]0*1*1VC <i>In verbose mode 2 or 3</i>	[X1] ^{1A} •[X1] ^{1B} •[X1] ² •Vid Vgp00•Out01*[X1] ^{1A} •[X1] ^{1B} •[X1] ² •Vid	
View all audio ties	[Esc]0*1*2VC <i>In verbose mode 2 or 3</i>	[X4] ^{1A} •[X4] ^{1B} •[X4] ² •[X4] ³ •Aud Vgp00•Out01*[X4] ^{1A} •[X4] ^{1B} •[X4] ² •[X4] ³ •Aud	
View all USB ties (USB model only)	[Esc]0*1*3VC <i>In verbose mode 2 or 3</i>	[X2] ¹ •[X2] ² •[X2] ³ •[X2] ⁴ •Usb Vgp00•Out03*[X2] ¹ •[X2] ² •[X2] ³ •[X2] ⁴ •Usb	
KEY: [X1] = Input number 00 to 04 (00 = untied input) [X2] = USB host input number 00 to 03 (00 = untied host) [X3] = Output number 00 to 03 (00 = untied output) [X4] = Audio input number 00 to 04 (00 = untied input) [X5] = USB device output number 00 to 04 (00 = untied device) [X6] = Audio output number 00 to 03 (00 = untied output)			
DTP Remote Power			
Set output remote power	[Esc]01*[X8] RPWR	Rpwr1*[X8]	Set remote power level [X8] for output 1.
View remote power	[Esc]01RPWR	[X8]	View remote power level [X8] for output 1.
KEY: [X8] = DTP remote power 0 = Off (default) 1 = 12 V (DTP) 2 = 48 V (DTP3)			
DP Alt Mode Lane Configuration			
Set DisplayPort mode	[Esc]F 1*[X12] USBC	UsbcF 1*[X12]	Set DisplayPort alt mode lane configuration to [X12].
View DisplayPort mode	[Esc]F 1 USBC <i>In verbose mode 2 or 3</i>	[X12] UsbcF 1*[X12]	View current DP alt mode setting [X12].
KEY: [X12] = DP alt mode line configuration 1 = Two lanes of DisplayPort video (default) 2 = Four lanes of DisplayPort video			

[illegible]

Command Function	SIS Command (Host to Unit)	Response (Unit to Host)	Additional Description
Mutes (continued)			
Audio mute			
NOTE: Outputs 1A and 1B cannot be independently muted. The following commands apply to all audio outputs.			
Mute audio	[X3]*1Z	Amt[X3]*1↵	Mute audio output [X3].
Unmute audio	[X3]*0Z	Amt[X3]*0↵	Unmute audio [X3].
Audio mute all	1*Z	Amt1↵	Mute audio on all outputs.
Audio unmute all	0*Z	Amt0↵	Unmute audio on all outputs.
View audio mute	[X3]Z In verbose mode 2 or 3	[X14]↵ Amt[X3]*[X14]↵	View audio mute status [X14] for output [X3].
KEY: [X3] = Output number 00 to 03 (00 = untied output) [X14] = Audio mute status 0 = Off (unmute audio) 1 = Mute audio			
View all output mutes			
View output mutes	[Esc]VM↵ In verbose mode 2 or 3	[X7] ^{1A} [X7] ^{1B} [X7] ² ↵ Mut00•[X7] ^{1A} [X7] ^{1B} [X7] ² ↵	View mute status [X7] for all outputs.
KEY: [X3] = Output number 00 to 03 (00 = untied output, valid for tie commands only) [X7] = Mute status 0 = Off (unmute video) 1 = Mute video 2 = Mute video and sync			
Audio Output Volume			
Output volume level	[X38]V	Vol[X38]↵	Set output audio volume level to [X38].
Increment output audio volume	+V	Vol[X38]↵	Increment the audio output volume.
Decrement output audio volume	-V	Vol[X38]↵	Decrement the audio volume
View audio output volume	V In verbose mode 2 or 3	[X38]↵ Vol[X38]↵	View audio volume level
KEY: [X38] = Audio output volume Volume adjustment range: 0 to -100 in 1 dB steps (0% to 100%) Default = 0.			
Power Save			
Set power save mode	[Esc] [X13]PSAV↵	Psav[X13]↵	Set power save mode [X13].
View power save setting	[Esc]PSAV↵ In verbose mode 2 or 3	[X13]↵ Psave[X13]↵	View power save setting.
KEY: [X13] = Power save modes 0 = Power save off — Device runs at full power (default). 1 = Power save on — Device powers everything down, including DTP and DTP3 remote power. Front panel LEDs, scaler outputs, and over TP functions are disabled. 2 = Power save on (partial) — Device enters a partial low power state, maintaining DTP remote power and Ethernet to RS-232 insertion communication. Front panel LEDs, scaler outputs, and over TP functions are also enabled. 9 = Low power state due to over temp (not settable, query and response only)			

Command Function	SIS Command (Host to Unit)	Response (Unit to Host)	Additional Description
Executive Mode			
Set executive mode	<code>[X15]X</code>	<code>Exe[X15]↵</code>	Set lock mode to <code>[X15]</code> .
View executive mode status	<code>X</code> <i>In verbose mode 2 or 3</i>	<code>[X15]↵</code> <code>Exe[X15]↵</code>	View the current lock mode.
KEY: <code>[X15]</code> = Executive mode 0 = Unlock the front panel (default). 1 = Mode 1 (complete front panel lockout) 2 = Mode 2 (Only tie configuration and preset management are unlocked.)			
Logo Configuration			
NOTE: Logos and switch effects cannot be set independently on buffered outputs, therefore, outputs 1A and 1B are not specified for these commands.			
Assign a logo to an output	<code>[Esc] E[X3]*[X16]LOGO↵</code>	<code>LogoE [X3]*[X16]↵</code>	Assign logo <code>[X16]</code> to output <code>[X3]</code> .
Unassign a logo	<code>[Esc] E[X3]*0LOGO↵</code>	<code>LogoE [X3]*0↵</code>	Remove the logo from output <code>[X3]</code> .
View logo assignment	<code>[Esc] E[X3] LOGO↵</code>	<code>[X16]↵</code>	View the logo (<code>[X16]</code>) assigned to output <code>[X3]</code> .
View all logo assignments	<code>[Esc] E LOGO↵</code> <i>In verbose mode 2 or 3</i>	<code>[X16]¹•[X16]²↵</code> <code>LogoE[X16]¹•[X16]²↵</code>	Up to two digits, which are the logo status of scaled outputs.
KEY: <code>[X3]</code> = Output number 1 to 03 (00 = untied output, valid for tie commands only) <code>[X16]</code> = Logo number 00 - 16 (00 = no logo, 0 to disable logo on a selected output)			
Unit Name			
NOTE: Text string of up to 63 alphanumeric characters and hyphens. - No spaces can be used. - First character must be a letter. The last character cannot be a hyphen. - The command does not distinguish between uppercase and lowercase letters.			
Set unit name	<code>[Esc] [X17]CN↵</code>	<code>Ipn•[X17]↵</code>	Set unit name to <code>[X17]</code> .
Set unit name to defaults	<code>[Esc] •CN↵</code>	<code>Ipn•DTP3-CrossPoint-42-xx-xx-xx↵</code> or <code>Ipn•DTP3-CrossPoint-42-USB-xx-xx-xx↵</code>	Reset the unit name to the unit factory defaults.
View unit name	<code>[Esc] CN↵</code> <i>In verbose mode 2 or 3</i>	<code>[X17]↵</code> <code>Ipn•[X17]↵</code>	View unit name <code>[X17]</code> .
KEY: <code>[X17]</code> = Unit name of up to 63 alphanumeric characters and hyphens. Default is DTP3-CrossPoint-42-xx-xx-xx or DTP3-CrossPoint-42-USB-xx-xx-xx. xx-xx-xx are the last six characters of the unit MAC address.			
Extron Serial Number			
View unit serial number	<code>19I</code> <i>In verbose mode 2 or 3</i>	<code>{Serial number}↵</code> <code>Inf19*{Serial number}↵</code>	
Signal Status			
View video signal status	<code>0LS↵</code> <i>In verbose mode 2 or 3</i>	<code>[X18]¹•[X18]²•[X18]³•[X18]⁴↵</code> <code>In00•[X18]¹•[X18]²•[X18]³•[X18]⁴↵</code>	View video signal status <code>[X18]</code> for all inputs.
KEY: <code>[X18]</code> = Input signal status 0 = No signal at input, 1 = Input signal detected			

Command Function	SIS Command (Host to Unit)	Response (Unit to Host)	Additional Description
Select USB Device Ports			
Enable device port	[Esc]X[X39]*0 USBC ←	UsbcX[X39]*0 ←	Enable USB downstream device port [X39] for peripherals.
Disable device port	[Esc]X[X39]*1 USBC ←	UsbcX[X39]*1 ←	Disable USB downstream device port [X39].
Enable all device ports	[Esc]X0 USBC ←	UsbcX 0 ←	Enable all USB downstream device ports for peripherals.
Disable all device ports	[Esc]X1 USBC ←	UsbcX 1 ←	Disable all USB device ports.
View status of all device ports	[Esc]X USBC ← <i>In verbose mode 2 or 3</i>	[X40] ¹ •[X40] ² •[X40] ³ •[X40] ⁴ •[X40] ^{RX} ← Usbc[X40] ¹ •[X40] ² •[X40] ³ •[X40] ⁴ •[X40] ^{RX} ← <i>Response format:</i> Device Port1•Port2•Port3•Port4•DTP3 receiver View status [X40] of all USB device ports	
KEY: [X39] = USB device port number 1 to 4, RX = DTP3 receiver [X40] = Device port signal status 0 = Port enabled (default) 1 = Port disabled			
USB Signal Status			
View the signal status of all USB input hosts	[Esc]I USBC ← <i>In verbose mode 2 or 3</i>	[X41]•[X41]•[X41] ← UsbcI[X41]•[X41]•[X41] ← <i>Response format:</i> USB-C input 1•Host input 2•Host input 3	View input signal presence [X41] on USB-C input 1 and USB 3.2 type B host ports 2 and 3.
View the signal status of all USB output devices	[Esc]O USBC ← <i>In verbose mode 2 or 3</i>	[X41] ¹ •[X41] ² •[X41] ³ •[X41] ⁴ •[X41] ^{RX} ← UsbcO[X41] ¹ •[X41] ² •[X41] ³ •[X41] ⁴ •[X41] ^{RX} ← <i>Response format:</i> Device port 1•Port 2•Port 3•Port 4•DTP3 receiver	View signal presence [X41] on the four USB type A device ports.
KEY: [X41] = USB port signal status 1 = USB enabled (default) 0 = USB disabled			
Telnet Port			
Set Telnet port mode	[Esc]Z[X27]P MAP ←	PmapZ[X28] ←	Set the Telnet port map to [X27].
View Telnet port mode	[Esc]Z PMP ← <i>In verbose mode 2 or 3</i>	[X28] ← PmapZ[X28] ←	View Telnet port map [X28].
KEY: [X27] = Enable Telnet port 23 0 = Off (default) 23 = Telnet port 23 enabled [X28] = Port number Response is 5 digits with leading zeros (<i>Example: 00000 or 00023</i>)			
Ethernet Data Port Timeout			
Set current port timeout	[Esc]0 * [X26]T C ←	Pti0 * [X26] ←	
View current port timeout	[Esc]0 T ←	[X26] ←	
KEY: [X26] = Timeout Number of seconds (each step = 10 seconds) before timeout on IP connections (1 to 65000) Default = 30 (300 seconds) If no data is received during the timeout period, the Ethernet connection closes.			

Command Function	SIS Command (Host to Unit)	Response (Unit to Host)	Additional Description
------------------	-------------------------------	----------------------------	---------------------------

Echo for SIS Over SSH (Port 22023)

NOTE: The echo setting is for the current connection only, and remains until the connection is closed. Apply after a connection is established.

Enable echo	Esc 1ECHO←	Echo1↵	Return command entered with response.
Disable echo	Esc 0ECHO←	Echo0↵	Return response only.
View	Esc ECHO← <i>In verbose mode 2 or 3</i>	X35 ↵ Echo X35 ↵	View echo status X35 .

KEY: **X35** = Echo for SIS over SSH 0 = Off, 1 = On (default)

IP Address

NOTE: Leading zeros are optional in setting IP values and are suppressed in returned values.

Set IP address	Esc X20 CI←	Ipi• X20 ↵	Set unit IP address X20 .
View IP address	Esc CI←	X20 ↵	
Set multiple IP parameters at once	Esc 1* X20 / X22 * X23 CISG←	Cisg1* X20 / X22 * X23 ↵	Set the IP address to X20 , the subnet mask to X21 , and the gateway IP address to X23 .
View all IP settings	Esc 1CISG←	X20 / X22 * X23 ↵	View the unit IP address, subnet mask (prefix), and gateway address.

KEY: **X20** = IP address (*nnn.nnn.nnn.nnn*)
X22 = Prefix representing subnet mask bits (subnet mask value in CISG commands). Leading zeros in all four octets are optional. Default is /24, which represents the default subnet mask: 255.255.255.0.
X23 = Gateway IP address (*nnn.nnn.nnn.nnn*)

Verbose Mode

NOTE: Verbose mode will revert back to default in the event of a power cycle or disconnecting from the Ethernet.

Set verbose mode	Esc X25 CV←	Vrb X25 ↵	Set verbose mode X25 .
View verbose mode	Esc CV←	X25 ↵	

KEY: **X25** = Verbose mode 0 = Clear or none (Ethernet default)
1 = Verbose mode
2 = Tagged response for queries
3 = Verbose mode and tagged response for queries
See the [verbose mode symbol definitions](#) on page 25 for more information.

Command Function	SIS Command (Host to Unit)	Response (Unit to Host)	Additional Description
Global Presets			
NOTES: - Saving a direct write preset does not make it active. It becomes active only when recalled. - If a preset has not been assigned to a slot, the name displays as [unassigned]. - If the user tries to name an unassigned preset or to recall a preset that is not saved, the unit responds with an E11 error code (see Switcher Error Responses on page 29). - If a space is used as a name, the preset name defaults to Preset [X24]. - The name can be up to 32 characters, including the following special characters: - ! # \$ % ^ & * () _ + . / - The following characters are invalid or not recommended for names: = ~ , @ ' " ; : \ ?			
Direct global preset	[Esc] + [X24] P [X1]*[X3]%. . . [X1]*[X3] % ←	Spr [X24] ←	Write and save a global configuration.
Save global preset	[X24],	Spr [X24] ←	Save the current configuration as preset [X24].
Recall global preset	[X24].	Rpr [X24] ←	Recall global preset [X24].
Write global preset name	[Esc] [X24], {preset name} NG ←	Nmg [X24], {preset name} ←	Write a name for preset [X24].
View global preset name	[Esc] [X24] NG ← In verbose mode 2 or 3	{preset name} ← Nmg [X24], {preset name} ←	View the name for preset [X24].
KEY: [X1] = Input number 01 to 04 [X3] = Output number 01 to 03 [X24] = Global preset number 0 to 16 (0 = current ties for system in view)			
Input and Output Names			
NOTES: - The name can be up to 32 characters, including the following special characters: - ! # \$ % ^ & * () _ + . / - The following characters are invalid or not recommended for names: = ~ , @ ' " ; : \ ? - If no name has been assigned, the default name is displayed.			
Name input	[Esc] [X1], {input name} NI ←	Nmi [X24], {input name} ←	Assign a name to input [X1].
View input name	[Esc] [X1] NI ← In verbose mode 2 or 3	{input name} ← Nmi [X1], {input name} ←	View name for input [X1].
Name output	[Esc] [X3], {output name} NO ←	Nmo [X3], {output name} ←	Assign name to output [X3].
View output name	[Esc] [X3] NO ← In verbose mode 2 or 3	{output name} ← Nmo [X3], {output name} ←	View the name for output [X3].
KEY: [X1] = Input number 01 to 04 [X3] = Output number 1 to 03			
DTP3 Scaler Functions — Output Configuration			
NOTE: For all scaler settings, the commands apply to output number only. For example, when issued to output 1, image resets output ports 1A and 1B simultaneously.			
Image reset			
Perform image reset	[X3] * [X30] A	Img [X3] * [X30] ←	Execute image reset [X30] on output [X3].
KEY: [X3] = Output number 01 or 02 [X30] = Image reset type 0 = Execute an image reset (follows aspect setting) 1 = Image reset and fill the output raster 2 = Image reset and follow the input aspect ratio			

DTP3 CrossPoint 42 Series Matrix Switchers • SIS Configuration and Control 41

Command Function	SIS Command (Host to Unit)	Response (Unit to Host)	Additional Description
Resets			
Erase all files from flash memory	Esc ZFFF←	Zpf↵	Remove files created in user space.
Reset unit settings	Esc ZXXX←	Zpx↵	Reset unit back to factory default.
Absolute reset, including IP settings	Esc ZQQQ←	Zpq↵	Absolute reset: Reset all device and IP settings to default values and delete user-loaded files.
Absolute reset, retaining IP settings	Esc Zy←	Zpy↵	Reset unit to factory defaults except IP settings.
Reset IP system	Esc 1ZQQQ←	Zpq1↵	Reset IP address to 192.168.254.254 and subnet mask to 255.255.255.000 only.
Audio gain and attenuation reset	Esc ZA←	Zpa↵	Reset the audio and attenuation levels to defaults.
Reboot system	Esc 1B00T←	Boot1↵	Reboot the system.