Quickstart Guide Barcodescanner V1.0

Nr.	Picture	To do
1		Download the newest Version of the barcodescanner image from the RCLL github page.
		Write barcodescanner image to SD card.
2		Insert SD card in a raspberry Pi3, connect LAN port to PC and power up raspberry.
3		Change PC IP adress to 192.168.2.xxx subnet (e.g. 192.168.2.80).
4		Open webbrowser and enter the following URL: http://192.168.2.123:1880/ui/#!/0
5	Select machine Cyan Select option Magenta Select option ▼	Now choose the MPS on which the barcodescanner will be mounted. (Basestation needs 2 Barcodescanner devices one at dir IN and one at dir OUT)
6	Select machine Raspberry control REBOOT RASPBERRY Cyan C-BS Out SHUTDOWN RASPBERRY Magenta Select option	Click « reboot raspberry » Raspberry reboots and changes his static IP and OPC UA Endpoint to the MPS chosen before.
7		Settings are changed and saved -> Mount raspberry and the USB barcodescanner (with 3d printed mount) on MPS. - Connect USB barcode reader to any USB port from the raspberry - Connect patchcable from raspberry LAN port to PLC LAN port.
8		Power up MPS.

