

CXT_KBT Tutorial

♠ / CXT_KBT

1. Description of CXT_KBT

This tool is used for functional testing, verification, and requirements collection before the official version of the driver is updated. The interface and functions do not represent the final rendering effect.

If you find problems during use, or have better suggestions, you can contact customer service C in the group to give feedback.


Options ▼

This tool only supports Windows system

Download address [2022-06-02] https://cxt-studio.lanzouf.com/iyHth05tii2d 🖸

2. Basic instruction

- ▶ 1. Turn on VIA-C and set the key position as a custom key
- ▶ 2. Open CXT_KBT, click the key that has just been set as a custom key in VIA-C, and set the desired function
- 3. Functions such as automatic layer change and layer indication do not need to be set in VIA-C, and CXT_KBT will run automatically after startup
- + 4. After selecting the keyboard model, the program will automatically connect the keyboard, and it will also automatically reconnect after re-plugging, no need to manually open the device



3. Shortcut function

With the custom keys in VIA-C, many functions can be realized. The current functions may not be perfect. Welcome to try and give feedback

3.1. Open the file

► Supports opening files by default, and using specified programs to open files



https://cxtkb.com/zh/CXT_KBT

12/2/22, 12:58 PM CXT_KBT Tutorial | CXT Labs



Translated to: English

Show original

Options ▼

3.2. Open folder

▶ can open folder

3.3. Start the program

3.4. Start URL

- You can call the default browser or specify a browser to open the URL
- Figure 1 If you checked Use the specified browser to open the URL, but the browser does not exist in the computer, there will be no change after the trigger
- ▶ The URL needs to start with http or https, please do not enter an incomplete URL like " <u>baidu.com "</u> ☑

3.5. Send text

The text here can be any character and encoding format, and can also be unicode characters, but the sending principle is different from that of macros, and it is not sent in the form of key values, so the scenarios are more limited and may not be used for password input and other scenarios.

3.6. Executing commands

3.7. Execute the script

3.8. One-key search

After setting this function and selecting a search engine, select text [such as WeChat, QQ, webpage, Word, etc.] in any interface, press this button, and the default browser will be invoked to display the search results with the specified search engine.

3.9. One-key translation

3.10. Macro

4. Floor indication floating window





- 1. The layer floating window can mainly display the current layer and scene of the keyboard, and can also display the utilization rate of the current system memory, network, CPU, and hard disk.
- 2. Through the shortcut menu of the right button of the floating window, you can quickly perform layer switching operations
- 3. Click the left mouse button on the blank area in the lower right corner of the floating window to drag the floating window, right click to select the recording position, and the next startup will appear in the previously recorded position


4.1 Layer indication

• After CXT_KBT is started, the floating window will be started by default, and the floating window will display the layer where the current keyboard is located

4.2 Scene indication

► If the scene is set, the floating window will also display the current scene


5. Encoder



- Click the encoder button on the main interface to pop up the encoder setting interface. After clicking Get, the encoder resolution parameters in the current keyboard will be read, and you can set it after modifying it according to your needs.
- ▶ 20 pulses 20 positioning is 4, 15 pulses 30 positioning is 2

6. Automatic layer change

https://cxtkb.com/zh/CXT_KBT 2/3



© 2022 CXT Labs. all rights reserved. | Provider CXT

https://cxtkb.com/zh/CXT_KBT 3/3