

]õÙ]•à]

2026-488395 :^...ä^ þ

]uÖ^uÜ]

]5Ö]2 ¥x]U

2 :uÖ^uÜ

] Ñ^ è^EÜ 12 ^

]õÙ]•à]e

Mettler Toledo :]õè^eÜ]C

electronic :^...Ù^•Ü]a

2131 :]õè^eÜ]•è^

]"%ç - :]Eá]ää

- :^¥Ö^uÖ]ä

- :)d(^¥Ü^•þ]â

- :)e(]ÅÖ]•Ü]â

- :^uÖ]•Ö

13.1.26 :]Eç]•Ó] Ú

13.1.27 :]EÐ] Ó] Eç]

^ Ø^EÜ] þ]

ACCURACY OF READING AND ZERO DEVIATION

LOAD MASS	¥á]åâ]UP]Eá]à UPLOAD READING]EÙ]Åâ] Ô] Ù^...ç UPLOAD ERROR]EÙ]Åâ] Ô]•Ø^ DOWNLOAD READING]EÓ]•è]Ñ]EÐ]•è^p DOWNLOAD ERROR]EÓ]•è]Ñ]EÙ]...á PERMISSIBLE ERROR
0	0	0	0	0	0.001
0.5	0.5	0	0.5	0	0.001
1	1	0	1	0	0.001
5	5	0	5	0	0.001
10	10	0	10	0	0.001
15	15	0	15	0	0.001

^ ¥è^¥Ö]â

LOADING POINT]Eá]åâ]B ê]5Ö^uà UPLOAD READING]EÙ]Åâ] Ô] Ù^...ç UPLOAD ERROR]EÙ]Åâ] Ô]•Ø^ PERMISSIBLE ERROR
leÜ^...þ	4.95	0	0.001
]öÙ]åÙ]•þ]5ç	4.95	0	0.001
]ÄÐ]åé]•þ]5ç	4.95	0	0.001
]öÙ]åÙ]•è]Ux]	4.95	0	0.001
]ÄÐ]åé]•è]Ux]	4.95	0	0.001

^ ¥è^¥Ö]â

LOAD MASS	¥á]åâ]UP]Eá]à MASS READING]Eá]åÔ ^¥Ð]•è^p READING ERROR]EÐ]•è^uÑ]EÙ]...á PERMISSIBLE ERROR
7.5	7.5	0	0.001

]õÙ^uê :^

PASS :]Eç]•Ó] Ô

.R O.I.M.L - 111]•þ]UÐ]Åà]•Ñ]õç^ç
]"%ç] Ô]5Ô]
.^¥Ô]•à^•Ñ]