

]õÙ]•à]

2026-727159 :^...ä^ þ

]uÖ^uÜ]

]5Ö]2 ¥x]U

2 :uÖ^uÜ

] Ñ^ è^EÜ 12

]õÙ]•à]e

Mettler Toledo :]õè^eÜ]C

electronic :^...Ù^•Ü]a

56756 :]õè^eÜ]•è

]"%ç - :]Eá]ää

- :^¥Ö^uÖ]ä

- :)d(^¥Ü^•þ]ä

- :)e(]ÅÖ]•Ü]ä

- :^uÖ]•Ö

13.1.26 :]Eç]•Ó] Ú

13.1.27 :]EÐ] Ó] Eç

^ Ø^EÜ] þ]

ACCURACY OF READING AND ZERO DEVIATION

LOAD MASS	¥á]ää]UP]Eá]à UPLOAD READING]EÙ]Åâ] Ô] Ù^...ç UPLOAD ERROR]EÙ]Åâ] Ô]•Ø^ DOWNLOAD READING]EÓ]•è]Ñ]EÐ]•è^p DOWNLOAD ERROR]EÓ]•è]Ñ]EÙ]...á PERMISSIBLE ERROR
0	0	0	0	0	0.001
0.5	0.5	0	0.5	0	0.001
1	1	0	1	0	0.001
5	5	0	5	0	0.001
10	10	0	10	0	0.001
15	15	0	15	0	0.001

^ ¥è^¥Ö]ä

LOADING POINT]Eá]ää]B ê]5Ö^uà UPLOAD READING]EÙ]Åâ] Ô] Ù^...ç UPLOAD ERROR]EÙ]Åâ] Ô]•Ø^ PERMISSIBLE ERROR	
]eÜ^...þ	4.95	0	0.001
]öÙ]äÙ]•þ]5ç	4.95	0	0.001
]ÅÐ]äé]•þ]5ç	4.95	0	0.001
]öÙ]äÙ]•è]Ux]	4.95	0	0.001
]ÅÐ]äé]•è]Ux]	4.95	0	0.001

^ ¥è^¥Ö]ä

LOAD MASS	¥á]ää]UP]Eá]à MASS READING]Eá]ää] Ô]•è^p READING ERROR]EÐ]•è^uÑ]EÙ]...á PERMISSIBLE ERROR
7.5	7.5	0	0.001

]öÙ^uê :^

PASS :]Eç]•Ó] Ô

.R O.I.M.L - 111]•þ]UÐ]Åà]•Ñ]õç^ç
]"%ç] Ô]5Ô]
.^¥Ô]•à^•Ñ]