

OWNER'S HANDBOOK



CITROËN C4 AIRCROSS



MyCITROËN

On-line owner's handbook

You can find your handbook on the CITROËN website, under the heading "MyCitröën".

This personal space provides you with information on your products and services, a direct and special contact with CITROËN and becomes a space tailored for you.

Referring to the owner's handbook on-line also gives you access to the latest information available, easily identified by the bookmarks, associated with this pictogram:



If the heading "MyCitröën" is not available on the public website for your country, you can find your handbook at the following address:
<http://service.citroen.com>

Select:

- > the link in "Private customer access",
 - > the language,
 - > the model,
 - > the edition date appropriate for the date of registration of your vehicle.
- You will find your handbook, presented in the same way as the paper version.

We draw your attention to the following...

Your vehicle is fitted with only some of the equipment described in this document, depending on the trim level, version and the specifications for the country in which it is sold.

The fitting of electrical equipment or accessories which are not recommended by CITROËN may result in a failure of your vehicle's electronic system. Please note this specific warning and contact a CITROËN dealer to be shown the recommended equipment and accessories.

Key



safety warning



additional information



contributes to the protection of the environment



refer to the page indicated

CITROËN has a presence on every continent,
a complete product range,
bringing together technology and a permanent spirit of innovation,
for a modern and creative approach to mobility.
We thank you and congratulate you on your choice.

At the wheel of your new vehicle,
getting to know each system,
each control, each setting,
makes your trips, your journeys
more comfortable and more enjoyable.

Happy motoring!

Familiarisation ■

Eco-driving ■

Monitoring 1

Instrument panel	24
Warning and indicator lamps	25
Instrument panel screen	31
Trip computer	43
Distance recorder	43
Trip distance recorder	43
Service indicator	44
Adjusting vehicle settings	48
AUDIO-CD system screen	54
Colour screen	56
Lighting dimmer	59

Access 2

Remote control key	60
"Keyless Entry and Starting" system	64
Doors	70
Boot	71
Alarm	73
Electric windows	76
Panoramic sunroof	78

Comfort 3

Front seats	79
Rear seats	83
Mirrors	85
Steering wheel adjustment	87
Ventilation	88
Manual heating / air conditioning	90
Automatic air conditioning	92
Rear screen demist - defrost	97
Interior fittings	98
Boot fittings	104

Driving 4

Starting - stopping the engine with the key	106
Starting - stopping the engine with the Keyless Entry and Starting system	107
Parking brake	110
Manual gearbox	111
Gear shift indicator	112
CVT gearbox	113
Hill start assist	118
Stop & Start (Auto Stop & Go) function	119
Four wheel drive system	122
Cruise control	124
Parking sensors	127
Reversing camera	130

Visibility 5

Lighting controls	131
Daytime running lamps	134
Automatic illumination of headlamps	134
Manual guide-me-home lighting	135
Welcome lighting	136
Headlamp adjustment	137
Wiper controls	138
Automatic rain sensitive wipers	140
Courtesy lamps	142
Boot lamp	144
Panoramic roof lighting	144

Safety

6

Direction indicators	145
Hazard warning lamps	145
Horn	145
Braking assistance systems	146
Trajectory control systems	148
Front seat belts	150
Airbags	154
Child seats	159
ISOFIX child seats	164
Child lock	169

Checks

8

Bonnet	205
Petrol engines	206
Diesel engines	207
Fuel tank	208
Running out of fuel (Diesel)	210
Checking levels	211
Checks	214

Audio and telematics

AUDIO-TELEMATIC system	223
AUDIO-CD system	283

Alphabetical index

Practical information

7

Temporary puncture repair kit	170
Changing a wheel	174
Changing a bulb	180
Changing a fuse	186
12 V battery	192
Automatic power cut-off to accessories	195
Changing a wiper blade	195
Recovering the vehicle	196
Towing a trailer	199
Fitting roof bars	201
Accessories	202

Technical data

9

Petrol engines	217
Petrol weights	218
Diesel engines	219
Diesel weights	220
Dimensions	221
Identification markings	222

Visual search

Exterior

Electronic key: Keyless Entry and Starting

This system allows you to lock, unlock and start the vehicle while keeping the key on your person and in the defined zone.


▶ 64



Stop & Start function (Auto Stop & Go)

This system puts the engine temporarily into standby during stops in the traffic (traffic lights, traffic jams, etc...). The engine restarts automatically as soon as you want to move off. The Stop & Start system reduces fuel consumption and exhaust emissions, as well as noise levels when stationary.

▶ 119



The door sill finisher should not be used as a step.

Welcome lighting

This additional exterior and interior lighting, controlled remotely, makes your approach to the vehicle easier when the light is poor.

▶ 136

Exterior

Temporary puncture repair kit

This kit is a complete system, consisting of a compressor and a sealant cartridge, for the temporary repair of a tyre.

▶ 170

Panoramic sunroof

This large glazed area provides incomparable visibility and light in the passenger compartment.

▶ 78

Reversing camera


This system is activated automatically on engaging reverse and provides an image in the colour screen.

▶ 130

Front and rear parking sensors


This system warns you of the presence of obstacles in front of or behind the vehicle when manoeuvring forwards or backwards.

▶ 127



Opening

Remote control



- A. Folding/unfolding the key.
- B. Unlocking the vehicle.
- C. Locking the vehicle.

▶ 60


Keyless Entry and Starting system



Unlocking

With the electronic key on your person and in one of the defined zones **A**, press one of the buttons **B** or **C** to unlock the vehicle, then pull on the handle to open the door.

▶ 64




Locking

With the electronic key on your person and in one of the defined zones **A**, press one of the buttons **B** or **C** to lock the vehicle.

▶ 65


Opening

Boot



Opening

After unlocking the vehicle with the remote control or the Keyless Entry and Starting system, press the handle **A**.



Closing


Pull the handle **B** downwards.



Fuel tank



A. Opening the filler flap.




B. Removing the filler cap.

C. Hooking the filler cap.

Capacity of the fuel tank: approximately 60 litres.



Bonnet



A. Interior release lever.

B. Exterior safety catch.

C. Bonnet stay.



Interior

CVT gearbox

This system offers driving combining a fully automatic mode and a manual mode.

▶ 113

4-wheel drive system with electronic control*

This system allows the selection of a transmission mode, according to the driving conditions.

▶ 122

* Depending on version.



Audio and communication systems

These systems benefit from the following technologies: radio, CD player, USB player, Bluetooth system, satellite navigation system with colour screen, auxiliary sockets.

AUDIO-TELEMATIC system

▶ 223

AUDIO-CD system

▶ 283


Digital air conditioning

This automatic air conditioning system maintains the desired comfort level and adequate air circulation in the passenger compartment.

▶ 92


Instruments and controls


1. Door mirror controls.
Electric window controls.
2. Bonnet release.
3. Fusebox.
4. Manual headlamp height adjustment.
Side switch panel.
5. Side adjustable air vent.
6. Instrument panel.
7. Lighting and direction indicator control stalk.
8. Steering wheel adjustment control.
9. Controls for Bluetooth system or telephone.
10. Controls for Audio-CD and Audio-telematic systems.
11. Driver's airbag.
Horn.
12. Cruise control switches.
13. Parking brake.



Instruments and controls


1. Heated seat control.
2. Gear lever, CVT gearbox.
3. Steering lock and ignition.
4. Wiper / screenwash control stalk.
5. Steering mounted control paddles for the CVT gearbox.
6. Windscreen demisting vent.
7. Passenger's airbag.
8. Glove box.
Passenger's airbag deactivation switch.
Back-up starting unit (with the "Keyless Entry and Starting" system).
9. Front door glass demisting vent.







Centre console

- A. Rear view mirror, manual or automatic.
- B. Courtesy lamp / Map reading lamps.
- C. Microphone for Audio-CD et Audio-telematic systems.
- D. Control for panoramic sunroof blind.
- E. Sunshine/rain sensor.



- 1. Central adjustable air vents.
- 2. Screen for the Audio-CD system or colour screen for the Audio-telematic system.
- 3. Ignition switch.
START/STOP button (with "Keyless Entry and Starting" system).
- 4. Audio-CD system or Audio-telematic system.
- 5. Central switch panel.
- 6. Temperature sensor.
- 7. Manual or digital heating / air conditioning controls.
- 8. Gear lever, manual or CVT gearbox.
- 9. Cigarette lighter / 12 V accessory socket.
- 10. Portable ashtray.
- 11. Control for 4 wheel drive system.
- 12. Cup holder.
- 13. Front armrest.



Sitting comfortably

Front seat

Manual adjustments

1. Seat forwards-backwards adjustment.
2. Driver's seat cushion height adjustment.
3. Seat backrest angle adjustment.
4. Head restraint adjustment.

▶ 79

Electric adjustments


1. Seat forwards-backwards adjustment.
2. Driver's seat cushion height and angle adjustment.
3. Seat backrest angle adjustment.

▶ 80




Sitting comfortably

Front armrest



For your comfort, the front armrest is adjustable longitudinally.


▶ 82



It also has two storage spaces; these can be fitted with accessory sockets.

▶ 101

Steering wheel adjustment




1. Release.
2. Adjust for height and reach.
3. Lock.

! As a safety precaution, these operations must only be carried out when stationary.

▶ 87

Sitting comfortably


Door mirrors



- A. Selection of the mirror to adjust.
- B. Adjusting the position of the mirror glass in four directions.
- C. Folding / Unfolding.

▶ 85-86

Rear view mirror



Manual day/night model


1. Selection of the "day" position of the mirror.
2. Adjustment of the mirror.

Automatic day/night model

- A. Brightness detection in automatic day/night mode.
- B. Adjustment of the mirror.

▶ 87

Front seat belts




1. Fastening the buckle.
2. Height adjustment.

▶ 150

Seeing clearly

Lighting



Ring A



Dipped / main beam headlamps.



Sidelamps.



Automatic illumination of headlamps.



Lighting off.

Ring B




Front and rear foglamps.



131

Wipers



Control A: windscreen wipers



138

Switching On / Off "AUTO"

Push the stalk downwards and release it.



140

Control B: rear wiper



Wash-wipe.



Intermittent wipe.





Park.



141


Ventilation

Recommended interior settings

I require...	Manual Air Conditioning				
	Air distribution	Air flow	Air recirculation / Intake of outside air	Temperature	Manual A/C
HOT					
COLD					ON
DEMISTING DEFROSTING					ON

Digital air conditioning: we recommend use of automatic operation by pressing the "AUTO" button.

Monitoring Instrument panel



- A. Speedometer dial.
- B. Instrument panel screen.
- C. Rev counter dial.
- D. Lighting dimmer.
- E. INFO button.

Used to cycle through the different information in the instrument panel screen.



24

Warning lamps




1. With the ignition on, the orange and red warning lamps come on.
2. With the engine running, these warning lamps should go off.

If warning lamps remain on, refer to the page concerned.



25

Central switch panel



- A. Passenger's airbag deactivation warning lamp.



155

- B. Hazard warning lamps.



145


- C. Front passenger's seat belt not fastened or unfastened.



151

Monitoring

Side switch panel



A. Manual headlamp adjustment.

▶ 137

B. Deactivation of the ASC/TCL system.

▶ 148

C. Deactivation of the parking sensors.


▶ 127

D. Deactivation of the Stop & Start (Auto Stop & Go) function.

▶ 120

Passenger safety

Passenger's front airbag



1. Open the glove box.
2. Insert the key.
3. Select the position:
"OFF" (deactivation), with "rear facing" child seat,
"ON" (activation), with front passenger or "forwards facing" child seat.
4. Remove the key keeping the switch in the new position.

▶ 155

Starting

Ignition switch



- Position 1: **LOCK**
- Position 2: **ACC**
- Position 3: **ON**
- Position 4: **START**

▶ 106

START/STOP button




Each press on the **START/STOP** button, without action on the pedals, changes the mode of the vehicle.

- First press: **ACC mode**
- Second press: **ON mode**
- Third press: **OFF mode**

▶ 107


Driving safely

CVT gearbox



This six-speed gearbox offers the choice of the ease of automatic operation or the pleasure of manual gear changing.


1. Gear lever.
2. "-" steering mounted control paddle.
3. "+" steering mounted control paddle.



Display in the instrument panel

The driving mode selected and/or the gear engaged appear in the instrument panel screen.

- P.** Park.
- R.** Reverse.
- N.** Neutral.
- D.** Drive (Automated mode).
- +/-.** Manual mode with sequential gear changes.



Moving off

From position **P**, with the parking brake applied:

- ☞ Press the brake pedal firmly.
- ☞ Start the engine.
- ☞ Then select position **R**, **D** or **+/-**.
- ☞ Release the parking brake.
- ☞ Progressively take your foot off the brake pedal, the vehicle moves off on its own.



Driving safely

Stop & Start (Auto Stop & Go) function

Engine going into STOP mode

AS&G The "**AS&G**" warning lamp comes on in the instrument panel or the instrument panel screen and the engine is put into standby after a few seconds:

- **with a manual gearbox;** with the vehicle stationary and your foot on the brake pedal, when you put the gear lever into neutral and release the clutch pedal.

In certain circumstances the STOP mode may not be available; the "**AS&G**" warning lamp flashes for a few seconds then goes off.

▶ 119


Engine going into START mode

AS&G The "**AS&G**" warning lamp goes off and the engine restarts automatically:

- **with a manual gearbox;** when you **fully** depress the clutch pedal.

In certain condition, START mode may engage automatically; the "**AS&G**" warning lamp flashes then goes off.

▶ 120



Deactivation / Reactivation


You can deactivate the system at any time by pressing the "**AS&G OFF**" button; the corresponding warning lamp comes on in the instrument panel or the instrument panel screen.

i The system is reactivated automatically every time you start the engine with the key or with the **START/STOP** button.

▶ 120

Driving safely

Four wheel drive system




Three transmission modes are available and selectable manually by the driver according to requirements:

- A. Two wheel drive (2WD),
- B. Four wheel drive (4WD AUTO),
- C. Four wheel drive (4WD LOCK).

▶ 122

Cruise control "CRUISE"



1. **"ON / OFF"** button: switches cruise control on and off.
2. **"COAST SET"** button: programme a driving speed then decrease the cruise speed.
3. **"ACC RES"**: increase the cruise speed, and recall the programmed speed.
4. **"CANCEL"** button: cruise control off.

In order to be programmed or activated, the vehicle speed must be higher than 25 mph (40 km/h), with at least second gear engaged.

▶ 124

Eco-driving

Eco-driving is a range of everyday practices that allow the motorist to optimise their fuel consumption and CO₂ emissions.

Optimise the use of your gearbox

With a manual gearbox, move off gently, change up without waiting and drive by changing up quite soon. If your vehicle has the system, the gear shift indicator invites you to change up; it is displayed in the instrument panel, follow its instructions.

With an automatic or electronic gearbox, stay in Drive **"D"** or Auto **"A"**, according to the type of gearbox, without pressing the accelerator pedal heavily or suddenly.

Drive smoothly

Maintain a safe distance between vehicles, use engine braking rather than the brake pedal, and press the accelerator progressively. These practices contribute towards a reduction in fuel consumption and CO₂ emissions and also helps reduce the background traffic noise.

If your vehicle has cruise control, make use of the system at speeds above 25 mph (40 km/h) when the traffic is flowing well.

Control the use of your electrical equipment

Before moving off, if the passenger compartment is too warm, ventilate it by opening the windows and air vents before using the air conditioning.

Above 30 mph (50 km/h), close the windows and leave the air vents open.

Remember to make use of equipment that can help keep the temperature in the passenger compartment down (sunroof and window blinds...).

Switch off the air conditioning, unless it has automatic digital regulation, as soon as the desired temperature is attained.

Switch off the demisting and defrosting controls, if not automatic.

Switch off the heated seat as soon as possible.

Switch off the headlamps and front foglamps when the level of light does not require their use.

Avoid running the engine before moving off, particularly in winter; your vehicle will warm up much faster while driving.

As a passenger, if you avoid connecting your multimedia devices (film, music, video game...), you will contribute towards limiting the consumption of electrical energy, and so of fuel.

Disconnect your portable devices before leaving the vehicle.

Limit the causes of excess consumption

Spread loads throughout the vehicle; place the heaviest items in the bottom of the boot, as close as possible to the rear seats.

Limit the loads carried in the vehicle and reduce wind resistance (roof bars, roof rack, bicycle carrier, trailer...). Use a roof box in preference.

Remove roof bars and roof racks after use.

At the end of winter, remove snow tyres and refit your summer tyres.

Observe the recommendations on maintenance

Check the tyre pressures regularly, when cold, referring to the label in the door aperture, driver's side.

Carry out this check in particular:

- before a long journey,
- at each change of season,
- after a long period out of use.

Don't forget the spare wheel and the tyres on any trailer or caravan.

Have your vehicle serviced regularly (engine oil, oil filter, air filter...) and observe the schedule of operations recommended by the manufacturer.

When refuelling, do not continue after the 3rd cut-off of the nozzle to avoid any overflow.

At the wheel of your new vehicle, it is only after the first 1 800 miles (3 000 kilometres) that you will see the fuel consumption settle down to a consistent average.

Instrument panel




Panel grouping together the dials and warning/indicator lamps. These inform the driver of the activation/deactivation of a system or of the occurrence of a fault.

1. Rev counter.
2. Speedometer.

3. Instrument panel display screen:

- Warning and status displays.
- Total and trip distance recorders.
- Service indicator.
- Coolant temperature.
- Trip computer information.
- Cruise control setting.
- Gear shift indicator recommendations.
- Settings menu (display, sound...).
- Fuel level.
- Ambient temperature.
- Transmission mode.

i Management of the display is done using the **INFO** button located on the dashboard to the left of the instrument panel.





Screen type 1



Screen type 2

Warning and indicator lamps



Visual indicators which inform the driver of the occurrence of a malfunction (warning lamp) or of the operation of a system (operation or deactivation indicator lamp).

When the ignition is switched on

Certain warning lamps come on for a few seconds when the ignition is switched on. When the engine is started, these warning lamps should go off.

Associated warnings

The illumination, fixed or flashing, of certain warning lamps may be accompanied by an audible signal and a message.

i If they remain on, before moving off, refer to the information on the warning lamp in question.

Warning lamps

When the engine is running or the vehicle is being driven, the illumination of one of the following warning lamps indicates a malfunction which requires action on the part of the driver. The warning comes on in the instrument panel or appears in the instrument panel screen.

! The illumination of a warning lamp may be accompanied by the display of an additional message, to assist you in identifying the problem.
If you encounter any problems, you should contact a CITROËN dealer or a qualified workshop.

Warning lamp	is on	Cause	Action / Observations
 Parking brake / Brake fluid level / Electronic brake force distribution	fixed.	It comes on for a few seconds, then goes off when the ignition is switched to "ON".	
		The parking brake is on or not fully released.	It is accompanied by a message. Release the parking brake to make the warning lamp go off.
		The brake fluid level is too low.	It is accompanied by a message. Top up with brake fluid and contact a CITROËN dealer or a qualified workshop.
		The electronic brake force distribution (EBFD) is faulty.	You must stop as soon as it is safe to do so. Have it checked by a CITROËN dealer or a qualified workshop.
 Engine autodiagnosis system	flashing.	The engine management system has a fault.	Risk of destruction of the catalytic converter. Have it checked by a CITROËN dealer or a qualified workshop.
	fixed.	The emission control system has a fault.	The warning lamp should go off when the engine is started. If it does not go off, contact a CITROËN dealer or qualified workshop without delay.

Warning lamp		is on	Cause	Action / Observations
	Battery charge*	fixed.	The battery charging circuit has a fault (dirty or loose terminals, slack or cut alternator belt, ...).	The warning lamp should go off when the engine is started. If it does not go off, contact a CITROËN dealer or a qualified workshop.
	Front seat belt not fastened / unfastened	fixed, then flashing, accompanied by an audible signal.	The driver has not fastened or has unfastened their seat belt.	Pull the strap, then insert the tongue in the buckle.
	Anti-lock Braking System (ABS)	fixed.	The anti-lock braking system has a fault.	The vehicle retains conventional braking. Drive carefully at reduced speed and contact a CITROËN dealer or a qualified workshop without delay.
	Airbags and pretensioners	temporarily.	When you switch on the ignition, this warning lamp comes on for a few seconds, then goes off.	If it does not go off, contact a CITROËN dealer or a qualified workshop.
		fixed.	Fault with one of the airbag or seat belt pretensioner systems.	Have it checked by a CITROËN dealer or a qualified workshop.

* According to destination country.

Operation indicator lamps

If one of the following indicator lamps comes on, this confirms that the corresponding system has come into operation. It may be accompanied by an audible signal and a message in the instrument panel screen.

Warning lamp		is on	Cause	Action / Observations
	Left-hand direction indicator	flashing with audible warning.	The lighting stalk has been pressed downwards.	If this indicator lamp flashes abnormally quickly, this could indicate that the bulb of one of the direction indicators has blown. Change the bulb or contact a CITROËN dealer or a qualified workshop.
	Right-hand direction indicator	flashing with audible warning.	The lighting stalk has been pushed upwards.	If this indicator lamp flashes abnormally quickly, this could indicate that the bulb of one of the direction indicators has blown. Change the bulb or contact a CITROËN dealer or a qualified workshop.
	Sidelamps or dipped beam headlamps	fixed.	The sidelamps or dipped beam headlamps are on.	
	Main beam headlamps	fixed.	The lighting stalk is pulled towards you.	Pull the stalk to return to dipped beam headlamps.
	Front foglamps	fixed.	The front foglamps are switched on.	Turn the ring on the stalk rearwards twice to switch off the front foglamps.
	Rear foglamp	fixed.	The rear foglamp is switched on.	Turn the ring on the stalk rearwards to switch off the rear foglamp.


Warning lamp		is on	Cause	Action / Observations
CRUISE	Cruise control	fixed	This comes on when the cruise control has been activated.	Press the "ON/OFF" button to activate/deactivate the cruise control.
	 Diesel engine pre-heating	fixed.	The engine is cold and: - the ignition switch is at the ON position (ignition on), or - the START/STOP starting button has been pressed (ignition on).	With key starting, wait until the warning lamp has gone off before starting. With the Keyless Entry and Starting system, the engine will only start after the warning lamp has gone off. The duration for which the warning lamp is on is determined by the climatic conditions (up to 30 seconds in severe weather). If the engine does not start, switch the ignition off and then on again and wait again until the warning lamp goes off, then start the engine.
	Active stability control and traction control (ASC/TCL)	flashing.	Operation of the ASC/TCL systems.	The systems optimise traction and improve the directional stability of the vehicle. Adapt your driving and moderate your speed.
		fixed.	Fault in the ASC/TCL systems.	Have it checked by a CITROËN dealer or a qualified workshop.
AS&G	Stop & Start (Auto Stop & Go) function	fixed.	When the vehicle stops (red lights, traffic jams, ...) the Stop & Start (AS&G) function has put the engine into STOP mode.	The warning lamp goes off and the engine restarts automatically in START mode, as soon as you want to move off.
		flashes for a few seconds, then goes off.	STOP mode is temporarily unavailable. or START mode is invoked automatically.	See "Stop & Start (AS&G) function" for special cases with STOP mode and START mode.

Deactivation indicator lamps

If one of the following indicator lamps comes on, this confirms that the corresponding system has been switched off intentionally. This may be accompanied by an audible signal and a message in the screen.

Warning lamp	is on	Cause	Action / Observations
	fixed.	The ASC/TCL off switch, located at the bottom of the dashboard (driver's side) has been pressed. ASC/TCL is deactivated. ASC: active stability control. TCL: traction control.	Press the button to activate the ASC/TCL. The ASC/TCL system is automatically activated on starting the vehicle.
	fixed.	The off switch for the Stop & Start (AS&G) system, located at the bottom of the dashboard (driver's side) has been pressed. The Stop & Start (AS&G) system is deactivated.	Press the switch again to activate the Stop & Start (AS&G) system.

Instrument panel screen



Each time the engine is started: warning lamps and/or messages come on, applying a checking self test. They go off after a few seconds.

Warnings and alerts

When an alert occurs, the displayed information then disappears. the warning lamp and its associated message appear, accompanied if appropriate by an audible signal.



When there are several alerts, they are displayed in turn and this symbol appears. It remains displayed while there are still alerts.

When you want to see the trip computer information, you can choose to ignore the alerts, by pressing the **INFO** button on the dashboard.



When this symbol appears: make a **short press**.



When this symbol appears: make a **long press**.

You will then be able to display the alerts again by pressing the **INFO** button several times to cycle through the trip computer information and return to the alerts.

The messages displayed may vary according to the type of display screen (type 1 or type 2) in the instrument panel.

Certain messages are only displayed in the type 2 screen.

Warning messages (ignition at "OFF")

Screen 1	Screen 2	Cause	Solution - Action	Observations
 TURN OFF LIGHTS	 TURN OFF LIGHTS	You have forgotten to switch off the vehicle lighting.	Switch off the vehicle lighting by placing the control at OFF.	There is an intermittent audible signal.
	 ALARM ACTIVATING	The alarm has been triggered.		
	 KEY BATTERY LOW	The battery for the Keyless Entry and Starting system is flat.	Replace the battery (see "Changing the batteries").	
	 KEY NOT DETECTED	The electronic key that you have on your person is not recognised.	Check that you have the correct electronic key.	If the message persists, contact a CITROËN dealer.
	 KEY STILL IN VEHICLE	The electronic key is still in the vehicle and you have tried to lock the doors or boot from the outside.	Ensure that you have the electronic key on your person before locking the vehicle.	
	 CHECK DOORS	One of the doors or the boot is not properly closed when locking the vehicle from the outside.	Close the door or the boot, then lock the vehicle.	

Screen 1	Screen 2	Cause	Solution - Action	Observations
	 KEYLESS OPERATION SYSTEM SERVICE REQUIRED	Fault with the "Keyless Entry and Starting" system.	Contact a CITROËN dealer.	
	 IMMOBILIZER SYSTEM SERVICE REQUIRED	Fault with the electronic anti-theft system.	Switch off the ignition, then start the engine.	If the problem persists, contact a CITROËN dealer.
	 KEY NOT DETECTED INSERT KEY INTO KEY SLOT IN GLOVE BOX	The electronic key is not detected.	Insert the electronic key into the housing located in the glove box.	Remember to remove the electronic key from the housing after starting the vehicle.
	 REMOVE KEY FROM KEY SLOT IN GLOVE BOX	The electronic key has not been removed from the housing in the glove box.	Remove the electronic key from the housing in the glove box.	
	 PUSH ENGINE SWITCH WHILE TURNING STEERING WHEEL	The steering column is locked.	Switch the ignition on and turn the steering wheel slightly to unlock the steering column.	
	 SHIFT TO P POSITION	The engine is off but the gear lever is not in position P.	Place the gear lever in position P.	Only for vehicles fitted with a "CVT" gearbox.

Screen 1	Screen 2	Cause	Solution - Action	Observations
	 STEERING LOCK SERVICE REQUIRED	The steering column has not locked after opening the driver's door.	Lock the steering column by turning the steering wheel slightly before leaving the vehicle.	
	 ELECTRICAL SYSTEM SERVICE REQUIRED	Fault with the electrical system.	Contact a CITROËN dealer or a qualified workshop.	

Warning messages (ignition at "ON")

Screen 1	Screen 2	Cause	Solution - Action	Observations
 SERVICE REQUIRED	 POWER STEERING SERVICE REQUIRED	Fault with the electric power steering.	Stop the vehicle, wait few moments then start the engine again.	If the message remains after restarting, contact a CITROËN dealer or a qualified workshop.
	 KEY BATTERY LOW	The battery for the "Keyless Entry and Starting" system is flat.	Replace the battery (see "Changing the batteries").	
	 KEY NOT DETECTED	The electronic key that you have on your person is not recognised.	Check that you have the correct electronic key.	If the message persists, contact a CITROËN dealer.
	 KEY STILL IN VEHICLE	The electronic key is still in the vehicle and you have tried to lock the doors or boot from the outside.	Ensure that you have the electronic key on your person before locking the vehicle.	
	 CHECK DOORS	One of the doors or the boot is not properly closed when locking the vehicle from the outside.	Close the door or the boot, then lock the vehicle.	
	 KEYLESS OPERATION SYSTEM SERVICE REQUIRED	Fault with the "Keyless Entry and Starting" system.	Contact a CITROËN dealer.	

Screen 1	Screen 2	Cause	Solution - Action	Observations
 CHECK	 BRAKE SYSTEM SERVICE REQUIRED	The brake fluid level is too low.	Top up using a brake fluid listed by CITROËN.	If the problem persists, contact a CITROËN dealer or a qualified workshop.
		Fault with the braking system.	You must stop as soon as it is safe to do so.	Have the system checked by a CITROËN dealer or a qualified workshop.
 SERVICE REQUIRED	 ABS SERVICE REQUIRED	Fault with the anti-lock braking system (ABS).	Contact a CITROËN dealer or a qualified workshop.	The vehicle retains conventional braking without assistance but you are advised to stop.
		One of the doors or the boot is not properly closed.	Close the door or the boot.	The opening in question is identified in the screen.
 CLOSE HOOD	 CLOSE HOOD	The bonnet is not properly closed.	Close the bonnet.	
	 IMMOBILIZER SYSTEM SERVICE REQUIRED	Fault with the electronic anti-theft system.	Switch off the ignition then start the engine again.	If the problem persists, contact a CITROËN dealer.
	 OFF	The driver's door is open and the ignition is still on.	Switch off the ignition before leaving the vehicle.	

Screen 1	Screen 2	Cause	Solution - Action	Observations
	 STEERING LOCK SERVICE REQUIRED	Fault in the steering column.	You must stop as soon as it is safe to do so.	Contact a CITROËN dealer or a qualified workshop.
	 ELECTRICAL SYSTEM SERVICE REQUIRED	Fault with the electrical system.	Stop the vehicle and contact a CITROËN dealer or a qualified workshop.	
 CHECK	 ENGINE OVERHEATING STOP SAFELY	The cooling system temperature is too high.	Wait for the engine to cool down before topping up, if necessary. If the problem persists, contact a CITROËN dealer or a qualified workshop.	You must stop as soon as it is safe to do so.
 SLOW DOWN	 TRANSMISSION OVERHEATING SLOW DOWN	The temperature of the CVT transmission fluid is too high.	Stop the vehicle and contact a CITROËN dealer or a qualified workshop.	
 FASTEN SEAT BELT	 FASTEN SEAT BELT	The driver has not fastened or has unfastened their seat belt.	Fasten your seat belt.	There is a continuous audible signal if you drive without fastening your seat belt.
 SERVICE REQUIRED	 FUEL SYSTEM SERVICE REQUIRED	Malfunction of the fuel system.	Contact a CITROËN dealer or a qualified workshop.	

Screen 1	Screen 2	Cause	Solution - Action	Observations
 RELEASE PARKING BRAKE	 RELEASE PARKING BRAKE	You have moved off with the parking brake not fully released.	Release the parking brake.	
 CHECK	 LOW OIL PRESSURE	The oil pressure is too low or there is a fault with the engine lubrication system.	Stop the vehicle and contact a CITROËN dealer or a qualified workshop.	
 SERVICE REQUIRED	 CHARGING SYSTEM SERVICE REQUIRED	Battery charge fault.	Stop the vehicle and contact a CITROËN dealer or a qualified workshop.	
 SERVICE REQUIRED	 AIRBAG SYSTEM SERVICE REQUIRED	Airbag or pretensioner fault.	Contact a CITROËN dealer or a qualified workshop to have the systems checked.	
 SERVICE REQUIRED	 HEADLAMP LEVELLING SERVICE REQUIRED	Fault with automatic headlamp adjustment system.	Contact a CITROËN dealer or a qualified workshop.	Only on vehicles fitted with xenon headlamps.
 SERVICE REQUIRED	 ASC SYSTEM SERVICE REQUIRED	Fault with the stability control system (ASC).	Contact a CITROËN dealer or a qualified workshop.	
 SERVICE REQUIRED	 4WD SYSTEM SERVICE REQUIRED	Fault with the four wheel drive transmission system.	Contact a CITROËN dealer or a qualified workshop.	

Screen 1	Screen 2	Cause	Solution - Action	Observations
 SERVICE REQUIRED	 TRANSMISSION SERVICE REQUIRED	Fault with the CVT gearbox.	Contact a CITROËN dealer or a qualified workshop.	
 SLOW DOWN	 4WD SYSTEM OVERHEATING SLOW DOWN	The temperature of the four wheel drive transmission system is too high.	Stop the vehicle and contact a CITROËN dealer or a qualified workshop.	The vehicle changes automatically to two wheel drive (2WD).
 REFUEL	 REFUEL	The fuel level is low.	Refuel as soon as possible.	
 CHECK + 	 CHECK DPF SYSTEM	The low level of the particle emissions filter additive reservoir has been reached.	Have the reservoir topped up as soon as possible by a CITROËN dealer or a qualified workshop.	Only for the 1.6 litre HDi engine.
		Start of saturation of the particle emissions filter.	As soon as the driving conditions allow, regenerate the filter by driving at a speed of at least 25 mph (40 km/h) for around 20 minutes (with the 1.6 litre HDi engine the minimum speed is 36 mph (60 km/h)).	If the message remains on, contact a CITROËN or a qualified workshop.
		The particle emissions filter is faulty.	Stop as soon as it is safe to do so.	Contact a CITROËN dealer or a qualified workshop as soon as possible.

Screen 1	Screen 2	Cause	Solution - Action	Observations
 CHECK ENGINE OIL LEVEL	 CHECK ENGINE OIL LEVEL	Engine oil level not correct (below minimum level or above maximum level).	Stop the vehicle as soon as it is safe to do so. Check the level with the dipstick and top-up if the level low. If the level is above the maximum mark, do not restart the engine and contact a CITROËN dealer or a qualified workshop.	Never drive with an incorrect oil level.
 REMOVE WATER IN SEPARATOR	 REMOVE WATER IN SEPARATOR	Presence of water in the Diesel fuel filter.	Risk of damage to the injection system on Diesel engines.	Contact a CITROËN dealer or a qualified workshop as soon as possible.
 POSSIBLE ICY ROADS	 POSSIBLE ICY ROADS	The ambient temperature is at or below 3 °C (37 °F).	There may be black ice on the road. Take care and drive gently.	
	 PRESS CLUTCH PEDAL TO START ENGINE	The clutch pedal is not depressed while starting the engine.	Depress the clutch pedal to start the engine.	For vehicles fitted with a manual gearbox.
	 PRESS BRAKE PEDAL TO START ENGINE	The gear lever is not in position P or position N when starting the engine.	Place the gear lever at position P to start the engine.	For vehicles fitted with a CVT gearbox.
		The brake pedal is not pressed while starting the engine.	Press the brake pedal to start the engine.	

Information messages (ignition at "ON")


Screen 1	Screen 2	System	Observations
 2WD	 2WD	2WD two wheel drive system	Flashes for a few moments when the "2WD" (2 wheel drive) mode is selected using the transmission mode selector, for 4 wheel drive versions.
 4WD AUTO	 4WD AUTO	4WD four wheel drive system	Flashes for a few moments when the "4WD" (4 wheel drive) mode is selected using the transmission mode selector, for 4 wheel drive versions.
 4WD LOCK	 4WD LOCK	4WD LOCK four wheel drive system	Flashes for a few moments when the "LOCK" (4 wheel drive) mode is selected using the transmission mode selector, for 4 wheel drive versions.
		Active stability control (ASC)	Flashes when the stability control system (ASC) is operating.

Prevention messages

Screen 1	Screen 2	System	Cause	Observations	Solution - Action
 ROUTINE MAINTENANCE REQUIRED	 ROUTINE MAINTENANCE REQUIRED	Service indicator	Informs the driver that the next service is overdue.	This is displayed for a few seconds when the ignition is switched on.	Contact a CITROËN dealer or a qualified workshop.
 REST REMINDER	 REST REMINDER	Rest reminder	Informs the driver that they should stop to take a break.	This is displayed when the driving time that you set previously is reached. An audible signal sounds 3 times and then every 5 minutes until the vehicle stops.	You are advised to take a break approximately every two hours.

Trip computer

Information display



With the ignition on, each press on the **INFO** button displays the following screens in succession:

- distance recorder and trip recorder A,
- distance recorder and trip recorder B,
- service indicator,
- coolant temperature,
- range,
- average fuel consumption,
- average speed,
- current fuel consumption,
- setting menu,
- any alert messages.


Distance recorder

System for measuring the total distance travelled by the vehicle during its life.



The total distance is displayed in the lower part of the screen.

Trip distance recorder (Trip A or B)



Each of these trip recorders indicates the distance travelled since the last reset. Press the **INFO** button to display the desired trip.

Reset to zero

With the ignition on and either trip **A** or **B** displayed, press the **INFO** button for more than 2 seconds. Only the trip displayed will be reset.

Service indicator

System which informs the driver when the next service is due in accordance with the manufacturer's servicing schedule.

The point at which the next service is due is calculated from the last service indicator zero reset.

It is determined by two parameters:

- the distance travelled (in miles (km)),
- the time elapsed since the last service (in months).


The distance remaining to be travelled may be weighted by the time factor, depending on the use made of the vehicle.

Operation

When the ignition is switched on, you must press the **INFO** button several times in succession until the service indicator is displayed. The distance recorder display line indicates the number of miles or kilometres remaining and the time elapsed line indicates the number of months remaining before the next service is due.



Example: the screen indicates that 7300 miles (kilometres) remain before the next service is due.



i The symbol "--" remains displayed until the first service of a new vehicle has been carried out.

Service overdue

Each time the ignition is switched on, the **"ROUTINE MAINTENANCE REQUIRED"** symbol is displayed for a few seconds to indicate that the service must be carried out without delay.



Example: the screen indicates that the service is overdue. This service must be carried out by a CITROËN dealer or a qualified workshop.

Resetting the service indicator to zero

Your CITROËN dealer or a qualified workshop carries out this operation after each service. If you have carried out your vehicle's service yourself, the zero reset procedure is the following:

- ☞ switch off the ignition,
- ☞ press the **INFO** button several times in succession until the service indicator is displayed,
- ☞ press and hold the **INFO** button for a few seconds until the **spanner flashes**,
- ☞ press the **INFO** button while the spanner is flashing to change the display "---" to **"CLEAR"** then the time remaining before the next service is due is displayed.

After a certain distance and a certain time, the display of "---" is reset automatically and the display indicates the time remaining before the next service is due.



Coolant temperature gauge



When the engine is running, this indicates the temperature of the coolant.


If the bar is close to the **critical** position located on the right, the temperature is too high. The symbol flashes when your engine is overheating.

You must stop your vehicle as soon as it is safe to do so.

Wait a few minutes before switching off the engine.

- i** Wait for the engine to cool before topping up the level. The cooling system is pressurised. To avoid any risk of scalding, unscrew the cap by two turns to allow the pressure to drop. When the pressure has dropped, remove the cap and top up the level, if necessary. Contact a CITROËN dealer or a qualified workshop.

Range



When the engine is running, this indicates the distance which can still be travelled with the fuel remaining in the tank based on the average fuel consumption over the last few miles/kilometres travelled.


When the range is less than **30 miles (50 km)**, dashes are displayed. Refuel as soon as possible. The display of the range is updated.

- i** This value may vary following a change in the style of driving or the relief, resulting in a large variation in the current fuel consumption.

If you only add a few litres, the value displayed will be incorrect. Therefore, you must fill the tank whenever possible.


- i** When you disconnect the battery, the previous fuel consumption data is lost and the value displayed will be different from that displayed before the battery was disconnected. The distance displayed must be considered an approximate indication.

Average fuel consumption (l/100 km or km/l or mpg)




This is the average fuel consumption calculated since the trip computer was last reset.

Average speed (km/h or mph)



This is the average speed calculated since the trip computer was last reset.

Resetting the information to zero




When the required information is displayed, press the **INFO** button for more than two seconds to reset all of the information to zero.

When the ignition is switched on, the zero reset switches automatically from manual mode to automatic mode.

Automatic

If the ignition key remains in the OFF position for more than 4 hours, the information is reset to zero automatically.

Current fuel consumption (l/100 km or km/l or mpg)



This is the average fuel consumption calculated over the last few seconds.

i This value may change following a change in the style of driving or the relief.

i If dashes "---" are displayed for long periods in place of the digits while driving, contact a CITROËN dealer or a qualified workshop.

Adjusting vehicle settings

The various menus may change between the type 1 instrument panel and the type 2 instrument panel.

With the ignition on, press the **INFO** button on the dashboard, to the left of the instrument panel, several times in succession until the "SETTINGS MENU" screen is displayed.



When the vehicle is stationary, it allows the user to change the following settings:

- the reinitialisation mode for average fuel consumption and average speed,
- the fuel consumption units,
- the temperature display unit,
- the display language,
- activation/deactivation of the sound when pressing the **INFO** button,
- the break (rest) reminder display interval,
- restore the factory settings.

! To change the settings, you must stop the vehicle and switch on the ignition. Apply the parking brake and place the gear lever in neutral.

i For your safety, **when the vehicle is moving**, the function settings are not displayed when you press the **INFO** button.

Operation

- ☞ Press and hold the **INFO** button for a few seconds to display the menu screen.



- ☞ In the menu screen, press the **INFO** button to select a function from the list:

MENU 1/3:

- **1 - 2, A - M, A - P*** (choice of the type of reset of average fuel consumption and average speed),
- **AVG UNIT** (choice of the fuel consumption units),
- choice of the **temperature display unit**,
- **LANGUAGE** (option of the display language),

* According to display language.

MENU 2/3:

- **a/b** (option of displaying a different language in the instrument panel screen and the navigation screen),
- **activation / deactivation of the INFO** button **sound**,
- **ALERT** (changing of the "REST REMINDER" display interval),
- **selection of the sound** of the direction indicators,
- **activation / deactivation of the current fuel consumption**,

MENU 3/3:

- **RESET** (restore factory settings).

i Press and hold the **INFO** button for a few seconds to return to the previous screen. When the menu screen is displayed, if no operation is carried out within 15 seconds, the Settings Menu screen is displayed.

Choice of the reset mode for average fuel consumption and average speed

You can choose between two average fuel consumption and average speed reset modes:

- automatic reset,
- manual reset.

In the menu screen:

- ☞ press the **INFO** button to select:



- ☞ press and hold the **INFO** button for a few seconds to switch in succession from reset mode **1 - A (automatic)*** to reset mode **2 - M - P (manual)***.

The mode selected is confirmed.


* According to display language.

Choice of the fuel consumption unit


The distance, speed and quantity of fuel units will also be changed in accordance with your choice of fuel consumption unit.

In the menu screen:

- ☞ press the **INFO** button to select **"UNIT"**.



- ☞ press and hold the **INFO** button for a few seconds to display the **"AVG UNIT"** screen.



- ☞ press the **INFO** button to scroll the units (km/L, L/100km, mpg (US), mpg (UK) and RETURN) in succession,
- ☞ press and hold the **INFO** button for a few seconds to confirm your selection.

i If the battery is disconnected, the settings memory is cleared and the default unit (km/L) is restored automatically.

Choice of the temperature display unit

In the menu screen:

- ☞ press the **INFO** button to select the temperature unit setting symbol (thermometer):



- ☞ press and hold the **INFO** button for a few seconds to scroll the units (°C and °F) in succession.

The mode selected is confirmed.

i If the battery is disconnected, the settings memory is cleared and the default unit (°C) is restored automatically.

Choice of the display LANGUAGE

In the menu screen:

- ☞ press the **INFO** button to select "**LANGUAGE**":



- ☞ press and hold the **INFO** button for a few seconds to display the "**LANGUAGE**" screen:



- press the **INFO** button to scroll the languages (Japonais, English, Deutsch, Français, Espanol, Italiano, Russe "---" and RETURN) in succession,
- press and hold the **INFO** button for a few seconds to confirm your selection.


Activation / deactivation of language cooperation between the instrument panel screen and the navigation screen*

You can choose to have the language used by the instrument panel screen linked to that of the navigation screen.

In the menus screen:



- press the **INFO** button to select the symbol for activation / deactivation of language cooperation.



- press and hold the **INFO** for a few seconds to run through the choices (**A - 1** "cooperation activated" and **M - 2 - P** "cooperation deactivated"). The selected mode is confirmed.

i If you select the "---" setting, no message will be displayed in message display situations.

i If the battery is disconnected, the settings memory is cleared and the default language (ENGLISH) is restored automatically.

i If the battery is disconnected, the settings memory is cleared and the default unit (**A - 1** "cooperation activated") is restored automatically.

* Depending on equipment.

** According to display language.

Activation / deactivation of the "INFO" button sound

You can activate or deactivate the sound associated with the **INFO** button.

In the menu screen:



- press the **INFO** button to select the **INFO** button sound activation / deactivation symbol (located in menu 2/3):



- press and hold the **INFO** button for a few seconds to scroll the choices (ON, OFF) in succession.

The mode selected is confirmed.

i If the battery is disconnected, the settings memory is cleared and the default choice (ON) is restored automatically.

Changing the display interval of the "REST REMINDER" message

The "REST REMINDER" function allows you to programme an alert message reminding you to take a break.

The **"REST REMINDER"** message appears accompanied by an audible signal.


You can change the display interval of the **"REST REMINDER"** message.

In the menu screen:

- press the **INFO** button to select **"ALARM"** (located in menu 2/3):



- press and hold the **INFO** button for a few seconds to display the **"ALARM"** screen,



- press the **INFO** button to select the display interval of the **"REST REMINDER"** message,
- press and hold the **INFO** button for a few seconds to confirm.

i As a safety measure, it is recommended that you stop for a break every two hours.

i If the battery is disconnected, the settings memory is cleared and the default value (OFF) is restored automatically.

Selection of the sound for the direction indicators

You can select the sound for the direction indicators, with the type 2 instrument panel only.

In the menu screen:

- press the **INFO** button to select sound 1 or 2 (located in menu 2/3):




Activation / deactivation of the current fuel consumption*

You can activate or deactivate the display of the current fuel consumption, with the type 2 instrument panel only.

In the menu screen:

- press the **INFO** button to select the current fuel consumption activation / deactivation symbol (located in menu 2/3):




- press and hold the **INFO** button for a few seconds to scroll through the choices in succession (ON, OFF).

Restoring factory settings (RESET)

You can restore all of the factory settings for all functions.

On the menu screen:

- press the **INFO** button to select **"RESET"** (located in menu 2/2 or 3/3 depending on the instrument panel):



- press and hold the **INFO** button for **at least 5 seconds**.

There is an audible signal and all of the factory settings are restored for all functions.

* Depending on equipment.

AUDIO-CD system screen



Associated with the audio system, this provides the following information:

- the time,
- audio system information (see "Audio and Telematics").

Setting the time



Selecting the adjustment mode


The digital clock can be set in **automatic mode** or in **manual mode**.

Automatic mode

This mode permits automatic setting of the local time using the signal from RDS stations. The symbol **"CT"** appears in the screen.

Manual mode


This mode permits manual setting of the time using the audio system buttons. It can also be used when the "Automatic mode" displays an inaccurate time, when the local RDS stations are broadcasting from a different time zone.



Select **automatic mode** or **manual mode** as follows:

- Press button **A "PWR"** to switch on the audio system.
- Access the setting mode by pressing button **B "TUNE"** for approximately 2 seconds.
- Press button **B "TUNE"** several times to scroll through the various menus and select the **CT menu** (clock time).

i The order of the menus is the following:
AF / CT / REG / TP-S / PTY display
language / SCV / PHONE / Functions
setting mode OFF.




- ☞ Turn button **B** "TUNE" to the left or to the right to select "**CT ON**" (automatic mode) or "**CT OFF**" (manual mode).
- ☞ After selecting the mode, you can exit the "Functions setting mode" menu by pressing button **B** "TUNE" for approximately 2 seconds.

i If no action is carried out within 10 seconds, the system will exit the "Functions setting mode" menu automatically.

Manual adjustment

Set the time using the buttons as indicated below:



- ☞ With the ignition on or in the ACC (Accessories) position, press and hold the **CLOCK** button until the time display flashes.
- ☞ Press the appropriate button to set the time:

Button H: to set the hours

The hours digits scroll when you press this button.

Button M: to set the minutes

The minutes digits scroll when you press this button.

Button 00: to reset the minutes to zero.

- from **1 to 29 min**: rounded down to the previous hour,
- from **30 to 59 min**: rounded up to the next hour.

- ☞ After setting the time, press the **DISP** button; the time display stops flashing.

i The digital clock does not display seconds. When the "minutes" display is set or reset to zero, the clock starts at the zero second of the minute selected. The time setting is lost if the battery is disconnected.

AUDIO-TELEMATIC system screen

If your vehicle is fitted with the navigation system, you have this colour touch screen.



! For reasons of safety, the driver should only carry out operations that require close attention, with the vehicle stationary. In addition, some functions are not accessible when driving.

! Do not use pointed objects on the touch screen. Do not touch the screen with wet hands.


i Uses a soft clean cloth to clean the screen.

General operation

Use the buttons on either side of the screen, or touch the virtual buttons appearing in the screen to operate the system.

1. **MODE**: access to the "Audio-video" menu.
2. **AUDIO**: selection of the Audio-video or Navigation display.
3. **VOL**: volume adjustment.
4. **PWR**: on/off.
5. **SET**: access to the "Settings" menu.
6. **OPEN**: access to the CD/DVD player.
7. **INFO**: access to the "Info" menu.
8. **NAVI**: display the map with the location of the vehicle.
9. **SCALE**: map scale.
10. **MENU**: access to the "Navigation-guidance" menu.
11. **ENT**: scroll through a list or select an item.

i For more information on these menus, refer to the "Audio and telematics" section.



"Settings" menu

On the control panel, press the **SET** button to open the menu.

System screen

Once in the "Settings" menu, select "System" to modify the time zone, the units, or the display language (English, Dutch, Swedish, French, Portuguese, Italian, German, Spanish or Danish) and adjust other settings.

Equipment screen

Once in the "Settings" menu, select "Equipment" to activate or deactivate certain driving and comfort systems, or to adjust settings.

Remote control:

- operation of the direction indicators when locking and unlocking the vehicle.

Keyless Entry and Starting system:

- operation of the direction indicators when locking and unlocking the vehicle,
- operation of the Keyless Entry and Starting system (only for unlocking, only for starting, or both).

Wipers:

- intermittent operation of the windscreen wipers,
- operation of the front screenwash associated with the wipers,
- adjust the frequency of rear wiper operation,
- continuous operation of the rear wiper,
- wiper linked to reverse gear.

Interior / exterior lighting:

- sensitivity of the sensor for automatic illumination of headlamps,
- guide-me-home lighting (activation/deactivation),
- welcome lighting (activation/deactivation),

- operating period for courtesy lamps after closing a door,
- automatic headlamp dipping (activation/deactivation),
- timing before automatic courtesy lamps go off,
- automatic lighting linked to the wipers.

Electric windows:

- operating period after switching off the ignition.

Direction indicators:

- motorway function.

Central locking:

- selective unlocking.
- automatic door unlocking,
- timing of the automatic re-locking of the vehicle after unlocking,
- deadlocking (activation/deactivation).

Others:


- automatic folding of the door mirrors,
- automatic cut of power supply to accessories.
- alarm (adjustment of sensor sensitivity, activation/deactivation).

Setting the time



The digital clock is set **automatically**. This mode enables the system to set the local time automatically using the signal from the RDS stations.

- On the control panel, press button **A** (SET) to access the **"Settings"** menu.




- On the touch screen, press button **B** to access the **"System"** menu.

The system settings screen is displayed.



- Press button **C** to access the **"Time"** menu.

Once this menu has been selected, you can access the following functions:




- RDS Auto Correct:**
Activate / deactivate automatic adjustment.
 - GMT / GMT+1 / GMT+2**
Select the time zone.
 - Summer Time:**
Summer time On / Off.
- Press button **D** to confirm and return to the previous menu.

i You must deactivate automatic adjustment (RDS Auto Correct) to change the time zone and summer time settings.
On each screen, you can return to the previous screen by pressing button **D** "Back".

Lighting dimmer

System for manual adjustment of the brightness of the instruments and controls in relation to the exterior brightness.



With the lighting on or off, press the button to change the intensity of the lighting of the instruments and controls in "day" or "night" mode.

With the vehicle's lighting off, only the brightness of the instrument panel is modified.

With the vehicle's lighting on, the brightness of the entire dashboard (instrument panel, screen, air conditioning control panel...) is modified.

i There is an audible signal and the intensity of the lighting increases each time the button is pressed.

When the lighting reaches the maximum setting, press again to change to the minimum setting.


When the lighting reaches the required intensity, release the button.

The setting is saved when the ignition switch is turned to OFF.

Remote control key

System which permits central unlocking or locking of the vehicle using the door lock or remotely. It is also used for the guide-me-home lighting and starting the engine, as well as providing protection against theft.

Unlocking the vehicle




Unfolding the key

- First press this button to unfold the key.

Complete unlocking using the remote control



- Press the open padlock to unlock the vehicle.



Unlocking using the key

- Turn the key to the front in the driver's door lock to unlock it.

i Unlocking is confirmed by the interior lighting which comes on for around 15 seconds and the direction indicators which flash **twice**. According to version, the door mirrors unfold at the same time.

Selective unlocking using the remote control



The complete or selective unlocking parameter is set via the colour screen "Equipment" menu.

Complete unlocking is activated by default.

- ☞ Press the open padlock once to unlock the driver's door only.
- ☞ Press the open padlock again to unlock the other doors and the boot.

i Unlocking is confirmed by illumination of the interior lighting for about 15 seconds and the direction indicators, which flash **twice**.

According to version, the door mirrors unfold at the same time as the first unlocking action.

i Selective unlocking is only available on versions not fitted with deadlocking. Selective unlocking is not available using the key.

Locking the vehicle

Normal locking using the remote control




- Press the closed padlock to lock the vehicle completely.

i Locking is confirmed by the direction indicators which flash **once**. According to version, the door mirrors fold at the same time.

i If one of the doors or the boot is still open, the central locking does not take place.
When the vehicle is locked, if it is unlocked inadvertently, it will re-lock automatically after a certain time (which can be set in the colour screen "Equipment" menu), except if a door is open.

i The folding and unfolding of the door mirrors using the remote control can be set in the colour screen "Equipment" menu.



Normal locking using the key

- Turn the key to the rear in the driver's door lock to lock it.

Deadlocking using the remote control



- Press the closed padlock to lock the vehicle completely.

- Press the closed padlock again within five seconds to deadlock the vehicle.

i Deadlocking is confirmed by the direction indicators, which flash **three times**.

According to version, the door mirrors fold at the same time.

! Deadlocking renders the exterior and interior door controls inoperative. It also deactivates the manual central control button. Therefore, you should never leave anyone inside the vehicle when it is deadlocked.




Folding the key

- First press this button to fold the key.


! If you do not press the button when folding the key, there is a risk of damage to the mechanism.

"Keyless Entry and Starting" system



System that allows the locking, unlocking and starting of the vehicle while keeping the electronic key on your person. It can also be used as a remote control; see the "Remote control" section.

Unlocking the vehicle



Complete unlocking

- With the electronic key on your person and in one of the defined zones **A**, press one of the buttons **B** or **C** to unlock the vehicle, then pull on the handle to open the door. Your passengers can also open their doors, as soon as the electronic key is in one of the defined zones.

! For security, the detection zones in which the electronic key is operational have a radius of about 70 cm around each opening button.

Selective unlocking


This setting is done via the "Equipment" menu of the colour screen.

By default, complete unlocking is activated.

- With the electronic key on your person, press button **B** once to unlock only the driver's door, then pull on the door handle to open.
- Press button **B** again to unlock the vehicle completely.

i Unlocking is confirmed by an audible signal and the direction indicators which flash **twice**. The door mirrors unfold at the same time. Selective unlocking is only available on versions not fitted with deadlocking.

Locking the vehicle




Locking

- With the key in one of the defined zones **A**, press one of the buttons **B** or **C**.

i Locking is confirmed by an audible signal and the direction indicators, which flash **once**.
The door mirrors fold at the same time.

i The operating mode must be "OFF".
With Stop & Start, if the engine is in Stop mode, the vehicle cannot be locked.

! Always ensure that you have the electronic key on your person before locking the vehicle: in some circumstances, it is possible to lock the vehicle without the presence of the electronic key having been detected inside the vehicle.



Deadlocking

- With the electronic key in one of the defined zones **A**, press button **B** or **C** to lock the vehicle.
- Within five seconds, press button **B** or **C** again to deadlock the vehicle.

i Locking is confirmed by two audible signals and by the direction indicators which flash **three times**.
The door mirrors unfold at the same time.

Switching on the lighting remotely

i The means by which locking/unlocking the vehicle and automatic folding/unfolding of the mirrors is confirmed can be configured in the colour screen "Equipment" menu.

! Deadlocking renders the exterior and interior door controls inoperative. It also deactivates the manual central control button. Therefore, never leave anyone inside the vehicle when it is deadlocked.



This only operates with the **ignition off** and the lighting control in the "**OFF**" or "**AUTO**" position.



Press this button to switch on the lighting remotely (illumination of the sidelamps and dipped beam headlamps) for a period of 30 seconds.

A second press switches off the lighting.


Remote operation of the lighting will be switched off:

- on switching on the ignition,
- if the lighting control is not in the "**OFF**" or "**AUTO**" position,
- when activating manual guide-me-home lighting.

Emergency procedure with the Keyless Entry and Starting system

Emergency unlocking/locking using the integral key


2



The integral key is used to lock and unlock the vehicle when the electronic key cannot operate:


- cell battery flat, vehicle battery discharged or disconnected, ...
- vehicle located in an area with strong electro-magnetic signals.

☞ Pull and hold button 1, to extract the integral key 2.



Unlocking

- ☞ Turn the key towards the front in the driver's door lock to unlock the vehicle.




Locking

- ☞ Turn the key towards the rear in the driver's door lock to lock the vehicle.

i The emergency key allows you to lock or unlock the driver's door only. To lock or unlock the other doors, use the interior controls (see "Locking / unlocking from inside").

Changing the batteries


With the Keyless Entry and Starting system, message appears in the instrument panel when replacement of the battery is needed.



Remote control key

Battery ref.: CR1620 / 3 volts.

- ☞ Unclip the cover using a small screwdriver at the cutout.
- ☞ Lift off the cover.
- ☞ Remove the flat battery from its location.
- ☞ Fit the new battery into its location observing the original direction of fitment.
- ☞ Clip the cover onto the casing.



Electronic key

Battery ref.: CR2032 / 3 volt.



Do not throw the remote control batteries away, they contain metals which are harmful to the environment. Take them to an approved collection point.

! Lost electronic key

Visit a CITROËN dealer with the vehicle's registration document and your personal identification documents and if possible the key code label. The CITROËN dealer will be able to retrieve the key code and the transponder code required to order a new key.

Electronic key

The electronic key is a sensitive system; do not operate it while it is in your pocket as there is a possibility that it may unlock the vehicle, without you being aware of it.

Do not repeatedly press the buttons of your electronic key out of range and out of sight of your vehicle. You run the risk of stopping it from working and the remote control would have to be reinitialised.

The electronic key cannot operate as a remote control when it is in the reader or even when the ignition is switched on.

Locking the vehicle

Driving with the doors locked may make access to the passenger compartment by the emergency services more difficult in an emergency.

As a safety precaution (with children on board), take the Keyless Entry and Starting electronic key when you leave the vehicle, even for a short time.

Electrical interference

The Keyless Entry and Starting electronic key may not operate if close to certain electronic devices: telephone, laptop computer, strong magnetic fields, ...

Anti-theft protection

Do not make any modifications to the electronic engine immobiliser system; this could cause malfunctions.


Don't forget to turn the steering to engage the steering lock.

When purchasing a second-hand vehicle

Have all of the keys in your possession paired by a CITROËN dealer, to ensure that only your keys allow your vehicle to be unlocked and started.


Doors

Opening



From outside

- ☞ After unlocking the vehicle using the remote control or the key, pull the door handle.




From inside

- ☞ Pull the front or rear door lever to open the door.

On the driver's side, this action on the door lever unlocks the door if it was locked.


On the passenger's side or for the rear doors, the door must first be unlocked manually (see "Individual controls") if it was locked.

Closing




If a door is not closed correctly, this warning lamp comes on in the instrument panel screen until the door concerned is closed.

Boot Opening




- ☞ After unlocking the vehicle, press the handle **A** and raise the tailgate.

Closing




- ☞ Pull the handle **B** downwards to guide the tailgate.
- ☞ Release the handle and press gently on the exterior surface of the tailgate to close it.



If the tailgate is not fully closed, this warning lamp comes on in the instrument panel screen until it is closed.

Manual release

This enables the boot to be unlocked in the event of a central locking fault.



- Fold back the rear seats to gain access to the tailgate release from inside the boot.
- Remove the plastic cover from the opening **A** in the tailgate interior pillar.
- Move the control **B** to the right to unlock and open the boot.

Locking / unlocking from inside

Central locking control

System which provides full manual locking or unlocking of the doors and boot from the inside.




Locking

- ☞ Press the front of button **A** to lock the vehicle.

Unlocking

- ☞ Press the rear of button **A** to unlock the vehicle.

Individual controls



Locking the front and rear doors

- ☞ Pivot the interior control **B** towards the front.

This control can also be used to lock the front passenger's door and the rear doors in the event of a failure with the central locking. To do this:

- ☞ Open the door in question.
- ☞ Pivot the interior control **B** towards the front, then close the door.

! It is possible to lock the vehicle with a passenger door open, using using the individual locking controls: ensure that you have the key before closing the passenger door.

Unlocking the front and rear doors

- ☞ Pivot the interior control **B** towards the rear.

Alarm*

System which protects and provides a deterrent against theft and break-ins. It provides the following types of monitoring:

- perimeter

The system checks for any opening of the vehicle. The alarm is triggered if anyone tries to open a door, the boot, the bonnet....

- volumetric

The system checks for any variation in the volume in the passenger compartment. The alarm is triggered if anyone breaks a window, enters the passenger compartment or moves inside the vehicle.

- tilt

The system checks for any change in the attitude of the vehicle. The alarm is triggered if the vehicle is lifted, moved or knocked.

Self-protection function

The system checks for the putting out of service of its components. The alarm is triggered if the battery, the central control or the siren wiring are put out of service or damaged.



For all work on the alarm system, contact a CITROËN dealer or a qualified workshop.

Locking the vehicle with full alarm system



Activation

- ☞ Switch off the ignition (OFF mode if your vehicle has the Keyless Entry and Starting system).
- ☞ Remove the key from the ignition switch, if your vehicle does not have the "Keyless Entry and Starting" system.
- ☞ Leave the vehicle, and close all the doors and the bonnet.
- ☞ Press the locking button on the remote control or one of the door or boot buttons if your vehicle has the "Keyless Entry and Starting" system.

The alarm is being activated: the indicator lamp **A** flashes rapidly accompanied by an intermittent audible signal for about 20 seconds.

Once the 20 seconds have expired, **the system is active**. The audible signal stops and the indicator lamp in the button flashes slowly.

Deactivation

Do one of the the following to deactivate the alarm:

- ☞ Press the unlocking button on the remote control or one of the door or boot buttons if your vehicle has the "Keyless Entry and Starting" system.
- ☞ Switch on the ignition (ON mode if your vehicle has the "Keyless Entry and Starting" system).
- ☞ Open a door or the boot while the system is being activated.

The alarm system is deactivated: the indicator lamp **A** goes off.

* According to equipment.

Locking the vehicle with perimeter monitoring only

Deactivate the interior volumetric and tilt monitoring to avoid unwanted triggering of the alarm in certain cases, such as:

- an animal left in the vehicle,
- a window left partly open,
- washing your vehicle.

Deactivation of the interior volumetric and tilt monitoring

- ☞ Switch off the ignition and remove the key from the ignition switch (OFF mode if your vehicle has the "Keyless Entry and Starting" system).
- ☞ Raise and hold the wiper control stalk in the **"MIST"** position for about 3 seconds.
- ☞ The audible signal sounds **once** and the interior volumetric and tilt monitoring are deactivated.

Raise and hold the wiper control stalk in the **"MIST"** position for about three seconds to activate them again, the audible signal sounds **twice**.

Triggering of the alarm

This is indicated by sounding of the siren and flashing of the direction indicators for thirty seconds.

A message then appears in the instrument panel screen while the siren is operating. When the ignition is next switched on (ON mode if your vehicle has the "Keyless Entry and Starting" system), an audible signal sounds four times to inform you that the alarm was triggered during your absence.

Complete deactivation of the alarm

You can completely deactivate the alarm system. To do this, proceed as follows:


- ☞ Switch off the ignition (OFF mode if your vehicle has the "Keyless Entry and Starting" system).
- ☞ Remove the key from the ignition switch, if your vehicle does not have the "Keyless Entry and Starting" system.
- ☞ Open the driver's door.
- ☞ Place the lighting control stalk in the **"OFF"** position.
- ☞ Pull the wiper control stalk towards you and hold.
After about ten seconds there is an audible signal.
- ☞ When the audible signal stops, continue to hold the wiper stalk pulled towards you and press the remote control locking button.

- ☞ The state of the system is then signalled to you by the number of beeps:
One beep: the alarm system is completely deactivated.
Two beeps: the alarm system is activated.
Each new press of the remote control locking button changes the state of the system.

i It is possible to adjust the sensitivity of the alarm sensor and to deactivate the function via the colour screen "Equipment" menu.

Electric windows

System which opens or closes a window manually or automatically. It is fitted with a system which provides protection if an obstacle is detected on one-touch models and a deactivation system to prevent misuse of the rear controls.



1. Driver's electric window.
2. Passenger's electric window.
3. Rear right electric window.
4. Rear left electric window.
5. Deactivating the passenger and rear electric window switches.

Front and rear passengers' electric windows

- ☞ With the ignition on, press or pull the switch. The window stops when you release the switch.

Driver's one-touch electric window

With the ignition on, you have two options:

- **manual mode**
 - ☞ Press the switch gently to open or pull it gently to close. The window stops as soon as the switch is released.
- **automatic mode**
 - ☞ Press the switch fully to open or pull it fully to close. The window opens or closes completely when the switch is released.
 - ☞ Pressing the switch again stops the movement of the window.

i The electric window switches remain operational for approximately 30 seconds after the ignition is switched off. The windows can no longer be opened or closed once a front door is opened. The rear windows do not lower fully.

Safety anti-pinch (driver's side)

In automatic mode, when the window rises and meets an obstacle, it stops and lowers again.

Reinitialising the electric windows

- i** Should there be no automatic movement of a window when rising or after the safety anti-pinch has been triggered three times in succession, the electric windows must be reinitialised.

From the switch in the driver's door:


- ☞ pull the switch until the window is fully closed, then release it,
- ☞ pull the switch again for at least one second after reaching the window closed position.

The safety anti-pinch function is not active during these operations.

- i** Always remove the key from the ignition when leaving the vehicle, even for a short time.
In the event of contact during operation of the windows, you must reverse the movement of the window. To do this, press the switch concerned.
When the driver operates the passenger electric window switches, they must ensure that no one is preventing correct closing of the windows.
The driver must ensure that passengers use the electric windows correctly.
Be aware of children when operating the windows.

Deactivating the passenger and rear electric window switches

2



- ☞ For the safety of your children, press switch **5** to prevent operation of the passenger and rear electric windows irrespective of their position.

When the button is pressed down, the switches are deactivated.


When the button is up, the switches are activated.

- i** When the button is pressed down, only the window in the driver's door operates.

Panoramic sunroof

It has a motorised blind.

Motorised blind



With the ignition on, there are two ways of opening or closing the blind:

- ☞ Briefly pull or push the control in direction **1** or **2**, the blind stops when you release the control.
- ☞ Maintain pressure on the control in direction **1** or **2** until movement starts, the blind then opens or closes fully.

Stopping temporarily

- ☞ To stop the opening or closing of the blind, press part **3** of the control or reverse the movement of the control.

Safety anti-pinch

At the end of its travel, if the blind encounters an obstacle to closing, it stops and moves back slightly.


! Remember to always switch off the ignition when leaving the vehicle, even for a short time.
When operating the control, the driver should ensure that there is nothing preventing movement of the blind.
The driver must ensure that passengers use the blind correctly.
Be aware of children when operating the blind.

Front seats

Seat consisting of a seat cushion, a seat back and a head restraint which can all be adjusted to adapt your position for ease of driving and comfort.

i As a safety measure, seat adjustments should only be done when stationary.


Manual adjustments



Forwards-backwards

- ☞ Raise the control bar and slide the seat forwards or backwards.

When the seat is in the correct position, push it forwards and backwards without raising the control bar to check that it has latched.




Seat backrest angle

- ☞ Pull the control lever up to adjust the seat backrest.



When the backrest is at the desired angle, release the control.

When the backrest is at the correct angle, release the control lever. To ensure that the backrest does not suddenly fold forwards and hurt you, restrain it with your back or your hand while operating the control.




Driver's seat height

- ☞ Pull the control upwards to raise or push it downwards to lower, as many times as necessary, to obtain the position required.


Front seats

Electric adjustments




Forwards-backwards

- ☞ Push the control forwards or rearwards to slide the seat.



Seat backrest angle

- ☞ Tilt the control forwards or rearwards to adjust the angle of the seat backrest.




Driver's seat cushion height and angle

- ☞ Pull or push the front part of the control upwards or downwards to raise or lower the front of the seat cushion.
- ☞ Pull or push the rear part of the control upwards or downwards to raise or lower the rear of the seat cushion.
- ☞ Pull or push all of the control upwards or downwards to raise or lower the whole seat cushion.

i To avoid discharging the battery, carry out these adjustments with the engine running.

Additional adjustments



Head restraint height

- ☞ To raise a head restraint, pull it upwards.
- ☞ To lower the head restraint, press the lug **A** and the head restraint at the same time.

The head restraint is fitted with a frame with notches which prevents it from lowering; this is a safety device in case of impact.

The adjustment is correct when the upper edge of the head restraint is level with the top of the head.


Removing a head restraint

- ☞ To remove a head restraint, press the lug **A** and pull the head restraint upwards.
- ☞ To put the head restraint back in place, engage the head restraint stems in the openings keeping them in line with the seat back and press the lug **A** at the same time.



Never drive with the head restraints removed; they must be in place and adjusted correctly.

Front armrest



Heated seats adjustment

With the engine running, tilt the button to the position required.


The temperature of the seat is regulated automatically.

There are two setting positions:

- "HI": High heating
- "LO": Low heating

When the button is in the intermediate position, the heating is switched off.

The indicator lamps **A** come on when the system is activated.




You can move the console housing cover in order to use it as an armrest.



Rear seats

Bench seat with fixed one-piece cushion and split backrest (left hand 2/3, right hand 1/3) which can be folded individually to adapt the load space in the boot.

Folding the backrest




- ☞ Move the corresponding front seat forward if necessary.
- ☞ Place the head restraints in the low position (see "Rear head restraints").
- ☞ Press control **1** forwards to release the seat backrest **2**.
- ☞ Fold the seat back **2** on to the cushion.



Repositioning the seat backrest

- ☞ Straighten the seat backrest **2** and secure it.
- ☞ Check that the red indicator, located next to the control **1**, is no longer visible.




When repositioning the seat backrests, they can be locked in one of two different positions, depending on the speed in which the operation is carried out:

- if done quickly, the backrest returns to its original position **1**,
- if done slowly, the backrest goes into the vertical position **2**.

To go from position **2** to position **1**, simply release the backrest and push it until it locks in place.

Rear head restraints



These have one position for use (up) and a stowed position (down).

They can also be removed.

To remove a head restraint:

- ☞ pull the head restraint upwards to the stop,
- ☞ then, press the lug **A**.



Never drive with the head restraints removed; they must be in place and correctly adjusted.

Rear armrest



- ☞ Lower the rear armrest for a more comfortable position.

It may be fitted with cup holders and also gives access to the ski flap.

Ski flap



Device for storing and transporting long objects.

Opening

- ☞ Lower the armrest.
- ☞ Lower the flap opening control.
- ☞ Lower the flap.
- ☞ Load the objects from inside the boot.

Mirrors

Door mirrors



Each fitted with an adjustable mirror glass permitting the lateral rearward vision necessary for overtaking or parking. They can also be folded for parking in confined spaces.

Demisting - Defrosting



If your vehicle is fitted with heated mirrors, the demisting-defrosting operates with the engine running, by switching on the heated rear screen (see "Rear screen demist-defrost").



Adjustment

Adjustment is possible when the ignition switch is in the "ON" or "ACC" position.

- ☞ Move control **A** to the right or to the left to select the corresponding mirror.
- ☞ Move control **B** in all four directions to adjust.
- ☞ Return control **A** to the central position.



The objects observed are, in reality, closer than they appear. Take this into account in order to correctly judge the distance of vehicles approaching from behind.



Electric folding / unfolding

From inside:

- with the ignition switch in the "ON" or "ACC" position, by pressing the control **C**,
- with the ignition switch in the "LOCK" position, by pressing control **C**, **within 30 seconds**.

From the outside:

- ☞ by locking or unlocking the vehicle, using the remote control or the locking / unlocking buttons (for vehicles fitted with the "Keyless Entry and Starting" system).



If you have folded the mirrors using the control **C**, you must use this control to unfold them, otherwise the mirrors will not be lock in place correctly. Some mirror functions (in particular the automatic folding and unfolding of the door mirrors) can be configured via the colour screen "Equipment" menu. The mirrors can also be folded manually.

Rear view mirror

Adjustable mirror providing a central rearward view.

Equipped with an anti-dazzle system, which darkens the mirror glass and reduces the nuisance to the driver caused by the sun, headlights from other vehicles...

! As a safety measure, the mirrors should be adjusted to reduce the "blind spot".

Manual day/night model



Adjustment

- ☞ Adjust the mirror so that the glass is directed correctly in the "day" position.

Day / night position

- ☞ Pull the lever to change to the "night" anti-dazzle position.
- ☞ Push the lever to change to the normal "day" position.


Automatic day/night model



By means of a sensor, which measures the light from the rear of the vehicle, this system automatically and progressively changes between the day and night uses.

i In order to ensure optimum visibility during your manoeuvres, the mirror lightens automatically when reverse gear is engaged.

Steering wheel adjustment



- ☞ **When stationary**, lower the control lever to release the steering wheel adjustment mechanism.
- ☞ Adjust the height and reach to suit your driving position.
- ☞ Pull the control lever to lock the steering wheel adjustment mechanism.

! As a safety precaution, these operations should only be carried out while the vehicle is stationary.

Ventilation

Air intake

The air circulating in the passenger compartment is filtered and originates either from the outside via the grille located at the base of the windscreen or from the inside in air recirculation mode.


Air treatment

The incoming air follows various routes depending on the controls selected by the driver:

- direct arrival in the passenger compartment (air intake),
- passage through a heating circuit (heating),
- passage through a cooling circuit (air conditioning).

Control panel

The controls of this system are grouped together on control panel **A** on the centre console.



Air distribution

1. Windscreen demisting-defrosting vents.
2. Front side window demisting-defrosting vents.
3. Side adjustable air vents.
4. Central adjustable air vents.
5. Air outlets to the front footwells.
6. Air outlets to the rear footwells.
7. Temperature sensor.
8. Sunshine / rain sensor.

Recommendations for ventilation and air conditioning

- i** In order for these systems to be fully effective, follow the operation and maintenance guidelines below:
- ☞ To obtain an even air distribution, take care not to obstruct the exterior air intake grilles located at the base of the windscreen, the nozzles, the vents and the air outlets, as well as the air extractor located in the boot.
 - ☞ Do not cover the sunshine sensor, located on the dashboard; this is used for regulation of the digital air conditioning system.
 - ☞ Operate the air conditioning system for at least 5 to 10 minutes, once or twice a month to keep it in perfect working order.
 - ☞ Ensure that the passenger compartment filter is in good condition and have the filter elements replaced regularly.
We recommend the use of a combined passenger compartment filter. Thanks to its special active additive, it contributes to the purification of the air breathed by the occupants and the cleanliness of the passenger compartment (reduction of allergic symptoms, bad odours and greasy deposits).
 - ☞ To ensure correct operation of the air conditioning system, you are also advised to have it checked regularly as recommended in the servicing booklet.
 - ☞ If the system does not produce cold air, switch it off and contact a CITROËN dealer or a qualified workshop.


When towing the maximum load on a steep gradient in high temperatures, switching off the air conditioning increases the available engine power and so improves the towing ability.

- ☘** If after an extended stop in sunshine, the interior temperature is very high, first ventilate the passenger compartment for a few moments.
Put the air flow control at a setting high enough to quickly change the air in the passenger compartment.
The air conditioning system does not contain chlorine and does not present any danger to the ozone layer.

- i** The condensation created by the air conditioning results in a discharge of water under the vehicle which is perfectly normal.

Manual heating / air conditioning

The system operates with the engine running.



1. Temperature setting



☞ Turn the temperature control dial to the right to raise the temperature, and to the left to lower it.

2. Air flow setting



☞ Turn the dial to the right to increase and to the left to reduce the air flow.



To avoid misting and deterioration of the air quality in the passenger compartment, ensure that an adequate air flow is maintained.

3. Air distribution setting



☞ Place the dial in the desired position, to direct air towards:



the centre and side vents,



the centre, side and footwell vents,



the footwells,



the windscreen, side windows and footwells,



the windscreen and side windows.

The air distribution can be modulated by placing the dial in intermediate positions.

4. Exterior air intake / Recirculation of interior air



- ☞ Press button **4** to select the air entry mode.

This function allows the passenger compartment to be isolated from exterior odours and smoke.

When the warning lamp in button **4** is off, the intake of exterior air is active.

When the warning lamp in button **4** is on, the intake of exterior air is deactivated, and you are in air recirculation.

Do not drive for long with interior air recirculation, except in truly exceptional atmospheric conditions.

5. Air conditioning On / Off

The air conditioning is designed to operate effectively in all seasons, with the windows closed. It enables you to:

- lower the temperature, in summer,
- increase the effectiveness of the demisting in winter, above 3 °C.

Switching on



- ☞ Press button **5**, the lamp in the button comes on.


Switching off

- ☞ Press button **5** again, the lamp in the button goes off.

Switching off may affect comfort levels (humidity, condensation).

i If your vehicle is not fitted with air conditioning, the button is not active.

Automatic air conditioning



1. Temperature adjustment
2. Air flow adjustment
3. Air distribution adjustment
4. Intake of exterior air / Recirculation of interior air
5. Air conditioning On / Off

Automatic operation

- ☞ Set the temperature control dial **1** to the temperature required.
- ☞ Place the air flow control dial **2** in the **"AUTO"** position.
- ☞ Place the air distribution adjustment dial **3** in the **"AUTO"** position.

The system controls the air distribution, the flow, the temperature and the air intake to ensure the level of comfort selected and adequate air circulation in the passenger compartment. No further action on your part is required.

In automatic mode:

- ☞ when the temperature is set to maximum (Rapid heating), the intake of exterior air is activated and the air conditioning stops.
- ☞ when the temperature is set to minimum (Rapid cooling), air recirculation is activated and the air conditioning operates.

i When the engine is cold, to avoid an excessive distribution of cold air, the ventilation will reach its optimum level gradually.

On entering the vehicle, the interior temperature may be much colder (or warmer) than the temperature setting. There is no need to change the temperature setting in order to reach the comfort required rapidly.

The automatic regulation of the air conditioning will operate to correct the temperature difference as quickly as possible.

Manual settings

It is possible to set one or more functions manually while leaving the other functions in automatic mode.

Switching to manual mode may result in discomfort (temperature, humidity, odour, condensation) and does not offer optimum comfort.

1. Temperature setting



☞ Turn the temperature control dial to the right to increase the temperature and to the left to decrease it.

2. Air flow setting



☞ Turn the dial to the right to increase the air flow or to the left to decrease it.

To avoid condensation and deterioration of the quality of the air in the passenger compartment, ensure that a sufficient flow of air is maintained.

3. Air distribution setting



☞ Place the dial in the position required to direct the air towards:



the central and side vents,



the central and side vents and the footwells,



the footwells,



the windscreen, the side windows and the footwells,



the windscreen and the side windows.

The air distribution can be adapted by placing the adjustment dial in the intermediate positions.

4. Intake of exterior air / Recirculation of interior air

This function insulates the passenger compartment from exterior odours and smoke.



Press button **4** to select the air intake mode.

When the indicator lamp on button **4** is off, the exterior air intake function is on.

When the indicator lamp on button **4** is on, the intake of exterior air is off and the system is in air recirculation mode.

i Do not drive for long periods in interior air recirculation mode, except in truly exceptional atmospheric conditions.

Personalisation of the Exterior air intake / Interior air recirculation function

This function is controlled automatically. However, you can deactivate its automatic control if you wish to change the air intake mode at any time.

Changing the status

Press the Air intake / Interior air recirculation button for at least 10 seconds.

When the status changes from active to inactive, three bleeps are heard and the indicator lamp flashes three times.

When the status changes from inactive to active, two bleeps are heard and the indicator lamp flashes three times.

Automatic control active

If the air distribution adjustment dial and the air flow adjustment dial are placed in the "AUTO" position, the Air intake / Interior air recirculation function is also controlled automatically.

Automatic control inactive

Even if the air distribution adjustment dial and the air flow adjustment dial are placed in the "AUTO" position, the Air intake / Interior air recirculation function is no longer controlled automatically.

The settings are retained, even after switching off the ignition.

5. Air conditioning On / Off



Press button **5** to activate the air conditioning.

The indicator lamp comes on.

Personalisation of the Air Conditioning On / Off function

This function is controlled automatically. However, you can deactivate its automatic control if you wish to activate or deactivate the air conditioning at any time.

Changing the status

Press the Air Conditioning On / Off button for at least 10 seconds.

When the status changes from active to inactive, three bleeps are heard and the indicator lamp flashes three times.

When the status changes from inactive to active, two bleeps are heard and the indicator lamp flashes three times.


Automatic control active

If the air distribution adjustment dial and the air flow adjustment dial are placed in the "AUTO" position, or if the temperature control dial is set to the minimum temperature, the air conditioning system is controlled automatically.


Automatic control inactive

The air conditioning system is no longer controlled automatically.

Front Demist - Defrost



1. Press button **A**, to select "exterior air intake". The lamp in the button is off.
2. Place the air distribution dial in the "windscreen, side windows and footwells" position.
3. Select the desired level of air flow.
4. Select the desired temperature.
5. If your vehicle has air conditioning, switch it on by pressing button **B**. The lamp in this button comes on.



Rapid demisting

1. Place the distribution control on the "windscreen and side window" position.
2. Select maximum air flow.
3. Select maximum temperature.

Rear screen demist - defrost

The control button is located on the air conditioning system control panel.

Switching on

The rear screen demisting/defrosting can only operate when the engine is running.



- ☞ Press this button to demist/defrost the rear screen and (depending on version) the door mirrors. The indicator lamp associated with the button comes on.


Switching off

The demisting/defrosting switches off automatically to prevent an excessive consumption of current.


- ☞ It is possible to stop the demisting/defrosting operation before it is switched off automatically by pressing the button again. The indicator lamp associated with the button goes off.
- ☞ Switch off the demisting/defrosting of the rear screen and door mirrors as soon as appropriate, as lower current consumption results in reduced fuel consumption.

Front fittings

1. Sun visor.
2. Glove box.
3. Portable ashtray.
4. Cigarette lighter
12 V socket (120 W max).
5. Armrest with storage compartments.
6. Cup holder.
7. Bottle holder.



Mat




When removing the mat on the driver's side, move back the seat as far as possible and remove the fixings.

When refitting, position the mat correctly on the pins and clip the fixings. Check that the mat is secured firmly.

To prevent any risk of jamming under the pedals:

- only use mats suited to the fixings already present in the vehicle; it is imperative that these fixings are used.
- never fit one mat on top of another.


Sun visor



The sun visors fold forwards, and to the side when they are unhooked.

They are fitted with a courtesy mirror and a ticket holder.

Glove box



It has dedicated locations for storing a water bottle, the vehicle's handbook pack...


☞ To open the glove box, raise the handle. It is illuminated when the lid is opened.

It houses the front passenger airbag deactivation switch **A**.

If the vehicle is fitted with air conditioning, it has a ventilation nozzle **B**, distributing the same conditioned air as the vents in the passenger compartment.


If your vehicle is fitted with the "Keyless Entry and Starting" system, it contains the back-up starting unit **C**.

Portable ashtray



- ☞ Pull the cover to open the ashtray.
- ☞ To empty it, remove the ashtray by pulling it upwards.

Cigarette lighter / 12 V accessory socket




- ☞ To use the cigarette lighter, press it in and wait a few seconds until it pops out automatically.
- ☞ To connect a 12 V accessory (max power: 120 W), remove the cigarette lighter and connect a suitable adaptor.

You can use this socket to connect a telephone charger, a bottle warmer...

After use, put the cigarette lighter back into place straight away.


Front armrest

Upper storage compartment




Pull the right-hand lever to open the storage compartment lid, which serves as an armrest. To close, fold down the lid until it locks.

Lower storage compartment



Pull the left-hand lever to open the lid. To close, fold down the lid until it locks. This storage compartment may contain up to 3 accessory sockets.

12 V socket (120 W max)




This operates when the ignition switch is in the "LOCK", "ACC" or "ON" position. Open the cover of the front armrest to gain access to the socket.

! Check that the electrical equipment operates on 12 V and that its maximum electrical power is 120 W. The prolonged use of electrical equipment without running the engine may discharge the battery.

3

Auxiliary socket (AUX)




It is used to connect a portable device (MP3 player...).

Open the front armrest cover for access to the socket.

For more information on using this equipment, see "Audio and Telematics".

USB port



It permits the connection of a portable device, such as a digital audio player of the iPod® or USB memory stick type.

Open the front armrest cover for access to the port.

It reads certain audio file formats allowing them to be heard via the vehicle's speakers.

You can manage these files using the steering mounted controls or the audio system control panel.

i Connected to the USB port, the portable device charges automatically while in use.

For more information on the use of this equipment, see "Audio and Telematics".


Rear fittings

Grab handle



Pull the handle downwards to lower it.

Coat hook



The rear left grab handle is fitted with a coat hook.


Seat pockets




3

Boot fittings

1. **Rear parcel shelf**
(see details on a following page)
2. **Lashing rings**
3. **Retaining strap**
4. **Side storage**



Rear parcel shelf




To remove the shelf:

- ☞ unhook the two cords,
- ☞ raise the shelf slightly, then remove it.

There are several options for storing the shelf:

- either upright behind the front seats,
- or flat at the base of the boot.

Stowing rings




There are four stowing rings in the boot for securing luggage:

- two rings are located on the boot floor,
- two rings are located on the rear side pillars.

Starting - stopping the engine with the key

Ignition switch



- Position 1: **LOCK**
The steering is locked.
- Position 2: **ACC**
The accessories (radio, 12 V socket...) can be used.
- Position 3: **ON**
Ignition on.
- Position 4: **START**
Starting the engine.

! If you use the accessories for a prolonged period (with the key in position **2 (ACC)**), you risk discharging the battery. Starting your vehicle will then no longer be possible. **Be aware.** See the "Automatic power cut-off to accessories" section.

Starting using the key

- ☞ Insert the key in the ignition switch.
- ☞ Turn the key to position **2 (ACC)** and unlock the steering column, by turning wheel slightly.
- ☞ Press and hold the brake pedal.
- ☞ Fully depress the clutch pedal (vehicles fitted with a manual gearbox).
- ☞ Put the gear lever into neutral (vehicles fitted with a manual gearbox), or in position **P** (vehicles fitted with a CVT gearbox).
- ☞ Operate the starter by turning the key to position **4 (START)**.
- ☞ Once the engine is running, release the key.
The key returns automatically to position **3 (ON)**.

i For Diesel vehicles, when the engine is cold wait with the ignition switch in position **3 (ON)** until the preheater warning lamp goes off, before turning the key to position **4 (START)**.
The warning lamp does not come on when the engine is hot.

Stopping

- ☞ Immobilise the vehicle.
- ☞ Put the gear lever into neutral (vehicles fitted with a manual gearbox), or in position **P** (vehicles fitted with a CVT gearbox).
- ☞ While pressing the key, turn it to position **1 (LOCK)**.
- ☞ Remove the key from the ignition switch.
- ☞ Lock the steering.


i Do not attach any heavy objects to the key as this could weigh down on it when in the ignition switch and cause a fault.

Key in ignition

A buzzer sounds on opening the driver's door, if the key has been left in the ignition.

Starting - stopping the engine with the Keyless Entry and Starting system

Changing the mode of the vehicle



With the electronic key inside the vehicle; each press on the "**START/STOP**" button, with no action on the pedals, changes the vehicle's mode:


- ☞ First press (ACC mode), the button's warning lamp comes on in orange. The accessories (radio, 12V socket...) can be used.
- ☞ Second press (ON mode), the button's warning lamp comes on in green. Switching on the ignition.
- ☞ Third press (OFF mode), the warning lamp in the button goes off.

i If the warning lamp flashes orange, contact a CITROËN dealer or a qualified workshop as soon as possible.

! If you use the accessories for a prolonged period with the ignition switch in position **2 (ACC)**, you risk discharging the battery. Starting your vehicle will then no longer be possible. **Take care.** See the "Automatic power cut-off to accessories" section.

Starting using the electronic key

For vehicles fitted with a manual gearbox, put the gear lever in neutral.
For vehicles fitted with a CVT gearbox, put the gear lever in **P**.



- ☞ With the electronic key inside the vehicle, depress the clutch pedal fully on vehicles with a manual gearbox or press the brake pedal on vehicles with a CVT gearbox.



- ☞ Press and release the "**START/STOP**" button.

Each attempt at starting takes around 15 seconds. If the engine does not start, press the **"START/STOP"** button once more to try again.

i If one of the starting conditions is not met, a reminder message appears in the instrument panel screen. In some circumstances, it is necessary to turn the steering wheel slightly while pressing the **"START/STOP"** button to assist unlocking of the steering; a message warns you when this is needed.

The presence of the electronic key in the defined zone is essential. For reasons of safety, do not leave this area when the engine is running.

!  For Diesel vehicles, when the engine is cold starting does not take place until the pre-heater warning lamp has gone off.

i The presence of the electronic key in the vehicle is essential for switching on the ignition and starting only. Once the engine has started, make sure that the electronic key remains with the vehicle until the end of the journey; otherwise you would not be able to lock the vehicle.

Switching off using the electronic key

-  Immobilise the vehicle.
-  Place the gear lever in neutral for vehicles fitted with a manual gearbox, or on **P** for vehicles fitted with a CVT gearbox.
-  With the electronic key inside the vehicle, press the **"START/STOP"** button.

The engine stops.

The steering locks when a door is opened or on locking the vehicle.


i If the vehicle is not immobilised, the engine will not stop.



This message is displayed when the driver's door is opened and the vehicle is not in "OFF" mode.

-  Press the **"START/STOP"** button again to change to "OFF" mode.

Back-up starting with the electronic key



When the electronic key is in the defined zone and your vehicle does not start after pressing the "**START/STOP**" button:

- ☞ Open the glove box.
- ☞ Insert the electronic key in the location **A**.

- ☞ Press the brake pedal on vehicles fitted with a CVT gearbox or depress the clutch pedal fully on vehicles with a manual gearbox.
- ☞ Press the "**START/STOP**" button.

i Once the engine has started, you can remove the electronic key from its housing **A** and close the glove box.



The message is displayed when you open the driver's door and the electronic key has not been removed from its location **A**. Remember to take the electronic key with you when you leave the vehicle.

Emergency stop with the electronic key

In the event of an emergency only, the engine can be stopped without any conditions. To do this, press and hold the "**START/STOP**" button for about 3 seconds or make 3 successive presses on the button. The engine stops and the vehicle goes into "ACC" mode.

! During an emergency stop, the braking servo assistance and steering power assistance functions are no longer provided. Take great care.

Anti-theft protection

Electronic engine immobiliser


The keys contain an electronic chip which has a secret code. When the ignition is switched on, this code must be recognised in order for starting to be possible.

This electronic engine immobiliser locks the engine management system a few minutes after the ignition is switched off and prevents starting of the engine by anyone who does not have the key.

In the event of a malfunction, you are informed by a message in the instrument panel screen.

In this case, your vehicle does not start; contact a CITROËN dealer as soon as possible.

Parking brake



Applying

- ☞ Pull the parking brake lever fully up to immobilise your vehicle.

Releasing

- ☞ Pull the parking brake lever up gently, press the release button **A** then lower the lever fully.



When the vehicle is being driven, if the parking brake is still on or has not been fully released, a message appears in the screen.

! When parking on a slope, direct your wheels against the kerb, apply the parking brake, engage a gear or place the gear lever in position **P** for vehicles fitted with a CVT gearbox, and switch off the ignition ("OFF" mode).

5-speed manual gearbox

Engaging reverse gear




- ☞ Push the gear lever to the right then backwards.

! Only engage reverse gear when the vehicle is stationary with the engine at idle.

- i** As a safety precaution and to facilitate starting of the engine:
- always select neutral,
 - press the clutch pedal.

6-speed manual gearbox

Engaging 5th or 6th gear



- ☞ Move the lever fully to the right to engage 5th or 6th gear.

Engaging reverse gear

- ☞ Raise the ring under the knob and move the gear lever to the left then forwards.

! Only engage reverse gear when the vehicle is stationary with the engine at idle.

- i** As a safety precaution and to facilitate starting of the engine:
- always select neutral,
 - press the clutch pedal.

Gear shift indicator*

System which reduces fuel consumption by advising the driver to change up on vehicles fitted with a manual gearbox.

Operation

The system intervenes only when driving economically.

Depending on the driving situation and your vehicle's equipment, the system may advise you to skip one or more gears. You can follow this instruction without engaging the intermediate gears.

The gear recommendations should not be considered compulsory. In fact, the configuration of the road, the amount of traffic and safety remain determining factors when choosing the best gear. Therefore, the driver remains responsible for deciding whether or not to follow the advice given by the system. This function cannot be deactivated.



The symbol appears in the instrument panel suggesting that you change up.

- i** In the case of driving which makes particular demands on the performance of the engine (firm pressure on the accelerator pedal, for example, when overtaking...), the system will not recommend a gear change. The system never suggests:
- engaging reverse gear,
 - engaging a lower gear.



* According to engine.

CVT gearbox

The six-speed automatic gearbox offers a choice between the comfort of automatic regulation or the pleasure of manual gear changing.

This gearbox has two driving modes:

- an automated mode for automatic control of the gears by the gearbox and therefore without any action on the part of the driver,
- a manual mode for sequential changing of the gears by the driver using the steering mounted controls or the gear lever.



4

i The mode can be changed at any time.

It includes the following controls:

- a gear lever **1** on the centre console for selecting the driving mode, reverse gear and neutral or for changing gear in manual mode,
- a **"-"** steering mounted control paddle **2** for manual downward gear changes,
- a **"+/OFF"** steering mounted control paddle **3** for manual upward gear changes.

Gear lever positions

P: park.

Immobilisation of the vehicle, parking brake applied or not.

R: reverse gear.

With the vehicle stationary, keep your foot on the brake pedal and push the gear lever forwards.

N: neutral.

D: driving in automated mode.

Move the lever backwards to select this mode.

+/-: manual mode with sequential gear changing.

Move the lever backwards, then to the left to select this mode, then:

- push forward to change up,
- pull backward to change down.

Functions of the steering mounted control paddles


+: gear changing in manual mode.

Press behind the **"+/OFF"** steering mounted control paddle to change up.

-: gear changing in manual mode.

Press behind the **"-"** steering mounted control paddle to change down.

Moving off



From position **P**, parking brake applied:



Press the brake pedal firmly while starting the engine.

☞ Start the engine.



Press the brake pedal firmly to release the gear lever.

☞ Select first gear (position **D** or **+/-**) or reverse (position **R**).

"D" or **"1"** or **"R"** appear in the instrument panel screen.


☞ Release the parking brake, the vehicle moves off on its own.

Stopping - Starting on a slope

It is essential to use the parking brake to hold the vehicle on a slope and not the accelerator pedal.

When starting on a slope, accelerate gradually while releasing the parking brake.

Manual mode



- ☞ Select position +/-.
- ☞ Use the steering mounted controls or the gear lever to change gear.

The gears engaged appear in succession in the instrument panel screen.


The gear change instructions are only carried out if the engine speed permits it.

You can change gear without taking your foot off the accelerator pedal.

When decelerating, the gearbox changes down automatically.

With the vehicle stationary, first gear is engaged.

Automated mode



- ☞ Select position D.

"D" appears in the instrument panel screen.

The gearbox operates in auto-active mode, without any action on the part of the driver. It continuously selects the gear most suited to the conditions of:

- driving style,
- road characteristics,
- vehicle load.

To optimise driving comfort and obtain the most suitable gear, avoid sharp variations in the pressure on the accelerator pedal.

i For the best acceleration, when overtaking another vehicle, for example, press firmly on the accelerator going beyond the point of resistance.

Stopping the vehicle

Manual gear changing

In the automated mode, you can take over control temporarily at any time using the steering mounted controls.

The use of these controls permits manual selection of the gears in situations which require a faster change down than that offered in automated mode (arrival at a roundabout, exit from a car park with a steep gradient, overtaking...).

The gearbox engages the gear requested if the engine speed permits it. The gear engaged appears.

To return to the automated mode, do one of the following:

- press the back of the **"+/OFF"** steering mounted control **3** for approximately 2 seconds,
- move the gear lever quickly towards position **+/-** and then return it to position **D**,
- stop the vehicle.

Before switching off the engine, you must place the gear lever in position **P**.

You must apply the parking brake to immobilise the vehicle.

Operating fault



With the ignition on, if the message **"Slow down"** or **"Service required"** appears in the instrument panel screen, this indicates a gearbox malfunction.


When a message is displayed, carry out the following operations:

- slow down and stop your vehicle in a safe place,
- place the lever in position **P** and let the engine run,
- open the bonnet to allow the engine to cool.

If the message disappears for a long period, you can set off again.

If the message remains displayed or appears frequently, contact a CITROËN dealer or a qualified workshop without delay.

Emergency release



If the battery is discharged or if the gear lever locking mechanism is damaged, it is possible for the gear lever to be locked in position **P**, even when you press the brake pedal firmly.

! You must contact a CITROËN dealer or a qualified workshop to have the system checked.

However, if you have to move the vehicle, release the gear lever using the following procedure:

- ☞ Apply the parking brake.
- ☞ Switch off the engine if necessary.
- ☞ Remove the cap **A**, using a flat screwdriver covered with a cloth.
- ☞ Press the brake pedal firmly.
- ☞ Put the ignition switch into position ACC (ACC mode, if you vehicle has the Keyless Entry and Starting system).
- ☞ Insert the screwdriver into the aperture.
- ☞ While pushing the screwdriver downwards, move the gear lever to position **N**.

Hill start assist

System which keeps your vehicle immobilised temporarily (approximately 2 seconds) when starting on a gradient, the time it takes to move your foot from the brake pedal to the accelerator pedal.

This function is only active when:


- the vehicle is completely stationary, with your foot on the brake pedal,
- when certain conditions of gradient are met,
- with the driver's door closed.

The hill start assist function cannot be deactivated.

! When the engine is not running, including periods on standby with the Stop & Start (AS&G) system, the function is not operative.

! Do not leave the vehicle while it is being held in the hill start assist phase. If you need to leave the vehicle while the engine is running, apply the parking brake.

Operation



On an ascending slope, with the vehicle stationary, the vehicle is held for a brief moment when you release the brake pedal:

- if you are in first gear or neutral with a manual gearbox,
- if you are in position **D** with the CVT gearbox.

On a descending slope, with the vehicle stationary and reverse gear engaged, the vehicle is held for a brief moment when you release the brake pedal.

Operating fault



SERVICE REQUIRED

**ASC SYSTEM
SERVICE REQUIRED**

If a fault occurs with the system, this warning lamp comes on, accompanied by a message in the instrument panel screen. Contact a CITROËN dealer or a qualified workshop to have the system checked.

Stop & Start (Auto Stop & Go) function

The Stop & Start (Auto Stop & Go) function puts the engine temporarily into standby during stops in the traffic (red lights, traffic jams, or other...). The engine restarts automatically as soon as you want to move off. The restart takes place instantly, quickly and silently.

Perfect for urban use, the Stop & Start (Auto Stop & Go) function reduces fuel consumption and exhaust emissions as well as the noise level when stationary.

Operation

Going into engine STOP mode

AS&G The "AS&G" warning lamp comes on in the instrument panel or the instrument panel screen and the engine goes into standby after a few seconds:

- **with a manual gearbox**, with the vehicle stationary and your foot on the brake, when you put the gear lever into neutral and release the clutch pedal.



When the engine is stopped automatically, the operation of certain vehicle systems, such as for example, braking, power steering... are modified. **Take care.**



Never refuel with the engine in STOP mode; you must switch off the ignition with the key or the START/STOP button.

Special cases: STOP mode not available

STOP mode is not invoked when:

- the driver's seat belt is not fastened,
- the bonnet is open,
- the vehicle has not exceeded 3 mph (5 km/h) since the last engine start,
- the vehicle has restarted less than 10 seconds ago,
- the engine is needed to maintain a comfortable temperature in the passenger compartment,
- demisting is active,
- some special conditions (battery charge, engine temperature, braking assistance, ambient temperature...) where the engine is needed to assure control of a system.

AS&G - the "AS&G" warning lamp is flashing in the instrument panel.

This operation is perfectly normal.

Going into engine START mode

AS&G The "AS&G" warning lamp goes off and the engine starts automatically:

- **with a manual gearbox**, when you **fully** depress the clutch pedal.

Special cases: START invoked automatically


For safety reasons or to ensure smooth operation, START mode is invoked automatically when:

- the speed of the vehicle exceeds 2 mph (3 km/h),
- some special conditions (battery charge, engine temperature, braking assistance, ambient temperature...) where the engine is needed to assure control of a system.

AS&G In this case the "AS&G" warning lamp flashes for few seconds, then goes off.

This operation is perfectly normal.

Deactivation



At any time, press the "AS&G OFF" switch to deactivate the system.

AS&G OFF This is confirmed by the "AS&G OFF" warning lamp coming on in the instrument panel or instrument panel screen.

i If the system has been deactivated in STOP mode, the engine will not start.

Reactivation

Press the **"AS&G OFF"** switch again.

The system is active again; this is confirmed by the **"AS&G OFF"** warning lamp going off in the instrument panel or instrument panel screen.

- The system is reactivated automatically at every new start using the key or the START/STOP button.

Operating fault



In the event of a malfunction with the system, the **"AS&G OFF"** warning lamp flashes in the instrument panel or instrument panel screen, and the system no longer operates. have it checked by a CITROËN dealer or a qualified workshop.

In the event of a fault in STOP mode, the vehicle may stall. The following warning lamps come on in the instrument panel or instrument panel screen:



It is then necessary to switch off the ignition, then restart the engine using the key or the START/STOP button.

Maintenance

- This system requires a specific battery with a special specification and technology (reference numbers available from a CITROËN dealer or a qualified workshop).


Fitting a battery not listed by CITROËN introduces the risk of malfunction of the system.

- The "Auto Stop & Go" system makes use of advanced technology. All work on this type of battery must be done only by a CITROËN dealer or a qualified workshop.

Four wheel drive system

System which permits the selection of a transmission mode in relation to the driving conditions.

Three transmission modes are available and can be selected manually by the driver in accordance with his requirements.



You can change transmission mode when stationary or while driving. The transmission mode can be selected by turning the control **A**.

Selecting the transmission mode

4WD AUTO (position 1)

The vehicle operates with four wheel drive and provides optimum traction for all levels of grip. This is the vehicle's normal and regular operating mode, the distribution of the torque between the front and rear axles is controlled automatically.

The distribution favours the front wheels, the transfer of torque to the rear wheels is managed electronically by the control unit in relation to the level of grip, so providing optimum road holding.

4WD LOCK (position 2)

The vehicle operates with four wheel drive in this mode also.

It is recommended when grip is particularly poor or difficult (sand, mud, slopes, ...).

2WD (position 3)

The vehicle operates with front two wheel drive. This is suitable for use on a tarmac roads or where the driver considers that there is no risk of loss of grip (dry road).



The selection of this mode is recommended when the level of grip permits.

Display in the instrument panel



2WD




4WD AUTO



4WD LOCK

The transmission mode is displayed in the form of an intermittent display in the instrument panel screen when the transmission mode is selected.



Operating faults

If the selected transmission mode display flashes, the vehicle switches automatically to front **"2WD"** transmission mode.

It is then no longer possible to select the transmission mode using the control **A**.

If the message "SLOW DOWN" is displayed on the instrument panel, let the transmission cool down then wait for the display to clear before setting off again.

If "4WD" and "LOCK" are displayed alternately and if "SERVICE REQUIRED" is displayed in the instrument panel, the system has failed and the safety system has been activated.

Contact a CITROËN dealer or a qualified workshop without delay.

i As the engine torque is applied to all four wheels, the condition of the tyres has a considerable impact on the performance of the vehicle. Ensure that all four tyres are in good condition.

Avoid driving the vehicle in sandy or muddy areas or in other areas in which the wheels could spin.

Spinning the wheels places the transmission components under pressure and could cause a serious malfunction.

Do not drive the vehicle through deep water.

Avoid driving over excessively uneven terrain (risk of scraping under the body or of grounding on crossing a bridge).

! **Have your vehicle towed on a flatbed.**

The vehicle must not be towed with the front or rear wheels on the ground even if it is in front "2WD" (2 wheel drive) mode.

Cruise control

System which automatically maintains the vehicle speed at the value programmed by the driver, without any action on the accelerator pedal.

The cruise control is **switched on** manually: the vehicle speed must be at least 25 mph (40 km/h) and second gear or higher must be engaged in the case of a manual gearbox.


The cruise control is **switched off** manually, by an action on the brake or clutch pedal or if the ASC system is triggered.

The programmed speed can be exceeded temporarily by pressing the accelerator pedal.

To return to the programmed speed, simply release the accelerator pedal. Switching off the ignition cancels any programmed speed value.

i The cruise control cannot, in any circumstances, take the place of the need to comply with speed limits or of the vigilance and responsibility of the driver.

Steering mounted controls



The controls of this system are grouped together on the steering wheel.

1. **"ON/OFF"** button: activation / deactivation of the cruise control mode.
2. **"COAST SET"** button: store a driving speed and decrease the cruising speed.
3. **"ACC RES"** button: increase the cruising speed and recall the stored speed.
4. **"CANCEL"** button: stop control of the vehicle's speed.

Display in the instrument panel



When you press button 1, the **"CRUISE"** indicator comes on in the instrument panel.

Programming

- ☞ Press button 1.
- ☞ Set the programmed speed by accelerating to the required speed, then press button 2 **"COAST SET"**.

Increasing the programmed speed

- ☞ Using button **3 "ACC RES"**:
 - successive presses increase the speed in steps of approximately 1 mph (1.6 km/h).
 - a maintained press of this button increases the programmed speed progressively.

Once the speed required has been reached, release the button, the new speed is stored.

- ☞ Using the accelerator pedal:
 - accelerate to reach the speed required, then press button **2 "COAST SET"**. Release the button to store the new speed.

Decreasing the programmed speed

- ☞ Using button **2 "COAST SET"**:
 - successive presses decrease the speed in steps of approximately 1 mph (1.6 km/h).
 - a maintained press of this button decreases the speed progressively.

Once the speed required has been reached, release the button, the new speed is stored.

- ☞ Using the brake pedal:
 - brake to deactivate the cruise control, then press button **2 "COAST SET"**. Release to store the new speed.

Temporary acceleration/ deceleration

Temporary acceleration

Press the accelerator pedal as normal. When the pedal is released, you return to the stored speed.

Temporary deceleration

Press the brake pedal to reduce the speed. To return to the stored speed, press button **3 "ACC RES"**.

Deactivating the function

To deactivate the cruise control:

- ☞ press the **brake** or **clutch** pedal, or
- ☞ press button **1 "ON OFF"**, or
- ☞ press button **4 "CANCEL"**.

The cruise control may be deactivated automatically:

- ☞ when the vehicle reaches a speed below 20 mph (35 km/h),
- ☞ when the active stability control system (ASC) comes into operation.

Reactivating the function


When the cruise control has been deactivated using the button **4 "CANCEL"**, you can return to the stored speed by pressing button **3 "ACC RES"** when you reach a minimum speed of 25 mph (40 km/h).



When the cruise control is in operation, pay attention if you press and hold one of the programmed speed adjustment buttons: this can result in a very rapid change in the speed of your vehicle. Do not use the cruise control on slippery roads or in heavy traffic. On a steep descent, the cruise control will not be able to prevent the vehicle from exceeding the programmed speed. To prevent the mat from becoming caught under the pedals:

- ensure that the mat is positioned correctly,
- never fit one mat on top of another.

Parking sensors



This system indicates the proximity of an obstacle (person, vehicle, tree, gate, etc.) which comes within the field of detection of sensors located in the bumper.

Certain types of obstacle (stake, roadworks cone, etc.) detected initially will no longer be detected at the end of the manoeuvre due to the presence of blind spots.



This function cannot, in any circumstances, take the place of the vigilance and responsibility of the driver.

Rear parking sensors



The system is switched on by engaging reverse gear. This is accompanied by an audible signal. The indicator lamp in the button comes on to confirm that the system is active. The system is deactivated when you come out of reverse gear.


Audible assistance

The proximity information is given by an intermittent audible signal, the frequency of which increases as the vehicle approaches the obstacle.


When the distance between the vehicle and the obstacle becomes less than approximately thirty centimetres, the audible signal becomes continuous.

Detection zones


The detection zones differ depending on whether the vehicle is fitted with a towbar. If you select towbar mode, the towbar zone **A** is excluded from the detection zones.



Vehicle only



Vehicle fitted with a towbar



Modification of the detection zones

- ☞ Press this button to deactivate the system.
- ☞ Press this button again for a few seconds and release it.

The detection zone modification information is indicated by an audible signal:

- **double** signal on vehicles fitted with a towbar,
- **single** signal on vehicles which are not fitted with a towbar.

Visual assistance




This supplements the audible signal by displaying bars in the screen, in front of or behind the vehicle.

These bars flash at the start of the manoeuvre then become fixed from a certain distance between the vehicle and the obstacle.

Front parking sensors

The front parking sensors are triggered when an obstacle is detected in front, a gear is engaged (position **D** for vehicles with a CVT gearbox) and the speed of the vehicle remains below 6 mph (10 km/h).

The front parking sensors are interrupted if the vehicle stops for more than five seconds in forward gear, if no further obstacles are detected or when the speed of the vehicle exceeds 6 mph (10 km/h).



Deactivation / Activation of the front and rear parking sensors

The function is deactivated by pressing this button. The indicator lamp in the button goes off.

Pressing this button again reactivates the function. The indicator lamp in the button comes on.

i Remember to deactivate the system if towing a trailer or caravan.

Operating fault

In the event of an problem, when reverse gear is engaged this lamp in the button flashes, accompanied by an audible signal.




If one of the sensors is faulty, it flashes in the instrument panel screen.


Contact a CITROËN dealer or a qualified workshop.

i In bad weather or in winter, ensure that the sensors are not covered with mud, ice or snow.
When the vehicle is moving at a speed below 6 mph (10 km/h), certain sound sources (motorcycle, lorry, pneumatic drill, etc.) may trigger the audible signals of the parking sensor system.

Reversing camera



Linked with the navigation option, the reversing camera complements the parking sensor system and is activated automatically when reverse gear is engaged.



The colour image is provided on the navigation screen with indication of the limit of the rear bumper and of the general direction of the vehicle.

Lighting controls

Stalk for selecting and switching the vehicle's front and rear exterior lamps.

Main lighting

The various front and rear lamps of the vehicle are designed to adapt the lighting progressively in relation to the climatic conditions and so ensure the best visibility for the driver:

- sidelamps, to be seen,
- dipped beam headlamps to see without dazzling other drivers,
- main beam headlamps to see clearly when the road is clear.

Additional lighting

Other lamps are provided to fulfil the requirements of particular driving conditions:

- a rear foglamp to be seen from a distance,
- front foglamps for even better visibility,
- daytime running lamps to be seen during the day.


5

i In some weather conditions (e.g. low temperature or humidity), the presence of misting on the internal surface of the glass of the headlamps and rear lamps is normal; it disappears after the lamps have been on for a few minutes.


i Other lighting functions are also available:

- automatic illumination of headlamps,
- guide-me-home lighting,
- welcome lighting.

i When using your vehicle in a country that drives on the other side of the road, the headlamps must be adjusted to avoid dazzling on-coming drivers. Contact a CITROËN dealer or a qualified workshop.



Model without AUTO lighting



Model with AUTO lighting

Manual controls

The lighting is controlled directly by the driver by means of the ring **A** and the stalk **B**.

- A.** Main lighting mode selection ring: turn it to position the symbol required facing the mark.


	Dipped headlamps or main beam headlamps.
	Sidelamps.
AUTO	Automatic illumination of headlamps.
OFF	Lamps off.

- B.** Stalk for switching headlamps: pull the stalk towards you to switch the lighting between dipped and main beam headlamps.


In the lamps off and sidelamps modes, the driver can switch on the main beam headlamps temporarily ("headlamp flash") by maintaining a pull on the stalk.

Displays

Illumination of the corresponding indicator lamp in the instrument panel confirms that the lighting selected is on.



Model with a rear foglamp only



Model with front foglamps and a rear foglamp

Foglamp selection ring.

They operate if at least the sidelamps are on.



rear foglamp

- ☞ To switch on the rear foglamp, turn the ring **C** forwards.
- ☞ To switch off the rear foglamp, turn the ring **C** rearwards.



front and rear foglamps

Rotate and release the ring **C**:

- ☞ forwards a first time to switch on the front foglamps,
- ☞ forwards a second time to switch on the rear foglamp,
- ☞ rearwards a first time to switch off the rear foglamp,
- ☞ rearwards a second time to switch off the front foglamps.



In good or rainy weather, both day and night, the front foglamps and the rear foglamps are prohibited. In these situations, the power of their beams may dazzle other drivers.

Do not forget to switch off the front foglamps and the rear foglamps when they are no longer necessary.

5



Lighting on reminder

An audible signal when the driver's door is opened warns the driver if the vehicle lighting is on, with the ignition off. Switching off the lighting stops the audible signal.

Daytime running lamps

Daytime lighting which comes on automatically when the engine is started making the vehicle more visible to other users.

This function is assured by special lamps. The lighting control stalk must be placed in position **"0"** or **"AUTO"** (day mode).

Automatic illumination of headlamps

The sidelamps and the dipped beam headlamps come on automatically, without any action on the part of the driver, if a low level of exterior light is detected or if the wipers are switched on.

When the light returns to a sufficient level or the wipers are switched off, the lighting is switched off automatically.

The sensor is located at the base of the windscreen.

Contact a CITROËN dealer or a qualified workshop to adjust the sensitivity of the sensor.

Automatic switching off

When the lighting control stalk is at "dipped or main beam headlamps", if the ignition switch is at "LOCK" or "ACC" or if the key has been removed from the ignition switch, the lamps switch off automatically **when the driver's door is opened**.



In foggy weather or in snow, the sunshine sensor may detect sufficient light. The lighting will not come on automatically.


Do not cover the sunshine sensor, the associated functions will no longer be controlled.



The sensitivity of the automatic illumination of headlamps can be configured via the colour screen "Equipment" menu.

Manual guide-me-home lighting

Temporarily keeping the dipped beam headlamps on after the vehicle's ignition has been switched off makes the exit of the vehicle's occupants easier when the light is poor.



Switching on

- ☞ Place the lighting control stalk in the "OFF" position, or "AUTO" for vehicles that have it.
- ☞ Place the ignition switch on "LOCK" and remove the key (or select "OFF" mode for vehicles that have the "Keyless Entry and Starting" system).
- ☞ Within one minute after switching off the ignition, "flash" the headlamps using the lighting control stalk.
The headlamps come on for around 30 seconds.
- ☞ A further "headlamp flash" within 60 seconds of switching the ignition to OFF (or selection of "OFF" mode for vehicles with the "Keyless Entry and Starting" system) reactivates the function for a further 30 seconds.

Switching off

The manual guide-me-home lighting switches off immediately if you.

- flash the headlamps again,
- place the lighting control stalk in another position,
- switch the ignition on (or select "ON" mode for vehicle with the "Keyless Entry and Starting" system).

i The duration of the guide-me-home lighting can be set in the colour screen "Equipment" menu.

Exterior welcome lighting

Remote switching on of the lighting makes your approach to the vehicle easier in poor light. It comes on when the vehicle is unlocked remotely.

Switching on




- ☞ Place the lighting control in position "OFF" or "AUTO".
 - ☞ Press the open padlock on the remote control or the electronic key.
- The sidelamps come on for about 30 seconds. For vehicles fitted with automatic illumination of headlamps, the welcome lighting only comes on under conditions of low ambient light.

Switching off

- The welcome lighting goes off immediately if:
- you press the open padlock on the remote control,
 - you place the lighting control in another position,
 - you switch on the ignition (or select "ON" mode for vehicles fitted with the "Keyless Entry and Starting" system).

i It is possible to choose the type of lamps switched on or to deactivate the function via the colour screen "Equipment" menu.


Manual adjustment of the headlamp beams



To avoid causing a nuisance to other road users, the height of the halogen headlamp beams should be adjusted according to the load in the vehicle.

- 0 1 or 2 people in the front seats.
- 1 5 passengers (including the driver).
- 2 5 passengers (including the driver) + maximum authorised load.
- 3 Driver + maximum authorised load.

Automatic headlamp adjustment



On vehicles with xenon bulbs: **when stationary**, the system automatically corrects the height of the beam, whatever the load of the vehicle. The driver is then assured of having optimum lighting and not causing a nuisance to other road users.




In cases of malfunction, this message appears in the multifunction screen.

! Do not touch the xenon bulbs. Contact a CITROËN dealer or a qualified workshop.


Wiper controls

System for selection and control of the various front and rear wiping modes for removing rain and cleaning the screens.

The vehicle's front and rear wipers are designed to improve the driver's visibility according to the climatic conditions.



Model with intermittent wiping



Model with AUTO wiping

Settings

Various automatic wiper control modes are also available depending on whether the following options are fitted:


- automatic rain sensitive windscreen wipers,
- rear wiping on engaging reverse gear.

Manual controls

Windscreen wipers

A. wiping speed selection stalk:

MIST	single wipe.
OFF	park.
INT	intermittent (the speed can be set manually).
	or
AUTO	automatic rain sensitive wipers (the speed can be set manually).
LO	slow.
HI	fast.



B. intermittent operation or rain sensor sensitivity adjustment ring.

You can increase or decrease:


- the wiping frequency when the intermittent mode is active,
- the sensitivity of the rain sensor when the automatic mode is active.
 - "+": high sensitivity.
 - "-": low sensitivity.

i Certain windscreen wiper functions (intermittent operation, ...) can be configured via the colour screen "Equipment" menu.

Windscreen wash

Pull the wiper stalk towards you. The windscreen wash then the wipers operate for a set time.

The headlamp wash is also activated **if the dipped beam headlamps are on.**




Headlamp wash

Press the end of the lighting stalk to activate the headlamp wash, when the dipped beam headlamps are on.

i To reduce the consumption of screenwash fluid, the headlamp washers only operate with the first operation of the screenwash.

Automatic rain sensitive wipers

The windscreen wipers operate automatically, without any action on the part of the driver, if rain is detected (sensor behind the rear view mirror), adapting their speed to the intensity of the rainfall.



Activation

☞ Move the stalk **A** to the "AUTO" position.



Deactivation

☞ Move the stalk **A** to the "OFF" position.


Operating fault

Do not cover the rain sensor, linked with the sunshine sensor and located in the centre of the windscreen behind the rear view mirror.

! Switch off the automatic rain sensitive wipers when using an automatic car wash.

To protect the rubber of the wiper, it is advisable to deactivate the automatic mode when the vehicle is parked and when the ambient temperature is below 0 °C.

In winter, it is advisable to wait until the windscreen is completely clear of ice before activating the automatic rain sensitive wipers.



Rear wiper

C. rear wiper selection ring:

• **OFF** park.

• **INT** intermittent wipe.

The wiper wipes twice then switches to intermittent mode.

•  wipe with screen wash.

Keep the ring in this position to operate the screen wash with several wipes of the wiper.

i The intermittence of the rear wiper can be configured via the colour screen "Equipment" menu.

Courtesy lamps

Front courtesy lamp



Position 1

The courtesy lamp comes on when a door or the tailgate is opened.

When the door or the tailgate is closed again, the lighting gradually dims for a few seconds before switching off.

However, the courtesy lamp is switched off automatically in the following cases:


- When the doors and the tailgate are closed and the ignition switch is placed in the "ON" position.
- When the doors and the tailgate are closed and you lock the vehicle.

Position 2

The courtesy lamp is permanently off.

i The durations of lighting of the front courtesy lamps can be configured via the colour screen "Equipment" menu.

Map reading lamps



There are two map reading lamps, one on each side of the courtesy lamp.

Press the corresponding lamp lens **A**.

Rear courtesy lamp



Position 1 "ON"

The courtesy lamp is permanently on.

Position 2 "•"

The courtesy lamp comes on when a door or the tailgate is opened. When the door or the tailgate is closed again, the lighting gradually dims for a few seconds before switching off.

However, the courtesy lamp is switched off immediately in the following cases:

- When the doors and the tailgate are closed and the ignition switch is placed in the "ON" position.
- When the doors and the tailgate are closed and you lock the vehicle.

Position 3 "OFF"

The courtesy lamp is permanently off.


Courtesy lamps automatic switch off

With the engine off, the courtesy lamps, map reading lamps and boot lamp switch off automatically after 30 minutes to prevent discharging of the battery.

The courtesy lamps are switched on again if the ignition switch is placed in the "ON" or "ACC" position, if you open then close a door or the tailgate or if you use the remote control.

i The duration of lighting of the rear courtesy lamps can be configured via the colour screen "Equipment" menu.

Boot lamp




This comes on automatically when the boot is opened and goes off automatically when the boot is closed.

Panoramic roof lighting



When active, the panoramic roof lighting comes on if the ignition switch is placed in the **"ON"** or **"ACC"** position.



Deactivation

When the ignition switch is placed in position **"ON"** or **"ACC"**:


- ☞ Press this button repeatedly until the lighting goes off.

Settings

When the ignition switch is placed in position **"ON"** or **"ACC"**:

- ☞ Press this button repeatedly to obtain the desired lighting level (high, medium, low).

Direction indicators



- ☞ Left: lower the lighting stalk passing the point of resistance.
- ☞ Right: raise the lighting stalk passing the point of resistance.

"Motorway" function

- ☞ Press briefly upwards or downwards, without going beyond the point of resistance; the direction indicators will flash 3 times.

i The function can be deactivated via the colour screen "Equipment" menu.

Hazard warning lamps



A visual warning by means of the direction indicators to alert other road users to a vehicle breakdown, towing or accident.

- ☞ Press this button, the direction indicators flash.

They can operate with the ignition off.


Automatic operation of hazard warning lamps

When braking in an emergency, depending on the deceleration, the hazard warning lamps come on automatically.

They switch off automatically the first time you accelerate.

- ☞ You can also switch them off by pressing the button.

Horn



Audible warning system to alert other road users to an imminent danger.

- ☞ Press the central part of the steering wheel.

i Use the horn moderately and only in the following circumstances:

- immediate danger,
- approaching a location lacking visibility.

Braking assistance systems

Group of supplementary systems which help you to obtain optimum braking in complete safety in emergency situations:

- anti-lock braking system (ABS),
- electronic brake force distribution (EBFD).

Anti-lock braking system and electronic brake force distribution

Linked systems which improve the stability and manoeuvrability of your vehicle when braking, in particular on poor or slippery surfaces.

Activation

The anti-lock braking system is active if the vehicle speed is higher than 6 mph (10 km/h). It is deactivated when the vehicle speed falls below 3 mph (5 km/h).

The anti-lock braking system comes into operation automatically when there is a risk of wheel lock.

Normal operation of the ABS may make itself felt by slight vibration of the brake pedal.



When braking in an emergency, press very firmly without releasing the pressure.

Operating fault



When the vehicle is stationary

If this warning lamp comes on, accompanied by the indication on the instrument panel screen, it indicates a malfunction of the anti-lock braking system which could result in a loss of control of the vehicle when braking.

The vehicle retains normal braking.

Drive carefully at moderate speed and contact a CITROËN dealer or a qualified workshop as soon as possible.



The warning lamp comes on for a few seconds when the ignition is switched on (ON position). If it does not switch off or does not come on, contact a CITROËN dealer or a qualified workshop.

When the vehicle is moving



If this warning lamp comes on continuously it indicates a malfunction of the anti-lock braking system which could result in a loss of control of the vehicle on braking.

The vehicle retains normal braking.
Drive carefully at moderate speed and contact a CITROËN dealer or qualified workshop as soon as possible.



If these two warning lamps come on, linked with the warnings on the instrument panel screen, they indicate a malfunction of the electronic brake force distribution which could result in a loss of control of the vehicle on braking.

You must stop as soon as it is safe to do so.
Contact a CITROËN dealer or a qualified workshop.

i The two warning lamps come on at the same time and the two warnings are displayed alternately in the instrument panel screen.
When replacing wheels (tyres and rims), ensure that they conform to the manufacturer's recommendations.

Trajectory control systems

Associated systems which guarantee the directional stability of the vehicle within the limits of the laws of physics:

- traction control (TCL),
- active stability control (ASC).

Traction control and active stability control

Traction control optimises traction to prevent wheel spin, by acting on the brakes of the driving wheels and on the engine.

Active stability control acts on the brake of one or more wheels and on the engine to keep the vehicle on the trajectory required by the driver.

Activation

These systems are activated automatically each time the vehicle is started.

Operation

They operate when the vehicle speed is higher than 10 mph (15 km/h).


They come into operation in the event of a grip or trajectory problem.



This is indicated by flashing of this symbol on the instrument panel screen.

Deactivation

In exceptional conditions (starting a vehicle which is bogged down, stuck in snow, on soft ground, ...), it may be advisable to deactivate the ASC system, so that the wheels can move freely and regain grip.



- Press this button, located to the left of the steering wheel, until the symbol appears in the instrument panel screen.



The illumination of this warning lamp in the instrument panel indicates that the ASC and TCL systems are deactivated.

Reactivation

☞ Press this button again to reactivate the ASC and TCL systems.

When the warning lamp goes off, this indicates the reactivation of the ASC and TCL systems.

Operating fault



The illumination of one of these warning lamps accompanied by a message in the instrument panel screen indicates a malfunction of these systems.

Contact a CITROËN dealer or a qualified workshop to have the ASC/TCL systems checked.

! The ASC/TCL systems offer exceptional safety in normal driving, but this should not encourage the driver to take extra risks or drive at high speed.

The correct functioning of these systems depends on observation of the manufacturer's recommendations on:

- wheels (tyres and rims),
- braking components,
- electronic components,
- assembly and repair procedures.

After an impact, have these systems checked by a CITROËN dealer or a qualified workshop.


Seat belts

Front seat belts

The front seat belts are fitted with a pretensioning and force limiting system. This system improves safety in the front seats in the event of a front or side impact. Depending on the severity of the impact, the pretensioning system instantly tightens the seat belts against the body of the occupants.

The pretensioning seat belts are active when the ignition is on.

The force limiter reduces the pressure of the seat belt on the chest of the occupant, so improving their protection.



Fastening

- ☞ Pull the strap, then insert the tongue in the buckle **A**.
- ☞ Check that the seat belt is fastened correctly by pulling the strap.

Unfastening

- ☞ Press the red button on the buckle **A**.



Height adjustment


- ☞ To lower the attachment point, press the control **B** and slide the fixing **C** down.
- ☞ To raise the attachment point, press the control **B** and slide the fixing **C** up.

Front seat belt not fastened / unfastened warning lamp

Driver's seat belt



When the ignition is switched on, this warning lamp comes on accompanied by an audible signal for a few seconds if the driver has not fastened their seat belt.



If the driver does not fasten their seat belt within one minute after switching on the ignition, the warning lamp flashes accompanied by an intermittent audible signal and a display on the instrument panel screen.

The warning lamp, the audible signal and the display stop after approximately 90 seconds and return until the driver fastens their seat belt.

If the seat belt is unfastened **while the vehicle is moving**, you are alerted by the same warnings.



Front passenger's seat belt



When the ignition is switched on, this warning lamp comes on the centre console panel.


It is accompanied by an audible signal for a few seconds if the passenger has not fastened their seat belt.

If the seat belt is unfastened **while the vehicle is moving**, you are alerted by the same warnings.

Centre rear seat belt


The seat belt for the centre rear seat is fitted in the roof.

It has three anchorage points and a reel.



Fitting the belt

- ☞ Pull out the belt and pass it through the belt guide **A**.
- ☞ Pull on the strap and insert the tongue **B** into the left hand buckle.
- ☞ Insert the tongue **C** into the right-hand buckle.
- ☞ Check that each buckle has engaged by pulling on the strap.



Removing and stowing the belt

- ☞ Press the red button on buckle **C**, and then on the red button on buckle **B**.
- ☞ Guide the belt as it reels in, passing it through the belt guide **A**.
- ☞ Stow the tongue **C** in the upper slot **D** and the tongue **B** in the lower slot **E**.

Outer rear seat belts

Each outer rear seat is fitted with a three-point inertia reel seat belt.

Fastening

- ☞ Pull the strap, then insert the tongue in the buckle.
- ☞ Check that the seat belt is fastened correctly by pulling the strap.

Unfastening

- ☞ Press the red button on the buckle.

i The driver must ensure that passengers use the seat belts correctly and that they are all restrained securely before setting off. Wherever you are seated in the vehicle, always fasten your seat belt, even for short journeys.

Do not interchange the seat belt buckles as they will not fulfil their role fully.

The seat belts are fitted with an inertia reel permitting automatic adjustment of the length of the strap to your size. The seat belt is stowed automatically when not in use.

Before and after use, ensure that the seat belt is reeled in correctly.

The lower part of the strap must be positioned as low as possible on the pelvis. The upper part must be positioned in the hollow of the shoulder.

The inertia reels are fitted with an automatic locking device which comes into operation in the event of a collision, emergency braking or if the vehicle rolls over. You can release the device by pulling firmly on the strap and releasing it so that it reels in slightly.

In order to be effective, a seat belt must:

- be tightened as close to the body as possible,
- be pulled in front of you with a smooth movement, checking that it does not twist,
- be used to restrain only one person,
- not bear any trace of cuts or fraying,
- not be converted or modified to avoid affecting its performance.

In accordance with current safety regulations, for all repairs on your vehicle, go to a qualified workshop with the skills and equipment needed, which a CITROËN dealer is able to provide.

Have your seat belts checked regularly by a CITROËN dealer or a qualified workshop, particularly if the straps show signs of damage.

Clean the seat belt straps with soapy water or a textile cleaning product, sold by CITROËN dealers.

After folding or moving a seat or rear bench seat, ensure that the seat belt is positioned and reeled in correctly.

Recommendations for children

Use a suitable child seat if the passenger is less than 12 years old or shorter than one and a half metres.

Never use the same seat belt to secure more than one person.

Never allow a child to travel on your lap.

In the event of an impact

Depending on the nature and seriousness of the impact, the pretensioning device may be deployed before and independently of the airbags. Deployment of the pretensioners is accompanied by a slight discharge of harmless smoke and a noise, due to the activation of the pyrotechnic cartridge incorporated in the system.

In all cases, the airbag warning lamp comes on.

Following an impact, have the seat belts system checked, and if necessary replaced, by a CITROËN dealer or a qualified workshop.

Airbags

System designed to maximise the safety of the occupants (with the exception of the rear centre passenger) in the event of violent collisions. It supplements the action of the force-limiting seat belts (with the exception of the rear centre passenger).


If a collision occurs, the electronic detectors record and analyse the front and side impacts sustained in the impact detection zones:

- in the case of a serious impact, the airbags are deployed instantly and protect the occupants of the vehicle (with the exception of the rear centre passenger); immediately after the impact, the airbags deflate rapidly so that they do not hinder visibility or the exit of the occupants,
- in the case of a minor or rear impact or in certain roll-over conditions, the airbags will not be deployed; the seat belt alone is sufficient to provide optimum protection in these situations.



The airbags do not operate when the ignition is switched off.

This equipment will only deploy once. If a second impact occurs (during the same or a subsequent accident), the airbag will not be deployed again.



Impact detection zones

- A. Front impact zone.
- B. Side impact zone.




Deployment of the airbag(s) is accompanied by a slight emission of harmless smoke and a noise, due to the activation of the pyrotechnic cartridge incorporated in the system.

This smoke is not harmful, but sensitive individuals may experience slight irritation.

The noise of the detonation may result in a slight loss of hearing for a short time.

Front airbags




System which protects the head and chest of the driver and front passenger in the event of a front impact.

The driver's airbag is fitted in the centre of the steering wheel; the front passenger's airbag is fitted in the dashboard above the glove box.

Deployment

The airbags are deployed simultaneously, unless the passenger's front airbag is deactivated, in the event of a serious front impact applied to all or part of the front impact zone A, in the longitudinal centreline of the vehicle on a horizontal plane and directed from the front to the rear of the vehicle.

The front airbag inflates between the front occupant of the vehicle and the dashboard to cushion their forward movement.



Deactivation

Only the front passenger's airbag can be deactivated:

- ☞ **with the ignition off**, insert the key in the passenger airbag deactivation switch **A**,
- ☞ turn it to the **"OFF"** position,
- ☞ remove the key.




This warning lamp comes on in the centre console panel when the ignition is on and until the airbag is reactivated.



To ensure the safety of your child, the passenger's airbag must be deactivated when you install a "rear facing" child seat on the front passenger seat. Otherwise, the child would risk being seriously injured or killed if the airbag were triggered.

Reactivation

When you remove the child seat, turn switch **A** to the **"ON"** position to reactivate the airbag and so ensure the safety of your front passenger in the event of an impact. The associated warning lamp goes off.



Operating fault




If this warning lamp comes on in the instrument panel and this display appears on the instrument panel screen, contact a CITROËN dealer or a qualified workshop to have the system checked. The airbags may no longer be deployed in the event of a serious impact.



If the airbag warning lamp and the display come on continuously, do not install a "rear facing" child seat on the front passenger seat. Contact a CITROËN dealer or a qualified workshop.

Knee airbag*



System which protects the driver's knees in the event of a serious front impact. This airbag is fitted in the dashboard below the steering column.

Deployment

It is deployed at the same time as the front airbags.

* According to country.

Lateral airbags




System which protects the driver and passenger in the event of a serious side impact in order to limit the risk of injury to the chest. Each lateral airbag is fitted in the front seat back frame, on the door side.

Deployment

The lateral airbag is deployed unilaterally in the event of a serious side impact applied to all or part of the side impact zone **B**, perpendicular to the longitudinal centreline of the vehicle on a horizontal plane and directed from the outside towards the inside of the vehicle.


The lateral airbag inflates between the front occupant of the vehicle and the corresponding door trim panel.



Impact detection zones

- A. Front impact zone.
- B. Side impact zone.

Curtain airbags



System which protects the driver and passengers (with the exception of the rear centre passenger) in the event of a serious side impact in order to limit the risk of injury to the head.

Each curtain airbag is fitted in the pillars and the upper section of the passenger compartment.

Deployment

The curtain airbag is deployed at the same time as the corresponding lateral airbag in the event of a serious side impact applied to all or part of the side impact zone **B**, perpendicular to the longitudinal centreline of the vehicle on a horizontal plane and directed from the outside towards the inside of the vehicle.

The curtain airbag inflates between the front or rear occupant of the vehicle and the windows.



In the event of a minor impact or bump on the side of the vehicle or if the vehicle rolls over, the airbag may not be deployed.

In the event of a rear or front collision, the airbag is not deployed.



Operating fault

If this warning lamp comes on in the instrument panel and this display appears in the instrument panel screen, contact a CITROËN dealer or a qualified workshop to have the system checked. The airbags may no longer be deployed in the event of a serious impact.

! For the airbags to be fully effective, observe the following safety rules:

Sit in a normal upright position.
 Wear a correctly adjusted seat belt.
 Do not leave anything between the occupants and the airbags (a child, pet, object...). This could hamper the operation of the airbags or injure the occupants.
 After an accident or if the vehicle has been stolen or broken into, have the airbag systems checked.
 All work on the airbag system must be carried out by a CITROËN dealer or a qualified workshop.
 Even if all of the precautions mentioned are observed, a risk of injury or of minor burns to the head, chest or arms when an airbag is deployed cannot be ruled out. The bag inflates almost instantly (within a few milliseconds) then deflates within the same time discharging the hot gas via openings provided for this purpose.

Front airbags

Do not drive holding the steering wheel by its spokes or resting your hands on the centre part of the wheel.
 Passengers must not place their feet on the dashboard.
 If possible, do not smoke as deployment of the airbags can cause burns or the risk of injury from a cigarette or pipe.
 Never remove or pierce the steering wheel or hit it violently.

Knee airbag*

Do not sit with your knees any nearer to the steering wheel than necessary.
 Avoid attaching a heavy object to the key as it could become a dangerous projectile if the airbag were deployed.

Lateral airbags

Use only approved covers on the seats, compatible with the deployment the lateral airbags. For information on the range of seat covers suitable for your vehicle, you can contact a CITROËN dealer.
 Refer to the "Accessories" section.
 Do not fix or attach anything to the seat backs (clothing...). This could cause injury to the chest or arms if the lateral airbag is deployed.
 Do not sit with the upper part of the body any nearer to the door than necessary.

Curtain airbags

Do not fix or attach anything to the roof. This could cause injury to the head if the curtain airbag is deployed.
 If fitted on your vehicle, do not remove the grab handles installed on the roof, they play a part in securing the curtain airbags.

* According to country.

General points relating to child seats

Although one of CITROËN's main criteria when designing your vehicle, the safety of your children also depends on you.

For maximum safety, please observe the following recommendations:

- in accordance with European regulations, **all children under the age of 12 or less than one and a half metres tall must travel in approved child seats suited to their weight**, on seats fitted with a seat belt or ISOFIX mountings*,
- **statistically, the safest seats in your vehicle for carrying children are the rear seats**,
- **a child weighing less than 9 kg must travel in the "rearwards-facing" position both in the front and in the rear.**

- i** **CITROËN recommends** that children should travel in the **rear seats** of your vehicle:
- **"rearwards-facing"** up to the age of 2,
 - **"forwards-facing"** over the age of 2.

* The rules for carrying children are specific to each country. Refer to the current legislation in your country.

Child seat in the front




"Rearwards-facing"

When a "rearwards-facing" child seat is installed on the **front passenger seat**, it is essential that the passenger airbag is deactivated. Otherwise, **the child would risk being seriously injured or killed if the airbag were to inflate.**



"Forwards-facing"

When a "forwards-facing" child seat is installed on the **front passenger seat**, adjust the vehicle's seat to the intermediate longitudinal position with the seat back upright and leave the passenger airbag activated.




Intermediate longitudinal position



Passenger airbag OFF

Refer to the advice given on the label present on both sides of the passenger's sun visor.



To assure the safety of your child, you must deactivate the passenger's front airbag when you install a child seat in the rearwards facing position on the front passenger's seat. Otherwise, there is a risk that the child could be seriously injured or killed if the airbag were deployed.

Child seats recommended by CITROËN

CITROËN offers a range of recommended child seats which are secured using a **three point seat belt**:

Group 0+: from birth to 13 kg	
	L1 "RÖMER Baby-Safe Plus" Installed in the rearwards-facing position.
Group 1: from 9 to 18 kg	
	L2 "FAIR G 0/1 S ISOFIX" Installed forwards-facing, without the ISOFIX base. 6 positions of inclination of the shell.
	L3 "RÖMER Duo Plus ISOFIX" Installed forwards-facing. Can be secured with the seat belt. 3 positions of inclination of the shell.

i These seats can also be installed using the ISOFIX mountings (see following pages).
Follow the instructions for fitting the child seat given in the seat manufacturer's installation guide.

Locations for child seats secured using the seat belt

In accordance with European regulations, this table indicates the options for installing child seats secured using a seat belt and universally approved (a) in relation to the weight of the child and the seat in the vehicle.

Seat		Weight of the child and indicative age			
		Less than 13 kg (groups 0 (b) and 0+) Up to ≈ 1 year	From 9 to 18 kg (group 1) From 1 to ≈ 3 years	From 15 to 25 kg (group 2) From 3 to ≈ 6 years	From 22 to 36 kg (group 3) From 6 to ≈ 10 years
Front passenger seat (c) with passenger airbag activated		X	X	X	X
Front passenger seat (c) with passenger airbag deactivated		L1	L2, L3	X	X
Outer rear seats (row 2)		U	U	U	U
Centre rear seat (row 2)		L1	L2, L3	X	X

(a) Universal child seat: child seat which can be installed in all vehicles using the seat belt.

(b) Group 0: from birth to 10 kg. Infant car seats and "car cots" cannot be installed on the front passenger seat.

(c) Consult the legislation in force in your country before installing your child on this seat.

U: seat suitable for the installation of a child seat secured using the seat belt and universally approved, "rear facing" and/or "forward facing".


X: seat not suitable for the installation of a child seat of the weight group indicated.

L-: only the child seats indicated can be installed on the seat concerned (according to country).


"ISOFIX" mountings

Your vehicle has been approved in accordance with the **latest ISOFIX regulations**.


The seats, represented below, are fitted with regulation ISOFIX mountings:



There are three rings for each seat:



- two rings **A**, located between the vehicle seat back and cushion, indicated by a label,



- a ring **B**, behind the seat, referred to as the **TOP TETHER** for fixing the upper strap.

This ISOFIX mounting system provides fast, reliable and safe fitting of the child seat in your vehicle.

The **ISOFIX child seats** are fitted with two latches which are easily secured on the two rings **A**.

Some also have an **upper strap** which is attached to ring **B**.

To attach this strap, raise the vehicle seat's head restraint then pass the hook between its rods. Then fix the hook on ring **B** and tighten the upper strap.

! The incorrect installation of a child seat in a vehicle compromises the child's protection in the event of an accident.

i For information regarding the ISOFIX child seats which can be installed in your vehicle, refer to the table showing the locations for installing ISOFIX child seats.

ISOFIX child seat recommended by CITROËN and approved for your vehicle

CITROËN offers a range of child seats secured using the ISOFIX mountings.

Group 0+: up to 13 kg	
IL1 RÖMER Baby-Safe Plus and its Baby-Safe plus ISOFIX base	
	Installed in the rearwards-facing position using its ISOFIX base, which is attached to the rings A. The base has a height-adjustable stay.
IL2 FAIR G 0/1 S and its RWF ISOFIX base	
	Installed in the rearwards-facing position using its ISOFIX base, which is attached to the rings A. The base has a stay. 6 positions of inclination for the shell. This configuration is reserved for children weighing up to 13 kg.

i These child seats can also be used on seats which are not fitted with ISOFIX mountings. In this case, they must be attached to the vehicle seat using the three point seat belt.
Follow the instructions for fitting the child seat given in the seat manufacturer's installation guide.

Group 1: from 9 to 18 kg	
IL3 RÖMER Duo Plus ISOFIX	
	Installed forwards-facing. Attached to the rings A, as well as ring B, known as the TOP TETHER, using an upper strap. 3 positions of inclination of the shell.
IL4 FAIR G 0/1 S and its FWF ISOFIX base	
	Installed in the rearwards-facing position using its ISOFIX base, which is attached to the rings A. the base has a stay. 6 positions of inclination of the shell. This configuration is suitable for children weighing more than 13 kg.

i These child seats can also be used on seats which are not fitted with ISOFIX mountings.
In this case, they must be attached to the vehicle seat using the three point seat belt.
Follow the instructions for fitting the child seat given in the seat manufacturer's installation guide.

Locations for ISOFIX child seats

In accordance with European Regulations, this table indicates the options for installing ISOFIX child seats on seats in the vehicle fitted with ISOFIX mountings.

In the case of universal and semi-universal ISOFIX child seats, the ISOFIX size category, determined by a letter between **A** and **G**, is indicated on the child seat next to the ISOFIX logo.

	Weight of the child / indicative age									
	Less than 10 kg (group 0) Up to approx. 6 months		Less than 10 kg (group 0) Less than 13 kg (group 0+) Up to approx. 1 year			From 9 to 18 kg (group 1) From approx. 1 to 3 years				
Type of ISOFIX child seat	infant car seat		"rear facing"			"rear facing"		"forward facing"		
ISOFIX size category	F	G	C	D	E	C	D	A	B	B1
Universal and semi-universal ISOFIX child seats which can be installed on the outer rear seats	X		X		IL1	IL2	X	IUF		

IUF: seat suitable for the installation of an Isofix Universal seat, "Forward facing" secured using the "Top Tether" upper strap.

For advice on securing of the "Top Tether" upper strap, refer to the "ISOFIX mountings" section.

IL-: only the child seats indicated can be installed using the ISOFIX mountings.

X: seat not suitable for the installation of an ISOFIX seat of the size category indicated.

If in the way, the head restraint of the vehicle's ISOFIX seat must be removed and stowed safely.

Advice on child seats

! The incorrect installation of a child seat in a vehicle compromises the child's protection in the event of an accident.

Remember to fasten the seat belts or the child seat harnesses **keeping the slack** in relation to the child's body **to a minimum**, even for short journeys.

For optimum installation of the "forward facing" child seat, ensure that the back of the child seat is in contact with the back of the vehicle's seat and that the head restraint does not cause any discomfort.

If the head restraint has to be removed, ensure that it is stored or attached securely to prevent it from being thrown around the vehicle in the event of sharp braking.

Children under the age of 10 must not travel in the "forward facing" position on the front passenger seat, unless the rear seats are already occupied by other children, cannot be used or are absent.

Deactivate the passenger's airbag when a "rear facing" child seat is installed on the front seat. Otherwise, the child would risk being seriously injured or killed if the airbag were to inflate.

Installing a booster seat

The chest part of the seat belt must be positioned on the child's shoulder without touching the neck.

Ensure that the lap part of the seat belt passes correctly over the child's thighs. CITROËN recommends the use of a booster seat which has a back, fitted with a seat belt guide at shoulder level.

As a safety precaution, do not leave:

- one or more children alone and unsupervised in a vehicle,
- a child or an animal in a vehicle which is exposed to the sun, with the windows closed,
- the keys within reach of children inside the vehicle.

To prevent accidental opening of the doors, use the "Child lock".

Take care not to open the rear windows by more than one third.

To protect young children from the rays of the sun, fit side blinds on the rear windows.

Child lock

Mechanical system to prevent opening of the rear doors using their interior controls.
The control is located on the edge of each rear door.



Child lock on

☞ Move the control **A** towards position **1**.

Child lock off



☞ Move the control **A** towards position **2**.

Temporary puncture repair kit

Complete system consisting of a compressor and a sealant cartridge which permits the **temporary repair** of a tyre so that you can drive to the nearest garage.

It is designed to repair most punctures which could affect the tyre, located on the tyre tread or shoulder.

Composition of the kit



Access to the kit



This kit is installed in the boot under the floor.

For access to it:

- ☞ Open the boot.
- ☞ Lift and remove the floor.
- ☞ Take out the kit.

1. 12 V compressor with integral pressure gauge, to measure and adjust the tyre pressure.


2. Sealant cartridge for the temporary repair of a tyre.
3. Replacement valve core.
4. Valve core removal/fitting tool.
5. Injection pipe.
6. Suction pipe, to remove the sealant product if necessary.
7. Speed limit sticker.

i The speed restriction sticker must be affixed to the vehicle's steering wheel to remind you that a wheel is in temporary use.

Do not exceed a speed of 50 mph (80 km/h) when driving with a tyre repaired using this type of kit.


Repair procedure

- ☞ Stop the vehicle in as safe a location as possible and on a level and stable surface.
- ☞ Apply the parking brake.
- ☞ Place the gear lever in position **R** for vehicle with a manual gearbox, or in position **P** for vehicles fitted with a CVT gearbox.
- ☞ Switch off the ignition.
- ☞ Indicate on the speed restriction sticker provided, the wheel to be repaired, then fix it to the steering wheel as a reminder that a wheel is in temporary use.




1. Sealing

- ☞ Shake the sealant cartridge, remove the cap and screw on the injection pipe.




- ☞ Remove the valve cap for the tyre to be repaired.
- ☞ Remove the valve core using the tool provided, and store in a clean place.
- ☞ Connect the injection pipe to the valve of the tyre to be repaired.

i Avoid removing any foreign bodies which have penetrated into the tyre.



- ☞ Tap the sealant cartridge (top down) several times with your hand, so as to inject **all of the product** into the tyre.
- ☞ Remove the injection pipe.
- ☞ Refit the valve core and tighten it using the tool provided.

! Take care, this product is harmful (e.g. ethylene-glycol, colophony...) if swallowed and causes irritation to the eyes.
Keep it out of reach of children.
The use-by date of the sealant is marked on the cartridge.
After use, do not discard the empty cartridge but take it to a CITROËN dealer (France) or an authorised waste disposal site.
Don't forget to obtain a replacement cartridge; they are available from a CITROËN dealer or a qualified workshop.



2. Inflation

- ☞ Check that the compressor switch **A** is in the **"OFF"** position.
- ☞ Uncoil the compressor pipe **B**.

- ☞ Connect this pipe to the valve of the repaired wheel.
 - ☞ Connect the compressor's electric plug to the vehicle's 12 V socket (ignition switch in position "ACC" or ACC mode).
 - ☞ Start the compressor by turning the switch **A** to the **"ON"** position.
 - ☞ Using the compressor, adjust the pressure in accordance with the vehicle's tyre pressure label (located in the driver's door aperture).
- A loss of pressure indicates that the puncture has not been fully plugged; contact a CITROËN dealer or a qualified workshop for assistance.
- ☞ Remove the compressor and stow the kit.
 - ☞ Drive off straight away at reduced speed (50 mph [80 km/h] max) for around 3 miles (5 km) or 10 minutes.


i If after around 10 minutes the pressure is not attained, this indicates that the tyre is not repairable; contact a CITROËN dealer or a qualified workshop for assistance.

! As soon as possible, go to a CITROËN dealer or a qualified workshop. Tell the technician that you have used the kit. After checking, the technician will advise you whether the tyre can be repaired or must be replaced.

Changing a wheel

Procedure for replacing a faulty wheel with the spare wheel using the tools supplied with the vehicle.


Access to the tools



The tools are stored in the boot under the floor.

To gain access to them:

- 🔧 Open the boot.
- 🔧 Lift and remove the boot floor.
- 🔧 Take out the tools.



List of tools

All of these tools are specific to your vehicle.

Do not use them for anything else.


1. Wheelbrace.
Used to remove the wheel trim and the wheel fixing bolts.
2. Jack.
Used to raise the vehicle.
3. Handle.
Used to operate the jack.
4. Removable towing eye.
See "Recovering the vehicle".
5. Security wheel bolt socket (available as an accessory).
Used to adapt the wheelbrace to the special "security" wheel bolts.

i Wheel with trim

When removing the wheel, remove the trim first using the handle 3, pulling at the cutout.

When refitting the wheel, refit the trim starting by placing its cutout opposite the valve and press on its outer edge with the palm of your hand.


Access to the spare wheel



The spare wheel is installed in the boot under the floor.

Depending on version, the spare wheel may be a standard size steel or alloy wheel, or for some countries it is the "space saver" type.

For access to the spare wheel, see "Access to the tools".




Taking out the standard wheel

- ☞ Unscrew the central bolt **A**.
- ☞ Raise the spare wheel towards you from the rear.
- ☞ Take the wheel out of the boot.

Putting the standard wheel back in place

- ☞ Put the wheel back in its housing.
- ☞ Put the central bolt **A** in place in the centre of the wheel.
- ☞ Tighten fully to retain the wheel correctly.

Removing a wheel




i Parking the vehicle

Immobilise the vehicle where it does not block traffic: if possible, park the vehicle on level, stable and non-slippery ground.

Apply the parking brake, switch off the ignition and engage first gear to lock the wheels.


If necessary, place a chock under the wheel diagonally opposite the wheel to be changed.

Never go underneath a vehicle raised using a jack; use a stand.




List of operations

- ☞ If your vehicle is equipped with security wheel bolts (equipment available as an accessory) fit the security socket **5** on the wheelbrace **1** to slacken the security bolt.
- ☞ Slacken the other bolts using the wheelbrace **1** only.




- ☞ Place the jack **2** in contact with one of the two front **A** or rear **B** locations provided on the underbody, whichever is closest to the wheel to be changed.
- ☞ Extend the jack **2** until its base plate is in contact with the ground. Ensure that the centreline of the jack base plate is directly below the location **A** or **B** used.



- ☞ Raise the vehicle until there is sufficient space between the wheel and the ground to admit the spare (not punctured) wheel easily.
- ☞ Remove the bolts and store them in a clean place.
- ☞ Remove the wheel.

Fitting a wheel



i After changing a wheel


When using the "space-saver" spare wheel, do not exceed a speed of 50 mph (80 km/h).

Have the tightening of the bolts and the pressure of the spare wheel checked by a CITROËN dealer or a qualified workshop without delay.

Have the punctured wheel repaired and replace it on the vehicle as soon as possible.


i Fitting snow tyres

If you equip your vehicle with snow tyres fitted on steel wheel rims, special bolts available from your CITROËN dealer or a qualified workshop **must** be used.




List of operations

- ☞ Put the wheel in place on the hub.
- ☞ Screw in the bolts fully by hand.
- ☞ Pre-tighten the security bolt using the wheelbrace **1** fitted with the security socket **5** (if your vehicle is equipped with security wheel bolts).
- ☞ Pre-tighten the other bolts using the wheelbrace **1** only.



- ☞ Lower the vehicle fully.
- ☞ Fold the jack **2** and detach it.



- ☞ Tighten the security bolt using the wheelbrace **1** fitted with the security socket **5** (if your vehicle is equipped with security wheel bolts).
- ☞ Tighten the other bolts using the wheelbrace **1** only.
- ☞ Store the tools (refer to the paragraph "Access to the tools").

Changing a bulb


- !** The headlamps have polycarbonate lenses with a protective coating:
- ☞ **do not clean them using a dry or abrasive cloth, nor with a detergent or solvent product,**
 - ☞ use a sponge and soapy water,
 - ☞ when using a high pressure washer on persistent marks, do not keep the lance directed towards the lamps or their edges for too long, so as not to damage their protective coating and seals.
 - ☞ Do not touch the bulb directly with your fingers, use lint-free cloths.
- Changing a bulb should only be done after the headlamp has been switched off for a few minutes (risk of serious burns).
- It is imperative to use only anti-ultraviolet (UV) type bulbs in order not to damage the headlamp.
- Always replace a failed bulb with a new bulb with the same type and specification.

! Risk of electrocution


Replacement of the xenon bulbs (D1S-35W) must be carried out by a CITROËN dealer or a qualified workshop.

- i** For bulbs that have alignment lugs (H1, H7...) ensure that they are fitted correctly for the best lighting performance.

Front lamps




1. Direction indicators (WY21W-21W).
2. Main beam headlamps (H1-55W).
3. Dipped beam headlamps (H11-55W) or Xenon bulb (D1S-35W).
4. Sidelamps (W5W-5W).
5. Daytime running lamps (P13W-13W).
6. Daytime running lamps / sidelamps (light emitting diodes-LEDs).
7. Front foglamps (H11-55W).



Access to bulbs

Carry out the following operations for access the bulb protective covers:

- ☞ Remove the retaining pins **A**.
- ☞ Remove the protective cover **B**.




Changing direction indicator bulbs (1)

i Rapid flashing of the direction indicator warning lamp (right or left) indicates the failure of a bulb on that side.

- ☞ Turn the bulb holder a quarter of a turn to the left and pull it out.
- ☞ Pull out the bulb and change it.

i To reassemble, carry out these operations in reverse order. Amber coloured bulbs, such as the direction indicators, must be replaced with bulbs of identical specifications and colour.




Changing sidelamp bulbs (4)

- ☞ Turn the bulb holder a quarter turn to the left and pull it out.
- ☞ Pull out the bulb and replace it.

To reassemble, carry out these operations in reverse order.

Changing the daytime running lamps / sidelamps (light-emitting diodes - LEDs) (6)

For the replacement of this type of LED lamp, contact a CITROËN dealer or a qualified workshop.



Changing main beam headlamp bulbs (2)

- ☞ Remove the protective plastic cover.
- ☞ Turn the bulb holder to the left and pull it out.
- ☞ Remove the bulb and its base by pressing on the lug at the bottom.
- ☞ Change the bulb.


For reassembly, carry out these operations in reverse order.

Changing dipped headlamp bulbs (3)

For the replacement of these bulbs, contact a CITROËN dealer or a qualified workshop.

Changing front foglamp bulbs (7) / daytime running lamp bulbs (5)

To replace these bulbs contact a CITROËN dealer or a qualified workshop.



Changing direction indicator side repeaters

- ☞ Push the repeater towards the rear to disengage it.
- ☞ Disconnect the repeater connector.
- ☞ Change the repeater unit.

To reassemble, carry out these operations in reverse order.

Contact a CITROËN dealer or a qualified workshop to obtain replacement repeaters.

Door mirror spotlamps


You should contact a CITROËN dealer or a qualified workshop for the replacement of the light emitting diode - LED.

Rear lamps



1. Third brake lamp (LEDs).
2. Number plate lamps (W5W-5W).
3. Rear foglamp (W21W-21W).
4. Reversing lamp (W16W-16W).
5. Direction indicators (WY21W-21W).
6. Sidelamps / brake lamps (W21-5W).

i Amber coloured bulbs, such as the direction indicators, must be replaced with bulbs of identical specification and colour.




Changing sidelamp / brake lamp (6), direction indicator (5), and foglamp (3) bulbs

These bulbs are changed from outside the boot.

- ☞ Open the boot.
- ☞ Remove the two fixing screws.
- ☞ Unclip the lamp unit carefully extract it pulling it towards the rear.
- ☞ Turn the bulb holder a quarter of a turn to the left and pull it out.
- ☞ Pull the bulb out and change it.

To reassemble, carry out these operations in reverse order.

Take care to align the pins on the lamp unit with the locations on the bodywork.




Changing reversing lamp bulbs (4)

- ☞ Open the boot.
- ☞ Insert a screwdriver into the aperture of the cover and lever it open.
- ☞ Turn the bulb holder a quarter of a turn to the left.
- ☞ Pull the bulb out and change it.

To reassemble, carry out these operations in reverse order.

You can also contact a CITROËN dealer or a qualified workshop for the replacement of these bulbs.



Changing number plate lamps (2)

- ☞ Push the lens to the left and then down.
- ☞ Turn the bulb holder a quarter turn to the left and pull it out.
- ☞ Remove the bulb and change it.


To refit, carry out these operations in reverse order and press on the lens to clip it in place.

Third brake lamp (light emitting diodes - LEDs) (1)

Contact a CITROËN dealer or qualified workshop for the replacement of this type of lamp.

Changing a fuse

Access to the tools



The extraction tweezers and spare fuses are fitted in the engine compartment fusebox.

To gain access to them:

- ☞ Open the bonnet (refer to the "Checks" section).
- ☞ Unclip the and remove the cover.
- ☞ Remove the tweezers.
- ☞ Carefully close the cover to ensure correct sealing of the fusebox.

Changing a fuse



Good



Failed

Before changing a fuse, the cause of the failure must be identified and rectified.


- ☞ Check that the switch is in the **"LOCK"** position or that the vehicle mode is **"OFF"**.
- ☞ Identify the faulty fuse by checking the condition of its filament.
- ☞ Use the special tweezers to extract the fuse from its location.
- ☞ Always replace the faulty fuse with a fuse of the same rating.
- ☞ Check that the number etched on the box, the rating etched on the top and the tables below all agree.

! The replacement of a fuse not mentioned in the following tables may cause a serious fault on your vehicle. Contact a CITROËN dealer or a qualified workshop.

i Your vehicle's electrical system is designed to operate with standard or optional equipment. Before installing other electrical equipment or accessories in your vehicle, contact a CITROËN dealer or a qualified workshop.

! CITROËN will not accept responsibility for the cost incurred in repairing your vehicle or for rectifying the malfunctions resulting from the installation of accessories not supplied and not recommended by CITROËN and not installed in accordance with its instructions, in particular when the consumption of all of the additional equipment connected exceeds 10 milliamperes.

Dashboard fuses



The fusebox is located in the lower dashboard (left-hand side).

Access to the fuses

- ☞ Open the cover and remove it completely by pulling it towards you.




Fuse N°	Rating	Functions
1*	30 A	Cabin fan.
2	15 A	Brake lamps, third brake lamp.
3	10 A	Rear foglamps.
4	30 A	Windscreen wiper, screenwash.
6	20 A	Central locking, electric door mirrors.
7	15 A	Audio equipment, telematics, USB unit, Bluetooth system.
8	7.5 A	Remote control key, air conditioning control unit, instrument panel, electric windows, rain and sunshine sensors, alarm, switch panel, steering mounted controls.
9	15 A	Instrument panel and interior lighting.
10	15 A	Hazard warning lamps
11	15 A	Rear wiper.
12	7.5 A	Instrument panel, multifunction screen, parking sensors, heated seats, heated rear screen, electric blind, automatic headlamp adjustment.
13	15 A	Cigarette lighter, accessory socket.
15	20 A	Electric blind.
16	10 A	Door mirrors, audio equipment.



Fuse N°	Rating	Functions
18	7.5 A	Reversing lamps.
19	15 A	Accessory socket.
20*	30 A	Electric window controls.
21*	30 A	Heated rear screen.
22	7.5 A	Heated door mirrors.
24	25 A	Driver's and passenger's electric seat.
25	30 A	Heated seats.

! * The maxi-fuses provide additional protection for the electrical systems. All work on the maxi-fuses must be carried out by a CITROËN dealer or a qualified workshop.


Engine compartment fuses




The fusebox is placed in the engine compartment (left-hand side).

Access to the fuses

☞ Unclip the cover and remove it completely.



Fuse N°	Rating	Functions
1	15 A	Front foglamps.
4	10 A	Horn.
5	7.5 A	Alternator.
6	20 A	Headlamp wash.
7	10 A	Air conditioning.
9	20 A	Alarm.
10	15 A	Demisting, wipers.
11	-	Not used.
12	-	Not used.



! The maxi-fuses provide additional protection for the electrical systems. All work on the maxi-fuses must be carried out by a CITROËN dealer or a qualified workshop.

i Carefully close the cover after replacing a fuse so as to ensure the correct sealing of the fusebox.

Fuse N°	Rating	Functions
13	10 A	Daytime running lamps.
14	10 A	Left-hand main beam headlamp.
15	10 A	Right-hand main beam headlamp.
16	20 A	Left-hand dipped beam headlamp (xenon).
17	20 A	Right-hand dipped beam headlamp (xenon).
18	10 A	Left-hand dipped beam headlamp (halogen), manual and automatic headlamp adjustment.
19	10 A	Right-hand dipped beam headlamp (halogen).
31	30 A	Audio amplifier.



Spare fuses

The spare fuses are located under the engine compartment fusebox cover.

Fuse N°	Rating
33	10 A
34	15 A
35	20 A


i The cover does not contain spare fuses with an amperage of 7.5 A, 25 A or 30 A. If one of the fuses with these amperages develops a fault, replace it with the following fuse:

A **7.5 A fuse** must be replaced with the **10 A spare fuse**, a **25 A fuse** with a **20 A spare fuse** and a **30 A fuse** with the **audio system fuse (N° 31)**.

12 V battery

Procedure for charging your battery when it is flat or for starting the engine using another battery and jump leads.


Access to the battery




The battery is located under the bonnet.

To gain access to it:

- ☞ open the bonnet using the interior release lever, then the exterior safety catch,
- ☞ secure the bonnet stay,




- ☞ remove the retaining pins **A**,
- ☞ remove the protective cover **B**,




- ☞ remove the retaining pins **C**,
- ☞ remove the air duct **D**.

Starting using another battery

Check the electrolyte level and top up if necessary (see "Checking levels").



- ☞ Raise the protective cover on the (+) terminal.



- ☞ Connect the red cable to the positive terminal (+) of the flat battery **A**, then to the positive terminal (+) of the slave battery **B**.
- ☞ Connect one end of the green or black cable to the negative terminal (-) of the slave battery **B**.
- ☞ Connect the other end of the green or black cable to the earth point **C** on your vehicle (engine mounting).
- ☞ Operate the starter, let the engine run.
- ☞ Wait until the engine returns to idle and disconnect the cables.

Charging the battery using a battery charger

- ☞ Disconnect the battery from the vehicle, if necessary.
- ☞ Follow the instructions for use provided by the manufacturer of the charger.
- ☞ Reconnect starting with the negative terminal (-).
- ☞ Check that the terminals and connectors are clean. If they are covered with sulphate (whitish or greenish deposit), remove them and clean them.



The batteries contain harmful substances such as sulphuric acid and lead. They must be disposed of in accordance with regulations and must not, in any circumstances, be discarded with household waste.
Take used remote control batteries and vehicle batteries to a special collection point.



It is advisable to disconnect the battery if the vehicle is to be left unused for more than one month.



Do not reverse the polarity and use only a 12 V charger.
Do not disconnect the terminals while the engine is running.
Do not charge the batteries without disconnecting the terminals first.
Do not push the vehicle to start the engine if it is fitted with a CVT gearbox.

Before disconnecting the battery

Wait 2 minutes after switching off the ignition before disconnecting the battery.
Close the windows and the doors before disconnecting the battery.

Following reconnection of the battery

Following reconnection of the battery, switch on the ignition and wait 1 minute before starting to permit initialisation of the electronic systems. However, if problems remain following this operation, contact a CITROËN dealer or a qualified workshop.

Automatic power cut-off to accessories

After the engine has stopped, **when the ignition switch is in the "ACC" position (or the vehicle in "ACC" mode)** you can still use functions such as the audio equipment, windscreen wipers, dipped beam headlamps, courtesy lamps, etc. for about thirty minutes.

Cutting off

Once the thirty minutes have expired, the power supply to the accessories will be automatically cut off.

Restoring power

The power supply will be restored the next time the ignition is switched on.

i The period before cut-off can be extended up to about sixty minutes or deactivated, via the colour screen "Equipment" menu.

Changing a wiper blade

Removing a front or rear wiper blade

- ☞ Raise the corresponding wiper arm.
- ☞ Remove the wiper blade, sliding it towards the outside.

Fitting a front or rear wiper blade

- ☞ At the front, check the size of the wiper blade as the shorter blade is fitted on the right-hand side of the vehicle.
- ☞ Put the corresponding new wiper blade in place and fix it.
- ☞ Fold down the wiper arm carefully.

Recovering the vehicle

! General recommendations

Observe the legislation in force in your country.

Ensure that the weight of the towing vehicle is higher than that of the towed vehicle.


The person at the wheel of the towed vehicle must have a valid driving licence.

When towing a vehicle with all four wheels on the ground, always use an approved towing bar; rope and straps are prohibited.

When towing a vehicle with the engine off, there is no longer any power assistance for braking or steering. In the following cases, you must always call on a professional recovery service:

- vehicle broken down on a motorway or fast road,
- 4 wheel drive vehicle,
- when it is not possible to put the gearbox into neutral, unlock the steering, or release the parking brake,
- towing with only two wheels on the ground,
- where there is no approved towing bar available...

Recovery of your vehicle



2 wheel drive (2WD) versions: towing with the wheels on the ground

- ☞ Fit the towing bar to the towing eye on the chassis, located under the front bumper.

! Towing with the wheels on the ground is only possible on 2 wheel drive (2WD) versions.

- ☞ Put the gear lever into neutral (position **N** for the CVT gearbox).
- ☞ Unlock the steering by turning the ignition switch to the "**ON**" position (or to "**ON**" mode for vehicle fitted with the "Keyless Entry and Starting" system).
- ☞ Release the parking brake.
- ☞ Switch on the hazard warning lamps on both vehicles.
- ☞ Move off gently and travel slowly for a short distance only.


4 wheel drive (4WD) versions: recovery on a flatbed



Vehicles fitted with the 4 wheel drive system must always be recovered on a flatbed.

! Never have the vehicle towed with the four wheels on the ground, this could damage the transmission. The vehicle must not be towed with the front or rear wheels on the ground even if it is in front "2WD" (2 wheel drive) mode.

Towing another vehicle



Access to the tooling


The towing eye and the tools are stored under the boot floor.

To gain access to them:


- ☞ open the boot,
- ☞ lift and remove the boot floor,
- ☞ take the towing eye and the tools required.

List of tools

1. Jack handle.
2. Towing eye.
3. Wheelbrace.



- ☞ On the rear bumper, remove the cover by pulling at the bottom using the jack handle 1.



- ☞ Screw in the towing eye 2 fully using the wheelbrace 3.
- ☞ Install the towing bar.
- ☞ Switch on the hazard warning lamps on both vehicles.
- ☞ Move off gently and travel slowly for a short distance only.

Towing a trailer, a caravan...



Your vehicle is primarily designed for transporting people and luggage, but it may also be used for towing a trailer.

i We recommend the use of genuine CITROËN towbars and their harnesses that have been tested and approved from the design stage of your vehicle and that the fitting of the towbar is entrusted to a CITROËN dealer or a qualified workshop.
If the towbar is not fitted by a CITROËN dealer, it is imperative that it is fitted following the manufacturer's instructions.

Driving with a trailer subjects the towing vehicle to more significant stress and its driver must be particularly careful.

Driving advice

Distribution of loads

- ☞ Distribute the load in the trailer so that the heaviest items are as close as possible to the axle and the nose weight approaches the maximum permitted without exceeding it.

Air density decreases with altitude, thus reducing engine performance. Above

1 000 metres, the maximum towing load must be reduced by 10 % of the GTW and so on for every 1 000 metres of altitude.

Refer to the "Technical Data" section for details of the weights and towing loads which apply to your vehicle.

Side wind

- ☞ Take into account the increased sensitivity to side wind.

Cooling

Towing a trailer on a slope increases the temperature of the coolant.

As the fan is electrically controlled, its cooling capacity is not dependent on the engine speed.

- ☞ To lower the engine speed, reduce your speed.

The maximum towing load on a long slope depends on the gradient and the outside temperature.

In all cases, pay attention to the coolant temperature.



- ☞ If this message is displayed, **stop your vehicle as soon as it is safe to do so.**

If the message flashes slowly, wait for the engine to cool before topping up the level, if necessary.

If the message flashes rapidly, contact a CITROËN dealer or a qualified workshop without delay.

Braking

Towing a trailer increases the braking distance.

Tyres

- ☞ Check the tyre pressures of the towing vehicle and of the trailer, observing the recommended pressures.


Lighting

- ☞ Check the lighting and signalling on the trailer.

Fitting roof bars


For reasons of safety and to avoid damaging the roof, it is essential to use transverse bars that are approved for your vehicle.

Vehicles fitted with longitudinal bars



The transverse roof bars are fitted to the longitudinal bars at the 8 fixing points masked by covers. Using a small screwdriver, remove the 8 covers on the inner faces of the longitudinal bars.

Vehicles not fitted with longitudinal bars




The transverse bars are fitted directly to the roof of the vehicle, at the 4 anchorage points masked by covers.

Slide the covers towards the front of the vehicle to remove them.

Retain the protective covers for refitting after removal of the roof bars.

i Use accessories recommended by CITROËN and follow the accessory manufacturer's fitting instructions. Maximum authorised weight on the roof bars, for a loading height not exceeding 40 cm (except bicycle carriers): 80 kg. If the height exceeds 40 cm, adapt the speed of the vehicle to the condition of the road, to avoid damaging the roof bars and the fixings on the roof. Please refer to national legislation to comply with the regulations regarding the transportation of objects which are longer than the vehicle.



! The body sill finishers should not be used as a step when fitting roof bars.

Accessories

A wide range of accessories and genuine parts is available from the CITROËN dealer network. These accessories and parts have been tested and approved for reliability and safety. They are all adapted to your vehicle and benefit from CITROËN's recommendation and warranty.

"Comfort":

front and rear parking sensors, smoker's kit, coat hanger on head restraint, insulated module, aluminium footrest, reading lamp, air deflectors, sun blinds...

"Transport solutions":

towbar with quickly detachable ball, rear carrying platform (easy base), roof bars, boot liner, boot spacers, bicycle carrier for roof bars, ski carrier, canoe carrier, rigid roof boxes, flexible roof boxes, boot net...



If a towbar and its harness is fitted outside the CITROËN dealer network, this must be done in line with the manufacturer's instructions.

Conversion kits

You can obtain an "Enterprise" kit to convert a trade vehicle to a private car and vice-versa.

"Style":

16 inch alloy wheels, 18 inch alloy wheels, chromed door handle shells, chromed mirror shells, front spoiler, brushed aluminium interior trim kit, gloss black interior trim kit, parking brake lever trim, aluminium gear knob, leather steering wheel...

"Security and safety":

anti-intrusion alarm, warning triangle, high visibility vest, breathalyser, first aid kit, snow chains, anti-slip covers, wheel security bolts, child seats, fire extinguisher, foglamp kit, dog guard, stolen vehicle tracking system, accessories for pets (seat belts, seat and boot protectors, cage)...

"Protection":

mat*, boot carpet, side protective mouldings, door sill protectors, boot sill protector, vehicle cover, front and rear bumper protective mouldings...

- * To prevent any risk of jamming of the pedals:
 - ensure that the mat is positioned and secured correctly,
 - never fit one mat on top of another.

"Multimedia":

semi-integral satellite navigation systems, portable satellite navigation systems, audio systems, speakers, rear shelf with speakers, hands-free kit, DVD player, mapping update DVD, speed camera detector, Wi-Fi on board, 230V socket, head-up display, iPhone charger, rear multimedia carrier...

Installation of radio communication transmitters

Before installing any after-market radio communication transmitter, you can contact a CITROËN dealer for the specification of transmitters which can be fitted (frequency, maximum power, aerial position, specific installation requirements), in line with the Vehicle Electromagnetic Compatibility Directive (2004/104/EC).

 Depending on the legislation in force in the country, it may be compulsory to have a high visibility safety vest, warning triangle and spare bulbs and fuses available in the vehicle.

 The fitting of electrical equipment or accessories which are not recommended by CITROËN may result in a failure of your vehicle's electronic system and excessive electrical consumption.
Please note this precaution. You are advised to contact a CITROËN representative to be shown the range of recommended equipment and accessories.

TOTAL & CITROËN

Partners in performance and protecting the environment

Innovation in the search for performance

For over 40 year, the TOTAL Research and Development departments have developed for CITROËN, lubricants to match the latest technical innovations on CITROËN vehicles, both for competition and for everyday motoring.

For you, this is an assurance that you will obtain of the best performance for your engine.

Optimum protection for your engine

By having your CITROËN vehicle serviced with TOTAL lubricants, you are contributing towards improving the life and performances of your engine, while also protecting the environment.




CITROËN prefers TOTAL




Bonnet


Opening



- ☞ Open the left-hand front door.
- ☞ Pull the interior bonnet release lever **A**, located at the bottom of the door aperture.



- ☞ Push the exterior safety catch **B** to the left and raise the bonnet.



- ☞ Unclip the stay **C** from its housing on the back of the bonnet.
- ☞ Fix the stay in the notch to hold the bonnet open.

! The cooling fan may start after switching off the engine: take care with articles and clothing that might become caught by the fan blades.

i The location of the interior bonnet release lever prevents opening of the bonnet while the front left door is closed.

! Do not open the bonnet in high winds. When the engine is hot, handle the exterior safety catch and the bonnet stay with care (risk of burns).

Closing

- ☞ Take the stay out of the support notch.
- ☞ Clip the stay in its housing on the back of the bonnet.
- ☞ Lower the bonnet and release it at the end of its travel.
- ☞ Pull on the bonnet to check that it is secured correctly.




This message appears in the instrument panel screen if the bonnet is not fully closed.


Petrol engines

Access for checking the levels of the various fluids and the replacement of certain components.

1. Screenwash and headlamp wash fluid reservoir.
2. Coolant header tank.
3. Brake fluid reservoir.
4. Battery.
5. Fusebox.
6. Air filter.
7. Engine oil dipstick.
8. Engine oil filler cap.



1.6 litre 115




2.0 litre 150


Diesel engines

The various caps and covers allow access for checking the levels of the various fluids, for replacing certain components and for priming the fuel system.

1. Screenwash and headlamp wash fluid reservoir.
2. Coolant reservoir.
3. Brake fluid reservoir.
4. Battery.
5. Fusebox.
6. Air filter.
7. Engine oil dipstick.
8. Engine oil filler cap.
9. Priming pump*.



1.6 HDi 110



1.8 HDi 150

* According to engine.

Fuel tank

Capacity of the tank: approximately 60 litres.

Low fuel level



When the low fuel level is reached, this indication appears in the instrument panel screen. When it first comes on, you have approximately 10 litres of fuel remaining.

The symbol **flashes slowly** (approximately once per second).



When the symbol begins to **flash rapidly** (approximately twice per second), there is not much fuel remaining in your tank (approximately 5 litres).

You must fill the tank to avoid running out of fuel.

Filling

A label, affixed on the inside of the flap, reminds you of the type of fuel to be used according to your engine.

More than 5 litres of fuel must be added in order to be registered by the fuel gauge.

Location of the cap



This symbol indicates that the fuel tank cap is located on the left-hand side of the vehicle.

Opening the cap may cause an inrush of air. This vacuum, which is completely normal, is caused by the sealing of the fuel system.


To fill the tank safely:

- ☞ **the engine must be switched off,**
- ☞ pull the control **A** located at the bottom left of the driver's seat to release the fuel filler flap,
- ☞ open the fuel filler flap **B**,
- ☞ turn the filler cap **C** to the left,
- ☞ remove the filler cap **C**,
- ☞ fill the tank, but **do not continue after the 3rd cut-off of the nozzle**; this could cause malfunctions.

When you have filled the tank:

- ☞ refit the filler cap, inserting the upper part first,
- ☞ screw in the filler cap to the right,
- ☞ close the flap.

Ensure that the fuel filler flap is closed correctly.



1. Opening the filler flap.
2. Removing the filler cap.
3. Hooking the filler cap.

Quality of the fuel used for petrol engines

The petrol engines are perfectly compatible with E10 or E24 type petrol biofuels (containing 10 % or 24 % ethanol), conforming to European standards EN 228 and EN 15376.

E85 type fuels (containing up to 85 % ethanol) are reserved exclusively for vehicles marketed for the use of this type of fuel (BioFlex vehicles). The quality of the ethanol must comply with European standard EN 15293.

For Brazil only, special vehicles are marketed to run on fuels containing up to 100 % ethanol (E100 type).

1.6 litre petrol engines, even though they have been designed to operate on 95 RON petrol, can accept 90 RON petrol without engine adjustments, but with a slight deterioration in performance.

2.0 litre petrol engines can accept 90 RON or higher petrol.

Quality of the fuel used for Diesel engines

The Diesel engines are perfectly compatible with biofuels which conform to current and future European standards (Diesel fuel which complies with standard EN 590 mixed with a biofuel which complies with standard EN 14214) available at the pumps (containing up to 7 % Fatty Acid Methyl Ester).

The B30 biofuel can be used in certain Diesel engines; however, this use is subject to strict application of the special servicing conditions. Contact a CITROËN dealer or a qualified workshop.

The use of any other type of (bio)fuel (vegetable or animal oils, pure or diluted, domestic fuel...) is strictly prohibited (risk of damage to the engine and fuel system).



SP98

SP95
E10



DIESEL

Running out of fuel (Diesel)



On vehicles fitted with the 1.6 litre HDi 110 engine, the fuel system must be manually primed if you run out of fuel; refer to the corresponding Diesel engine compartment view.

1.6 litre HDi engine

- ☞ Fill the fuel tank with at least five litres of diesel.
- ☞ Open the bonnet.
- ☞ If necessary, unclip the styling cover for access to the priming pump.
- ☞ Squeeze and release the priming pump repeatedly until resistance is felt (there may be resistance at the first press).
- ☞ Operate the starter until the engine starts (if the engine does not start at the first attempt, wait around 15 seconds before trying again).
- ☞ If the engine does not start after a few attempts, operate the priming pump again then start the engine.
- ☞ Clip the styling cover back in place.
- ☞ Close the bonnet.

Checking levels

If a level drops significantly, have the corresponding system checked by a CITROËN dealer or a qualified workshop.

Check all of these levels regularly, in line with the servicing booklet and the requirements of the warranty. Top them up if necessary, unless otherwise indicated.



Take care when working under the bonnet, as certain areas of the engine may be extremely hot (risk of burns).

Oil level



The check is carried out with the dipstick.

This check will only be correct if the vehicle is on level ground and the engine has been off for more than 30 minutes. It is normal to top up the oil level between two services (or oil changes). CITROËN recommends that you check the level, and top up if necessary, every 3 000 miles (5 000 km). After topping up the oil, the check when switching on the ignition with the oil level indicator in the instrument panel is not valid during the 30 minutes after topping up.

Engine oil change

Refer to the servicing booklet for details of the interval for this operation.

In order to maintain the reliability of the engine and emission control system, the use of additives in the engine oil is prohibited.

Oil specification

The oil must be the correct grade for your engine and conform to the manufacturer's recommendations.

Dipstick

There are two marks on the dipstick:



A = maximum

If you fill past this mark, contact a CITROËN dealer or a qualified workshop.

B = minimum

Never allow the level to fall below this mark.

Brake fluid level



The brake fluid level should be close to the "MAX" mark. If it is not, check the brake pad wear.

Changing the fluid

Refer to the servicing booklet for details of the interval for this operation.

Fluid specification

The brake fluid must conform to the manufacturer's recommendations and meet the DOT3 or DOT4 standard.

Coolant level



The coolant level should be close to the "MAX" mark but should never exceed it.

When the engine is warm, the temperature of the coolant is regulated by the fan.

The cooling fan may start after switching off the engine: take care with articles and clothing that might become caught by the fan blades.

In addition, as the cooling system is pressurised, wait at least one hour after switching off the engine before carrying out any work. To avoid any risk of scalding, unscrew the cap by two turns to allow the pressure to drop. When the pressure has dropped, remove the cap and top up the level.

Changing the coolant

The coolant does not have to be changed.

Fluid specification

The coolant must conform to the manufacturer's recommendations.

Screenwash and headlamp wash fluid



In the case of vehicles fitted with headlamp washers, the low fluid level is indicated by an audible signal and a message in the instrument panel screen.

Top up the reservoir when you next stop the vehicle.

Fluid specification

For optimum cleaning and to avoid freezing, this fluid must not be topped up with or replaced with plain water.

Additive level (1.6 HDi 110 Diesel versions with particle emissions filter)



The additive reservoir low level is indicated by the display of this message.

Topping up

The reservoir must be topped up without delay by a CITROËN dealer or a qualified workshop.

Used products



Avoid prolonged contact of used oil or fluids with the skin. Most of these fluids are harmful to health or indeed very corrosive.



Do not discard used oil or fluids into sewers or onto the ground. Take used oil to a CITROËN dealer or a qualified workshop (France) or to an authorised waste disposal site.

Checks

Unless otherwise indicated, check these components in accordance with the servicing booklet and according to your engine. Otherwise, have them checked by a CITROËN dealer or a qualified workshop.


12 V battery



Electrolyte level

For access to the battery, refer to the "12V battery" section.

The electrolyte level must be between the "LOWER LEVEL" and "UPPER LEVEL" marks.



If necessary, top up using distilled water, removing the battery cap from each cell. Check the electrolyte level at least once a month.

When carrying out work on the battery, refer to "12V battery" section for details of the precautions to be taken before disconnecting the battery and following its reconnection.

Air filter and passenger compartment filter



Refer to the servicing booklet for details of the replacement intervals for these components.

Depending on the environment (e.g. dusty atmosphere) and the use of the vehicle (e.g. city driving), **replace them twice as often if necessary.**

A clogged passenger compartment filter may have an adverse effect on the performance of the air conditioning system and generate undesirable odours.

Oil filter



Replace the oil filter each time the engine oil is changed.

Refer to the servicing booklet for details of the replacement interval for this component.

Particle emissions filter (Diesel)



The start of saturation of the particle filter is indicated by the temporary illumination of this warning lamp accompanied by a message in the instrument panel screen.

i As soon as the traffic conditions permit, regenerate the filter by driving at a speed of at least 25 mph (40 km/h) for about 20 minutes (with the 1.6 litre HDi engine the minimum speed is 36 mph (60 km/h)).
If the warning lamp stays on, this indicates a low additive level.

On a new vehicle, the first particle filter regeneration operations may be accompanied by a "burning" smell, which is perfectly normal.
Following prolonged operation of the vehicle at very low speed or at idle, you may, in exceptional circumstances, notice the emission of water vapour at the exhaust on acceleration. This does not affect the behaviour of the vehicle or the environment.

Manual gearbox



Refer to the servicing booklet for maintenance of the gearbox.

"CVT" gearbox



Refer to the servicing booklet for maintenance of the "CVT" gearbox.

Brake pads



Brake wear depends on the style of driving, particularly in the case of vehicles used in town, over short distances. It may be necessary to

have the condition of the brakes checked, even between vehicle services.

Unless there is a leak in the circuit, a drop in the brake fluid level indicates that the brake pads are worn.

Brake disc wear



For information on checking brake disc wear, contact a CITROËN dealer or a qualified workshop.

Parking brake



If excessive travel or a loss of effectiveness of this system is noticed, the parking brake must be checked, even between two services.

Checking this system must be done by a CITROËN dealer or a qualified workshop.



Only use products recommended by CITROËN or products of equivalent quality and specification.

In order to optimise the operation of units as important as the braking system, CITROËN selects and offers very specific products.

To avoid damaging the electrical units, the use of a high pressure washer in the engine compartment is strictly **prohibited**.

Engines and gearboxes

PETROL ENGINES	1.6 litre 115	2.0 litre 150			
Model codes: BU...	NKZ7 NKZ7/S NKZ0 NKZ0/S	AFYR AFZ7	AFYV AFZM	AFYT AFZH	AFYW AFZP
Transmission mode	2WD	2WD	4WD	2WD	4WD
Cubic capacity (cc)	1 590	1 998			
Bore x stroke (mm)	75 x 90	86 x 86			
Max power: EU standard (kW)	86	113			
Max power engine speed (rpm)	6 000	6 000			
Max torque: EU standard (Nm)	154	199			
Max torque engine speed (rpm)	4 000	4 200			
Fuel	Unleaded	Unleaded			
Catalytic converter	Yes	Yes			
GEARBOXES	Manual (5-speed)	Manual (5-speed)		CVT (6-speed)	
OIL CAPACITY (in litres)					
Engine (with filter replacement)	4.2	4.3			

.../S: model fitted with the Stop & Start (AS&G) function.

Weights and towed loads (kg)

PETROL ENGINES	1.6 litre 115		2.0 litre 150			
Gearboxes	Manual (5-speed)		Manual (5-speed)		CVT (6-speed)	
Model codes: BU...	NKZ7 NKZ7/S	NKZ0 NKZ0/S	AFYR AFZ7	AFYV AFZM	AFYT AFZH	AFYW AFZP
Transmission mode	2WD		2WD	4WD	2WD	4WD
- Unladen weight	1 320	1 305	1 365	1 430	1 395	1 460
- Kerb weight	1 395	1 380	1 440	1 505	1 470	1 535
- Gross vehicle weight (GVW)	1 870	1 870	1 970	1 970	1 970	1 970
- Gross vehicle weight (GVW) when towing	1 925	1 925	2 035	2 035	2 035	2 035
- Gross train weight (GTW) on a 12% gradient	3 025	3 025	3 335	3 335	3 335	3 335
- Braked trailer (within GTW limit) on a 10% or 12% gradient	1 100	1 100	1 300	1 300	1 300	1 300
- Unbraked trailer	685	685	720	750	720	750
- Recommended nose weight	55	55	65	65	65	65

Caution, towing with a lightly loaded towing vehicle can have an adverse affect on its roadholding.

The GTW and towed load values indicated are valid up to a maximum altitude of 1 000 metres; the towed load mentioned must be reduced by 10 % for each additional 1 000 metres of altitude.

The speed of a towing vehicle must not exceed 60 mph (100 km/h) (comply with the legislation in force in your country).

High ambient temperatures may result in a reduction in the performance of the vehicle to protect the engine; if the ambient temperature is above 37 °C, limit the towed load.

Engines and gearboxes

DIESEL ENGINES	1.6 HDi 110		1.8 HDi 150	
Model codes: BU...	9HD8/S	9HDB/S	6HZ8/S	6HZB 6HZB/S
Transmission mode	2WD	4WD	2WD	4WD
Cubic capacity (cc)	1 560		1 798	
Bore x stroke (mm)	77 x 88.3		83 x 83.1	
Max power: EU standard (kW)	84		110	
Max power engine speed (rpm)	3 600		4 000	
Max torque: EU standard (Nm)	270		300	
Max torque engine speed (rpm)	1 750		2 000 to 3 000	
Fuel	Diesel		Diesel	
Catalytic converter	Yes		Yes	
Particle emission filter (PEF)	Yes		Yes	
GEARBOXES	Manual (6-speed)		Manual (6-speed)	
OIL CAPACITY (in litres)				
Engine (with filter replacement)	3.75		5.3	

.../S: model fitted with the Stop & Start (AS&G) function.

Weights and towed loads (kg)

DIESEL ENGINES	1.6 HDi 110		1.8 HDi 150	
Gearboxes	Manual (6-speed)		Manual (6-speed)	
Model codes: BU...	9HD8/S	9HDB/S	6HZ8/S	6HZB 6HZB/S
Transmission mode	2WD	4WD	2WD	4WD
- Unladen weight	1 315	1 425	1 430	1 495
- Kerb weight	1 390	1 500	1 505	1 570
- Gross vehicle weight (GVW)	2 060	2 060	2 060	
- Gross vehicle weight (GVW) when towing	2 130	2 130	2 130	
- Gross train weight (GTW) on a 12% gradient	3 260	3 260	3 530	
- Braked trailer (within GTW limit) on a 10% or 12% gradient	1 130	1 130	1 400	
- Braked trailer* (with transfer of load within the GTW limit)	1 300	1 300		
- Unbraked trailer	695	750	750	
- Recommended nose weight	70	70	70	

* The weight of the braked trailer can be increased within the GTW limit provided that the weight of the towing vehicle is reduced by the same amount.
Caution, towing with a lightly loaded vehicle may adversely affect roadholding.


The GTW and towed load values indicated are valid up to a maximum altitude of 1 000 metres; the towed load mentioned must be reduced by 10 % for each additional 1 000 metres of altitude.

The speed of a towing vehicle must not exceed 60 mph (100 km/h) (comply with the legislation in force in your country).

High ambient temperatures may result in a reduction in the performance of the vehicle to protect the engine; if the ambient temperature is above 37 °C, limit the towed load.

Dimensions (in mm)


These dimensions have been measured on a vehicle that is not loaded.



* Mirrors folded.

Identification markings

Various visible markings for the identification and tracing of your vehicle.



A. Manufacturer's plate.

It is riveted to the right hand middle pillar and carries the following information:

- manufacturer,
- EU type approval number,
- vehicle identification number (VIN),
- gross vehicle weight,
- gross train weight,
- maximum front axle weight,
- maximum rear axle weight.

B. Tyre label.

This label is affixed to the the driver's side middle pillar and carries the following information:

- tyre sizes,
- tyre pressures.

C. Vehicle Identification Number (VIN) under the bonnet.


This number is engraved on the bodywork near the damper support.

i The tyre pressures must be checked when the tyres are cold, at least once a month.



If the tyre pressures are too low, this increases fuel consumption.

i Original equipment tyres can be chained using 9 mm chains. Contact a CITROËN dealer or a qualified workshop.



AUDIO-TELEMATIC system



The system is protected in such a way that it will only operate in your vehicle.



For safety reasons, the driver must carry out operations which require prolonged attention while the vehicle is stationary.

When the engine is switched off and to prevent discharging of the battery, the system switches off following the activation of the energy economy mode.

CONTENTS

01 First steps - Control panel	p. 224
02 General operation	p. 225
03 Navigation - Guidance	p. 226
04 Audio / Video	p. 236
05 Settings	p. 258
06 Information	p. 261
07 USB player	p. 264
08 BLUETOOTH® streaming - telephone	p. 269
09 BLUETOOTH® telephone	p. 271

01 FIRST STEPS

AUDIO: select Audio-video (FM, CD, music server, ...) or Navigation (map) display.

VOL: adjust audio-video volume.

POWER: audio system on/off (only).



Move a finger over the screen to operate the system.

Use the buttons offered on the screen.

! For safety reasons, the driver must only carry out operations which require prolonged attention with the vehicle stationary.



SCALE: change the scale of the map.

ENT: confirms the choice of the item selected in the screen.
For certain operations, confirmation is given by pressing the touch screen.

Scroll the map displayed or selection of an item.



OPEN: opens the screen and gives access to CD/DVD.
A second press closes the screen.

Mute on/off.

Next or previous selection for:

- a radio station,
- an audio track (CD),
- a chapter (DVD).

Set the audio volume.

Change the audio-video source (FM, CD, music server, ...).



02 GENERAL OPERATION

DESCRIPTION OF THE CONTROLS - MENUS



MODE: **Audio-video** menu for:

- radio,
- audio, MP3 or WMA CD,
- music server,
- DVD.



SET: **Settings** menu for:

- switching off the screen,
- selecting the sound setting,
- selecting the picture quality,
- selecting the language, the time zone or the units,
- selecting the size of the DVD picture,
- selecting the guidance voice, the screen colour schemes or display of the audio-video icon,
- setting certain equipment available in your vehicle.



MENU: **Navigation-guidance** menu for selecting:

- a destination,
- a point of interest (POI),
- an advanced search by POI,
- one of the 20 previous destinations,
- an address stored in the address book,
- the return home,
- certain navigation settings,
- a route demonstration.



INFO: **Information** menu for the consultation or adjustment of certain settings for your vehicle.



NAVI: display of the current location on the **map**.

03 NAVIGATION - GUIDANCE

GPS SYSTEM

WHAT IS THE NAVIGATION SYSTEM AND GPS?

The satellite navigation system guides the driver to the destination that he has set in accordance with a chosen route.

Initially, it searches for the destination required by the user, then it calculates the route and finally it provides the visual and vocal guidance instructions.



GPS (Global Positioning System) consists of several satellites arranged around the earth. They continuously transmit digital signals which travel at the speed of light, on 2 different frequencies.

At any given time, the system receives its position in relation to the satellites detected and the time of transmission of the signal.

This enables the telematic unit to calculate its position and therefore that of the vehicle.

A repositioning process using the map database stored on the hard disk allows the vehicle to be positioned on the road network, so improving the accuracy of the vehicle location function.

WHAT PRECAUTIONS SHOULD BE OBSERVED IN ORDER TO MAKE BEST USE OF THE SYSTEM?

Do not place anything on or near the GPS aerial.

Do not use any digital communication equipment (personal computers, etc.) near the GPS aerial.

Do not affix any reflective films or films containing carbon to the windows.

The system's measurements may be inaccurate if the vehicle is:

- in a tunnel or underground car park,
- underneath a two-level motorway,
- in an area with several very high buildings,
- surrounded by closely planted trees.

Depending on the vehicle's situation and the reception of the GPS information, the displayed information may disappear from the screen temporarily.

WHAT IS A POINT OF INTEREST (POI)?



A point of interest (POI) is represented by an icon on the map, it represents an airport, a station, a town hall, ...




Up to 40 different icons may be displayed (refer to the section "Points of interest icon").

They are classified in 5 groups and identified by one colour for each group:


- Shops, finance and businesses (Green),
- Vehicles and travel (Dark blue),
- Restaurants (Orange),
- Public places and emergency services (Brown),
- Entertainment and attractions (Blue).

03 NAVIGATION - GUIDANCE

INFORMATION DISPLAYED ON THE MAP DURING NAVIGATION



Single map display.



Two-map display.

- A. Manoeuvre icon: indicates whether the driver should turn left or right at the next junction indicated by the guidance and the distance to this junction.
- B. Guidance route: indicates the route to the destination.
- C. Vehicle marker: indicates the position of the vehicle while driving.
- D. TMC icon: displays traffic information such as traffic jams, road works, etc. When the icon is touched, detailed TMC information can be viewed.
- E. Orientation mark: indicates the orientation of the map displayed.
- F. Map scale: indicates the scale of the map displayed.
- G. Name of the street: indicates the name of the current street.
- H. Direction frame: displays the number of the next road or the name of the next street which the driver should turn into.
- I. Destination/intermediate destination icon: indicates the direction of the destination or intermediate destination.

- J. Destination/intermediate destination information: indicates the distance and the time remaining until the destination or intermediate destination is reached.






Route

- K. Press for access to the **Route Menu** in order to:
 - K1 - change the route in favour of another making a detour through a specified region,
 - K2 - change the position of the destination, add an intermediate destination and change the route calculation conditions,
 - K3 - display a route by various methods,
 - K4 - delete a route created,
 - K5 - search for points of interest (POI) around the current location.

03 NAVIGATION - GUIDANCE

SEARCHING FOR A DESTINATION USING AN ADDRESS OR POINTS OF INTEREST (POI)




- A - Select a location using the address or street name of the destination. Select:
 - A1 - the country,
 - A2 - the city,
 - A3 - the street,
 - A4 - the house number,
 - A5 - the name of a junction,
 - A6 - to select the search using either a number or a junction.
- B - Select a location using the name of a point of interest (POI). Select:
 - B1 - the country,
 - B2 - the city,
 - B3 - the name of a stored POI,
 - B4 - a POI category (airport, bowling alley, bus station, car park, service station, hotel, cinema, ...),
 - B5 - a detailed POI list.
- C - Select a location using an advanced search based on a POI:
 - C1 - around the current location,
 - C2 - on the current route,
 - C3 - in the vicinity of the destination,
 - C4 - on a chosen street,
 - C5 - along a motorway or in the vicinity of the exit,
 - C6 - by scrolling the map,
 - C7 - taking the point of departure of the current route,
 - C8 - specifying the latitude/longitude coordinates.



You have a maximum of 100 points of interest (POI) within a radius of approximately 60 miles (100 km).

03 NAVIGATION - GUIDANCE

SEARCHING USING PREVIOUS DESTINATIONS, A STORED ADDRESS OR A RETURN HOME



D - Select a location using one of the 20 previous destinations.

E - Select a location using an address stored in the address book. Sort by:

E1 - Icon,



E2 - Name,

E3 - Date.

F - Select a return home directly.
Press YES to store your home address (the first time).

03 NAVIGATION - GUIDANCE


NAVIGATION SETTINGS AND INFORMATION (1/2)



- G** - Select the settings of functions linked with the navigation to:
- G1** - set the screen display parameters such as:
- display 1 or 2 maps,
 - display or do not display the POIs on the map, display selected icons,
 - change the colours of the map,
 - display or do not display the name of the current street.
 - display or do not display the address of the current street.
- G2** - set route conditions, such as:
- avoiding traffic problems,
 - avoiding selected areas,
 - avoiding roads at a certain time.
- G3** - set the route guidance mode and the displaying of the results of the route search.
- G4** - save, change or delete a location in the address book,
- G5** - display and select the traffic information such as traffic jams or road works by selecting dynamic guidance.

03 NAVIGATION - GUIDANCE

NAVIGATION SETTINGS AND INFORMATION (2/2)



- H - Select basic information relating to the navigation as well as a pre-set route demonstration to:
- H1 - choose to divert your route to avoid certain areas,
- H2 - select a location using an advanced search based on a POI along a motorway or in the vicinity of the motorway exit,
- H3 - start/stop the demonstration,
- H4 - recall a stored map screen.

03 NAVIGATION - GUIDANCE

SELECTING POINTS OF INTEREST (POI) ICONS DISPLAYED ON THE MAP



You can select up to 40 types of point of interest icon which are displayed on your map screen.

Press the MENU button then [Navigation Settings].



Press [Screen] then [Select] on the POI line. Press [] which is displayed.



Press each POI required.

At each contact with a POI, the display of [α] changes (α = the POI will be displayed on the screen).

General

	Town centre
	Locality

Shops, finance and businesses (Green)

	Major companies
	Shopping centre

Vehicles and travel (Dark blue)

	CITROËN
	Airport
	Bus stop
	Vehicle hire
	Suburban / main line station
	Ferry terminal
	Hotel
	Park and ride
	Car park (press +)
	Service station
	Rest area
	Toll booth
	Tourist information
	Railway station

Restaurant (Orange)

	Night life / night club
	Restaurant

Public places and emergency services (Brown)



	Town Hall
	Community centre
	Convention / exhibition centre
	Hospital
	University / college

Entertainment and attractions (Blue)

	Theme park
	Bowling alley
	Casino
	Cinema
	Golf course
	Historical monument
	Skating rink
	Marina
	Museum
	Flying club
	Leisure area
	Ski station
	Sports centre
	Theatre / opera
	Tourist attraction
	Vineyard / wine and spirit store

03 NAVIGATION - GUIDANCE

Entering an address and starting guidance (1/2)

Press	Explanation	Result
	Press the MENU button.	
	Press [Address/Junction].	
	Press [Country] and enter the name of the country using the touch keypad. When a character of the name of the country is entered, if 5 countries or fewer are recognised, you can select a country from a list which is displayed or press [List].	
 Last 5	You can select one of the 5 most recently selected countries by pressing [Last 5] on the "Country" line.	
	Press [City] then [Keyword] and enter the name of the city using the touch keypad. When a character of the name of the city is entered, if 5 cities or fewer are recognised, you can select a city from a list which is displayed or press [List].	
 Postal Code	You can select a city using the post code. Press [Post Code] and enter the number.	
 Last 5	You can select one of the 5 most recently selected cities by pressing [Last 5] on the "City" line.	

03 NAVIGATION - GUIDANCE

Entering an address and starting guidance (2/2)

Press	Explanation	Result
 	Press [Street] and enter the name of a street using the touch keypad. When a character of the name of the street is entered, if 5 streets or fewer are recognised, you can select a street from a list which is displayed or press [List].	
 	Press [House #] and enter the number of the house using the touch keypad.	
  	You can enter the name of a junction instead of the number of the street. Press [Junction] and select the name from a list which is displayed.	

This is the result once all of the information has been entered:



/



	If you agree with the information press [Set], otherwise press one of the buttons to correct.	
	Press [Start] to start the navigation.	

03 NAVIGATION - GUIDANCE

TRAFFIC INFORMATION

During navigation, the system gives you traffic information received in real time.

The system can then suggest a detour route, if dynamic guidance has been activated by pressing MENU, [Navigation settings] then [TMC].



Press	Explanation	Result
	Press [Route].	
	Press [Display new route]. The system offers a detour route (dynamic guidance).	
	Press [Back] and enter to return to the previous screen. The system asks you to confirm or not the new route.	
	Press [Yes] to confirm your choice. The system displays the name of the new route. Press [No] to not register the route.	

04 AUDIO / VIDEO

RADIO, RDS, AF, REG, TP, PTY

WHAT IS RDS?

RDS

The Radio Data System (RDS) function on the FM waveband permits:

- automatic retuning to alternative frequencies carrying the same station while travelling through different regions (if the transmitters of this station cover the area through which you are travelling),
- temporary tuning to traffic information announcements,
- display of the name of the station, etc...

Most FM stations use RDS.

These stations transmit non-audible data in addition to their programmes.

The data transmitted in this way allows you access to various functions, mainly displaying of the name of the station, temporary tuning to traffic information announcements or automatic retuning to alternative frequencies.

RDS allows you to continue listening to the same station automatically by means of alternative frequencies. However, alternative frequencies may not be provided throughout the country. Radio stations do not cover the whole country, which explains the loss of reception of the station during a journey.

RDS ALTERNATIVE FREQUENCIES

AF

Your radio automatically checks and selects the best frequency for the radio station to which it is tuned (if the station broadcasts on several transmitters or frequencies).

The frequency of a radio station covers approximately 30 miles (50 km). The change from one frequency to another explains the loss of reception during a journey.

If the station to which you are listening does not have several frequencies in the region in which you are currently located, you can deactivate automatic alternative frequencies.

REGIONAL MODE

REG

Some stations are organised in a network.

In different regions, they broadcast different or shared programmes depending on the time of day.

You can follow:

- a regional station only,
- the entire network, with the possibility that you will be listening to a different programme.

TRAFFIC INFORMATION FUNCTION

TP

The Traffic Programme (TP) function permits automatic and temporary switching to an FM station broadcasting traffic information. The radio station or the source that you are listening to at this point is paused.

Once the traffic information has ended, the system switches back to the radio station or the source that you were listening to initially.

PROGRAMME TYPES


PTY

Some stations offer the option of listening to a themed type of programme as a priority, selected from the list available below:

NEWS, AFFAIRS, INFOS, SPORT, EDUCATE, DRAMA, CULTURE, SCIENCE, VARIED, POP M, ROCK M, EASY M, LIGHT M, CLASSICS, OTHER M, WEATHER, FINANCE, CHILDREN, SOCIAL, RELIGION, PHONE IN, TRAVEL, LEISURE, JAZZ, COUNTRY, NATION M, OLDIES, FOLK M, DOCUMENT.

04 AUDIO / VIDEO

INFORMATION DISPLAYED IN RADIO MODE




The diagram illustrates the information displayed in Radio Mode. It shows a physical control panel with a 'MODE' button and an 'AUDIO' button. An arrow points from the 'MODE' button to a digital display screen. The screen shows 'A/V Mode' at the top, with 'FM' selected. Below 'FM' are buttons for 'MW', 'LW', 'CD', 'Music Server', 'DVD', 'USB / iPod', 'Bluetooth Audio', and 'AUX'. The main display area shows 'FM 1' and 'BFM 96.4'. Below this are buttons for 'INFO', 'FIP', 'RFM', and 'MFM'. At the bottom are buttons for 'PTY', 'Seek', and 'Tune'. Callouts A through N point to specific features on the display.

- A. A preset number is displayed when a preset station has been selected.
- B. The name of the station is displayed during the reception of RDS information. If the station name has not been transmitted, the frequency is displayed.
- C. Stereo is displayed when a stereo transmission is received.
- D. AF is displayed when the AF function is on.
- E. PTY (programme type) is displayed if the RDS information received is displayed. TRAFINF is displayed, during an interruption, for traffic information. ALARM is displayed, during an interruption, for urgent information.
- F. Display of 6 preset stations.
- G. To receive the preset station. Press and hold to store a station.
- H. To change the frequency step by step. Press and hold for continuous frequency changing.
- I. To search for currently broadcasting stations which can be received in the current location, until a station is found.
- J. To display the programme type setting screen, e.g.: sport, rock, classical, news, ... Press PTY again to exit.
- K. Press this button to display the secondary menu.
- L. REG is displayed during the reception of regional frequencies information.
- M. RDS is displayed during the reception of RDS information.
- N. TP is displayed when the traffic information is in standby mode.

04 AUDIO / VIDEO

RADIO, SELECTING AN FM STATION AND PRESETTING

Press	Explanation	Result
	Press the MODE button.	
	Press FM. By default the screen shows the FM1 stations.	
	Press [◀ Tune] to decrease the frequency or [Tune ▶] to increase the frequency. The frequency is changed in steps of 0.1 MHz. Continue to press to tune to a station automatically.	
 	You can select [◀ Seek] or [Seek ▶] to start a continuous search until the stations which can be received in the current location are detected.	
 	You can also start a search by type of programme by pressing [PTY].	
 107.9  BFM 96.4	Once the frequency has been selected, a long press on the station (e.g. 3) will preset it. The name of the station is displayed if it is available.	
 	You can start automatic presetting on FM3 for 6 stations, which can be received in the current location, by pressing [^] then [Auto-Store].	

04 AUDIO / VIDEO

RADIO, RDS SETTINGS

Press	Explanation	Result
	Press the MODE button.	
	Press FM. By default the screen shows the stations on FM1.	
	Press [^].	
	Press [RDS Settings].	
	Press [On] or [Off] to activate or deactivate the functions: - AF: automatic search for the best frequency, - REG: switch to the regional frequencies, - TP: automatic selection of stations broadcasting traffic information.	

04 AUDIO / VIDEO

CD PLAYER

Your Audio-Telematic system allows you to listen to audio CDs (CDDA, CD-Text, CD-R/RW) or MP3 and WMA CDs.

PLAYING AN AUDIO CD



When the audio CD is inserted in the player, playing of the tracks is automatic and they can be recorded onto the hard disk.

Simultaneous access to the music recognition service "Gracenote CDDb" on the hard disk permits display of the title information.

RECORDING ONTO THE MUSIC SERVER



The tracks of audio CDs (not MP3/WMA) can be recorded onto the hard disk at approximately 4x speed (e.g.: 60 minutes converted to 15 minutes) and stored on the music server.

The sounds recorded may be altered by the noise present and the quality of the sound may differ from the original.

The tracks recorded on the music server cannot be reproduced on another medium (CD-R/RW, HDD, etc ...).

Previously recorded tracks cannot be recorded again from the same CD.

Switching off the engine or removing the CD during recording will result in the tracks being faulty.

The operation of the navigation system may slow down during recording.

The recording speed may be slower than 4x due to the processing load on the equipment or the condition of the audio CD.

If jumps or other errors occur, return to the beginning of the track and start the recording again.

Even if there is no gap between the tracks on the CD, a brief silence between tracks is stored on the hard disk.

WHAT IS THE GRACENOTE CDDb?



The title information for the track currently being played can be obtained from the "Gracenote CDDb" database stored on the hard disk.

The Gracenote company uses this standard to identify the music and the associated information such as:

- the title of the album,
- the name of the artist,
- the title of the tracks,
- the genre, ...

For further details, consult the site: www.gracenote.com.


The Gracenote CDDb database incorporated in this equipment cannot guarantee the content of the data 100%. You can update this database using a DVD sold separately.

COPYRIGHT

Your Audio equipment may allow you to listen to music which is usually protected by copyright in accordance with current national and international standards. Please consult these standards and comply with them.

04 AUDIO / VIDEO


INFORMATION DISPLAYED IN CD MODE AND COPYING A CD



The CD button is only active if the player contains a CD.



Press Open to return the screen to the vertical position.



- A. The name of the album is displayed for the track currently being played.
- B. The name of the artist is displayed for the album currently being played.
- C. The playing time of the track currently being played is displayed.
- D. The playing mode currently selected is displayed.
- E. Position of the cursor and total number of tracks on the album.
- F. Displays the item currently selected.
- G. To scroll up or down through the tracks. Press and hold for fast backwards or forwards playing of a track.

- H. Displays the number and the name of the track. While driving, they are not available and cannot be selected.
- I. To display the secondary menu.
- J. Move the cursor onto the track currently being played.
- K. The number and the name of the track currently being played are displayed.



- L. During copying, this symbol is displayed in red and it goes off when all copying operations are complete. The number indicates the percentage of the total number of tracks on the CD already copied onto the hard disk. 00% when only one track has been copied.
- M. The tracks which have not been copied are displayed in blue. No symbol is displayed for tracks for which copying has finished.


04 AUDIO / VIDEO

PLAYING A CD

Press	Explanation	Result
 	Press the MODE button then CD, if the player already contains a CD.	
 	Otherwise, insert a CD in the player, play begins automatically.	
	Press [⏮ Track] to select the previous track or return to the beginning of the track currently being played. Press and hold for fast backwards play.	
	Press [Track ⏭] to select the next track. Press and hold for fast forwards play.	
	Press [^] to access the secondary menu.	
	Press [Repeat] to play the track in a loop (repetition). Press [^] then [Repeat] to stop.	
	Press [Scan] to play the beginning of each track for approximately 9 seconds (scan). Press [^] then [Scan] to stop or press the current track (during the 9 seconds) and play begins.	
	Press [Random] to play the tracks in random order. Press [^] then [Random] to stop.	

04 AUDIO / VIDEO

Copying a CD onto the music server (1/3)

Press	Explanation	Result
	Automatic copying of all of the tracks All of the tracks are copied automatically when a CD is inserted. This automatic copy is programmed by default on leaving the factory.	
	If you have changed the copy mode (manual or first track), while a CD is being played press [^] for access to the secondary menu.	
	Press [REC. Setting].	
 	Press [Auto REC.] and confirm by pressing [Back].	
	Next, eject the CD currently being played then insert a CD and copying of all of the tracks begins.	
 	If you wish to copy the CD which is currently being played, press [^] for access to the secondary menu and press [REC. Start].	



If another track (already copied) is selected during copying, the copying continues and the new track selected is played.

If another track (not copied) is selected, the copying which is in progress stops and the copying of the new track selected begins. This track is played during copying.

04 AUDIO / VIDEO

Copying a CD onto the music server (2/3)

Press	Explanation	Result
 	Manual copying of individual tracks You can copy the tracks manually, one by one. After inserting a CD and while it is being played, press [^] for access to the secondary menu.	
	Press [REC. Setting].	
 	Press [Manual REC.] and confirm by pressing [Back].	
 	Once the manual programming has been carried out, select the track to be copied then press [^].	
	Press [REC. Start], the copying of the track selected begins.	



If another track is selected during copying, the copying stops and the new track selected is played.

04 AUDIO / VIDEO


Copying a CD onto the music server (3/3)

Press	Explanation	Result
 	Automatic copying of the first track You can programme the automatic copying of the first track when a CD is inserted. After inserting a CD and while it is being played, press [^] for access to the secondary menu.	
  	Press [REC. Setting] then [Single REC.] and confirm by pressing [Back].	
 	Next, eject the CD which is currently being played then insert a CD and the copying of the first track begins.	
	If you wish to copy the first track of the CD which is currently being played, press [^] for access to the secondary menu and press [REC. Start].	
 If another track is selected during copying, the copying stops and the track selected is played.		
	Stopping automatic or manual copying During the copying of a CD or of a track on a CD, press [^] for access to the secondary menu.	
	Press [REC. Stop], the copying stops.	

04 AUDIO / VIDEO

GENERAL NOTES ON THE MUSIC SERVER

WHAT IS THE MUSIC SERVER?



Your Audio-Telematic system allows you to copy audio CDs onto a music server, up to 2,500 songs on a 10 Gb hard disk.

The tracks on audio CDs (not MP3 or WMA) can be recorded onto the hard disk at approximately 4x speed and stored in the music server.

Refer to the "Recording a CD" section.

The music server then allows you to manage groups and lists of tracks.

04 AUDIO / VIDEO

"ORIGINAL" GROUP, NUMBER 01:

01 Original CDs

This is the location of the original playlist created automatically (not manual) when a track of an audio CD is recorded.

It is not possible to change its name or delete it.
You can record up to 9999 playlists in this group.

"MY BEST" GROUP, NUMBER 02:

02 My Best

This is the location of the playlists, etc ... created automatically from the information read in the music server.

It is not possible to change its name or delete it.
The groups "My Favorites" and "My Frequency" are stored here.

"NEW GROUP" GROUP FOR THE USER, NUMBERS 03 TO 99:

03 (New Group)

This is the location of the user's playlists.
You can record up to 9999 playlists in this group.
The group can be created, renamed or deleted.

"ORIGINAL PLAYLIST" LISTS:

01 Original Playlist

02 Original Playlist

These are original playlists created automatically (not manual) when an audio CD is copied.
The lists and the artists can be renamed or deleted. The genres can also be set.

04 AUDIO / VIDEO

"MY FAVORITES" LIST:

01 My Favorites

This is the location for storing your favourite tracks.

They can be deleted from the list and the order in which they are played can be changed.

"MY MOST PLAYED" LIST:

02 Most Played

This is the location of the playlists used most frequently from the **original** list.

It is not possible to add tracks or change their order.

"USER PLAYLIST" LIST:

01 User Playlist

This is the location of a playlist of tracks selected by the user from the **original** list.


If you delete a track from the original list, it will be deleted from the user list.

The list and the artist can be renamed or deleted.

It is possible to add tracks or change their order.

04 AUDIO / VIDEO

INFORMATION DISPLAYED IN MUSIC SERVER MODE




- G. To display the list of groups, the playlist and the list of tracks.
- H. To scroll up or down through the tracks. Press and hold for fast backwards or forwards playing of a track.
- I. To scroll up or down through the playlists.
- J. Group lists: number and name of the group. Playlists: number and name of the playlist. Track lists: number and name of the track.
- K. To display the secondary menu.
- L. Displays the item currently selected.
- M. Move the cursor onto the track currently being played.

04 AUDIO / VIDEO

PLAYING A TRACK OR A PLAYLIST IN THE MUSIC SERVER

Press



Explanation

Press the MODE button then Music Server.

Result



The playlists are played in a loop.

The server can play a track while recording another track from a CD. You must wait until recording is complete before playing the recorded track.

Selecting a track

Press [**⏮ Track**] to select the previous track or return to the beginning of the track currently being played.

Press and hold for fast backwards.

04 AUDIO / VIDEO


CREATING A GROUP AND A PLAYLIST IN THE MUSIC SERVER

Press	Explanation	Result
Creating a group		
	Press [^] to access the secondary menu.	
 	Press [New Group], enter the name of the group and press [SET]. The group is stored on the server.	
Creating a playlist		
 	Press [^] to access the secondary menu then press [Function Settings].	
	Press [New Playlist].	
	Select the group to which the playlist is to be attached. The group must be created first.	
	Enter the name of the playlist and confirm by pressing [SET]. Then select the search method attached to this new list (either from the list or by conditions). The list is stored on the server.	

04 AUDIO / VIDEO

GENERAL NOTES ON MP3/WMA CDs

PLAYING AN MP3/WMA CD



When the MP3/WMA CD is inserted in the player, playing of the tracks is automatic.
The tracks cannot be recorded onto the music server.
You can play CDs with up to 8 levels, 255 folders and 400 files maximum.

WHAT IS THE MP3/WMA FILE FORMAT?



MP3 is the abbreviation of MPEG-1 Audio Layer 3 and MPG is the abbreviation of Motion Pictures Experts Group, a digital video data compression standard used on media such as video CDs.

The MP3 compression reduces the number of bytes in a song by eliminating the long sound waves in the range of frequencies which are imperceptible to the human ear, so producing high quality audio files with a low volume of data.

This compression divides the size of the content of a conventional audio CD by approximately 10, which means that the content of 10 audio CDs can be recorded onto a single CD-R or CD-RW.

WMA is the abbreviation of Windows Media Audio, another audio data compression standard offered by Microsoft.

It can be used to create and save audio files at a compression rate higher than that of the MP3 format.

Windows Media and Microsoft Corporation are trademarks registered in the United States and/or other countries.

ACCEPTANCE OF THE FILES

Some blank CDs may not be played by your equipment (quality, recording speed...).

When you burn a CD-R or CD-RW, select the ISO 9660 level 1.2 or Joliet burning standard.

To obtain the best acoustic quality possible, select the lowest burning speed.

The MPEG1 and MPEG2 standards are accepted.

Transmission speeds between 32 and 320 kbits/s and scans between 16 kHz and 48 kHz are accepted.


To display the title information (the name of the artist, the title of the album, etc...), the information contained in the ID3 Tags or the WMA Tags must be included in the MP3/WMA files burned onto the disc.

COPYRIGHT

Your audio system may allow you to listen to music which is usually protected by copyright in accordance with current national and international standards. Please consult these standards and comply with them.

04 AUDIO / VIDEO


INFORMATION DISPLAYED IN MP3/WMA CD MODE



The CD button is only active if the player contains a CD.



Press Open to return the screen to the vertical position.



- A. The number and the name of the track currently being played are displayed.
- B. The name of the album/folder is displayed for the track currently being played.
- C. The name of the artist is displayed for the track currently being played.
- D. The playing time of the current track is displayed.
- E. The playing mode currently selected is displayed.
- F. Position of the cursor and total number of folders or tracks on the current level.
- G. To display the list of folders of a higher level.
- H. Displays the item currently selected.
- I. To scroll up or down through the tracks. Press and hold for fast backwards or forwards playing of a track.
- J. To scroll up or down through the folders.
- K. Displays the folder number and the folder name. Plus the lists and numbers of tracks and the name of the file (without extension).
- L. To display the secondary menu.
- M. Move the cursor onto the track currently being played.
- N. Displays the type of medium, MP3 or WMA.

04 AUDIO / VIDEO

PLAYING AN MP3/WMA CD (1/2)

Press



Explanation

Press the MODE button then CD, if the player already contains a CD.

Result



Otherwise, insert a CD in the player, play begins automatically.



Moving around the folders

Folder 01

You can move by one level at a time.

Press on the name of a folder and at each press the list of folders of the level below is displayed.



These displays indicate the current level:

CD: level 0, folder below: level, folder below that, level 2, etc ...
Up to 8 levels.



Press on the folder above to move up and/or select a level.



Selecting a folder

◀ Folder ▶


Press [◀ Folder] to select the previous folder.

Press [Folder ▶] to select the next folder.




04 AUDIO / VIDEO

PLAYING AN MP3/WMA CD (2/2)

Press	Explanation	Result
	Selecting a track Press [⏮ Track] to select the previous track or return to the beginning of the track currently being played. Press and hold for fast backwards play.	
	Press [Track ⏭] to select the next track. Press and hold for fast forwards play.	
	Changing the playing mode Press [^] to access the secondary menu.	
	Press [Repeat] to play the track selected in a loop (repetition). Press [Repeat] again to play all of the tracks in the selected folder in a loop. Press again to stop.	
	Press [Scan] to play the beginning of each track in each folder for approximately 10 seconds (scanning). Press [Scan] again the play the beginning of each track in the selected folder in a loop. Press again to stop or press on the current track (during the 10 seconds) and play begins.	
	Press [Random] to play all of the tracks in the selected folder in random order. Press [Random] again to play all of the tracks on the CD in random order. Press again to stop.	

04 AUDIO / VIDEO


INFORMATION DISPLAYED IN DVD MODE



The DVD button is only active if the player contains a DVD.



Press Open to return the screen to the vertical position.



- A. This icon is displayed when the operation requested cannot be carried out.
- B. The number of the chapter currently being played is displayed.
- C. The number of the title currently being played is displayed.
- D. Symbols display the current status of the player.
- E. The playing time is displayed.
- F. To resume normal play when play is paused or during slow-motion play.
- G. To stop play temporarily.
- H. To stop play. Press the screen to access the menu.
- I. For slow-motion play.

- J. To play the previously selected zone on the disc.
- K. To display the DVD title menu.
- L. To scroll up or down through the chapters. Press and hold for fast backwards or forwards play.
- M. To scroll up or down through the titles.
- N. To enter a title or chapter number.
- O. To change the angle.
- P. To change the language of the subtitles.
- Q. To change the language.
- R. To select a chapter or title or specify a number.

! For safety reasons, the video is not displayed while driving, however the audio can be played.
To display the picture and watch a DVD, park the vehicle in a safe place.


04 AUDIO / VIDEO

PLAYING A DVD

Press	Explanation	Result
	Press the MODE button then DVD, if the player already contains a DVD.	
 	Otherwise, insert a DVD in the player, the picture is displayed automatically. Press the screen to access the menus.	
	While driving, only the soundtrack is played and no picture is displayed.	
Selecting a chapter		
	Press [⏮ Chapter] to select the previous chapter or return to the beginning of the chapter currently being played. Press and hold for fast backwards play.	
	Press [Chapter ⏭] to select the next chapter. Press and hold for fast forwards play.	
Selecting a title		
	Press [◀ Title] to select the previous title.	
	Press [Title ▶] to select the next title.	

05 SETTINGS


DISPLAY SCREEN, SOUND, PICTURE



- A** - Choose to switch off the screen.
To switch it back on, touch the screen or press any button.
- B** - Choose the settings of the sound in the vehicle, if an audio source is selected (FM, CD, ...), for:
 - B1** - the sound distribution or the volume such as the front-rear balance, the bass, the medium, the treble, the volume adjustment in relation to the vehicle speed,
 - B2** - the type of music (with surround option) such as classic, jazz, pop, rock, hip hop, country, normal, ...
 - B3** - the sound field (with surround option) such as stage, live, hall, normal, ...
- C** - Choose the quality of the picture for:
 - C1** - the colour (when playing DVDs),
 - C2** - the intensity of the colours (when playing DVDs),
 - C3** - the brightness,
 - C4** - the contrast,
 - C5** - the level of black.

05 SETTINGS


TIME AND DATE, LANGUAGE, UNIT, PICTURE SIZE



- D - Choose the base settings of the system for:
 - D1 - setting of the time by the RDS signal, time zone, summer time,
 - D2 - the language (English, Français, Deutsch, Nederlands, Portuguese, Español, Svenska, Italiano, Dansk),
 - D3 - the units for calculation of the distances (km or miles and °C or °F),
 - D4 - other settings such as:
 - the voice guidance volume,
 - the type of voice guidance voice (female or male),
 - the volume of the operation bleeps (1 to 3 and 0=no bleep),
 - the type of keypad (alphabet or PC),
 - the range of menu colours (red or blue),
 - the display or not of the audio play icons in the map screen,
 - the reinitialisation of the vehicle sensor,
 - the interruption or not of the display when the air conditioning is used.
- E - Choose the size of the DVD picture for:
 - E1 - normal 4/3,
 - E2 - extends the picture evenly to the right and to the left in wide screen mode,
 - E3 - extends the right and left parts only leaving the centre as it stands in wide screen mode,
 - E4 - enlarges the picture in 4/3 format. The top and the bottom are outside the frame.

05 SETTINGS

EQUIPMENT, CONTRAST, TRAFFIC INFORMATION (TP)



F - Choose to adjust or set the parameters of certain equipment offered in your vehicle (e.g.: unfolding/folding of the mirrors, closing the windows on locking, timing and sensitivity of the automatic lighting, direction indicators motorway function, ...):

F1 - to scroll up the list,

F2 - to scroll down the list,

F3 - to reinitialise all of the settings (manufacturer's settings).


Press each setting to select or change the parameters.

G - Choose to adjust the contrast of the display in relation to the ambient light level (day, night or automatic).


H - Choose to activate or deactivate the traffic information (TP).

06 INFORMATION

SYSTEM VERSION, SATELLITE



- A - View the system information:
 - A1 - the software version,
 - A2 - the map data version,
 - A3 - the system information database version.
- To update the versions, insert the DVD containing the new data and follow the instructions on the screen.




- B - View the GPS information:
- B1 - the satellite positions diagram with the direction of movement of the vehicle. Plus the position of the satellite signal receivers,
- B2 - the name of the current location,
- B3 - the longitude and latitude of the current location,
- B4 - the position measurement status (2D=3 satellites or fewer, 3D=4 satellites or more),
- B5 - the number of receiving satellites,
- B6 - to have north at the top of the map,
- B7 - to have the direction of the vehicle at the top of the map,
- B8 - to pivot the map from overhead or change the angle of the map.

06 INFORMATION

CALENDAR, TRIP




These double arrows permit access to the driving information screen, previous or next.



- C - Make a note on the calendar of special days, birthdays, ...
Use the arrows to find a date and press directly on the day required to enter the event.
- D - View the driving information:
 - D1 - the average speed,
 - D2 - the average fuel consumption,
 - D3 - the current fuel consumption,
 - D4 - for speed and fuel consumption graphs in 5 minute intervals,
 - D5 - choose an automatic reset (key at off for more than 4 hours) or manual reset (press [Reset]),
 - D6 - the distance which can still be travelled (based on the fuel remaining and the recent average consumption),
 - D7 - the distance travelled since the fuel tank was last filled (press [Refuel] to reinitialise),
 - D8 - the driving time (duration between the key being turned on then to off).
- press [Start] to measure intermediate times with:
 - D9 - the duration,
 - D10 - the distance,
 - D11 - the speed,
 - D12 - the fuel consumption.

06 INFORMATION

ENVIRONMENT, AIR CONDITIONING, TELEPHONE



- E - View the environment information:
- E1 - the altitude,
- E2 - the atmospheric pressure,
- E3 - the ambient temperature. The ice symbol flashes if there is a risk of ice.

- F - View the air conditioning settings:
- F1 - the fan speed indicator,
- F2 - the air selection indicator,
- F3 - the windscreen demisting indicator,
- F4 - the air conditioning indicator,
- F5 - the rear screen demisting indicator,
- F6 - the AUTO mode indicator.

- G - Make and receive telephone calls:
- G1 - enter the telephone number,
- G2 - delete a character,
- G3 - make the call.

! Refer to the hands-free telephone section to connect your Bluetooth® mobile telephone.

07 USB PLAYER


USING THE USB PORT



The USB port is used to connect a portable device (MP3 player, Apple® player, ...). The files are sent from the player to your audio system and heard through the vehicle's speakers.


1

With the vehicle stationary, ignition switch in the **LOCK** position, connect a suitable cable to the portable player.



2

Then connect the cable to the vehicle's USB port.



Models supported:

- iPod touch®: FW version 1.1.1 or later.
- iPod classic®: FW version 1.0 or later.
- iPod 5th generation®: FW version 1.2.2 or later.
- iPod nano 5th generation®: FW version 1.2 or later.
- iPod nano 2nd generation®: FW version 1.1.2 or later.
- Compatible USB mass storage device: 256 Mb capacity or greater.

File formats: MP3, WMA, AAC, WAV.

Maximum number of levels (including root): 8.

Number of folders: 700.

Number of files: 65 535.



Do not connect the portable device directly to the USB port, use a cable.



To disconnect the cable, the ignition switch must be in the **LOCK** position.

Navigation in the file base is done via the portable device / iPod®.

Take care not to trap the cable when closing the armrest.

07 USB PLAYER

INFORMATION DISPLAYED IN USB OR AUX MODE




- A. The number and the name of the track currently being played are displayed.
- B. The name of the album/folder is displayed for the track currently being played.
- C. The name of the artist is displayed for the track currently being played.
- D. The playing time of the current track is displayed.
- E. To display the list of folders of higher levels.
- F. To display in list mode.
- G. To scroll up or down through the tracks. Press and hold for fast backwards or forwards playing of a track.
- H. To scroll up or down through the folders.


- I. To display the secondary menu.
- J. Move the cursor to the track being played.
- K. Display the format of the current file: MP3, WMA, AAC, WAV.
- L. Displays the type of medium: USB or iPod.

07 USB PLAYER

INFORMATION DISPLAYED IN IPOD (OR APPLE® PLAYER) MODE





- A. The number and the name of the track currently being played are displayed.
- B. The name of the album/folder is displayed for the track currently being played.
- C. The name of the artist is displayed for the track currently being played.
- D. The playing time of the current track is displayed.
- E. To display/sort each category:



- F. The item currently selected and being played is highlighted.
- G. To scroll up or down through the tracks. Press and hold for fast backwards or forwards playing of a track.
- H. To display the secondary menu.
- I. Move the cursor onto the track currently being played.
- J. Displays the type of medium: USB or iPod.

07 USB PLAYER

PLAYING A TRACK (1/2)

Press	Explanation	Result
 	Press the MODE button then on USB/iPod.	
	In USB or AUX mode: you can press the next folder up at any time, to go up one level/ or select a level.	
	In iPod mode: you can display / sort by category at any time.	
	Press on a track to play it.	
Selecting a previous / next track		
	Press [⏮ Track] to select the previous track or return to the beginning of the track currently being played. Press and hold for fast backwards.	
	Press [Track ⏭] to select the next track. Press and hold for fast forwards.	




07 USB PLAYER

PLAYING A TRACK (2/2)

Press	Explanation	Result
Selecting a folder (in USB or AUX mode)		
	Press [◀ Folder] to select the previous folder.	
	Press [Folder ▶] to select the next folder.	
Changing the playing mode (in USB, AUX or iPod mode)		
	Press [^] to access the secondary menu.	
	Press [Repeat] to play the track selected in a loop (repetition). Press [Repeat] again to play all of the tracks in the selected folder in a loop. Press again to stop.	
	Press [Random] to play all of the tracks in the selected folder in random order. Press [Random] again to play all of the tracks on the player in random order. Press again to stop.	
	Press [Scan] to play the beginning of each track in each folder for approximately 10 seconds (scanning). Press [Scan] again the play the beginning of each track in the selected folder in a loop. Press again to stop or press on the current track (during the 10 seconds) and play begins.	
	Press on [Database] to display the Gracenote® version (Compact Disc Database: database of music CDs).	

08 BLUETOOTH® STREAMING - TELEPHONE

MATCHING A TELEPHONE, PLAYING A TRACK


Press on	Explanation	Results
 	Press the MODE button then Bluetooth Audio.	
	Press on [Matching] to start matching.	
	Press on [New device] to detect a telephone.	
	Enter the PIN in the audio system.	
	Refer to the instructions for your telephone to authorise the matching. Enter the PIN in the telephone then after a short time it appears in the list.	
 	Select the telephone in the list, then choose [Hands free] for telephone and/or [Audio Bluetooth] for streaming (an iPhone is recognised automatically). Then confirm with [Yes].	
 Once the telephone is matched, select a track then press [▶] to play it.		

08 BLUETOOTH® STREAMING - TELEPHONE


INFORMATION DISPLAYED IN TELEPHONE MODE



Refer to the section "matching a telephone" to connect your telephone by Bluetooth®.



- A. Enter the number using the keypad.
- B. Erasing a number one at a time.
- C. Return to the previous screen.
- D. To display the list of contacts (in the Bluetooth telephone or the vehicle). Select a contact in the list.
- E. To start [Dial] or start again [Redial] a telephone call



- F. To display the secondary menu:
- F1. Is displayed if the personal identification number has not been defined. Press to enter it.
- F2. Is displayed if the personal identification number has been defined.
- F3. To display the list of matched telephones.
- F4. To display the list of voice commands.
- F5. To reset all settings.

09 BLUETOOTH® TELEPHONE



Audio system on/off.

Increase the audio volume.

Decrease the audio volume.

ANSWER A CALL

Press this button to accept an incoming call.

In the event of a 2nd incoming call, press to put the 1st call on hold and speak to the second caller.

In this case, press briefly to switch from one call to the other.

To establish a three-way conversation, press on SPEAK to change from voice recognition and say **"Incorporate the call"**.

END CALL

Press this button to reject an incoming call.

During a conversation, press this button to end the call.


SPEAK

Press this button to activate voice recognition ("**Listening**" is displayed).

During a voice recognition, press this button briefly to put this voice recognition on hold.

Make a long press on this button to deactivate voice recognition.

Press this button briefly to activate voice recognition, even during a call.



09 BLUETOOTH® TELEPHONE



CHANGING THE VOICE COMMAND LANGUAGE



What is the Bluetooth® hands-free telephone with voice recognition?

The system uses wireless communication technology known as Bluetooth® which allows you to make hands-free telephone calls in your vehicle via your Bluetooth® compatible mobile telephone.

You can make telephone calls using a microphone located in the courtesy lamp, making use of the simple steering mounted controls or by the voice recognition function with voice commands. Five languages are available: English (the default), Spanish, French, German and Italian.



By default, the voice recognition system is in English.




If you do not start the training procedure within around 3 minutes of pressing SPEAK, the process is cancelled.

If you press SPEAK within 5 seconds following the play of a voice command, this command is saved again.

1



Press this button.



2



Say **"Setup"**.

3



Say **"Language"**.

4

The system says **"Select a language: English, Spanish, French, German or Italian"**.

5



Say the language of your choice in English, example: say **"French"** for French.

6

The system then says **"French selected. Is this correct?"**

7



Say **"Yes"** to start the change of language process
Say **"No"** to return to steps 4 to 7.

8

The system repeats the language chosen and completes the change of language process.

09 BLUETOOTH® TELEPHONE



TRAINING THE USER'S VOICE



You can use the user voice training function to create a voice model for one person per language.


The characteristics of your voice and your pronunciation are saved in this model to provide the best voice recognition.

The vehicle must be stationary with the parking brake applied. Switch off your telephone during the operation to avoid any interruption.

1



Press this button.



2



Say **"Word training"**.


3

An explanation message is given.

4



When you are ready to start, press and hold this button.



5

The system says the first of 45 standard phrases.

6



Repeat each of the phrases in the table on the following page.

The system saves your voice and moves on to the next command.

Continue the process until all of the phrases have been saved.

7

After playing all the voice commands, the system says **"The word enrolment is complete"** and ends the process.

!

If you do not start the programming process within approximately 3 minutes after pressing the SPEAK button, the process is cancelled.

If you press the SPEAK button within 5 seconds of the play of a voice command, this command is saved again.

09 BLUETOOTH® TELEPHONE



VOICE TRAINING COMMANDS

1	# 790 (for # = "Hash")	16	55 66 77 88 99	31	Home, Work, Mobile, Pager
2	* 671 (for * = "Star")	17	44 33 22 11 00	32	List of names
3	212 - 4 903	18	Call 293 - 5804	33	No
4	235 - 3 494	19	Call * 350	34	Phone book: Delete
5	315- 5 657	20	Call 1 (234) 567 - 8 901	35	Phone book: New entry
6	456 - 7 930	21	Dial 639 - 1542	36	Previous
7	793 - 5 462	22	Dial # 780	37	Phone book: Clear all
8	794 - 1 826	23	Dial (987) 654 - 3210	38	Redial
9	826 - 3 145	24	1058# 3794# Send	39	Repeat the training
10	962 - 7 305	25	27643# 4321# Send	40	Configure the confirmation requests
11	(531) 742 - 9 860	26	Cancel	41	Configure the language
12	(632) 807 - 4 591	27	Continue	42	Configure the matching options
13	(800) 222 - 5 015	28	Emergency number	43	Match a telephone
14	(888) 555 - 1 212	29	Clear all	44	Transfer the call
15	0 123 456 789	30	Help	45	Yes

09 BLUETOOTH® TELEPHONE



MATCHING A BLUETOOTH® TELEPHONE FIRST CONNECTION



For reasons of safety and because the sustained attention of the driver is needed, operations of matching a Bluetooth® mobile phone with the audio system's hands-free function must be done with the **vehicle stationary**.




The system can register up to 7 Bluetooth® compatible mobile telephones.
The telephone which has the highest level of priority is connected automatically.

1



Press this button.



2



Say "**Configure**".

3



Say "**Matching options**".

4

The system says "**Do you wish to match a telephone, delete a telephone or obtain the list of matched telephones?**".

5



Say "**Match a telephone**".

6

The systems says "**Please say the 4 digits of a matching code**".

7



Say a 4-digit number which will be recorded as the matching code.

8



The system confirms the validity of the number spoken, answer "**Yes**".
Say "**No**" to return to step 7.

!

Remember this matching code as you must enter it in the telephone in one of the following steps of the matching procedure.

09 BLUETOOTH® TELEPHONE



The services available depend on the network, the SIM card and the compatibility of the Bluetooth® telephone used. Check in your telephone user manual and with your service provider for the services you have access to.

9

The system says **"Start the matching procedure on the telephone. Consult the instructions in the telephone manual"**.

10



Consult your mobile telephone's user manual and enter the matching code recorded in step 7 in the telephone.



If the code is incorrect, the system locks. To clear the code:

- check that the telephone's voice recognition is not activated,
- with the ignition on and the audio system active, press the END CALL button for 2 seconds, 3 times in succession.

11

When it detects a Bluetooth® compatible mobile telephone, the system says **"Please say the name of the telephone after the beep"**.

12



After the audible signal, allocate a name to the telephone by saying the name of your choice.

13

The system says **"Allocate an order of priority between 1 and 7. One is the highest level of priority"**.

14



Give a number between 1 and 7 to establish the level of priority of the mobile telephone.

15

The system says and confirms the **"name of the telephone"** and the **"number"** of its priority.

16



Answer **"Yes"**
Say **"No"** to return to step 13.

17

The systems says **"Matching complete"** then emits an audible signal and deactivates the voice recognition.



If the system does not detect the Bluetooth® compatible mobile telephone, the matching process stops and is accompanied by an audible signal.

If you select a level of priority which has already been allocated to another telephone, the system asks you if you wish to replace this level of priority.

09 BLUETOOTH® TELEPHONE



USING A TELEPHONE NUMBER


!

You must have first matched a Bluetooth® compatible mobile telephone with the system.

1



Press this button.



2



Say "**Dial**".

3

The system says "**Number please**".

4



Call out the telephone number.

5



The system asks you to confirm this number, answer "**Yes**".
Say "**No**" to return to the previous step.

09 BLUETOOTH® TELEPHONE



SAVING A NAME IN THE SYSTEM PHONE BOOK




The system has its own phone book, independent of that of the mobile telephone.
It can contain up to 32 names for each language.
Each name in the phone book is associated with 4 locations:
HOME, WORK, MOBILE and PAGER.

1



Press this button.



2



Say **"Phone book"**.

3

The system says **"Select one of the following items: New Entry, Change, List of names, Delete or Clear all, or say Cancel to return to the main menu"**.

4



Say **"New entry"**.

5

The system says **"Name please"**.

6



Give the name of your choice.

7

The system says **"HOME, WORK, MOBILE OR PAGER"**.

8



Give the location which corresponds to the number that you wish to record.

9

The system asks you to confirm the location.

10



Answer **"Yes"**.
Say **"No"** to return to step 7.

11

If a telephone number has already been recorded for this location, the system says **"The current number is -number-, number please"**.

12



If you do not wish to change the telephone number, repeat the original number to retain it, otherwise say the new number.

13

The system asks you to confirm the number.

14



Answer **"Yes"**
Say **"No"** to return to step 11.

09 BLUETOOTH® TELEPHONE



USING A NAME IN THE PHONE BOOK


!

You must have first matched a compatible Bluetooth® mobile telephone with the system.

1



Press this button.



2



Say "**Call**".

3

The system says "**Name please**".

4



Give the name of the person that you wish to call.

5

If several telephone numbers have been recorded for this person, the system says "**Do you wish to call <name> {home}, {work}, {mobile} or {pager}?**"

6



Give the location corresponding to the number that you wish to call.

7

The system request confirmation of the name.

8



Answer "**Yes**".
Say "**No**" to return to step 4.

9

The system says "**Call to <name> at <location>**" and makes the call.

09 BLUETOOTH® TELEPHONE




REDIAL THE LAST NUMBER CALLED

1



Press this button.



2



Say **"Redial"**.

RECEIVING A CALL




The telephone ring is sent to the speaker by the front passenger's seat.

If an audio source (CD, radio, ...) is in operation when the call is received, it is placed on MUTE and only the incoming call is heard. When the ignition switch is in the ACC or ON position, the audio system is activated automatically if an incoming call is received, even if it was originally off.

1



Press this button.



At the end of the call, the audio system returns to its previous state.

09 BLUETOOTH® TELEPHONE



VOICE COMMANDS (1/2)



Press this button to start the voice recognition.

Configure	Divert the call	Home, at home
Phone book	Add a location	Work, at work
Dial	Configure the confirmation requests	Mobile, on mobile
Call	Language	Pager, on pager
Redial	New entry	Help
Emergency number	Delete	Continue
Matching options	Change	All
Match a telephone	Call this number	Cancel
Delete a telephone	Change another entry	Mute
List of matched telephones	Try again	Deactivate mute
Select a telephone	Clear all	Yes
Previous	List of names	No



When the system is waiting for a voice command, say **"Help"** to obtain a list of commands which can be used in the current situation.

09 BLUETOOTH® TELEPHONE



VOICE COMMANDS (2/2)




Press this button to start the voice recognition.

Zero	English	Word training
One	Phone book New entry	PIN
Two	Phone book Change	Repeat training
Three	Phone book Delete	Activate
Four	Phone book Clear All	Deactivate
Five	Phone book List of names	Incorporate the call
Six	Configure the confirmation requests	<digits> Send
Seven	Configure Select a telephone	
Eight	Configure the matching options	
Nine	Delete a name	
Star (*)	Configure the language	
Hash (#)	Configure the PIN	



When the system is waiting for a voice command, say **"Help"** to obtain a list of commands which can be used in the current situation.



AUDIO-CD system



The system is protected in such a way that it will only operate in your vehicle.




For safety reasons, the driver must carry out operations which require prolonged attention while the vehicle is stationary.

When the engine is switched off and to prevent discharging of the battery, the system switches off following the activation of the energy economy mode.

CONTENTS


01 First steps - Control panel	p. 284
02 Steering mounted controls	p. 286
03 General operation	p. 287
04 Radio	p. 291
05 Music media players	p. 297
06 USB player	p. 305
07 BLUETOOTH® streaming	p. 307
08 BLUETOOTH® telephone	p. 309
Error messages	p. 320

01 FIRST STEPS




* Available according to version.

01 FIRST STEPS



02 STEERING MOUNTED CONTROLS



03 GENERAL OPERATION

SWITCHING ON / OFF

1




Press the "PWR" button.

The last source selected before switching off resumes operation.

The audio equipment functions can be used when the ignition switch is in the "ON" or "ACC" position.

To switch off, press the "PWR" button again.




QUICK ACCESS MODE

1



To access the personalised sound functions quickly, press and hold this button, then turn it to reach the personalised sound setting of your choice.

Release the button to store the setting.




ADJUSTING THE VOLUME

1



Turn the "VOL" dial respectively to the left to decrease the volume or to the right to increase it.




"HOLD" MODE

1



If you press this button for more than 2 seconds in the audio setting mode, the system switches to "Hold" mode. The audio mode selected will be retained until you press this button again for more than 2 seconds.




SETTING THE AUDIO MODES

1



Press the "SOUND" button several times; the audio modes change in the following order:

SUB PUNCH / TYPE / FIELD /
BASS / MID / TREBLE / FADER /
BALANCE / OFF.



!

The audio setting mode is deactivated when the radio is operated or a CD is played or after approximately 10 seconds without any action.

03 GENERAL OPERATION

SELECTING THE "TYPE" MUSICAL AMBIENCE

1

Turn the "SOUND" dial; the musical ambiances change in the following order:

CLASSIC / JAZZ / POP / ROCK / HIP-HOP.

Once the ambience has been selected, press the "SOUND" button to confirm.




"CLASSIC": optimises the acoustics to obtain perfect equalisation of the sound for classical music.

"JAZZ": optimises the acoustics to obtain an ambient sound with specific modulations in the bass, mid tone and treble for jazz.

"POP": optimises the acoustics to obtain clear vocals and modulation of the bass and treble for pop music.

"ROCK": optimises the acoustics to obtain a sound in harmony with the rhythm which places the emphasis on the mid tone for rock music.

"HIP-HOP": optimises the acoustics to obtain a powerful sound and accentuation of the bass for hip-hop music.



!

If the "TYPE" is changed, the sound cuts out briefly.

SELECTING "FIELD" SURROUND EFFECT

1

Turn the "SOUND" dial; the surround effects change in the following order: NORMAL / STAGE / LIVE / HALL.

Once the surround effect has been selected, press the "SOUND" button to confirm.




"NORMAL": produces a sound in which the voices are at the front and the instruments surround the listener.

"STAGE": produces a sound in which the voices are immediately facing the listener, as on a stage.

"LIVE": produces a sound similar to that of a live show, in which the sound reaches the listener from all directions.

"HALL": produces a sound similar to that of a concert hall with deflection of the sound.



!

If the "FIELD" is changed, the sound cuts out briefly.


03 GENERAL OPERATION

"BASS" SETTING

1



Turn the "SOUND" dial to set the required bass value.




"FADER" FRONT/REAR SOUND DISTRIBUTION SETTING

1



Turn the "SOUND" dial to set the balance of the volume of the front and rear speakers.




"MID" MID-RANGE SETTING

1



Turn the "SOUND" dial to set the required mid tone value.




"BALANCE" LEFT/RIGHT SOUND DISTRIBUTION SETTING

1



Turn the "SOUND" dial to set the balance of the volume of the right and left speakers.




"TREBLE" SETTING

1



Turn the "SOUND" dial to set the required treble value.



!

If the value "0" is set, an audible signal will be heard.

03 GENERAL OPERATION


"SUB PUNCH" BASE UNIT VOLUME SETTING

1



Turn the "SOUND" dial to set the volume of the bass unit.

Only vehicles fitted with the "Premium Sound" system can offer the "SUB PUNCH" setting.



!

If the "SUB PUNCH" is changed, the sound cuts out briefly.

"SCV" AUTOMATIC VOLUME ADJUSTMENT

1




Press the "SOUND" button for more than two seconds to gain access to the functions setting mode.

Then, press this same button several times; the functions setting mode changes in the following order:

AF / CT / REG / TP-S / PTY (languages) / SCV / PHONE / OFF.

Turn the "SOUND" dial respectively to the left to deactivate the function or to the right to activate it.



04 RADIO


SELECTION / PRESETTING

SELECTING RADIO SOURCE

1



Press the "PWR" button or the "AM/FM" button to switch on the radio.




AUTOMATIC STATION SEARCH

1



Press the "SEEK ◀" or "SEEK ▶" button to search the lower frequencies or the higher frequencies respectively. The search begins automatically and stops at the first station found.




SELECTING THE WAVEBAND

1



Press the "AM/FM" button several times in succession to select the waveband; it changes in the following order: FM1 / FM2 / FM3 / MW / LW / FM1...



MANUAL STATION SEARCH

1



Turn the "TUNE" dial respectively to the left to search the lower frequencies or to the right to search the higher frequencies.



04 RADIO

MANUAL STATION PRESETTING

You can preset up to six stations on each waveband. Presetting a new station replaces the previous station.


1



Press one of the six buttons "1" to "6" until an audible signal is heard.

The sound cuts out then becomes audible again when the station has been preset.

The number of the button and the associated radio frequency appear on the screen.



To recall the pre-set stored setting, press the button and release it within two seconds.

AUTOMATIC STATION PRESETTING

Stations can only be preset automatically on wavebands FM3, MW and LW.

Presetting new stations replaces the previous stations.


This presetting can be activated automatically irrespective of the waveband selected.

1



Press the "AM/FM" button for more than two seconds.

The six stations offering the best reception are preset and classified from the weakest to the strongest on the six corresponding buttons.



RECALLING PRESET STATIONS

1



Press one of the six buttons "1" to "6". The station corresponding to the waveband selected appears on the screen.



Disconnecting the battery terminals clears the preset radio stations.

04 RADIO

RDS

The "Radio Data System" (RDS) function on the FM waveband permits:

- access to the display of information, such as the name of the station, ...
- listening to the same station while travelling through different regions,
- temporary tuning to traffic information announcements.

Most FM stations use RDS. These stations transmit non-audible data in addition to their programmes.

The data transmitted in this way allows you access to various functions, mainly displaying of the name of the station, automatic retuning to alternative frequencies or temporary retuning to traffic information announcements.

RDS allows you to continue listening to the same station by means of alternative frequencies that carry the same station. However, in certain conditions, RDS alternative frequencies may not be provided throughout the country. Radio stations do not cover the whole country, which explains the loss of reception of the station during a journey.

1



The "AF", "REG" and "TP" functions can be deactivated or activated via the "TUNE" button functions setting mode.



"AF" ALTERNATIVE FREQUENCIES

Your radio automatically checks and selects the best frequency for the radio station to which it is tuned (if the station broadcasts on several transmitters or frequencies).

The frequency of a radio station covers approximately 30 miles (50 km). The change from one frequency to another explains the temporary loss of reception during a journey.

If the station to which you are listening does not have several frequencies in the region in which you are currently located, you can deactivate alternative frequencies.

REG REGIONAL MODE

Some stations are organised in a network.

In different regions, they broadcast different or shared programmes depending on the time of day.

You can follow:

- a regional station only,
- the entire network, with the possibility that you will be listening to a different programme.



On long distance journeys, when the stored station becomes weak, the radio searches first for another frequency for the same station (AF). Then, if this fails, it searches for a frequency broadcasting the regional programme (REG). If this also fails, the radio returns to the stored station.

04 RADIO

"TP" TRAFFIC INFORMATION

The "Traffic Programme" (TP) function permits automatic and temporary switching to an FM station broadcasting traffic information.


The radio station or the source that you are listening to at this point is paused.

Once the traffic information has ended, the system switches back to the radio station or the source that you were listening to initially.

1



Press the "TP" button.
"TP" appears in the screen. If the station is compatible, "RDS" also appears.



If the radio detects traffic information, "TRAF INF" appears on the display, followed by the frequency of the broadcasting station, then its name.

The volume is different from that of the previous source.

Following the broadcasting of the traffic information, the volume returns to that of the source prior to the interruption.



When "TP" appears in the screen, the radio stops only at RDS stations broadcasting traffic information.

"ALERT" EMERGENCY BROADCASTS

An emergency broadcast automatically and temporarily interrupts the FM station or the source that you are listening to.

The message "ALERT" appears in the screen and the volume is different from that of the previous source.

Following the emergency broadcast, the message disappears and the volume returns to that of the source prior to the interruption.

"PTY" THEMED TYPE OF PROGRAMME

Some stations offer the option of listening to a themed type of programme as a priority, selected from the list available below:
NEWS, AFFAIRS, INFO, SPORT, EDUCATE, DRAMA, CULTURE, SCIENCE, VARIED, POP M, ROCK M, EASY M, LIGHT M, CLASSICS, OTHER M, WEATHER, FINANCE, CHILDREN, SOCIAL, RELIGION, PHONE IN, TRAVEL, LEISURE, JAZZ, COUNTRY, NATION M, OLDIES, FOLK M, DOCUMENT.


04 RADIO

SEARCH FOR A "PTY" BROADCAST

1



Press the "PTY" button.
Turn the "TUNE" dial to select the type of programme required.
Two seconds later, the radio searches for a broadcast which corresponds to your selection; the type of PTY selected flashes in the screen.
Once the station has been found, its name appears in the screen.
You can press the "SEEK ◀" or "SEEK ▶" buttons to find another station.



If no station is found corresponding to your selected type of programme, "NONE" appears in the screen for five seconds and the radio returns to the previous station.


PRESETTING A "PTY" PROGRAMME

You can preset up to six PTY programmes.
Each new programme stored replaces the previous one.

1



Turn the "TUNE" dial to set the PTY programme to be stored.



2



Press one of the six buttons "1" to "6" for more than two seconds.
The sound cuts out then becomes audible again when the programme has been stored.
The number of the button and the associated PTY programme appear in the screen.



To recall the preset memory setting, press the button and release it within two seconds.

04 RADIO

CHANGING THE DISPLAY LANGUAGE OF THE "PTY" PROGRAMME

1



Press the "TUNE" button for more than two seconds to access the functions setting mode.

Then, press this button several times in succession; the functions setting mode changes in the following order:

AF / CT / REG / TP-S / PTY (languages) / SCV / PHONE / OFF.

Turn the "TUNE" dial to the left or to the right to select the language (ENGLISH, FRANCAIS, DEUTSCH, SVENSK, ESPAGNOL, ITALIANO).



FUNCTIONS SETTING MODE

1




This permits activation or deactivation of the functions below.

Press the "TUNE" button for more than two seconds to access the functions setting mode.

Then, press this button several times in succession; the functions setting mode changes in the following order:

AF / CT / REG / TO-S / PTY (languages) / SCV / PHONE / OFF.

Turn the "TUNE" dial respectively to the left to deactivate the function ("OFF") or to the right to activate it ("ON").



The "PHONE" is not operational at present.

The functions setting mode is deactivated after approximately 10 seconds without any action.

05 MUSIC MEDIA PLAYERS

CD PLAYER

This can play audio CDs (CD-DA, CD-Text, CD-R/RW) or MP3 CDs.


SELECTING CD MODE

After inserting a disc, printed face upwards, the player starts automatically.

1



If the player already contains a disc, press the "CD" button. "CD", the track number and the playing time appear in the screen.



!


Insert circular compact discs only.
8 cm compact discs must be inserted in the centre of the player slot.

EJECTING A DISC

1



Press this button to remove the disc from the player. The system automatically switches to radio mode.



!

Once ejected, if the compact disc is not removed within fifteen seconds, it is reloaded into the player.

05 MUSIC MEDIA PLAYERS


AUDIO CD

Fast search

1



Press and hold button "◀◀" or "▶▶" to carry out a fast backwards or forwards search respectively.
Play begins when the button is released.




Selecting a track

1



Press button "◀" or "▶" to select the previous or next track respectively.




Repeating a track

1



Press the "RPT" button to repeat the play of the current track. "RPT" appears in the screen.
To exit this mode, press this button again.




Random playing of a disc

1



Press the "RDM" button to start random play of the tracks on the disc. "RDM" appears in the screen.
To exit this mode, press this button again.




Playing the beginning of each track

1



Press the "SCAN" button to start playback of the first ten seconds of each track on the disc. "SCAN" appears in the screen and the corresponding track number flashes.
To exit this mode, press this button again.



!

On CD-R/RWs, the quality of the playback sound depends on the encoding software, the burning device and the burning speed used.

05 MUSIC MEDIA PLAYERS


CD-TEXT DISPLAY

The CD player and the CD changer are compatible with the display of CD-Text information.

1




Press the "DISP" button several times in succession; the CD-Text information appears in the following order:
DISC NAME / TRACK NAME /
NORMAL DISPLAY MODE.



2



If the information exceeds 12 characters, press the "PAGE" button to see the rest.
In the absence of CD-Text information to be displayed, "NOTITLE" appears on the screen.



MP3 / ID3 TAG CD

The CD player and the CD changer are compatible with the playing of MP3 files.

These must be recorded in ISO9660 Level 1 / Level 2, Joliet or Romeo format on CD ROMs, CD-Rs or CD-RWs. The CDs can contain a maximum of 255 files and 100 folders on 16 levels.

The ID3 version 1 Tag can be displayed while playing MP3 files.



In the case of compact discs containing both CD-DA and MP3 files, play automatically begins with the CD-DA files.

To switch play between the two types of file, press the "CD" button for more than two seconds until an audible signal is heard.

While using these compact discs, the "Repeat", Random play" and "Playing of the beginning of the tracks" functions are only applied to files of the same format.

SELECTING AN MP3 FOLDER

1



Turn the "FOLDER" dial respectively to the right to select a folder in ascending order or to the left to select a folder in descending order.




05 MUSIC MEDIA PLAYERS

REPEATING THE TRACKS IN A FOLDER

1



Press the "RPT" button for more than two seconds to repeat the playing of the tracks contained in the current folder. "D-RPT" appears in the screen. To exit this mode, press this button again.




PLAYING THE BEGINNING OF EACH TRACK

1



Press the "SCAN" button to start playing the first ten seconds of each track in all of the folders. "SCAN" appears in the screen and the corresponding track number flashes. To exit this mode, press this button again.




RANDOM PLAYING OF A FOLDER

1



Press the "RDM" button to start random playing of the tracks in the current folder. "RDM" appears in the screen. To exit this mode, press this button again.




RANDOM PLAYING OF A DISC

1



Press the "RDM" button for more than two seconds to start random playing of the tracks in all of the folders. "D-RDM" appears in the screen. To exit this mode, press this button again.




MP3 / ID3 TAG DISPLAY

When play begins, "READING" appears in the screen then disappears to make way for the folder number, the track number, the playing time and "MP3".

1



Press the "DISP" button several times in succession; the MP3 information appears in the following order:
FOLDER NAME / TRACK NAME /
NORMAL DISPLAY MODE.



05 MUSIC MEDIA PLAYERS


2



Press the "DISP" button for more than two seconds to activate the ID3 Tag information. "TAG" appears in the screen.

Press the "DISP" button several times in succession; the Tag ID3 information appears in the following order:
ALBUM NAME / TRACK NAME /
ARTIST NAME / NORMAL DISPLAY
MODE.

To deactivate this information, press the "DISP" button again for more than two seconds.




3



If the information exceeds 12 characters, press the "PAGE" button to see the rest.

In the absence of MP3 or ID3 Tag information to be displayed, "NOTITLE" appears in the screen.



!

On CD-R/RWs, the quality of the playing sound depends on the encoding software, the burning device and the burning speed used. Depending on the flow chart of the MP3 folders and files on the disc, play may not begin immediately.

CD CHANGER

See also "CD-Text display" and "MP3 / ID3 Tag CD".

SELECTING CHANGER MODE


1



After inserting at least one disc, printed face upwards, the changer starts automatically.

If the changer already contains a disc, press the "CD" button.

"CD", the disc and track numbers and the playing time appear in the screen.



LOADING A DISC


1



The CD changer can hold up to 6 CDs. Press the "LOAD" button briefly. "WAIT" appears on the display.

When the changer is ready, the indicator lamp on the "LOAD" button comes on and "LOAD DISC N° (1-6)" appears in the screen.

If several slots are empty, select one using one of the "DISC" buttons.



!

Insert circular compact discs only.
8 cm compact discs cannot be played by the changer.

05 MUSIC MEDIA PLAYERS

LOADING ALL OF THE DISCS

1


Press the "LOAD" button for more than two seconds.

The changer selects an empty slot from the lowest to the highest and switches to waiting for loading mode.

"LOAD DISC N° (1-6)" appears on the display; insert the disc in the corresponding slot.

The changer automatically selects the next empty slot number and returns to waiting for loading mode.

Repeat these steps until loading is complete. Play begins with the last disc inserted.




EJECTING ALL OF THE DISCS

1

Press this button for more than two seconds. The current disc is ejected.

Once this disc has been removed, the next disc is ejected automatically in its turn.

Repeat these steps until unloading is complete.




Once ejected, if the compact disc is not removed within fifteen seconds it is re-loaded into the changer.

SELECTING A DISC

1

Press one of the "DISC" buttons several times in succession until you reach the disc required. The symbol of the disc selected appears in the screen.



EJECTING A DISC

1

Press this button briefly to remove the current disc from the changer.



05 MUSIC MEDIA PLAYERS


AUDIO CD

Fast search

1



Press and hold button "◀◀" or "▶▶" to carry out a fast backwards or forwards search respectively.
Play begins when the button is released.




Selecting a track

1



Press button "◀" or "▶" to select the previous track or next track respectively.




Repeating a track

1



Press the "RPT" button to repeat the playing of the current track. "RPT" appears in the screen.
To exit this mode, press this button again.




Repeating a disc

1



Press the "RPT" button for more than two seconds to repeat the playing of the tracks of the current disc. "D-RPT" appears in the screen.
To exit this mode, press this button again.




Random playing of a disc

1



Press the "RDM" button to start random playing of the tracks on the disc. "RDM" appears in the screen.
To exit this mode, press this button again.




05 MUSIC MEDIA PLAYERS

Random playing on all of the discs

1



Press the "RDM" button for more than two seconds to start random playing of the tracks on all of the discs. "D-RDM" appears in the screen. To exit this mode, press this button again.



Playing of the beginning of each track

1



Press the "SCAN" button to start play of the first ten seconds of each track on the disc. "SCAN" appears in the screen and the corresponding track number flashes. To exit this mode, press this button again.



!


On CD-R/RWs, the playback sound quality depends on the encoding software, the burning device and the burning speed used.

USING THE AUXILIARY SOCKET (AUX)

JACK / RCA cable not supplied



The auxiliary socket, JACK or RCA, permits the connection of portable equipment (MP3 player...).



!

Do not connect a single piece of equipment via the USB port and the JACK socket at the same time.


1

Connect the portable equipment (MP3 player...) to the JACK socket or to the RCA-type audio sockets (white and red) using a suitable cable, not supplied.

2



Press the "CD" button for more than two seconds. "AUX" appears in the screen and the external mode is activated. Press "CD" again to deactivate the mode or on "AM/FM" to go to another mode.



06 USB PLAYER


USING THE USB PORT



The USB port is used to connect a portable device (MP3 player, Apple® player, ...). The files are sent from the player to your audio system and heard through the vehicle's speakers.


1

With the vehicle stationary, ignition switch in the **LOCK** position, connect a suitable cable to the portable player.



2

Then connect the cable to the vehicle's USB port.



Models supported:

- iPod touch®: FW version 1.1.1 or later.
- iPod classic®: FW version 1.0 or later.
- iPod 5th generation®: FW version 1.2.2 or later.
- iPod nano 5th generation®: FW version 1.2 or later.
- iPod nano 2nd generation®: FW version 1.1.2 or later.
- Compatible USB mass storage device: 256 Mb capacity or greater.

File formats: MP3, WMA, AAC, WAV.

Maximum number of levels (including root): 8.

Number of folders: 700.

Number of files: 65 535.



Do not connect the portable device directly to the USB port, use a cable.

To disconnect the cable, the ignition switch must be in the **LOCK** position.

Navigation in the file base is done via the portable device / iPod®.

Take care not to trap the cable when closing the armrest.

06 USB PLAYER

MANAGING A TRACK (OR FOLDER)


PLAY

1



Once the portable player / iPod® is connected, make several successive presses on the CD button and select USB (U is displayed) / iPod® (i is displayed).

Once the player is selected, play starts.




STOP

1



Press AM/FM or CD to change mode.




SELECT A TRACK

1



Press SEEK-TRACK to select a previous or next track; the track number goes down or up. Press and hold to go faster.



SELECT A FOLDER (OR TRACK)


1



Turn the dial to select a previous or next track.



Press the button to select the folder and go down or up one level.



The dial can also be used for tracks.

07 BLUETOOTH® STREAMING




MANAGING A TRACK

1



To listen to tracks on a telephone connected via Bluetooth®, press the audio system ON/OFF button.




PLAY

1



Make several successive presses on the CD button and select Bluetooth® (B is displayed). Once the player is selected, play commences.




PAUSE / STOP / RESUME*

1



Press the 5 DISC button to pause or stop play.
Press the 6 DISC button to resume play.



Streaming allows music files on a telephone to be heard via the vehicle's speakers. The telephone must support the appropriate Bluetooth® profiles (profiles A2DP / AVRCP).


Connect the telephone: see the "BLUETOOTH® TELEPHONE" section.

SELECT A TRACK*

1



Press SEEK-TRACK to select a previous or next track, the track number goes down or up.
A continuous press allows you to go faster.




REPEAT PLAY*

1



Press this button during play.
Press again to exit this mode.




RANDOM PLAY*

1



Press this button during play.
Press again to exit this mode.



* If the function is supported by the device.

07 BLUETOOTH® STREAMING



PLAY THE START OF EACH TRACK*


1



Press this button.

"**SCAN**" appears in the screen and the start of each track on the telephone connected via Bluetooth® is played for around 10 seconds.

Press again to exit this mode.



The screen displays a maximum of 10 characters at a times. If the end of the title is cut off, press the PAGE button. The next characters are displayed each time the button is pressed.

If no title is stored: "**NO TITLE**" appears in the screen.

Characters that cannot be displayed are replaced by ".".

CHANGING THE DISPLAY*


1



Press and hold this button until an audible signal is heard and "**TAG**" is displayed.

Press this button to change the display.

Make a new long press to exit this mode.



* If the function is supported by the device.

08 BLUETOOTH® TELEPHONE



CHANGING THE VOICE COMMAND LANGUAGE



What is the Bluetooth® hands-free telephone with voice recognition?

The system uses wireless communication technology known as Bluetooth® which allows you to make hands-free telephone calls in your vehicle via your Bluetooth® compatible mobile telephone.

You can make telephone calls using a microphone located in the courtesy lamp, making use of the simple steering mounted controls or by the voice recognition function with voice commands. Five languages are available: English (the default), Spanish, French, German and Italian.



By default, the voice recognition system is in English.




If you do not start the training procedure within around 3 minutes of pressing SPEAK, the process is cancelled.

If you press SPEAK within 5 seconds following the play of a voice command, this command is saved again.

1



Press this button.



2



Say **"Setup"**.

3



Say **"Language"**.

4

The system says **"Select a language: English, Spanish, French, German or Italian"**.

5



Say the language of your choice in English, example: say **"French"** for French.

6

The system then says **"French selected. Is this correct?"**

7



Say **"Yes"** to start the change of language process
Say **"No"** to return to steps 4 to 7.

8

The system repeats the language chosen and completes the change of language process.

08 BLUETOOTH® TELEPHONE



TRAINING THE USER'S VOICE



You can use the user voice training function to create a voice model for one person per language.


The characteristics of your voice and your pronunciation are saved in this model to provide the best voice recognition.

The vehicle must be stationary with the parking brake applied. Switch off your telephone during the operation to avoid any interruption.

1



Press this button.



2



Say "**Word training**".


3

An explanation message is given.

4



When you are ready to start, press and hold this button.



5

The system says the first of 45 standard phrases.

6



Repeat each of the phrases in the table on the following page.

The system saves your voice and moves on to the next command.

Continue the process until all of the phrases have been saved.

7

After playing all the voice commands, the system says "**The word enrolment is complete**" and ends the process.

!

If you do not start the programming process within approximately 3 minutes after pressing the SPEAK button, the process is cancelled.

If you press the SPEAK button within 5 seconds of the play of a voice command, this command is saved again.

08 BLUETOOTH® TELEPHONE



VOICE TRAINING COMMANDS

1	# 790 (for # = "Hash")	16	55 66 77 88 99	31	Home, Work, Mobile, Pager
2	* 671 (for * = "Star")	17	44 33 22 11 00	32	List of names
3	212 - 4 903	18	Call 293 - 5804	33	No
4	235 - 3 494	19	Call * 350	34	Phone book: Delete
5	315- 5 657	20	Call 1 (234) 567 - 8 901	35	Phone book: New entry
6	456 - 7 930	21	Dial 639 - 1542	36	Previous
7	793 - 5 462	22	Dial # 780	37	Phone book: Clear all
8	794 - 1 826	23	Dial (987) 654 - 3210	38	Redial
9	826 - 3 145	24	1058# 3794# Send	39	Repeat the training
10	962 - 7 305	25	27643# 4321# Send	40	Configure the confirmation requests
11	(531) 742 - 9 860	26	Cancel	41	Configure the language
12	(632) 807 - 4 591	27	Continue	42	Configure the matching options
13	(800) 222 - 5 015	28	Emergency number	43	Match a telephone
14	(888) 555 - 1 212	29	Clear all	44	Transfer the call
15	0 123 456 789	30	Help	45	Yes

08 BLUETOOTH® TELEPHONE



MATCHING A BLUETOOTH® TELEPHONE FIRST CONNECTION




The system can register up to 7 Bluetooth® compatible mobile telephones.
The telephone which has the highest level of priority is connected automatically.

1



Press this button.



2



Say **"Configure"**.

3



Say **"Matching options"**.

4

The system says **"Do you wish to match a telephone, delete a telephone or obtain the list of matched telephones?"**.

5



Say **"Match a telephone"**.



For reasons of safety and because the sustained attention of the driver is needed, operations of matching a Bluetooth® mobile phone with the audio system's hands-free function must be done with the **vehicle stationary**.

6

The systems says **"Please say the 4 digits of a matching code"**.

7



Say a 4-digit number which will be recorded as the matching code.

8



The system confirms the validity of the number spoken, answer **"Yes"**.
Say **"No"** to return to step 7.



Remember this matching code as you must enter it in the telephone in one of the following steps of the matching procedure.

08 BLUETOOTH® TELEPHONE



!

The services available depend on the network, the SIM card and the compatibility of the Bluetooth® telephone used. Check in your telephone user manual and with your service provider for the services you have access to.

9

The system says **"Start the matching procedure on the telephone. Consult the instructions in the telephone manual"**.

10



Consult your mobile telephone's user manual and enter the matching code recorded in step 7 in the telephone.

!

If the code is incorrect, the system locks. To clear the code:

- check that the telephone's voice recognition is not activated,
- with the ignition on and the audio system active, press the END CALL button for 2 seconds, 3 times in succession.

11

When it detects a Bluetooth® compatible mobile telephone, the system says **"Please say the name of the telephone after the beep"**.

12



After the audible signal, allocate a name to the telephone by saying the name of your choice.

13

The system says **"Allocate an order of priority between 1 and 7. One is the highest level of priority"**.

14



Give a number between 1 and 7 to establish the level of priority of the mobile telephone.

15

The system says and confirms the **"name of the telephone"** and the **"number"** of its priority.

16



Answer **"Yes"**
Say **"No"** to return to step 13.

17

The systems says **"Matching complete"** then emits an audible signal and deactivates the voice recognition.

!

If the system does not detect the Bluetooth® compatible mobile telephone, the matching process stops and is accompanied by an audible signal.

If you select a level of priority which has already been allocated to another telephone, the system asks you if you wish to replace this level of priority.

08 BLUETOOTH® TELEPHONE



USING A TELEPHONE NUMBER


!

You must have first matched a Bluetooth® compatible mobile telephone with the system.

1



Press this button.



2



Say "**Dial**".

3

The system says "**Number please**".

4



Call out the telephone number.

5



The system asks you to confirm this number, answer "**Yes**".
Say "**No**" to return to the previous step.

08 BLUETOOTH® TELEPHONE



SAVING A NAME IN THE SYSTEM PHONE BOOK




The system has its own phone book, independent of that of the mobile telephone. It can contain up to 32 names for each language. Each name in the phone book is associated with 4 locations: HOME, WORK, MOBILE and PAGER.

1



Press this button.



2



Say **"Phone book"**.

3

The system says **"Select one of the following items: New Entry, Change, List of names, Delete or Clear all, or say Cancel to return to the main menu"**.

4



Say **"New entry"**.

5

The system says **"Name please"**.

6



Give the name of your choice.

7

The system says **"HOME, WORK, MOBILE OR PAGER"**.

8



Give the location which corresponds to the number that you wish to record.

9

The system asks you to confirm the location.

10



Answer **"Yes"**.
Say **"No"** to return to step 7.

11

If a telephone number has already been recorded for this location, the system says **"The current number is -number-, number please"**.

12



If you do not wish to change the telephone number, repeat the original number to retain it, otherwise say the new number.

13

The system asks you to confirm the number.

14



Answer **"Yes"**.
Say **"No"** to return to step 11.

08 BLUETOOTH® TELEPHONE



USING A NAME IN THE PHONE BOOK


!

You must have first matched a compatible Bluetooth® mobile telephone with the system.

1



Press this button.



2



Say "**Call**".

3

The system says "**Name please**".

4



Give the name of the person that you wish to call.

5

If several telephone numbers have been recorded for this person, the system says "**Do you wish to call <name> {home}, {work}, {mobile} or {pager}?**"

6



Give the location corresponding to the number that you wish to call.

7

The system request confirmation of the name.

8



Answer "**Yes**".
Say "**No**" to return to step 4.

9

The system says "**Call to <name> at <location>**" and makes the call.

08 BLUETOOTH® TELEPHONE




REDIAL THE LAST NUMBER CALLED

1



Press this button.



2



Say **"Redial"**.

RECEIVING A CALL




The telephone ring is sent to the speaker by the front passenger's seat.

If an audio source (CD, radio, ...) is in operation when the call is received, it is placed on MUTE and only the incoming call is heard. When the ignition switch is in the ACC or ON position, the audio system is activated automatically if an incoming call is received, even if it was originally off.

1



Press this button.



At the end of the call, the audio system returns to its previous state.

08 BLUETOOTH® TELEPHONE



VOICE COMMANDS (1/2)



Press this button to start the voice recognition.

Configure	Divert the call	Home, at home
Phone book	Add a location	Work, at work
Dial	Configure the confirmation requests	Mobile, on mobile
Call	Language	Pager, on pager
Redial	New entry	Help
Emergency number	Delete	Continue
Matching options	Change	All
Match a telephone	Call this number	Cancel
Delete a telephone	Change another entry	Mute
List of matched telephones	Try again	Deactivate mute
Select a telephone	Clear all	Yes
Previous	List of names	No



When the system is waiting for a voice command, say "**Help**" to obtain a list of commands which can be used in the current situation.

08 BLUETOOTH® TELEPHONE



VOICE COMMANDS (2/2)



Press this button to start the voice recognition.

Zero	English	Word training
One	Phone book New entry	PIN
Two	Phone book Change	Repeat training
Three	Phone book Delete	Activate
Four	Phone book Clear All	Deactivate
Five	Phone book List of names	Incorporate the call
Six	Configure the confirmation requests	<digits> Send
Seven	Configure Select a telephone	
Eight	Configure the matching options	
Nine	Delete a name	
Star (*)	Configure the language	
Hash (#)	Configure the PIN	



When the system is waiting for a voice command, say **"Help"** to obtain a list of commands which can be used in the current situation.

ERROR MESSAGES

If an error message appears on the screen, refer to the table below to find out what it means and the solution to be applied in order to rectify it.

TEXT	DESCRIPTION	SOLUTION
NO DISC	No disc present. Disc not compatible.	Insert a disc.
ERROR 01	Disc inserted incorrectly. Disc with condensation.	Insert the disc with the printed face upwards. Clean the dampness off the disc.
ERROR 02	Disc dirty, scratched or distorted. Excessive vehicle vibration.	Clean or replace the disc. Try again when the vibration has stopped.
ERROR 03	Error on insertion or ejection. Playing head misaligned.	Eject the disc and insert it again. If it is not ejected, have the audio equipment checked.
ERROR HOT	Triggering of the internal protection against high temperatures.	Wait approximately 30 minutes to allow the audio system to cool.
ERROR	Communication error between the audio system and the external system. External system supply error.	Consult a CITROËN dealer.

A

ABS and EBFD systems	146
Accessories	202
Accessory socket, 12V	98, 100, 101
Access to bulbs	181
Active stability control (ASC)	148
Adjusting headlamps	137
Adjusting head restraints	81
Adjusting seat belt height	150
Adjusting the steering wheel	87
Airbag, knee	156, 158
Airbags, curtain	157, 158
Airbags, front	154, 158
Airbags, lateral	156, 158
Air conditioning	22
Air conditioning, automatic	89, 92
Air conditioning, manual	89, 90
Air filter	214
Air flow	22
Air intake	92
Air vents	88
Alarm	73
Anti-lock braking system (ABS)	146
Anti-theft	110
Apple® player	266-268
Armrest, front	82, 98, 101
Armrest, rear	84
ASC	148
Ashtray, portable	98, 100
Audible warning	145
Audio-CD system	283-320
Audio-telematic system	223-282
Audio-video	236
Audio streaming (Bluetooth)	269, 307
Audio system functions	224, 285

Automatic illumination of headlamps	132, 134
Automatic operation of hazard warning lamps	145
Automatic rain sensitive windscreen wipers ...	140
Automatic switching off of lighting	134
Auxiliary sockets	102, 264, 304, 305

B

Battery	192, 214
Battery, charging	194
Battery, remote control	68, 69
Bluetooth (telephone)	269-282, 309-319
Bonnet	205
Bonnet stay	205
Boot	71
Boot lamp	144
Bottle holder	98
Brake discs	216
Brake lamps	184
Brake pads	216
Brakes	216
Braking assistance system	146
Bulbs (changing, type)	180, 184

C

Capacity, fuel tank	208
CD changer	301
CD MP3	240, 299
Central locking	62, 65
Changing a bulb	180-185
Changing a fuse	186-191

Changing a wheel	174-179
Changing a wiper blade	195
Changing the remote control battery	68
Changing the time	54, 58
Checking levels	211-213
Checking the engine oil level	211
Checks	205-216
Child seats	159-168
Child lock	169
Cigarette lighter	100
Closing the boot	62, 71
Closing the doors	62, 65, 70
Colour screen	56, 224, 225
Connectors, audio	102, 264, 304, 305
Controls for air conditioning	90, 92
Coolant	46
Coolant level	212
Courtesy lamp, front	142
Courtesy lamp, rear	143
Copying a CD	241
Cruise control	124
Cup holder	98
CVT gearbox	113, 215

D

Daytime running lamps	134, 182
Deactivating ASC	148
Deactivating the passenger airbag	155
Deactivation of the passenger and rear window control switches	77
Deadlocking	63, 65
Defrosting	96, 97
Demisting	96, 97
Dials	24
Diesel additive level	213

Dimensions	221
Dipped beam	132, 180, 182
Dipstick	211
Direction indicators	145, 180, 181, 184
Driving economically	22
Doors	60, 64, 67, 70
DVD (mode)	256, 257

E

EBFD	146
Eco-driving	22
Electronic brake force distribution (EBFD)	146
Electronic engine immobiliser	69, 110
Emergency boot release	71
Emergency warning lamps	145
Engine, Diesel	207, 209, 210, 219, 220
Engine, petrol	206, 209, 217, 218
Engine compartment	206, 207
Engine compartment fusebox	189
Engine oil	211
Engine oil level	206, 207, 211
Engines	217, 219
Environment	22, 68, 194, 213
Equipment settings	57
Error messages (audio equipment)	320

F

Filling with fuel	208, 209
Fitting a wheel	178
Fittings, boot	104
Fittings, rear	103
Fitting the mat	99

Flashing indicators	145, 180, 181, 183, 184
Folding/unfolding the door mirrors	86
Four-wheel drive system	122
Front foglamps	133, 180, 182
Front seats	79, 80, 82
Fuel	22, 208, 209
Fuel consumption	22
Fuel filler cap	208
Fuel filler flap	208
Fuel gauge	208
Fuel tank	208
Fusebox, dashboard	187
Fuses	186

G

G.P.S.	226-235
Gearbox, manual	111, 112, 119, 215
Gear shift indicator	112
Gear lever, manual gearbox	111
Glove box	98, 99
Grab handles	103
Guidance	226-235

H

Hazard warning lamps	145
Headlamp adjustment	137
Headlamp wash	139
Headlamp wash reservoir	213
Head restraints, front	81
Head restraints, rear	83
Heated seats	84
Heating	22, 90, 92

Height and reach adjustment, steering wheel	87
Hill start assist	118

I

Identification plates	222
Indicators, direction	145, 181, 184
Inflating tyres	22, 222
Inputs for audio system	102, 264, 304, 305
Instrument panel	24
Instrument panel screen	24, 31
Interior fittings	98, 99
iPhone	269
iPod	266-268
ISOFIX child seats	165, 167
ISOFIX mountings	164, 167

J

Jack	174
JACK socket	264, 304, 305

K

Keeping children safe	155, 159-169
Key	60-63, 68
Key, electronic	64, 68, 69
Key in ignition warning	106
Keyless Entry and Starting	64-67, 107
Key with remote control	60, 62, 110

L

Labels, identification	222
Lamps, front	180
Lamps, rear	184
Lamps, warning and indicator	25-42
LED daytime running lamps	182
Level, brake fluid	212
Level, headlamp wash	213
Levels and checks	205-216
Lighting, guide-me home	135
Lighting, interior	142-144
Lighting bulbs (replacement)	180-185
Lighting control stalk	131
Lighting dimmer	59
Lighting on reminder	133
Loading	22
Long objects, transporting	84
Low fuel level	208
Luggage retaining strap	104

M

Main beam	136, 180, 182
Maintenance	22
Map (colour screen)	227
Map reading lamps	142
Markings, identification	222
Mat	99
Match telephone	269, 312
Menus (audio)	225
Mirror, rear view	87
Mirrors, door	85
Motorway function (direction indicators)	145
Mountings for ISOFIX seats	164, 167
MP3 CD	240, 299
Music server	240-251

N

Navigation	226-235
Number plate lamps	184, 185

O

Oil filter	214
Oil level	211
Opening the bonnet	205
Opening the boot	60, 64, 71
Opening the doors	60, 64, 70
Opening the fuel filler flap	208
Operation indicator lamps	25-42

P

Panoramic glass sunroof	78
Parcel shelf, rear	105
Parking brake	110, 216
Parking sensors, front	129
Parking sensors, rear	127, 128
Particle emission filter	205, 212, 213, 215
Passenger compartment filter	214
Player, CD MP3	240, 299
Port, USB	102, 264, 304, 305
Priming the fuel system	210
Protecting children	155, 159-169
Puncture	170

R

Radio	236, 291
Range	46
RCA sockets	304
Rear foglamp	133, 184
Rear screen (demisting)	97
Recharging the battery	194
Recirculation / exterior air intake	91, 94
Regeneration of the particle emissions filter	215
Remote control	60-69
Removing a wheel	176
Removing the mat	99
Repair kit, puncture	170
Replacing bulbs	180-185
Replacing fuses	186-191
Replacing the air filter	214
Replacing the oil filter	214
Replacing the passenger compartment filter	214
Replacing wiper blades	195
Rev counter	24
Reversing camera	130
Reversing lamps	184
Roof bars	201
Roof blind	78
Routine checks	214-216
Running out of fuel (Diesel)	210

S

Screen (audio equipment)	54
Screen, instrument panel	31, 43
Screen-wash reservoir	213
Screenwash, front	139
Screenwash fluid level	213

Seat, rear bench	83
Seat adjustment	79, 80
Seat back storage pockets	103
Seat belts	150-153
Seat belts warning lamp	151
Seats, electric	80
Seats, rear	83
Serial number, vehicle	222
Service indicator	44
Servicing	22
Setting the clock	54, 58
Sidelamps	131, 180, 182, 184
Side repeater	183
Ski flap	84
Spare wheel	175
Speedometer	24
Spotlamps, side	183
Starting the vehicle	106, 107
Stopping the vehicle	106, 107
Stop & Start system (Auto Stop & Go)	119
Storage	84, 99, 104
Stowing rings	104, 105
Sun visor	99
System, audio-CD	283-320
System, audio-telematic	223-282

T

Table of weights	218, 220
Tables of engines	217, 219
Tables of fuses	186
TCL	148
Technical data	217-222
Telephone	269, 309
Temperature, coolant	46
Temperature adjustment	90, 93

Temporary tyre repair kit	170
Third brake lamp	184, 185
Tools	174
Total distance recorder	43
Towbar	199
Towed loads	218, 220
Towing another vehicle	198
TP (Traffic information)	260, 294
Traction control (TCL)	148
Trajectory control systems	148
Tyre pressures	222
Tyres	22

U

Unlocking	60, 64
USB player	264, 305


V

Vehicle configuration	52
Vehicle identification	222
Ventilation	88-89
Video	256, 257
Voice commands	272, 273, 277-281, 309, 310, 314-318


W

Warning lamp, low fuel level	208
Warning lamps	25-42
Weights	218, 220
Welcome lighting	66, 136
Wheel, changing	174-179
Wheelbrace	174
Window controls	76
Wiper control stalk	138-141
Wipers	138-141


Exterior




Interior



Instruments and controls



Maintenance - Technical data



This handbook describes all of the equipment available in the whole range.

Your vehicle will be fitted with some of this equipment described in this document, depending on its trim level, version and the specification for the country in which it is sold.

The descriptions and illustrations are given without any obligation. Automobiles CITROËN reserves the right to modify the technical specifications, equipment and accessories without having to update this edition of the handbook.

This document is an integral part of your vehicle. It should be passed on to the new user in the event of sale or transfer.

Automobiles CITROËN declares, by application of the provisions of the European regulation (Directive 2000/53) relating to End of Life Vehicles, that it achieves the objectives set by this regulation and that recycled materials are used in the manufacture of the products that it sells.

Reproduction or translation of all or part of this handbook is prohibited without written authorisation from Automobiles CITROËN.

For any work on your vehicle, use a qualified workshop that has the technical information, competence and equipment required, which a CITROËN dealer is able to provide.

Printed in the EU
Anglais

04-12

Automobiles CITROËN

Siège social : 6 rue Fructidor - 75835 Paris Cedex 17 - France

TÉL. : +33 (0) 1 58 79 79 79 - www.citroën.fr

S.A. au capital de 16 000 000 € - R.C.S. Paris 642 050 199 - Siret 642 050 199 00990 - APE 741 J



12ACR.0041

Anglais

2012 – DOCUMENTATION DE BORD

4Dconcept

Diadeis

Edipro