Cosmic Byte — Product Knowledge Base

Auto-generated from the official Cosmic Byte support knowledge base (source v1.15.1) on 2026-10-15. Single source of truth: do not edit by hand — it is regenerated on every update.

This document contains official product manuals, specifications, setup steps, and troubleshooting for Cosmic Byte products. It also contains the official website policies (order tracking, returns & refunds, shipping, pre-orders, warranty service, rewards) and support contacts. Use it to answer customer questions accurately. If a detail is not stated here, say it is not specified rather than guessing.

Aether Mouse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-aether-tri-mode-gaming-mouse-pixart-3311-sensor-optical-switches-replaceable-battery/

COSMIC BYTE AETHER MOUSE - TRI-MODE GAMING MOUSE - FULL MANUAL

CONNECTIVITY:
- Three modes: Wired USB, 2.4GHz, Bluetooth BLE.
- Wired: connect 1.8m paracord USB cable - plug and play, no drivers. Auto switches to wired.
- 2.4GHz: slide mode switch to 2.4G. Plug USB receiver. First-time pair: hold Left + Middle + Right for 3 seconds - green LED flashes, insert receiver.
- Bluetooth: slide mode switch to BT. Blue LED flashes slowly = standby. First-time pair: hold Left + Middle + Right for 3 seconds - blue flashes rapidly. Select 'CB Aether' on device.
- NOTE: Bluetooth requires BLE (Bluetooth Low Energy) support. Devices without BLE cannot pair - use wired or 2.4GHz instead.
- USB dongle is stored inside the battery compartment - remove battery cover to access it.

DPI LEVELS (press DPI button to cycle):
- 800=Red, 1600=Blue, 2400=Purple, 4800=Green, 6400=Yellow, 12000=Cyan.
- Configurable via software (thecosmicbyte.com).

REPLACEABLE BATTERY:
- 400mAh Li-Ion battery. TWO batteries included in box.
- To replace: open battery compartment (also houses USB dongle), swap battery.
- Supports PD Fast Charging via USB cable - unique in this range.
- Weight: 44g without battery, 55g with battery.

CHARGING: Red LED blinks slowly = low battery. Charge via USB cable.

SWITCHES: TTC Optical Switches (100M clicks). Use light beam - no physical wear, no double-click issues.

SLEEP: Auto-sleep after inactivity. Wake by moving or clicking. Slight delay on wake = normal.

TROUBLESHOOTING:
- 2.4G not connecting: re-pair (hold L+M+R 3s), try USB 2.0 port, check battery.
- Bluetooth not pairing: device must support BLE. Remove old pairing first. Hold L+M+R 3s for pairing mode.
- Cursor erratic: use mousepad, lower DPI, check for interference.

SOFTWARE: All 6 buttons programmable via Cosmic Byte software (Windows ONLY). Download from https://www.thecosmicbyte.com/downloaddrivers/. macOS NOTE: The Aether works as a plug-and-play mouse on macOS for normal use. However, there is NO dedicated macOS software — software-only features (custom DPI beyond presets, button remapping, RGB customization) are Windows-only. Do NOT direct macOS users to a "macOS version" — none exists.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered.
Support: +91 7351615161 (Mon-Sat 10am-6pm), cc@thecosmicbyte.com.

Arcturus 65

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-arcturus-tri-mode-gasket-mechanical-keyboard/

COSMIC BYTE ARCTURUS 65 — TRI-MODE 65% GASKET MECHANICAL KEYBOARD

ARCTURUS FAMILY — 3 SIZES: The Arcturus line has three tri-mode gasket keyboards that share switches, battery, sound-dampening, connectivity and hot-swap, differing mainly in SIZE/LAYOUT and a few shortcuts: Arcturus 65 (65%, 66 keys+knob), Arcturus 75 (75%, 82 keys+knob), Arcturus 98 (98%, 101 keys+knob). If a customer just says "Arcturus" without a size AND asks something size-specific (factory reset, exact FN shortcuts, dimensions/weight), ASK which size they have. KEY DIFFERENCE: factory reset is FN + Space on the 65, but FN + ESC on the 75 and 98.

TRI-MODE: Wired USB-C + 2.4GHz + Bluetooth (5.0/3.0, up to 3 devices). 65% layout (66 keys + volume knob). Outemu Custom Yellow pre-lubed LINEAR switches, hot-swappable. Gasket-mounted design. 4000mAh battery. Per-key RGB. PBT keycaps.

SPECS: 65% (66 keys + volume knob). Outemu Custom Yellow (pre-lubed linear) switches, HOT-SWAPPABLE (3-pin & 5-pin, no soldering), 50M presses. 4000mAh battery. PBT keycaps, non-shine-through legends (no light bleed). RGB, south-facing LEDs. Polling: 1000Hz (Wired / 2.4G), 125Hz (Bluetooth). Bluetooth range up to 10m. Key travel 3.6 ± 0.5mm, actuation 45 ± 5g. Cable: 1.6m Type-C (PVC with ferrite core). Dual-stage adjustable feet with silicone pads. Size 321 x 114 x 40 mm, weight 660g ± 20g. Software: Cosmic Byte Orbit web configurator (browser-based, Chromium desktop — works on Windows / macOS / Linux / ChromeOS; USB or 2.4GHz only, not Bluetooth).

SOUND DAMPENING (multi-layer): Poron foam + IXPE switch pad + PET dampening film + DPEM switch pad + silicone bottom pad. Result: reduced hollow sound, deeper premium acoustics, minimal resonance.

WHAT'S IN THE BOX: Keyboard, USB-C cable, 2-in-1 keycap & switch puller, 2 spare mechanical switches, extra keycaps, user manual. (Use a spare switch for a single failed key instead of a service claim.)

CONNECTIVITY / SWITCHING MODES:
- Wired: connect the Type-C cable to the PC, wait ~15s for driver install. Plug & play.
- 2.4GHz: switch to 2.4G mode, hold FN + R (3s), insert the USB receiver — auto-connects. (Avoid USB hubs; reinsert the receiver if it drops.)
- Bluetooth (3 devices): switch to BT mode, hold FN + Q / W / E (3s) → the indicator flashes = pairing mode; select the keyboard in your device's Bluetooth menu.
  - Device names: Bluetooth 5.0 = "CB 65 BT5.0", Bluetooth 3.0 = "CB 65 BT3.0". Each of the 3 slots supports BT 5.0 or 3.0 depending on the device.
  - Switch between paired devices: FN + Q / W / E.
  - Notes: pairing timeout 1 minute, reconnect ~20s, auto-sleep when idle.

HOT-SWAP (3-pin & 5-pin, no soldering): remove the keycap with the puller → pull the switch with the puller → align pins carefully → press the new switch straight into the socket. Do NOT bend pins or use excessive force; insert switches straight.

RGB / VOLUME KNOB: Volume knob — rotate = volume, press = mute.

BATTERY: 4000mAh. Indicator: low = blinking, charging = constant (solid), full = OFF. Battery %: press FN + Backspace, then number keys show battery level. RGB / wireless use drains battery faster — reduce RGB or use wired mode to extend runtime.

TROUBLESHOOTING: Won't power on → charge, check the mode switch. Wired not detected → different USB port, restart PC, wait for driver. 2.4G not working → reinsert receiver, press FN + R, avoid USB hubs. Bluetooth not connecting → hold FN + Q/W/E, remove old pairing, reconnect. BT disconnecting → charge battery, stay within ~10m range. Keys not working / double typing → replace the switch (use a spare), reset. RGB not working → FN + X to toggle RGB, raise brightness. Battery drains fast → reduce RGB, use wired. Input lag → use 2.4G mode for gaming.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products are NOT covered. Compliance: RoHS, WEEE, BIS, ETA.

SOFTWARE — COSMIC BYTE ORBIT (web-based): the Arcturus is configured through Cosmic Byte Orbit, the official BROWSER-BASED configurator at https://orbit.thecosmicbyte.com — no download needed. Use it to remap keys, set RGB effects/colour/brightness/speed and record macros. Requirements: open it in Chrome / Edge / Brave / Opera on a DESKTOP computer (Windows / macOS / Linux / ChromeOS — not Firefox, Safari, phones or tablets), connect the keyboard by USB cable or its 2.4GHz dongle, click Detect device and approve the browser prompt. NOT supported over Bluetooth — switch to USB or 2.4GHz to configure (this matches the manual: software works in Wired and 2.4GHz modes only). The supported-device grid at orbit.thecosmicbyte.com is the authoritative list.

BUY: https://www.thecosmicbyte.com/product/cosmic-byte-arcturus-tri-mode-gasket-mechanical-keyboard/ — use coupon code ONLINEPAY for 10% off on online payments.

FN SHORTCUTS (Arcturus 65):
- Function row: FN + 1-0 = F1-F10 | FN + - / = = F11 / F12
- FN + U / I / O = Print Screen / Scroll Lock / Pause | FN + PgUp / PgDn = Insert / Home | FN + Del = End
- Media: FN + V = Play/Pause | FN + B / N = Previous / Next | FN + M = Mute | FN + , / . = Volume - / +
- System: FN + H / J = Screen Brightness - / + | FN + K = Task View | FN + L = My Computer / Launchpad | FN + Win = Lock Windows key

RGB CONTROLS (Arcturus 65): FN + Backslash = change effect | FN + [/] = speed | FN + Up/Down = brightness | FN + Left/Right = direction / color | FN + X = RGB on/off.

FACTORY RESET (Arcturus 65): hold FN + Space for 3 seconds. (The 65 uses FN + Space — the 75 and 98 use FN + ESC.)

Arcturus 75

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-arcturus-tri-mode-gasket-mechanical-keyboard/

COSMIC BYTE ARCTURUS 75 — TRI-MODE 75% GASKET MECHANICAL KEYBOARD

ARCTURUS FAMILY — 3 SIZES: The Arcturus line has three tri-mode gasket keyboards that share switches, battery, sound-dampening, connectivity and hot-swap, differing mainly in SIZE/LAYOUT and a few shortcuts: Arcturus 65 (65%, 66 keys+knob), Arcturus 75 (75%, 82 keys+knob), Arcturus 98 (98%, 101 keys+knob). If a customer just says "Arcturus" without a size AND asks something size-specific (factory reset, exact FN shortcuts, dimensions/weight), ASK which size they have. KEY DIFFERENCE: factory reset is FN + Space on the 65, but FN + ESC on the 75 and 98.

TRI-MODE: Wired USB-C + 2.4GHz + Bluetooth (5.0/3.0, up to 3 devices). 75% layout (82 keys + volume knob). Outemu Custom Yellow pre-lubed LINEAR switches, hot-swappable. Gasket-mounted design. 4000mAh battery. Per-key RGB. PBT keycaps.

SPECS: 75% (82 keys + volume knob). Outemu Custom Yellow (pre-lubed linear) switches, HOT-SWAPPABLE (3-pin & 5-pin, no soldering), 50M presses. 4000mAh battery. PBT keycaps, non-shine-through legends (no light bleed). RGB, south-facing LEDs. Polling: 1000Hz (Wired / 2.4G), 125Hz (Bluetooth). Bluetooth range up to 10m. Key travel 3.6 ± 0.5mm, actuation 45 ± 5g. Cable: 1.6m Type-C (PVC with ferrite core). Dual-stage adjustable feet with silicone pads. Size 332 x 141 x 40 mm, weight ~800g ± 20g. Software: Cosmic Byte Orbit web configurator (browser-based, Chromium desktop — works on Windows / macOS / Linux / ChromeOS; USB or 2.4GHz only, not Bluetooth).

SOUND DAMPENING (multi-layer): Poron foam + IXPE switch pad + PET dampening film + DPEM switch pad + silicone bottom pad. Result: reduced hollow sound, deeper premium acoustics, minimal resonance.

WHAT'S IN THE BOX: Keyboard, USB-C cable, 2-in-1 keycap & switch puller, 2 spare mechanical switches, extra keycaps, user manual. (Use a spare switch for a single failed key instead of a service claim.)

CONNECTIVITY / SWITCHING MODES:
- Wired: connect the Type-C cable to the PC, wait ~15s for driver install. Plug & play.
- 2.4GHz: switch to 2.4G mode, hold FN + R (3s), insert the USB receiver — auto-connects. (Avoid USB hubs; reinsert the receiver if it drops.)
- Bluetooth (3 devices): switch to BT mode, hold FN + Q / W / E (3s) → the indicator flashes = pairing mode; select the keyboard in your device's Bluetooth menu.
  - Device names: Bluetooth 5.0 = "CB 75 BT5.0", Bluetooth 3.0 = "CB 75 BT3.0". Each of the 3 slots supports BT 5.0 or 3.0 depending on the device.
  - Switch between paired devices: FN + Q / W / E.
  - Notes: pairing timeout 1 minute, reconnect ~20s, auto-sleep when idle.

HOT-SWAP (3-pin & 5-pin, no soldering): remove the keycap with the puller → pull the switch with the puller → align pins carefully → press the new switch straight into the socket. Do NOT bend pins or use excessive force; insert switches straight.

RGB / VOLUME KNOB: Volume knob — rotate = volume, press = mute.

BATTERY: 4000mAh. Indicator: low = blinking, charging = constant (solid), full = OFF. Battery %: press FN + Backspace, then number keys show battery level. RGB / wireless use drains battery faster — reduce RGB or use wired mode to extend runtime.

TROUBLESHOOTING: Won't power on → charge, check the mode switch. Wired not detected → different USB port, restart PC, wait for driver. 2.4G not working → reinsert receiver, press FN + R, avoid USB hubs. Bluetooth not connecting → hold FN + Q/W/E, remove old pairing, reconnect. BT disconnecting → charge battery, stay within ~10m range. Keys not working / double typing → replace the switch (use a spare), reset. RGB not working → FN + X to toggle RGB, raise brightness. Battery drains fast → reduce RGB, use wired. Input lag → use 2.4G mode for gaming.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products are NOT covered. Compliance: RoHS, WEEE, BIS, ETA.

SOFTWARE — COSMIC BYTE ORBIT (web-based): the Arcturus is configured through Cosmic Byte Orbit, the official BROWSER-BASED configurator at https://orbit.thecosmicbyte.com — no download needed. Use it to remap keys, set RGB effects/colour/brightness/speed and record macros. Requirements: open it in Chrome / Edge / Brave / Opera on a DESKTOP computer (Windows / macOS / Linux / ChromeOS — not Firefox, Safari, phones or tablets), connect the keyboard by USB cable or its 2.4GHz dongle, click Detect device and approve the browser prompt. NOT supported over Bluetooth — switch to USB or 2.4GHz to configure (this matches the manual: software works in Wired and 2.4GHz modes only). The supported-device grid at orbit.thecosmicbyte.com is the authoritative list.

BUY: https://www.thecosmicbyte.com/product/cosmic-byte-arcturus-tri-mode-gasket-mechanical-keyboard/ — use coupon code ONLINEPAY for 10% off on online payments.

FN SHORTCUTS (Arcturus 75):
- FN + F1 / F2 = Screen Brightness - / + | FN + F3 = Task View | FN + F4 = App switch | FN + F5 = Emoji | FN + F6 = Screenshot
- FN + F7 / F8 / F9 = Media control | FN + F10 = Search | FN + F11 = Input method | FN + F12 = Desktop

RGB CONTROLS (Arcturus 75): FN + Backslash = effect | FN + Enter = color | FN + Up/Down = brightness | FN + Left/Right = speed | FN + X = RGB on/off.

FACTORY RESET (Arcturus 75): hold FN + ESC for 3 seconds. (The 75 and 98 use FN + ESC — the 65 uses FN + Space.)

Arcturus 98

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-arcturus-tri-mode-gasket-mechanical-keyboard/

COSMIC BYTE ARCTURUS 98 — TRI-MODE 98% GASKET MECHANICAL KEYBOARD

ARCTURUS FAMILY — 3 SIZES: The Arcturus line has three tri-mode gasket keyboards that share switches, battery, sound-dampening, connectivity and hot-swap, differing mainly in SIZE/LAYOUT and a few shortcuts: Arcturus 65 (65%, 66 keys+knob), Arcturus 75 (75%, 82 keys+knob), Arcturus 98 (98%, 101 keys+knob). If a customer just says "Arcturus" without a size AND asks something size-specific (factory reset, exact FN shortcuts, dimensions/weight), ASK which size they have. KEY DIFFERENCE: factory reset is FN + Space on the 65, but FN + ESC on the 75 and 98.

TRI-MODE: Wired USB-C + 2.4GHz + Bluetooth (5.0/3.0, up to 3 devices). 98% layout (101 keys + volume knob). Outemu Custom Yellow pre-lubed LINEAR switches, hot-swappable. Gasket-mounted design. 4000mAh battery. Per-key RGB. PBT keycaps.

SPECS: 98% (101 keys + volume knob). Outemu Custom Yellow (pre-lubed linear) switches, HOT-SWAPPABLE (3-pin & 5-pin, no soldering), 50M presses. 4000mAh battery. PBT keycaps, non-shine-through legends (no light bleed). RGB, south-facing LEDs. Polling: 1000Hz (Wired / 2.4G), 125Hz (Bluetooth). Bluetooth range up to 10m. Key travel 3.6 ± 0.5mm, actuation 45 ± 5g. Cable: 1.6m Type-C (PVC with ferrite core). Dual-stage adjustable feet with silicone pads. Size 409 x 142 x 40 mm, weight ~1000g ± 20g. Software: Cosmic Byte Orbit web configurator (browser-based, Chromium desktop — works on Windows / macOS / Linux / ChromeOS; USB or 2.4GHz only, not Bluetooth).

SOUND DAMPENING (multi-layer): Poron foam + IXPE switch pad + PET dampening film + DPEM switch pad + silicone bottom pad. Result: reduced hollow sound, deeper premium acoustics, minimal resonance.

WHAT'S IN THE BOX: Keyboard, USB-C cable, 2-in-1 keycap & switch puller, 2 spare mechanical switches, extra keycaps, user manual. (Use a spare switch for a single failed key instead of a service claim.)

CONNECTIVITY / SWITCHING MODES:
- Wired: connect the Type-C cable to the PC, wait ~15s for driver install. Plug & play.
- 2.4GHz: switch to 2.4G mode, hold FN + R (3s), insert the USB receiver — auto-connects. (Avoid USB hubs; reinsert the receiver if it drops.)
- Bluetooth (3 devices): switch to BT mode, hold FN + Q / W / E (3s) → the indicator flashes = pairing mode; select the keyboard in your device's Bluetooth menu.
  - Device names: Bluetooth 5.0 = "CB 98 BT5.0", Bluetooth 3.0 = "CB 98 BT3.0". Each of the 3 slots supports BT 5.0 or 3.0 depending on the device.
  - Switch between paired devices: FN + Q / W / E.
  - Notes: pairing timeout 1 minute, reconnect ~20s, auto-sleep when idle.

HOT-SWAP (3-pin & 5-pin, no soldering): remove the keycap with the puller → pull the switch with the puller → align pins carefully → press the new switch straight into the socket. Do NOT bend pins or use excessive force; insert switches straight.

RGB / VOLUME KNOB: Volume knob — rotate = volume, press = mute.

BATTERY: 4000mAh. Indicator: low = blinking, charging = constant (solid), full = OFF. Battery %: press FN + Backspace, then number keys show battery level. RGB / wireless use drains battery faster — reduce RGB or use wired mode to extend runtime.

TROUBLESHOOTING: Won't power on → charge, check the mode switch. Wired not detected → different USB port, restart PC, wait for driver. 2.4G not working → reinsert receiver, press FN + R, avoid USB hubs. Bluetooth not connecting → hold FN + Q/W/E, remove old pairing, reconnect. BT disconnecting → charge battery, stay within ~10m range. Keys not working / double typing → replace the switch (use a spare), reset. RGB not working → FN + X to toggle RGB, raise brightness. Battery drains fast → reduce RGB, use wired. Input lag → use 2.4G mode for gaming.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products are NOT covered. Compliance: RoHS, WEEE, BIS, ETA.

SOFTWARE — COSMIC BYTE ORBIT (web-based): the Arcturus is configured through Cosmic Byte Orbit, the official BROWSER-BASED configurator at https://orbit.thecosmicbyte.com — no download needed. Use it to remap keys, set RGB effects/colour/brightness/speed and record macros. Requirements: open it in Chrome / Edge / Brave / Opera on a DESKTOP computer (Windows / macOS / Linux / ChromeOS — not Firefox, Safari, phones or tablets), connect the keyboard by USB cable or its 2.4GHz dongle, click Detect device and approve the browser prompt. NOT supported over Bluetooth — switch to USB or 2.4GHz to configure (this matches the manual: software works in Wired and 2.4GHz modes only). The supported-device grid at orbit.thecosmicbyte.com is the authoritative list.

BUY: https://www.thecosmicbyte.com/product/cosmic-byte-arcturus-tri-mode-gasket-mechanical-keyboard/ — use coupon code ONLINEPAY for 10% off on online payments.

FN SHORTCUTS (Arcturus 98):
- FN + F1 / F2 = Screen Brightness - / + | FN + F3 = Task View | FN + F4 = App switching | FN + F5 = Emoji | FN + F6 = Screenshot
- FN + F7 / F8 / F9 = Media control | FN + F10 = Search | FN + F11 = Input method | FN + F12 = Desktop

RGB CONTROLS (Arcturus 98): FN + Backslash = effect | FN + Enter = color | FN + Up/Down = brightness | FN + Left/Right = speed | FN + X = RGB on/off.

FACTORY RESET (Arcturus 98): hold FN + ESC for 3 seconds. (The 75 and 98 use FN + ESC — the 65 uses FN + Space.)

NOTE: The Arcturus 98 is the near-full-size (98%) member of the family with a numpad. Its manual spec table lists the RGB as SMD bottom-mounted LEDs (south-facing) — same placement family as the 65/75.

Ares Pro

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-ares-pro-tri-mode-wireless-bluetooth-wired-controller-for-pc/

COSMIC BYTE ARES PRO - TRI-MODE CONTROLLER - FULL MANUAL

⚠️ CRITICAL — READ FIRST: WHAT THE ARES PRO DOES *NOT* HAVE

The Ares Pro is a strong mid-range controller but several features customers sometimes assume are present are actually ABSENT. Listing any of these as "features it has" is a customer-visible WRONG ANSWER:

✗ NO GYRO / MOTION SENSING — at all. The Ares Pro does NOT have gyro hardware. There is no gyro chip in the controller. Gyro / motion aim / aim-tilt CANNOT be enabled on any platform (PC, iPad, iPhone, Android, anywhere) because the hardware doesn't exist. (Lumora, Drakon, Stellaris, and Blitz Tri-Mode all have 6-axis gyro hardware. Ares Pro does NOT. If gyro is essential for the customer, recommend one of those instead.)

✗ NO TMR JOYSTICKS. Ares Pro Gen 2 has HALL EFFECT joysticks (not TMR). The back label does NOT carry "TMR" or "HE" markings — Ares Pro doesn't use those badges. (Drakon, Stellaris Gen 2, and Blitz Tri-Mode have TMR. Ares Pro has Hall Effect, which is a different drift-resistant tech — both are drift-resistant but they're not the same thing.)

✗ NO 4 MACRO BUTTONS / SLOTS. Ares Pro has 2 macro slots (ML / MR). (Lumora has 4. Do NOT say Ares Pro has 4 macros.) Both gens have the same 2 macro paddles.

✗ NO REPLACEABLE STICK TOPS / D-PAD COVERS. Single fixed set, not in the box. (Lumora ships with 6 stick tops + 2 D-pad covers. Ares Pro does NOT.)

✗ NO KEYBOARD/MOUSE REMAPPING via software. Gen 2 software (Mappings tab) supports gamepad-to-gamepad remap only. (Lumora supports KB/mouse remap. Ares Pro does NOT.) Gen 1 has no PC software at all.

✗ NO CHARGING DOCK SUPPORT. Ares Pro does not have the back contacts for a charging dock. Charges via USB-C cable only. (Blitz Tri-Mode supports a charging dock — Ares Pro does NOT.)

✗ NO SOFTWARE POLLING-RATE ADJUSTMENT. The Gen 2 Cosmic Byte Ares Pro Software does NOT have a polling-rate slider, an Extended Settings polling rate option, or any other UI element for changing polling rate. The polling rate is HARDWARE-FIXED on the Ares Pro: 1000Hz on wired and 2.4GHz dongle, lower on Bluetooth (Bluetooth chipset/spec limit). If you find yourself listing "polling rate adjustment" or "configure up to 1000Hz" as a software feature, STOP — that's a fabrication (production session ff30571b, 2026-05-13 01:26 surfaced this in a customer-facing reply; the KB previously documented this feature incorrectly, corrected in v1.10.8). The bot must NOT include polling rate in lists of software-adjustable features for the Ares Pro.

✗ NO "SOFTWARE WORKS IN WIRED MODE ONLY" CLAIM. The Cosmic Byte Ares Pro Software works in BOTH Wired USB-C mode AND 2.4GHz Dongle mode. Only Bluetooth mode is unsupported by the software. Do NOT tell customers they must connect via USB-C to use the software — the 2.4GHz dongle works for software access too (production session ff30571b also surfaced this; KB previously documented this incorrectly, corrected in v1.10.8). When walking the customer through "how to start using the software", give both options ("connect via USB-C cable OR plug in the 2.4GHz dongle"), not just the USB-C path.

✗ NO CONSOLE SUPPORT. Windows PC is the primary platform. Does not work on PlayStation / Xbox / Switch. Android via USB-C OTG works but is not covered under warranty. macOS support is not advertised — if a Mac customer asks, refer them to the MAC COMPATIBILITY POLICY in the system prompt.

✗ GEN 1 SPECIFIC: NO companion software, NO software-based RGB or macro programming, NO software-based firmware update path (firmware on Gen 1 uses a manual standalone-file procedure — see SECTION 2). (Current Ares Pro Gen 2 HAS all of these. See "DOES HAVE" block below for what upgrades come with Gen 2.)

✓ WHAT THE ARES PRO *DOES* HAVE (real features for current Gen 2; real upgrades over Gen 1 — list ALL of these confidently when asked "what does the current Ares Pro add over the older one?". Do NOT

shorten to a vague "improved features" summary.)

The CURRENT Ares Pro (Gen 2 with "App Support" label) is a genuine generational upgrade over Gen 1. Real, KB-documented Gen 2 features:

✓ TRI-MODE CONNECTIVITY: Wired (USB-C) + 2.4GHz wireless dongle + Bluetooth — all three modes present on BOTH generations.
✓ HALL EFFECT JOYSTICKS — drift-resistant magnetic-sensor sticks. (Gen 1 also has Hall Effect joysticks per the Gen 1 manual; if a Gen 1 customer asks, confirm "yes, Hall Effect" — this is NOT a Gen-2-only feature.)
✓ HALL EFFECT ANALOG TRIGGERS — drift-resistant, pressure-sensitive triggers. Range adjustable via software (Initial / Max sliders) on Gen 2. (Gen 1 has Hall Effect triggers too but no software range adjust.)
✓ APP SUPPORT — Cosmic Byte PC companion software (download from thecosmicbyte.com/downloaddrivers) for: RGB customization, button mapping (Mappings tab), macro programming (Macro tab, 2 slots), stick deadzone/curve config, trigger range, vibration, firmware updates, auto-shutdown timing. The controller back label has "App Support" in the top-left corner. (Gen 1 had NO PC software.)
✓ 2 MACRO PADDLES on the back (ML / MR), programmable to single actions, button sequences, or full macros via the software's Macro tab. (Both gens have the 2 paddles physically; only Gen 2 can program them via software.)
✓ RGB LIGHTING — customizable via Gen 2 software on the RGB tab. Gen 1 RGB is fixed (no customization since there's no software).
✓ FIXED POLLING RATE (not software-adjustable) — 1000Hz on wired and 2.4GHz dongle modes. Lower on Bluetooth (Bluetooth is a chipset/spec limit, NOT a defect — do NOT tell customers Bluetooth should be 1000Hz). The polling rate is a HARDWARE-FIXED value on the Ares Pro; the Gen 2 software does NOT have a polling-rate adjustment / Extended Settings polling slider / any UI element for changing polling rate. If you find yourself listing "polling rate adjustment" as a software feature for the Ares Pro, STOP — that's a hallucination (the KB previously documented this incorrectly; corrected in v1.10.8). The software CANNOT change polling rate on either Gen 1 or Gen 2.
✓ SOFTWARE-CONTROLLED VIBRATION STRENGTH on Gen 2 (Vibration tab). Gen 1 has the vibration motors but no software control over intensity.
✓ FIRMWARE UPDATES — Gen 2 firmware updates run THROUGH the companion software (Extended Settings → Firmware Update). Gen 1 firmware updates use a manual standalone-file procedure (see SECTION 2 of this entry for the Gen 1 process). Either path works for its respective generation; do not cross them.

ASK-FIRST GUIDANCE (READ BEFORE ANSWERING SOFTWARE / FIRMWARE / RGB QUESTIONS):

GENERATIONS: There are TWO generations of Ares Pro currently in customer hands. They differ in software support and firmware-update mechanism. ALWAYS ask the customer to check the back label of their controller (or the back of the original packaging) for "App Support" text in the top-left corner — that single check distinguishes the two generations:

- "App Support" text PRESENT on back label → CURRENT Ares Pro (Gen 2). Has companion PC software. Software handles RGB customization, button mapping, firmware updates, auto-shutdown adjustment, and other advanced features.
- "App Support" text ABSENT on back label → ARES PRO Gen 1 (older model). NO companion software. Works fully as a controller but cannot be configured via software. Firmware updates use a manual standalone-file path (see SECTION 2 below).

Default to Gen 2 (current) unless customer signals otherwise (e.g. "no software for my Ares Pro," "back label has no App Support text," explicitly "older model"). Don't proactively ask "Gen 1 or Gen 2?" on every query — only when the answer materially differs (software questions, firmware questions, software-only feature questions).

PLATFORM: Designed exclusively for Windows PC. NOT compatible with PlayStation, Xbox, Nintendo Switch or any console. No warranty for console use. Android via OTG works but is not covered under warranty.

GYRO: NONE. The Ares Pro does NOT have gyro / motion sensor hardware. This is a HARDWARE FACT, not a platform limitation — there is no gyro chip in the controller, so gyro / motion-aim cannot be enabled on any platform (PC, iPad, iPhone, Android, anywhere). If a customer asks about gyro / motion control / aim-tilt for the Ares Pro, the answer is NO, full stop. Do NOT tell the customer "gyro only works on PC, not iPad" or any variation that implies gyro hardware exists — there is no gyro hardware. If gyro is important to the customer, recommend Lumora, Drakon, Stellaris, or Blitz Tri-Mode instead, all of which have 6-axis gyro hardware (and on-the-fly software gyro that can mimic joystick movement on non-Windows platforms — see ON-THE-FLY SOFTWARE GYRO POLICY in the system prompt).

SECTION 1: CURRENT ARES PRO (Gen 2 — "App Support" label present)

This is the version sold currently. Has companion software that handles all advanced features.

SOFTWARE (Cosmic Byte Ares Pro Software — Windows ONLY):

Download from https://www.thecosmicbyte.com/downloaddrivers/. Current software version is v1.2.11 (visible at the bottom-right of the app window). The Ares Pro is plug-and-play on Windows for normal gamepad use; the software is OPTIONAL and only needed for customisation. There is no macOS / Linux / Android build — Ares Pro works on those platforms via its supported connection modes for normal gamepad use, but software-only features below are not available off Windows. The Cosmic Byte software ONLY works for the current Gen 2 Ares Pro (back label has "App Support" text); Gen 1 Ares Pro has no companion software at all (see SECTION 2 of this manual entry).

CONNECTION REQUIREMENT: software works in WIRED USB-C mode AND in 2.4GHz Dongle mode. Both are supported by the Cosmic Byte Ares Pro Software on Windows. Bluetooth mode is NOT supported by the software — if a customer is paired via Bluetooth and reports the software won't detect their controller, ask them to switch to either USB-C wired or 2.4GHz dongle. Do NOT tell customers the software is "wired-only" — that's wrong (corrected in v1.10.8). Plug-and-play normal gamepad use still works in all three connection modes; only the software (RGB, button mapping, macros, firmware updates, stick/trigger config, etc.) requires Wired or 2.4GHz.

APP LAYOUT:
- TITLE BAR: "Cosmic Byte Ares Pro Software" (orange title bar at top).
- LANDING / DEVICE PICKER: shows "Connected Devices" with the controller card (model name, connection type "Wired", current firmware version), plus two buttons: "Configure" (enters the tab-based editor) and "Firmware Update" (jumps directly to the firmware tab).
- INSIDE THE EDITOR: three columns.
  * LEFT SIDEBAR (7 tabs): Mappings / Macro / Sticks / Triggers / Vibration / Extended Settings / Firmware Update.
  * MIDDLE PANEL: per-tab settings.
  * RIGHT PANEL: live render of the controller with per-stick X/Y % readouts and trigger intensity bars on the far left (LT) and far right (RT). Profiles selector (1, 2, 3, 4) with the active profile highlighted.
- BOTTOM-LEFT: Back button + "Restore To Default" button (resets the current tab's settings on the active profile).
- BOTTOM-RIGHT: language selector (EN currently) and software version (v1.2.11 currently).

PROFILES SYSTEM (4 profiles, switchable on the controller without the software running):
- 4 independent profiles labelled 1, 2, 3, 4.
- Each profile saves its own complete configuration: button mappings, macros, stick / trigger / vibration settings, etc.
- ON-CONTROLLER SWITCH: press Back + Right Joystick Up/Down to cycle through profiles.
- HOME LED FEEDBACK: flashes 1, 2, 3, or 4 times to indicate the active profile after a switch.
- Profile switching is hardware-based once profiles are saved; the controller does NOT need a PC connection to switch.

EDITOR TABS — what each tab does:

(1) MAPPINGS — button remapping. Two columns of buttons displayed: source (left) and destination (right), with arrows (>>) between. Visible button rows include: ML, MR, UP, UNDER, LEFT, RIGHT, A, B, X, Y, LB, LT, LSB, RB (and likely more accessible by scrolling). Each row remaps that physical button to a different output. Defaults are 1:1 (each button maps to itself).

(2) MACRO — macro recording. The Ares Pro has 2 macro slots assigned to the back paddle buttons:
  - ML (left back paddle)
  - MR (right back paddle)
  Each macro stores up to 32 events (shown as "0 / 32" when empty). Click "+ Empty" on a slot to enter the recorder. Macros are independent of mapping -- the back paddle still triggers the macro regardless of how it's mapped on the Mappings tab. (Ares Pro has 2 macro slots; Lumora has 4 -- this is a real difference between the products, not a software limitation.)

(3) STICKS — joystick configuration. Per-stick settings (Left Stick / Right Stick selector at the bottom of the middle panel):
  - Deadzone slider — input below this threshold is treated as zero. Default towards the lower end.
  - Anti-Deadzone slider — input above zero but below this threshold is boosted to compensate for in-game deadzones. Useful for games that have their own deadzone applied on top of the controller's.
  - Enable Radial Trace (toggle) — affects the stick's response shape (radial vs squared). Default ON.
  - Output (dropdown) — which on-PC output the stick acts as. Default "Left Stick" for the Left Stick.
  Both sticks are configured independently via the Left Stick / Right Stick selector.

(4) TRIGGERS — trigger configuration. Per-trigger settings (Left Trigger / Right Trigger selector at the bottom of the middle panel):
  - Deadzone slider
  - Anti-Deadzone slider
  Both triggers are configured independently. Trigger range is mostly handled by the physical Trigger Travel switch on the back of the controller (Long/Short); the software adjusts the response curve within whichever physical mode is active.

(5) VIBRATION — vibration intensity per profile.

(6) EXTENDED SETTINGS — currently exposes one setting:
  - Auto-sleep — Off / 5 minutes / 10 minutes / 20 minutes. (Maximum is 20 minutes -- there is no 30-minute or higher option in the current software.)
Default depends on factory setting; most customers will see Off or a short timeout.

(7) FIRMWARE UPDATE — firmware update interface. CONNECTION REQUIREMENT: WIRED USB-C ONLY (NOT 2.4GHz, NOT Bluetooth). The rest of the Ares Pro software (Mappings, Macro, Sticks, Triggers, Vibration, Extended Settings) works in either Wired or 2.4GHz, but firmware update specifically needs the wired cable so the install can complete reliably without RF interference. Connect Ares Pro via USB-C wired, the software detects the current firmware version, offers update if available, and applies it. Do NOT disconnect during update. There is NO separate firmware-updater tool for the current Ares Pro -- the same software handles configuration AND firmware updates. If a customer says the firmware update tab is greyed-out or refusing to start, first confirm they are connected via USB-C, not the 2.4GHz dongle.

GENERAL SOFTWARE NOTES:
- All settings are stored on the CONTROLLER itself (not just in the software), so they persist across PCs and across power cycles. The customer doesn't need to keep the software running for the settings to take effect.
- Profile switching on the controller (Back + Right Joystick Up/Down) works without the software running once profiles are saved.
- Software is WINDOWS ONLY. Do NOT direct macOS / Linux / Android users to a "Mac version" or similar -- none exists.
- Software v1.2.11 (released Jan 2026) added the auto-shutdown adjustment (Extended Settings tab) and updated the on-controller vibration shortcut. If a customer is using an older software version and a feature is missing, suggest updating from the downloaddrivers page.

FIRMWARE UPDATE (current Ares Pro): Done THROUGH the companion software. Connect Ares Pro via USB-C in WIRED mode → power on the controller → open the software → use the firmware update option inside the software → do NOT disconnect during update. There is NO separate firmware-updater tool for the current Ares Pro — the same software handles both configuration and firmware.

LATEST FIRMWARE FEATURES (recent updates):
- New joystick calibration shortcut: Power OFF controller → Press and hold Back + X + Home for 1 second → LEDs flash green and blue + controller vibrates once → Follow on-screen steps → Press Start to confirm → Green LED + vibration = done.
- Joystick mode switching now has clear vibration cues.
- Auto shutdown time can now be adjusted via the software.
- Controller vibration strength shortcut updated to prevent unintended changes during gameplay.

═══

SECTION 2: ARES PRO GEN 1 (no "App Support" label — older model)

═══

This is the older Ares Pro without companion software support. Works fully as a controller but cannot be configured via software. Some Gen 1 units are still in customer hands under warranty.

DIFFERENCES FROM CURRENT ARES PRO:
- NO companion software. All configuration via gamepad button shortcuts (turbo, vibration, macro, RGB) only.
- NO software-only features (no software-based button remapping, no custom DPI/polling adjustment via software, no auto-shutdown time adjustment).
- Polling rate is the SAME as Gen 2 — both Gen 1 and current Ares Pro are 1000Hz. The Gen 1 vs Gen 2 distinction is about COMPANION SOFTWARE SUPPORT, not polling rate. Do NOT tell a Gen 1 customer their polling rate is lower than Gen 2 — that is incorrect.

GEN 1 FIRMWARE UPDATE — MANUAL FILE PATH:
- There is NO companion software for Gen 1, so the standard "update through the software" path does NOT apply.
- Firmware updates for Gen 1 are done MANUALLY via a separate standalone firmware file from thecosmicbyte.com. Customer downloads the firmware file and applies it manually following the instructions on the support page.
- If the customer cannot locate the right firmware file for their model, direct them to support (cc@thecosmicbyte.com or +91 7351615161) — do NOT invent a URL or filename. Support will provide the correct file.
- Do NOT direct Gen 1 customers to the companion software — it does not work for their generation.

═══

COMMON FAILURE MODES TO AVOID (AI-FACING NOTES)

═══

- Do NOT tell a Gen 1 customer (no "App Support" label) to download the companion software. It does not detect or work with their controller.
- Do NOT tell a Gen 2 customer (with "App Support" label) to download a separate standalone firmware file. Their firmware is updated INSIDE the companion software, not as a separate file.
- ALWAYS ask the customer to check the back label for "App Support" text before answering any software, RGB-via-software, or firmware question. This single check disambiguates the two generations.
- Do NOT tell any Ares Pro customer that it works on PlayStation/Xbox/Switch. It is PC-only.
- Do NOT claim the Ares Pro has gyro / motion control of any kind. It does NOT have gyro hardware. The catalogue listing was previously wrong (corrected in v2.19.0); the manual was correct by omission. If a customer asks about gyro / motion / tilt-aim for the Ares Pro, the answer is NO -- redirect them to Lumora / Drakon / Stellaris / Blitz Tri-Mode if gyro matters to them.

═══

LED COLOR INDICATORS:
- Orange LED = X-Input mode (PC).
- Red LED = Direct Input / DInput mode (PC).
- Green LED = Android mode.
- Blue LED = iOS mode.

CONNECTIVITY:
- Wireless Dongle (PC): Plug dongle into PC. Hold HOME for 3 seconds when controller is off. Motor vibrates once, LED blinks, stays solid when connected.
- Wired USB-C: Connect cable. Auto-switches to X-Input mode (Orange LED).
- Bluetooth PC XInput: Hold X + Home for 3 seconds. Orange LED.
- Bluetooth Android: Hold A + Home for 3 seconds. Green LED.
- Bluetooth iOS: Hold B + Home for 3 seconds. Blue LED.
- Switch X-Input/DInput in wireless or wired: Hold Back + Start for 3 seconds. Orange=XInput, Red=DInput.
- No need to switch modes for Android - connection is automatic.
- Windows defaults to X-Input mode.
- Android requires OTG support. Android compatibility not covered under warranty.
- Turn off controller: Hold Back + B for 3 seconds.

TURBO:
- Enable: Press desired button + Turbo.
- Disable: Press same button + Turbo again.
- Adjust speed increase: Turbo + Right Joystick Up (vibrates once).
- Adjust speed decrease: Turbo + Right Joystick Down (vibrates once).
- Supported buttons: A, B, X, Y, L1, L2, R1, R2.

M1/M2 MACRO SETUP:
- To set up: Hold M1/M2 + TURBO simultaneously for 3 seconds. Purple LED starts flashing.
- Press the key to assign (A, B, X, Y, L1, R1, L2, R2, etc.). Cannot assign to Back, Start, Turbo, or Home.

- Press M1/M2 again to save. Controller vibrates once, LED stops flashing.
- To activate: Press M1/M2 during gameplay.
- To cancel: Hold M1/M2 + TURBO for 3 seconds until purple LED flashes. Press M1/M2 once. Vibrates once confirming cancellation.

LED CONTROLS:
- ABXY LED toggle: Press X + Back.
- V LED (V-shape light) toggle: Press A + Back.
- Two independent LED groups.
- If LEDs won't toggle, check if battery is low - charge first.

JOYSTICK AND D-PAD TOGGLE:
- Press L3 + Back to switch between left joystick and D-pad functions.

D-PAD 4-WAY / 8-WAY MODE:
- Toggle: Hold D-pad Up, then press Back button.
- 4-Way: Only pure directional inputs (up/down/left/right). Eliminates diagonal inputs. Best for fighting games.
- 8-Way (default): All 8 directions including diagonals.

JOYSTICK RANGE SELECTION:
- Activate with R3/L3 + Turbo.
- Full Circle (default): Full joystick movement. Medium vibration confirms.
- Small Circle: Reduced range for precision control. Small vibration confirms.
- Square Mode: Square-style input for tight angles. Strong vibration confirms.

JOYSTICK CALIBRATION:
- Power off controller completely.
- Hold Back + X + Home for 1 second. LEDs flash green and blue, vibrates once.
- Rotate both joysticks clockwise 3 times.
- Press both triggers fully 3 times.
- Press Start to finish. Green LED lights up, vibrates once to confirm.

VIBRATION CONTROL (current/Gen 2 with v1.2.11+ software):
- Increase: HOLD R3 + Left Joystick Up for 3 seconds (must hold - not just tap).
- Decrease: HOLD R3 + Left Joystick Down for 3 seconds.
- Updated to prevent accidental changes during gameplay.
- Auto shutdown time can be adjusted via software on Gen 2 only.

HEADSET JACK:
- Works in wireless dongle and wired modes only.
- NOT supported in Bluetooth mode.
- Supports audio output and microphone input.

BATTERY:
- Low battery: LED flashes. Vibration automatically disabled to save power.
- Charging: LED flashes slowly. Fully charged: LED turns off.

POLLING RATE:
- Wired (USB-C): 1000Hz on BOTH Gen 1 and Gen 2.
- 2.4GHz (dongle): 1000Hz on BOTH Gen 1 and Gen 2.
- Bluetooth: 500Hz max on BOTH Gen 1 and Gen 2 (hardware-protocol limit; this is the highest the Bluetooth protocol practically supports for this controller and is NOT a defect). If a customer wants the full 1000Hz polling rate, they need to switch to Wired or 2.4GHz mode -- 1000Hz over Bluetooth is not achievable on this controller.
- Polling rate is the same across both generations on each given connection mode -- the Gen 1 vs Gen 2 distinction (back label "App Support" text present or absent) is about COMPANION SOFTWARE SUPPORT, NOT polling rate. Do not conflate the two.

CRITICAL -- do NOT tell customers the Ares Pro has a "fixed 1000Hz polling rate" or that it "remains constant regardless of connection mode" or that it's "1000Hz across all modes including Bluetooth". All three of those statements are FABRICATIONS that pattern-match to Bug 2 in changelog v1.8.1. Bluetooth polling on the Ares Pro is 500Hz max -- about half the wired/2.4GHz figure -- because of Bluetooth-protocol limitations, not because the controller is defective.

WARRANTY:
- 1 year against manufacturing defects only.
- Physical damage, water damage, tampered products NOT covered.
- Regular wear and tear from battery usage NOT covered (unique to Ares Pro).
- Console use NOT covered.

ARES PRO BACK LABEL — WHAT IS AND ISN'T PRINTED ON IT:

The Ares Pro back label carries ONLY one piece of information that distinguishes a generation: the text "App Support" in the top-left corner.
  - "App Support" text PRESENT → Gen 2 (current). Has companion PC software.
  - "App Support" text ABSENT → Gen 1 (older). No companion software.

The back label DOES NOT contain any of the following:
  - "Hall Effect" or "HE" text
  - "TMR" text
  - Polling rate / Hz markings
  - Sensor model numbers
  - Generation number ("Gen 1" / "Gen 2")

- "1000Hz" or any frequency spec
- "2026" or any year / batch identifier

If a customer wants to verify Hall Effect on the Ares Pro, do NOT tell them to look on the back label for "HE" / "Hall Effect" / "TMR" markings — those are not printed there. Instead:
- Trust the HALL EFFECT QUICK-REFERENCE MATRIX in the system prompt: current 2026-batch Ares Pro (Gen 2 with App Support label) has BOTH Hall Effect joysticks AND Hall Effect analog triggers. This is confirmed by the Cosmic Byte team and is the authoritative answer.
- For software verification, walk them through the gamepad-tester check on https://hardwaretester.com/gamepad: a Hall Effect joystick at rest shows 0–2% circularity error (essentially zero drift at center). A standard joystick shows visibly larger jitter.
- For Gen 1 specifically, the Hall Effect status may differ — if a Gen 1 customer asks, do not assert Gen 1 has Hall Effect; the HE matrix specifically references current 2026-batch / Gen 2 Ares Pro. Ask the customer to share the back label photo or use the software check above to verify.

ANTI-HALLUCINATION GUARD (Ares Pro — read this before answering any back-label / generation / polling-rate / Hall-Effect verification question):

Known hallucinations and KB errors the AI has produced for the Ares Pro — do NOT reproduce any of these, even if a general rule elsewhere in the KB seems to suggest them:

(a) "1000Hz polling rate is not available on Gen 1 / older Ares Pro" -- WRONG. Both Gen 1 and Gen 2 are 1000Hz. The generation distinction is about COMPANION SOFTWARE ("App Support" label), not polling rate. (This used to be an error in the KB itself prior to v1.5.1; if you are reading an older mirror of this content, ignore the "Gen 1 has lower polling rate" claim.)

(b) "Check the back label -- if it says 'Hall Effect' or 'HE' printed there, you have Hall Effect" -- WRONG for Ares Pro. The Ares Pro back label has ONLY the "App Support" text (or its absence). It does NOT have "Hall Effect", "HE", or "TMR" markings anywhere. The general HALL EFFECT VERIFICATION GUIDE in the system prompt covers the back-label check for products whose back labels DO carry HE/TMR text (e.g. Ares Wired, Ares Wireless per their per-product manuals); Ares Pro is NOT one of those products. For Ares Pro, use the HE Quick-Reference Matrix in the system prompt or guide the customer through the software/gamepad-tester check instead.

(c) Telling a Gen 1 customer their joystick technology, polling rate, or RGB capabilities are inferior because they don't have App Support -- INCOMPLETE / MISLEADING. App Support is about companion-software access, not hardware. Gen 1 controllers lack software-driven configuration, but their hardware specs (polling rate, joystick tech where matrix applies) are not automatically downgraded. State only what is confirmed: Gen 1 has no companion software; everything else (HE on joysticks/triggers, exact battery, exact RGB capability) needs to be verified per case rather than asserted.

(d) Inferring information from the back label that isn't there -- the back label is a binary "App Support yes/no" check, NOT a feature spec sheet. If a customer asks "does my back label confirm X?", and X is anything other than "App Support text", the honest answer is "the back label only confirms whether you have Gen 1 or Gen 2 (App Support text presence/absence) -- it does not confirm . To verify , here's a different check: ...".

(e) "The Ares Pro has a fixed 1000Hz polling rate -- it does NOT fluctuate. This is consistent and stable whether you're using Wired USB-C, 2.4GHz wireless dongle, or Bluetooth mode" / "The polling rate remains constant regardless of connection mode" -- WRONG. The 1000Hz figure applies to Wired and 2.4GHz only. Bluetooth polling on every Cosmic Byte tri-mode controller (and on consumer gamepads in general) is hardware-limited LOWER than 1000Hz by the Bluetooth protocol itself. Do not state "fixed 1000Hz across all modes" or "polling rate remains constant" or "1000Hz in Bluetooth mode" -- all three are fabrications. State per-mode polling rates explicitly per the POLLING RATE section above; for Bluetooth specifically, route the customer to CB support if they need the precise figure.

(f) Extrapolating per-connection-mode behaviour from a non-mode-specific KB statement -- WRONG. If the KB describes a feature or spec without specifying which connection modes it applies to, the AI must NOT assume it applies to all three modes (Wired, 2.4GHz, Bluetooth) automatically. Tri-mode controllers commonly have different specs per connection mode (firmware update only on wired, Bluetooth lower polling rate, software detection not over Bluetooth, etc.). When the per-mode answer is not explicit in the KB, state what IS known and ask the customer to confirm their connection mode rather than asserting a blanket value.

GENERAL GUIDANCE FOR VAGUE ARES PRO QUESTIONS:
If a customer's message is just "Ares Pro" or a single-word product reference with no specific question, DO NOT assume they are asking about polling rate, Hall Effect, software, or any specific topic. ASK what they need help with -- pairing, software, RGB, charging, drift, calibration, etc. -- before launching into a how-to. Volunteering an unrequested technical breakdown is the exact context where the AI is most likely to hallucinate or propagate an out-of-date KB claim.

Ares Tri-Mode

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-ares-tri-mode-wireless-bluetooth-wired-controller-hall-effect-joystick/

COSMIC BYTE ARES TRI-MODE CONTROLLER - FULL MANUAL

CUSTOMER-FACING NAME: The customer's controller is branded "Ares Tri-Mode" on thecosmicbyte.com (URL slug: cosmic-byte-ares-tri-mode-wireless-bluetooth-wired-controller-hall-effect-joystick). The dropdown product entry is "Ares Tri-Mode". In replies use "Ares Tri-Mode" or "your Ares Tri-Mode" — do NOT abbreviate to just "Ares" (ambiguous given the four-SKU Ares lineup: Ares Wired, Ares Wireless, Ares Tri-Mode, Ares Pro). Do NOT call this product "Tri-Mode Ares" or "the new 2026 Ares" — the official SKU name is "Ares Tri-Mode".

JOYSTICKS: Hall Effect — drift-resistant magnetic-sensor sticks. Per Cosmic Byte, ALL four current-generation Ares controllers (Ares Wired, Ares Wireless, Ares Tri-Mode, Ares Pro) have Hall Effect joysticks on their current 2026 batches. The Ares Tri-Mode is a 2026 SKU; there is NO older "non-Hall-Effect" batch of the Ares Tri-Mode specifically. The dual-batch (2026 Hall Effect vs older standard joysticks) only applies to Ares Wired and Ares Wireless — see their separate entries. If a customer asks whether the Ares Tri-Mode has Hall Effect joysticks, the answer is YES.

TRIGGERS: Hall Effect (analog). Both LT and RT use the same drift-resistant magnetic-sensor tech as the joysticks. If a customer asks whether the Ares Tri-Mode has Hall Effect triggers, the answer is YES.

GYRO: NONE. The Ares Tri-Mode does NOT have a gyro / motion sensor. This is a HARDWARE FACT — there is no gyro chip in the controller, so gyro / motion-aim cannot be enabled on any platform (PC, Android, iOS). If a customer asks about gyro / motion control / tilt-aim for the Ares Tri-Mode, the answer is NO, full stop. If gyro matters to them, recommend Lumora, Drakon, Stellaris, Blitz Tri-Mode, or Eclipse (BT mode only) — all of which have gyro hardware.

MACROS: NONE. The Ares Tri-Mode does NOT have macro buttons (no M1/M2/M3/M4) and no macro recording feature. Only TURBO and AUTO TURBO functions exist (see TURBO section below). If a customer asks about macros / programmable back buttons / button recording for the Ares Tri-Mode, the answer is NO. If macros matter, recommend Lumora (4 macros), Starforge (4 macros via M1-M4), Drakon (2 macros ML/MR), or Quantum (2 macros ML/MR).

RGB: NONE customizable. The controller has ABXY button LEDs and a mode-indicator LED only (Orange/Red/Green/Blue for the four modes). No RGB zones, no software-controlled lights, no breathing/rainbow effects. The ABXY LEDs can be toggled on/off (X + Back) but cannot be colour-customized. If a customer asks about RGB customization / lighting effects / colour control for the Ares Tri-Mode, the answer is NO.

PACKAGE CONTENTS:
- Ares Tri-Mode Controller
- 2.4GHz USB Dongle
- USB Type-C Cable
- User Manual

CONNECTIVITY (three modes — confirmed by the manual title "Tri Mode Controller"):
- 2.4GHz Wireless (recommended for PC): plug the 2.4GHz USB dongle into the PC. Hold the Home button for 3 seconds to power on the controller. Controller vibrates once and LED blinks. When connected, LED stays solid. Ensure a clear line of sight between controller and dongle for optimal connectivity.
- Wired (USB Type-C, PC only): connect the controller to the PC via the USB Type-C cable. Windows auto-detects and installs drivers. No additional setup.
- Bluetooth 5.0: pairing combo varies by target device:
  * PC (XInput via Bluetooth): hold X + Home for 3 seconds. Orange LED = pairing mode.
  * Android (with OTG): hold A + Home for 3 seconds. Green LED = pairing mode.
  * iOS (MFI-supported games only): hold B + Home for 3 seconds. Blue LED = pairing mode.

LED MODE INDICATORS:
- Orange LED solid = XInput mode (PC default).
- Red LED solid = DirectInput mode (PC).
- Green LED solid = Android mode.
- Blue LED solid = iOS mode.
- LED slow blink = charging.
- LED off (after being on) = fully charged.
- LED slow flash (irregular) = low battery warning.

PLATFORM COMPATIBILITY:
- PC (Windows): primary platform, full support across all three modes.
- Android: limited support; requires OTG cable for wired or 2.4GHz dongle use. Bluetooth 5.0 also supported. Android compatibility issues are NOT covered under warranty.
- iOS: Bluetooth only; supports MFI-enabled games only. iOS compatibility issues are NOT covered under warranty.
- NOT compatible with PlayStation, Xbox, Nintendo Switch, or any console. No warranty or support for console usage.

XINPUT / DIRECTINPUT SWITCHING (PC only, 2.4GHz dongle or wired mode):
- Press Back + Start together for 3 seconds. Orange LED = XInput, Red LED = DirectInput. Always relaunch the game after switching modes.

4-WAY / 8-WAY D-PAD TOGGLE:
- Press and hold Up D-pad, then press the Back button.

JOYSTICK / D-PAD SWAP:
- Press L3 + Back to toggle the left joystick and the D-pad's functions. Press the same combo again to restore.

TURBO FUNCTION:
- Set Turbo: hold the desired button (A, B, X, Y, L1, L2, R1, R2), then press the Turbo button. The held button now turbo-fires on press.

- Cancel Turbo: repeat the same procedure (hold the same button + press Turbo).
- Set Auto Turbo: hold the desired button, then press the Auto button. The held button now auto-fires continuously.
- Cancel Auto Turbo: repeat the same procedure.
- Adjust Turbo Speed: hold Turbo + Right Joystick Up (increase) or Turbo + Right Joystick Down (decrease).
- Turbo and Auto Turbo are customizable on all main action buttons (A/B/X/Y/L1/L2/R1/R2). D-pad and joystick clicks (L3/R3) are NOT supported for Turbo.

VIBRATION:
- Enable / disable vibration: press A + Back. The vibration LED toggles to reflect the current state.
- Increase vibration intensity: press R3 + Left Joystick Up.
- Decrease vibration intensity: press R3 + Left Joystick Down.
- The controller automatically disables vibration when battery is critically low (to save power).
- IMPORTANT — VIBRATION PLATFORM SUPPORT: Vibration works on PC (XInput mode) only. Android and iOS do NOT support vibration on this controller. Game support is also required — even on PC, the game must implement rumble for vibration to function.

ABXY LED CONTROL:
- Turn the ABXY button LEDs on / off: press X + Back.

POWER OFF:
- Hold B + Back for 3 seconds. Controller powers off.

RESET:
- Use a thin pin to press the reset pin-hole on the back of the controller. Re-pair the controller after reset.

BATTERY & CHARGING:
- Charge via the USB Type-C cable plugged into a PC USB port or a standard USB source. Do not use a wall adapter — use a PC USB port or a standard USB source.
- LED slowly blinks while charging.
- Fully charged: LED turns off.
- Low battery warning: LED slowly flashes.
- Battery voltage: 3.7V - 4.2V.
- Vibration auto-disables at critically low battery.

TECHNICAL SPECIFICATIONS (from the manual):
- Polling Rate: 1000Hz.
- Working Current: <150mA.
- Working Distance (2.4GHz / Bluetooth): 8-10 metres.
- Operating Temperature: -10°C to +60°C.
- Humidity tolerance: 20% to 80%.
- Weight: 210g.
- Dimensions: 156mm x 105mm x 60mm.
- Interface: USB 2.0 / 3.0.

TROUBLESHOOTING (from the manual's Q&A section):
- Controller not turning on: charge the battery, then hold Home for 3 seconds.
- Controller won't connect: verify it's in the correct mode (LED colour matches the target device — Orange/Red for PC, Green for Android, Blue for iOS), restart the pairing process, ensure the dongle or Bluetooth on the device is active and functioning.
- Connected to PC but not responding: try switching between XInput and DirectInput (Back + Start for 3 seconds). Ensure Windows has finished installing drivers.
- Controller keeps disconnecting: ensure a clear line of sight between controller and the 2.4GHz dongle, recharge the battery, avoid interference from nearby wireless devices (other 2.4GHz peripherals, microwave ovens, etc.).
- Some buttons not responding: use the reset pin-hole on the back of the controller to reset it. Ensure the connection is solid.
- Vibration not working: confirm it's enabled (A + Back), check battery level (vibration auto-disables on low battery), confirm the game supports rumble. Android and iOS do NOT support vibration on this controller.
- Turbo function not working: reconfirm the setup procedure (hold the button + press Turbo, or hold the button + press Auto for Auto Turbo).
- Not pairing with Android: confirm the pairing combo (A + Home for 3 seconds, Green LED). Ensure the Android device supports OTG (required for wired or dongle mode).
- Not pairing with iOS: confirm the pairing combo (B + Home for 3 seconds, Blue LED). Ensure the iOS game supports MFI controllers.

JOYSTICK DRIFT:
- The Ares Tri-Mode has Hall Effect joysticks (drift-resistant by design). Drift on a Hall Effect Ares Tri-Mode MAY indicate a manufacturing defect — covered under standard 1-year warranty per rule #11 (raise-a-ticket flow) and rule #11a (seller-agnostic — covers Flipkart / Amazon / Croma / etc. purchases too). Customer needs to provide BOTH invoice (from any authorized seller) AND the controller's serial number.
- Do NOT assume wear-and-tear and decline warranty. The wear-and-tear disclaimer applies to the OLDER non-Hall-Effect Ares Wired / Ares Wireless 2025-and-earlier batches — NOT to the Ares Tri-Mode (which is a 2026 SKU with HE joysticks).

WARRANTY:
- 1 year against manufacturing defects only.
- Physical damage, water damage, and tampered / modified products NOT covered.
- Console use NOT covered.
- Android / iOS compatibility issues NOT covered (per the manual's IMPORTANT DISCLAIMER section).
- For warranty claim path, see rule #11 (raise-a-ticket) and rule #11a (seller-agnostic warranty — Flipkart / Amazon / Croma / Reliance Digital / etc. all covered, CB handles directly).

SUPPORT:
- Customer Care Phone: +91 7351615161 (Mon-Sat 10am-6pm).
- WhatsApp Support: +91 7351615161.

- Email: cc@thecosmicbyte.com.
- Raise a Ticket: https://www.thecosmicbyte.com/raise-a-ticket/.

ANTI-HALLUCINATION GUARD (Ares Tri-Mode — read before answering)

✗ WHAT THE ARES TRI-MODE DOES *NOT* HAVE — do not invent these:
✗ NO macros / programmable back buttons / M1 / M2 / M3 / M4. Only Turbo and Auto Turbo exist. If you find yourself describing macro recording for the Ares Tri-Mode, stop — that's a hallucination borrowed from Starforge / Lumora / Drakon.
✗ NO gyro / motion sensor / tilt-aim. Hardware fact — no gyro chip exists. Do NOT say "gyro works on PC but not iPad" — there is no gyro hardware on any platform.
✗ NO RGB customization, no RGB zones, no breathing/rainbow effects, no software-controlled lighting. Only the ABXY button LEDs (toggleable on/off) and the mode-indicator LED (Orange/Red/Green/Blue). Do NOT describe RGB customization for the Ares Tri-Mode.
✗ NO TMR joysticks. The Ares Tri-Mode has Hall Effect joysticks, not TMR. TMR is on Stellaris 2nd Gen, Blitz Tri-Mode, Drakon, Eclipse, and Starforge.
✗ NO console support. Not compatible with PS4, PS5, Xbox, Nintendo Switch, or any console. PC-only (with limited Android / iOS Bluetooth support). Do NOT recommend it for console gaming.
✗ NO companion PC software / no app for RGB / no firmware-updater app. Configuration is via on-controller button combos only. The Key Linker mobile app is for OTHER CB controllers (Eclipse, Starforge, Stellaris Gen 1) — NOT the Ares Tri-Mode.
✗ NO older 125Hz wired-only batch of the Ares Tri-Mode. The Ares Tri-Mode is a 2026 SKU only. The 125Hz wired-only / standard-joystick dual-batch issue applies to Ares Wired and Ares Wireless (separate SKUs with their own entries). Do NOT carry the dual-batch ASK-FIRST framing into Ares Tri-Mode replies.

✓ WHAT THE ARES TRI-MODE *DOES* HAVE — confidently affirm these:
✓ Hall Effect joysticks AND Hall Effect analog triggers — both confirmed.
✓ Tri-mode connectivity: 2.4GHz dongle (PC) + Bluetooth 5.0 (PC/Android/iOS) + USB-C wired (PC). All confirmed by manual title and Product Overview section.
✓ 1000Hz polling rate. Confirmed in Technical Specifications.
✓ XInput / DirectInput switching on PC via Back + Start (3 seconds). Always relaunch the game after.
✓ Turbo and Auto Turbo on A/B/X/Y/L1/L2/R1/R2. Speed adjustable with Turbo + Right Joystick Up/Down.
✓ Vibration on PC XInput only — adjustable intensity via R3 + Left Joystick Up/Down. Enable/disable via A + Back. NOT on Android/iOS.
✓ 4-way / 8-way D-pad toggle (Up + Back). Left-Joystick / D-pad swap (L3 + Back).
✓ 8-10m wireless range. 210g weight. USB-C charging from PC USB port.
✓ 1-year manufacturing-defect warranty. CB handles warranty directly regardless of authorized seller (Flipkart, Amazon, Croma, Reliance Digital, etc. — per rule #11a). Both invoice and serial number required.

✓ VAGUE QUESTION GUIDANCE: If a customer's message is just "Ares" (without specifying Tri-Mode, Pro, Wired, or Wireless), ASK them which Ares variant they have BEFORE answering — there are four distinct SKUs in the Ares family with materially different specs. Example: "Which Ares are you using — Ares Tri-Mode, Ares Pro, Ares Wired, or Ares Wireless? They have different connectivity and features, so the answer depends on the model." Once they confirm, proceed with the relevant entry's content.

Ares Wired

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-ares-wireless-controller-for-pc/

COSMIC BYTE ARES WIRED - USB WIRED CONTROLLER - FULL MANUAL

==========

ASK-FIRST GUIDANCE: TWO batches exist — current 2026 and older.

==========

- 2026 BATCH (current): Hall Effect joysticks AND Hall Effect analog triggers. Drift-resistant by design.
- OLDER BATCH: Standard joysticks and standard triggers (not Hall Effect). Drift from wear is NOT covered under warranty for older batch.

How to identify: 2026 batch back label / packaging mentions "Hall Effect". Older batch does not. If a customer reports joystick drift, ask which batch they have BEFORE answering — drift on 2026 batch may be a manufacturing defect (covered), drift on older batch is wear and tear (not covered). Do not promise warranty coverage without identifying the batch.

CONNECTIVITY:
- USB wired only. No wireless or Bluetooth support.
- Plug into PC USB port - recommend rear USB port on desktop for stable power.
- Plug and Play on Windows 8, 10, and 11. Windows 7 may need manual setup.
- Auto-detects in XInput mode (Blue LED) by default.
- Android: connect via OTG. LED turns Green for Android mode. Android use not covered under warranty.
- NOT compatible with any gaming console.

LED INDICATORS:
- Blue LED = XInput mode (default, PC).
- Red LED = DirectInput mode.
- Yellow LED = PC Analog mode.
- Green LED = Android mode.

SWITCHING INPUT MODES:
- Hold the HOME button for 5 seconds to toggle between XInput and DirectInput.
- Old games need DirectInput (Red LED). Modern games use XInput (Blue LED).
- Always relaunch game after switching.

TURBO & AUTO TURBO:
- Turbo (fires fast while button held): press desired button + Turbo button.
- Auto Turbo (fires continuously without holding): press desired button + AUTO button.
- Cancel Turbo: repeat same button + Turbo combo.
- Supported buttons: A, B, X, Y, L1, L2, R1, R2.
- Auto-firing button fix: press that button + Turbo to cancel.

LED CONTROLS:
- ABXY LED toggle: press X + Back.
- V LED (centre V-shaped strip) toggle: press A + Back.
- Both groups are independent toggles.

JOYSTICK & D-PAD SWAP:
- Press L3 + Back to swap left joystick and D-pad functions. Toggle to restore.

HALL EFFECT JOYSTICKS (2026 BATCH):
- 2026 manufacturing batch has Hall Effect joysticks AND Hall Effect analog triggers.
- Hall Effect = magnetic sensors, drift-resistant, no physical wear.
- Older models have standard joysticks - drift from wear is NOT covered under warranty.
- No upgrade path available.

RESET / FACTORY RESET:
- The Ares Wired has NO BUTTON-COMBO RESET PROCEDURE. There is no documented "hold HOME for X seconds", no "press SELECT + START + L3 + R3", no on-controller key sequence that resets the device. This is by design, not an oversight in the manual.
- The CORRECT reset procedure is simple physical power cycling: UNPLUG the USB-A cable from the PC, wait a couple of seconds, then plug it back in. That's the complete procedure — single action.
- Why this works (and why no button combo exists): the Ares Wired has NO BATTERY. The controller is powered entirely through the USB-A cable from the host PC. When the cable is unplugged, the controller has zero power source — all volatile state clears instantly. Reconnecting the cable boots the controller fresh from a cold-start state. This is functionally equivalent to a factory reset for the controller's runtime state. A button-combo reset would be redundant on a controller that goes fully cold the moment the cable comes out.
- What this reset DOES affect: any current input-mode setting (X-Input vs D-Input) reverts to the controller's default boot mode on

reconnect; any LED toggle state (ABXY LED on/off, V LED on/off) resets to default; any active joystick / D-pad swap reverts to default.
- What this reset DOES NOT affect: nothing persistent — because there IS nothing persistent. The Ares Wired has no firmware-modifiable settings, no companion software, no stored profiles, no battery-backed memory. Every USB connect is effectively a fresh boot.

✗ DO NOT SAY about Ares Wired reset:
- "Hold the HOME button for X seconds to reset" -- WRONG, no such procedure exists on the Ares Wired.
- "Press SELECT + START + L3 + R3 to factory reset" -- WRONG, no such combo, this is a fabrication pattern from controllers with battery-backed memory.
- "Use the Cosmic Byte software to reset" -- WRONG, the Ares Wired has no companion software at all (no profiles, no firmware update tool, no mappings UI — software-related answers belong on Lumora, Blitz Tri-Mode, Drakon, or Stellaris Gen 2, NOT on the Ares Wired).
- "Press the rear RESET button / pin into the RESET hole" -- WRONG, there is no physical RESET button or pinhole on the Ares Wired. (Stellaris Gen 2 has a rear RESET button next to its USB-C port, but the Ares Wired is a different controller with different hardware.)
- Any button-combo reset procedure -- WRONG. The only reset on the Ares Wired is to physically unplug the USB-A cable from the PC and reconnect it. The "no battery" hardware design makes the cable itself the reset mechanism.

✓ CORRECT FRAMING when a customer asks "how do I reset my Ares Wired":
"The Ares Wired doesn't have a button-combo reset procedure — but it doesn't need one. Because the controller has no battery (it's USB-powered only), unplugging the USB-A cable from your PC cuts power completely and resets the controller's state instantly. To reset: just unplug the USB cable, wait a couple of seconds, then plug it back in. The controller will boot fresh — same effect as a factory reset on a controller that has battery + a hold-button-to-reset procedure. If you had any runtime issue like a stuck input mode, an LED state stuck on/off, or a joystick/D-pad swap that won't clear, this will restore everything to default."

TROUBLESHOOTING:
- Not detected: try different USB port, avoid USB hubs, restart PC.
- Buttons unresponsive: switch input mode (HOME 5s), test in joy.cpl, reconnect, restart PC.
- Joystick drift: recalibrate via Windows Control Panel -> Game Controllers. 2026 batch drift = possible manufacturing defect. Older batch drift = wear and tear, not covered.

WARRANTY:
- 1 year against manufacturing defects only.
- Physical damage, water damage, tampered products NOT covered.
- Regular wear and tear (including joystick drift on older models) NOT covered.
- Console use NOT covered.

Ares Wireless

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-ares-wireless-controller-for-pc/

COSMIC BYTE ARES WIRELESS - 2.4GHz WIRELESS CONTROLLER - FULL MANUAL

═══════════════════════════════════════

ASK-FIRST GUIDANCE: TWO batches exist — current 2026 and older.

═══════════════════════════════════════

- 2026 BATCH (current): Hall Effect joysticks AND Hall Effect analog triggers. Drift-resistant.
- OLDER BATCH: Standard joysticks and standard triggers (not Hall Effect). Drift from wear is NOT covered under warranty for older batch.

How to identify: 2026 batch back label / packaging mentions "Hall Effect". If a customer reports joystick drift, ask which batch they have BEFORE answering — drift on 2026 batch may be a manufacturing defect (covered), drift on older batch is wear and tear (not covered). Do not promise warranty coverage without identifying the batch.

CONNECTIVITY:
- 2.4GHz wireless via USB dongle. PC only. No Bluetooth.
- Insert USB receiver into PC. Press HOME button to power on - auto-connects in XInput mode (Blue LED solid).
- Plug and Play - no drivers needed.
- Re-pairing (if both controller and dongle LEDs blink): plug receiver into PC, press HOME, then press HOME twice quickly (double-press) - LEDs stop blinking = paired.
- Android: connect dongle via OTG adapter. Not covered under warranty.
- NOT compatible with any gaming console.
- Range: up to 8 metres. Clear line of sight recommended.

LED INDICATORS:
- Blue LED = XInput mode (default, PC). Blue ALSO indicates Android mode on this SKU (see next line).
- Red LED = DirectInput mode.
- Yellow LED = PC Analog mode.
- Android mode = Blue LED (NOT green). Corrected 2026-05-20: the Ares Wireless shows BLUE in Android mode — the SAME colour as XInput. There is NO green Android indicator on the Ares Wireless. Because Blue covers both XInput and Android, the colour alone does not distinguish them — tell them apart by the host (connected to a PC = XInput; connected to Android via OTG = Android mode).
- LEDs blinking = connecting / needs pairing.
- LED solid = connected.
- LED flashes + vibration disabled = low battery.
- LED blinks slowly = charging.
- LED turns OFF = fully charged.

SWITCHING INPUT MODES:
- Hold HOME button for 5 seconds to toggle XInput ↔ DirectInput.
- Old games need DirectInput (Red LED). Always relaunch game after switching.

POWERING OFF:
- Hold B + Back button for 5 seconds to power off. Press HOME to power on.
- Always power off when not in use to conserve battery.

CHARGING:
- Use 5V/1A charger or standard PC USB port ONLY.
- Fast chargers (e.g. 65W) are NOT supported - damages battery and voids warranty.
- Charging: LED blinks slowly. Fully charged: LED turns off.

TURBO & AUTO TURBO:
- Turbo (fires fast while button held): press desired button + Turbo.
- Auto Turbo (fires continuously): press desired button + AUTO.
- Cancel: repeat same combo.
- Supported: A, B, X, Y, L1, L2, R1, R2.

LED CONTROLS:
- ABXY LED toggle: press X + Back.
- V LED toggle: press A + Back. Both are independent.

HALL EFFECT (2026 BATCH):
- 2026 batch has Hall Effect joysticks AND Hall Effect analog triggers.
- Drift-resistant by design. No upgrade path for older models.
- Drift on older models from wear is NOT covered under warranty.

DISCONNECTIONS:
- Move dongle to front USB port or use USB extension for better line of sight.
- Keep away from Wi-Fi routers and USB 3.0 devices (2.4GHz interference).
- Replace/charge battery even if LEDs appear lit.
- Double-press HOME to re-pair if disconnected.

WARRANTY:
- 1 year against manufacturing defects only.
- Physical damage, water damage, tampered or modified products NOT covered.

- Battery wear and tear NOT covered.
- Joystick drift on older batch (no Hall Effect) is wear and tear, NOT covered. Drift on 2026 Hall Effect batch may be a manufacturing defect — depends on circumstances.
- Console use NOT covered.
- To claim warranty: visit thecosmicbyte.com/raise-a-ticket/ or email cc@thecosmicbyte.com with proof of purchase and description of the issue.
- Support: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm.

DONGLE / WIRELESS DISCONNECT — CLARIFY THE QUESTION FIRST:

When a customer asks "how to disconnect the dongle from the controller" / "how to unpair the dongle" / "how to disconnect from 2.4GHz" / similar, the question is genuinely ambiguous. There are three possible interpretations and the answer differs for each. ASK the customer which interpretation they mean BEFORE giving any procedure -- do NOT pick one and run with it.

Interpretation (i) — PHYSICALLY UNPLUG THE DONGLE: this is the typical / literal reading. The dongle is a USB stick. To "disconnect" it, the customer just pulls it out of whatever USB port it's plugged into. No button combo, no software, no on-controller procedure needed. The controller will simply have no 2.4GHz partner once the dongle is unplugged. If the customer then plugs the dongle back in (or into a different USB port on the same PC), the existing pairing is remembered and the controller reconnects automatically -- the dongle and controller are factory-paired and the pairing memory persists across power cycles, USB unplug/replug, and PC reboots.

Interpretation (ii) — UNPAIR / FORGET THE PAIRING: stop the controller from being paired with this specific dongle so it can be paired with a different dongle. There is NO documented user-accessible procedure for this on Ares Wireless. The pairing memory is tied to the factory-set dongle pair and is not resettable from the controller via any button combo. If the customer has a legitimate need to do this (e.g. lost original dongle, dongle stopped working and needs replacement), the right answer is to contact Cosmic Byte support for a replacement-and-re-pair process -- not a self-serve procedure.

Interpretation (iii) — SWITCH CONNECTION MODE: change from 2.4GHz to wired or Bluetooth. The Ares Wireless does NOT support this -- it is 2.4GHz-only with no wired and no Bluetooth (see KEY FEATURES at the top of this entry). If a customer asks about switching modes for an Ares Wireless, they may actually have a TRI-MODE variant (Ares Tri-Mode or Ares Pro) -- ASK them to confirm the exact model before answering. A Tri-Mode variant has a physical mode-switch slider on the back of the controller for switching modes -- no button combo on the front.

Suggested clarifying question to the customer: "Just to make sure I give you the right steps -- are you trying to:
(a) Just physically remove the dongle from the USB port?
(b) Pair the controller with a different dongle?
(c) Switch to wired or Bluetooth mode?
The answer is different for each, so I want to make sure I help you with the right one."

ANTI-HALLUCINATION GUARD (Ares Wireless — read this before answering any dongle / pairing / disconnect / unpair question):

Known hallucinations the AI has produced for the Ares Wireless dongle disconnect question -- do NOT reproduce any of these, even if they sound like a plausible button combo:

(a) "Hold Turbo + Back for 3 seconds on the controller. This will unpair the dongle from the controller. The LED should blink to indicate the disconnect." -- WRONG. There is no documented Turbo + Back combo for any Ares variant. There is no on-controller unpair procedure. There is no LED disconnect indicator. All three claims are fabricated.

(b) "To Re-pair Later: Hold Turbo + Home for 3 seconds on the controller. The LED will blink -- it's searching for the dongle. Once paired, the LED stabilizes." -- WRONG. The actual re-pair procedure on Ares Wireless is HOME button DOUBLE-PRESS (per the existing pairing section above in this entry) -- not a Turbo + Home hold. Do not invent a Turbo-prefixed combo for re-pairing.

(c) Inventing other button combos for unpair / disconnect / switch like "Hold M + Back", "Hold Home for 5 seconds", "Press the pairing button twice", "Hold A + B + Home for 3 seconds" -- WRONG unless explicitly documented in the manual entry above. Default to "physically unplug the dongle" for the disconnect interpretation, "contact support" for the swap-to-different-dongle interpretation, and "Ares Wireless doesn't support that, please confirm your exact model" for the switch-modes interpretation.

(d) Inventing a "TV setup" framing when the customer hasn't mentioned a TV -- WRONG. The Ares Wireless is documented as PC-only with optional Android via OTG. If the customer mentions a TV, ask whether their TV / streaming device has a USB-A port and whether it's been recognised; do NOT assume the TV use case is supported or fabricate TV-specific instructions.

(e) "Hold Turbo + Home for 3 seconds to cycle between XInput and DirectInput modes" -- WRONG. Turbo + Home is not a documented combo for any Ares variant. The correct XInput / DirectInput toggle DIFFERS BY SKU:
* Ares Wired AND Ares Wireless (per the manuals — same combo on both):
Hold the HOME button for 5 seconds. LED colour changes: Blue = XInput, Red = DirectInput, Yellow = PC Analog. On the Ares Wireless, Android mode ALSO shows BLUE (auto-detected via OTG; corrected 2026-05-20 — NOT green). (The Ares Wired's LED scheme is documented in the Ares Wired entry.)
* Ares Tri-Mode (different combo — confirmed by the Ares Tri-Mode manual):
Press Back + Start together for 3 seconds. LED colour changes: Orange = XInput, Red = DirectInput, Green = Android, Blue = iOS.
* Ares Pro: granular per-mode table — the combo depends on connection mode (Wired / 2.4GHz / Bluetooth) AND platform (PC / Android). See the Ares Pro entry's modes table.
If you find yourself writing "Turbo + Home" or "Hold X + Y for 3 seconds" as a mode-switch combo for an Ares Wireless or Ares Wired, stop — that's a hallucination. The correct answer is HOME 5 seconds for both.

(f) "Orange LED = XInput mode" for an Ares Wireless or Ares Wired -- WRONG colour. Orange = XInput is the Ares TRI-MODE LED scheme (a different SKU). The LED colour scheme on the Ares Wireless per its manual is (the Ares Wired is documented in its own entry):
* BLUE LED solid = XInput mode (default on PC) — and ALSO Android mode (Blue is shared on the Ares Wireless; corrected 2026-05-20, was previously mis-documented as green).
* Red LED solid = DirectInput mode.
* Yellow LED solid = PC Analog mode (a separate state — NOT XInput).
* There is NO green Android indicator on the Ares Wireless — Android shows BLUE.
If a customer with an Ares Wireless reports their LED is "yellow" and asks if that's XInput, the answer is NO — yellow is PC Analog, not XInput. To

switch them to XInput, they hold HOME for 5 seconds until the LED turns Blue.
    DO NOT borrow LED colours from the Ares Tri-Mode (Orange / Red / Green / Blue for XInput / DInput / Android / iOS) when answering an Ares Wireless or Ares Wired question — those are different SKUs with different LED schemes.

(g) Blindly accepting a customer-stated framing that is internally inconsistent with their product -- WRONG. The Ares Wireless is 2.4GHz-only with no wired mode. If a customer asks about "switching modes via wired USB cable" while their session is identified as Ares Wireless, do NOT just go with the wired framing -- the customer most likely has a different Ares variant (Ares Tri-Mode, Ares Pro). ASK which variant before generating any procedure. This is a specific instance of the general rule (#14) in the SYSTEM_PROMPT: when a customer's stated framing contradicts the product they appear to have, clarify before procedure.

(h) CORRECTION (2026-05-20, operator-reported): On the ARES WIRELESS the Android-mode LED is BLUE, NOT green. The KB previously stated "Green = Android" for this SKU — that was WRONG and has been corrected throughout this entry. On the Ares Wireless, BLUE now indicates BOTH XInput (PC default) and Android (via OTG). Consequences for answering:
    * NEVER tell an Ares Wireless customer the LED is green in Android mode. There is no green state on this SKU.
    * If an Ares Wireless customer says "my LED is blue," do NOT assume it must be XInput — on this SKU blue is shown for BOTH XInput and Android. Distinguish by the host: connected to a PC = XInput; connected to an Android device via OTG = Android mode. If unsure, ask what they have it plugged into.
    * This correction applies to the ARES WIRELESS ONLY. The Ares TRI-MODE legitimately uses Green = Android (different SKU) — do NOT "correct" the Tri-Mode. The Ares WIRED entry still documents Green = Android per its own manual; do not change it based on this Ares Wireless correction.

GENERAL GUIDANCE FOR VAGUE ARES DONGLE QUESTIONS:
If a customer's message is ambiguous about disconnect / unpair / switch (as it almost always is -- "disconnect" can mean unplug, unpair, or mode-switch), DO NOT pick one interpretation and generate a procedure. ASK the clarifying question above. Volunteering an unrequested multi-step procedure is the exact context where the AI is most likely to hallucinate, and where a fabrication is most likely to send the customer down a useless rabbit hole.

Artemis

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-artemis-68-key-per-key-rgb-mechanical-gaming-keyboard/

COSMIC BYTE ARTEMIS — WIRED 68-KEY MECHANICAL KEYBOARD

⚠️ DISAMBIGUATION — TWO DIFFERENT ARTEMIS KEYBOARDS EXIST:
- "Artemis" (THIS entry) = WIRED-ONLY 68-key mechanical. No battery, no wireless.
- "Artemis Wireless" (CB-GK-40) = TRI-MODE (2.4GHz dongle / Bluetooth ×3 / wired USB-C), 2500mAh battery — a SEPARATE product with its own KB entry.
If the customer mentions ANY of: wireless, Bluetooth, 2.4GHz, dongle, tri-mode, battery/charging, range/dropout, or calls it "Artemis 3" / "Artemis Tri-Mode" — they have the Artemis Wireless (CB-GK-40). Use the "Artemis Wireless" entry, and do NOT tell them their keyboard is wired-only. Both are Outemu Blue MECHANICAL swappable-switch boards (neither is optical).

WIRED ONLY. No wireless, no battery. 68-key compact layout. Outemu swappable switches. Per-key RGB with software customization.

SPECS: 68 keys, US layout. Outemu swappable switches, 50M keystrokes. 1.7m PVC USB-C cable. 292x102x40mm, 560g. Software: Windows and Mac (basic use). Keycaps: Injection molded double-shot. All key anti-ghosting. Win-Key lock available.

SOFTWARE WARNING: ALWAYS download software from thecosmicbyte.com ONLY. Do NOT use old software from other download links — it can force an older firmware and cause LEDs to stop working. The 2025 updated software auto-detects the keyboard RGB generation and prompts for upgrade. If LED issues occur due to wrong firmware, contact cc@thecosmicbyte.com for the correct firmware fix.

WHAT'S IN THE BOX: Keyboard, USB-C cable, keycap puller, switch puller, 2 extra switches, user manual.

FN KEY SHORTCUTS:
- FN + 1 to 9: F1-F9 | FN + 0: F10 | FN + -: F11 | FN + =: F12
- FN + [: Print Screen | FN +]: Scroll Lock | FN + ;: Pause/Break | FN + ': Insert
- FN + .: Home | FN + /: End
- FN + Win: Lock/Unlock Windows key
- FN + Ctrl (Right): Search | FN + Right Alt: Mute
- FN + PgUp: Volume Up | FN + PgDn: Volume Down

BACKLIGHT CONTROLS:
- FN + DEL: Cycle lighting effects
- FN + ~: Change single colour
- FN + backslash key: User-defined lighting mode
- FN + Up: Increase brightness | FN + Down: Decrease brightness
- FN + Right: Increase speed | FN + Left: Decrease speed
- FN + Space: Toggle backlight On/Off
- FN + ESC (hold 3s): Full factory reset

SWITCH SWAPPING:
Step 1: Remove keycap with keycap puller. Step 2: Squeeze switch puller on both sides of switch, pull straight up. Step 3: Insert new switch straight down until it clicks. Compatible: Outemu Blue, Red, Brown or any Outemu swappable switches. Buy from thecosmicbyte.com.

SOFTWARE: Download from https://www.thecosmicbyte.com/downloaddrivers/
- v1.0.0.4 (March 2026): Fixed icon and software resolution display.
- v1.0.0.3 (Nov 2025): Fixed Debounce Time Adjustment issue.
Always use the latest version from the official website.. Windows only. Enables per-key RGB customization, macros, key remapping. IMPORTANT: Use only the official software from the Artemis product page. Older third-party software versions can cause LED firmware issues.

TROUBLESHOOTING:
- Keyboard not detected: Try different USB port. Connect directly to PC (not via USB hub or extension). Try different cable.
- Key not working: Remove and re-insert switch. Replace if faulty.
- Backlight not working: FN + Space to toggle. FN + Up for brightness. Factory reset: FN + ESC 3s.
- Software not detecting keyboard: Run as administrator. Try different USB port. Reinstall software.
- LED stopped working after software update: Contact support at cc@thecosmicbyte.com for correct firmware. Do not use older versions of Artemis software.
- Windows key not working: FN + Win to unlock.
- Mac use: Works plug-and-play for basic typing. RGB software is Windows only.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

Artemis Wireless

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-cb-gk-40-artemis-wired-wireless-bluetooth-68-key-per-key-rgb-mechanical-gaming-keyboard/

COSMIC BYTE ARTEMIS WIRELESS — TRI-MODE 68-KEY MECHANICAL KEYBOARD (CB-GK-40)

TRI-MODE: 2.4GHz + Bluetooth (3 devices) + Wired USB-C. 68-key compact layout. Outemu Blue swappable switches. 2500mAh battery. Per-key RGB.

SPECS: 68 keys, US layout. Outemu Blue switches, swappable, 50M keystrokes. 2500mAh battery, ~7 hours charge time. 17 backlight effects, per-key RGB. 1.7m detachable USB-C cable. 292x102x40mm, 620g. Software: Windows only. Keycaps: Premium Double shot ABS. NOTE: Battery switch is on the back of the keyboard — must be ON to use wireless modes.

WHAT'S IN THE BOX: Keyboard, USB-C cable, 2.4G USB receiver, keycap puller, switch puller, user manual.

SWITCHING CONNECTION MODES:
- FN + Q: Switch to 2.4GHz mode
- FN + W: Switch to Bluetooth channel 1 (BT1)
- FN + E: Switch to Bluetooth channel 2 (BT2)
- FN + R: Switch to Bluetooth channel 3 (BT3)
- FN + T: Switch to wired USB mode
- FN + TAB (short press): Check current mode — the corresponding key (Q/W/E/R/T) flashes red for 2 seconds

2.4GHz SETUP:
1. Turn on battery switch (back of keyboard). Press FN + Q to enter 2.4G mode.
2. Plug USB receiver into PC — pre-paired at factory, connects automatically.
3. If pairing lost: Hold FN + Q for 3 seconds until Q key LED blinks green. Receiver must be plugged in. Stops blinking when paired.
4. Auto-connects next time — pairing is one-time only.

BLUETOOTH SETUP (3 devices):
1. Turn on battery switch. Press FN + W/E/R to switch to that BT channel.
2. If previously paired: Connects within 15 seconds. Blue LED on W/E/R turns off when connected.
3. If not connecting within 15s, keyboard sleeps (all LEDs off) — press any key to retry.
4. Pair new device: Hold FN + W/E/R for 3 seconds until that key LED blinks blue rapidly. Select "Artemis" from your device Bluetooth menu. LED stops blinking when paired.
5. Switch between 3 paired devices: Press FN + W, E, or R briefly.

WIRED MODE: Press FN + T. Connect USB-C cable. Works while charging battery.

BATTERY:
- Check level: Press FN + Left CTRL. Left CTRL key lights up: RED = Low, YELLOW = Medium, GREEN = High. (Only works in battery/wireless mode)
- Charge via USB-C cable. Red indicator while charging, turns off when full.

SLEEP MODE (wireless only):
- 180 seconds idle: Backlight turns off
- 30 minutes idle: Deep sleep
- Wake: Press any key

FN KEY SHORTCUTS:
- FN + 1 to 9: F1-F9 | FN + 0: F10 | FN + -: F11 | FN + =: F12
- FN + [: Print Screen | FN +]: Scroll Lock | FN + ;: Pause/Break | FN + ': Insert
- FN + .: Home | FN + /: End
- FN + Win: Lock/Unlock Windows key
- FN + PgUp: Volume Up | FN + PgDn: Volume Down

BACKLIGHT CONTROLS:
- FN + DEL: Cycle lighting effects (17 total)
- FN + ~: Change single colour lighting
- FN + backslash key: User-defined lighting mode (ESC, WASD, arrow keys light up blue by default)
- FN + Up arrow: Increase brightness (5 levels)
- FN + Down arrow: Decrease brightness
- FN + Right arrow: Increase animation speed (3 levels)
- FN + Left arrow: Decrease animation speed
- FN + Space: Toggle backlight On/Off
- FN + ESC (hold 3-5s): Full factory reset

CUSTOM BACKLIGHT RECORDING:
1. Press FN + DEL to enter Backlight Recording Mode (ESC, WASD, arrows light blue)
2. Press FN + backslash to enter custom recording
3. Press each key to select its colour
4. Press FN + backslash again to exit and save

SWITCH SWAPPING:
Step 1: Remove keycap with keycap puller. Step 2: Use switch puller on both sides, squeeze and pull straight up. Step 3: Insert new switch straight down until it clicks. Compatible: Outemu Blue, Red, Brown or any Outemu swappable switches.

SOFTWARE: Download from https://www.thecosmicbyte.com/downloaddrivers/
- v1.0.0.4 (March 2026): Fixed icon and software resolution display.
- v1.0.0.3 (Nov 2025): Fixed Debounce Time Adjustment issue.
Always use the latest version from the official website.. Windows only. Per-key RGB, macros, key remapping. Keyboard must be in wired mode for software to work.

TROUBLESHOOTING:
- Keyboard not powering on in wireless: Check battery switch on back is turned ON.
- 2.4G not working: FN + Q, receiver plugged in. Hold FN + Q for 3s to re-pair.
- 2.4G short range / drops out after a short distance (e.g. cuts out within ~0.5m): this is almost always USB 3.0 radio interference or dongle placement, not a faulty keyboard. Try, in order: (1) move the receiver to a USB 2.0 port, or use a USB extension cable to position the dongle away from the PC case and away from USB 3.0 ports / hubs (USB 3.0 ports emit 2.4GHz noise that swamps the dongle); (2) keep the dongle in line-of-sight of the keyboard, not behind a metal case or monitor; (3) make sure the battery isn't critically low (FN + Left CTRL — RED = low; charge it, a low battery can weaken the radio); (4) re-pair with FN + Q held 3s (Q LED blinks green, stops when paired); (5) if it still drops, switch to Bluetooth (FN + W/E/R) or wired (FN + T) to confirm the keyboard itself is fine, and contact support to check the dongle. (NOTE: an exact rated 2.4GHz range isn't listed in the manual — do not quote a specific metre figure; if the customer needs the official spec, route them to cc@thecosmicbyte.com.)
- Bluetooth not connecting: FN + W/E/R. Hold for 3s to re-pair. Enable BT on device.
- Keyboard sleeps during use: Normal — press any key to wake.
- Key not working: Remove and re-insert switch. Replace if still faulty.
- Backlight not working: FN + Space to toggle. FN + Up for brightness. Factory reset: FN + ESC 3-5s.
- Software not detecting: Switch to wired mode (FN + T, USB-C connected). Run as administrator.
- LED issue (Laser/Ripple effects): Download latest software from thecosmicbyte.com — updated firmware fixes LED issues with latest production batches. Use only official software.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

Astra

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-cb-gk-33-astra-hot-swappable-mechanical-wired-bluetooth-keyboard-with-per-key-rgb-and-software-2/

COSMIC BYTE ASTRA — WIRED + BLUETOOTH 67-KEY MECHANICAL KEYBOARD (CB-GK-33)

DUAL MODE: Wired USB-C + Bluetooth 5.0 (up to 3 devices). NO 2.4GHz wireless. 67 keys + dedicated volume knob. Wider switch compatibility than any other Cosmic Byte keyboard.

SPECS: 67 keys + volume knob, US layout. Preinstalled Outemu Blue switches, hot-swappable. Supports Cherry MX, Gateron, Kailh, Outemu switches. 1000Hz polling rate. 1800mAh Li-Po battery. 18 preset RGB lighting configs, per-key RGB. 1.8m removable USB-C PVC cable. ABS Doubleshot Keycaps. All key anti-ghosting. Dual adjustable height. Software: Windows only, wired mode only.

WHAT'S IN THE BOX: Keyboard, USB-C cable, keycap puller, switch puller, 2 extra switches, user manual.

IMPORTANT: Toggle switch on the BOTTOM of the keyboard controls Bluetooth mode.
- Switch ON = Bluetooth active | Switch OFF = Wired mode only

BLUETOOTH SETUP (3 devices — BT1/BT2/BT3):
First-time pairing:
1. Turn ON the switch on the bottom of the keyboard.
2. Hold FN + Left Shift (device 1) for 3+ seconds → LED blinks rapidly → keyboard ready to pair.
   Hold FN + Left Ctrl (device 2) for 3+ seconds for second device.
   Hold FN + Left Alt (device 3) for 3+ seconds for third device.
3. Go to Bluetooth settings on your device → search for "CB Astra" → select it.
4. LED turns off when connected successfully.

Switch between paired devices (short press):
- FN + Left Shift → Device 1 | FN + Left Ctrl → Device 2 | FN + Left Alt → Device 3

WIRED MODE:
1. Toggle switch on bottom of keyboard to OFF.
2. Connect USB-C cable to keyboard and PC.
3. Software only works in wired mode.

VOLUME KNOB: Dedicated knob on top-right corner — rotate for volume control.

OS MODE SWITCHING:
- FN + I: Windows mode (default)
- FN + O: Mac mode

BATTERY INDICATOR (Left Shift key LED):
- Blinks red slowly: Low battery — charge immediately
- Steady red: Charging in progress
- Returns to default colour: Fully charged

FACTORY RESET: Hold FN + Del for 3 seconds — restores all default settings.

FN KEY SHORTCUTS:
- FN + Esc: Backtick/tilde (~)
- FN + 1 to 9: F1 to F9
- FN + 0: F10 | FN + -: F11 | FN + =: F12
- FN + Win: Scroll Lock
- FN + P: Print Screen
- FN + [: Scroll Lock | FN +]: Pause/Break
- FN + L: Insert | FN + ;: Home | FN + Quote: End

Mac-specific (FN + number in Mac mode):
- FN + 5: Previous | FN + 6: Play/Pause | FN + 7: Next | FN + 8: Mute
- FN + 9: Volume Down | FN + 0: Volume Up

BACKLIGHT CONTROLS:
- FN + TAB: Cycle through LED lighting modes
- FN + backslash: Toggle LED On/Off
- FN + Up arrow: Increase brightness | FN + Down arrow: Decrease brightness
- FN + Left arrow: Change LED direction | FN + Right arrow: Change LED colour
- FN + PgUp: Increase animation speed | FN + PgDn: Decrease animation speed

SWITCH SWAPPING (WIDEST COMPATIBILITY):
The Astra supports more switch brands than other Cosmic Byte keyboards:
Compatible: Cherry MX, Gateron, Kailh, Outemu (Blue, Red, Brown, any colour)
Step 1: Remove keycap with keycap puller.
Step 2: Squeeze switch puller on both sides, pull straight up.
Step 3: Insert new switch straight down until it clicks.
Buy switches from thecosmicbyte.com.

SOFTWARE: Download from https://www.thecosmicbyte.com/downloaddrivers/
- v1.0.0.4 (March 2026): Fixed icon and software resolution display.
- v1.0.0.3 (Nov 2025): Fixed Debounce Time Adjustment issue.
Always use the latest version from the official website.. Windows only. Must be in wired mode — Bluetooth mode does not support software.

TROUBLESHOOTING:
- Keyboard not working wirelessly: Check bottom toggle switch is ON. Hold FN + Left Shift/Ctrl/Alt for 3s to re-pair.
- Bluetooth not connecting: Ensure BT is enabled on your device. If keyboard doesn't connect within 15s, press FN + Left Shift/Ctrl/Alt briefly to retry.
- Software not detecting keyboard: Toggle switch to OFF, connect USB-C cable, run software as administrator.
- LED blinks red on Left Shift: Low battery — connect USB-C to charge.
- Backlight not working: FN + backslash to toggle. FN + Up to increase brightness. Factory reset: FN + Del for 3s.
- Wrong key output on Mac: Press FN + O to switch to Mac mode.
- Key not registering: Remove and re-insert switch using switch puller. Replace if faulty.
- Cherry MX switch I bought not fitting: The Astra works with 3-pin AND 5-pin MECHANICAL switches. Confirmed compatible brands: Cherry MX, Gateron, Kailh, Outemu — in either 3-pin or 5-pin format. The Astra does NOT work with Optical switches (those have a different socket design — Trinity uses optical and the two are not interchangeable). The Astra does NOT work with Magnetic switches. If a customer asks about a specific switch, verify it is mechanical (not optical, not magnetic) and 3-pin or 5-pin.
- Charging LED bug (older units): Some units show red LED in wired mode even when charged. Firmware update fixes this — download latest software from product page.

WARRANTY: 1 year manufacturing defects only. Physical, water damage, battery wear NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

Atlas Mouse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-atlas-wireless-bluetooth-wired-tri-mode-mouse/

COSMIC BYTE ATLAS MOUSE - TRI-MODE GAMING MOUSE - FULL MANUAL

CONNECTIVITY:
- Three modes: Type-C Wired, 2.4GHz wireless, Bluetooth.
- Wired: connect USB-C cable - automatically takes priority over all other modes. Works while charging.
- 2.4GHz: plug USB receiver into PC. Press M button briefly to switch to 2.4G mode (L2 = Green).
- Bluetooth: press M button briefly to switch to Bluetooth mode (L2 = Blue). Hold M for 2 seconds to enter pairing mode - L2 flashes blue rapidly.
- Mode switch priority: wired > 2.4G > Bluetooth.
- Compatible with: Windows XP+, Android 9.0+, Linux, macOS (basic use). Software is Windows ONLY.

LED INDICATORS:
- L1 flashing Red = Low battery - charge immediately.
- L1 steady Blue = Charging in progress.
- L1 steady Green = Fully charged.
- L2 Green = 2.4GHz mode. L2 Blue = Bluetooth mode.

DPI LEVELS (press D button to cycle):
- 800 DPI = Red. 1600 DPI = Green (default). 2400 DPI = Blue. 5000 DPI = Purple. 12000 DPI = Yellow.

POLLING RATE:
- 1000Hz in 2.4GHz and wired modes. Bluetooth = 133Hz only (hardware limitation, not a defect).
- For gaming, always use 2.4GHz or wired for full 1000Hz.

BATTERY: 500mAh built-in. ON/OFF switch controls wireless power.

SOFTWARE: 5 buttons fully programmable via Cosmic Byte software (Windows only). Download from https://www.thecosmicbyte.com/downloaddrivers/.

TROUBLESHOOTING:
- Not responding: check ON/OFF switch is ON. Check L1 for battery. Try different USB port for receiver. Re-pair: switch between modes using M button.
- Bluetooth not connecting: hold M 2 seconds for pairing mode, remove old pairing from device first.
- Cursor erratic: use proper mousepad (not glass), lower DPI, check for 2.4GHz interference.

WARRANTY: 1 year manufacturing defects only. Physical, water damage, tampered products NOT covered.
Support: +91 7351615161 (Mon-Sat 10am-6pm), cc@thecosmicbyte.com.

Blitz Tri-Mode

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-blitz-wireless-wired-controller-for-pc-hall-effect-joystick-triggers-1000hz-polling-rate-black/

COSMIC BYTE BLITZ TRI-MODE CONTROLLER - FULL MANUAL

⚠️ CRITICAL — READ FIRST: WHAT THE BLITZ TRI-MODE DOES *NOT* HAVE

The Blitz Tri-Mode is a focused mid-range controller. Several features that sibling Cosmic Byte products have are ABSENT here. Listing any of these as "features it has" is a customer-visible WRONG ANSWER (this exact failure mode has happened in production — see Blitz Tri-Mode Section 4 / Common Failure Modes at the bottom of this entry):

✗ NO MACRO BUTTONS. Zero dedicated macro buttons. Not 2, not 4, ZERO. No ML / no MR / no LK / no RK / no M1 / no M2. (Lumora has 4 macros. Drakon has 2 macros. Blitz Tri-Mode has NONE. Do not confuse.)
✗ NO RGB LIGHTING. The controller is solid BLACK with no RGB at all. No RGB zones, no joystick rings, no software-controlled lights, no breathing modes, no colour cycling. (Lumora has 5-zone RGB. Drakon has 7-zone RGB. Blitz Tri-Mode has NONE.)
✗ NO REPLACEABLE STICK TOPS / D-PAD COVERS. Single fixed set, not in the box. (Lumora ships with 6 stick tops + 2 D-pad covers.)
✗ NO KEYBOARD/MOUSE REMAPPING via software. Software supports gamepad-to-gamepad remap only. (Lumora supports KB/mouse remap.)
✗ NO CHARGING DOCK IN THE BOX. The controller SUPPORTS a charging dock accessory (contacts on the back) but the dock itself is SOLD SEPARATELY on thecosmicbyte.com — it is NOT included.
✗ NO ANALOG/DIGITAL TRIGGER SWITCH. Triggers are Hall Effect analog only. Range is adjustable via software (Initial/Max sliders) but there's no physical trigger-mode switch like Stellaris or Lumora have.
✗ NO LARGER BATTERY than the discontinued Blitz Wireless. Both are 600mAh. Do NOT say the Blitz Tri-Mode has a "larger battery" or "bigger battery" -- it does not.
✗ NO CONSOLE SUPPORT. PC is the primary platform. Does not work on PlayStation / Xbox / Switch. (Some Android/iOS support exists for specific connection modes; see CONNECTIVITY section below.)
✗ NO TURBO BUTTON ON THE GRIP / NEAR VIBRATION MOTOR / ON THE BACK / UNDER THE PADDLE AREA. The TURBO button is NOT on the grip side. It is NOT near the vibration motor (the motors are inside the grips, not user-accessible). It is NOT a back-paddle button (this controller has no back paddles). It is NOT under the controller. The TURBO button is on the FRONT FACE of the controller, in the center area below the HOME button — see BUTTON LAYOUT section below for the exact position. If you find yourself describing the TURBO button as being "on the right side of the grip", "near the vibration motor area", "on the back of the controller", or any similar grip-side or rear-side location, STOP — that's a fabrication (production session 6677fd75, 2026-05-13 17:24 surfaced this exact wording; guard added in v1.10.13 to prevent recurrence).

✗ MOUSE MODE IS ANDROID-ONLY ON BLITZ TRI-MODE — NOT A PC FEATURE. The Blitz Tri-Mode's Mouse Mode (CAPTURE + R3 for 5 seconds — turns the controller into a mouse with right stick = cursor, A = left click, B = right click) is documented in the user manual as an ANDROID-ONLY feature. It is NOT available on PC. The connection mode (Wired vs 2.4GHz) does NOT determine Mouse Mode availability — the HOST OS does. Mouse Mode requires an Android host. On PC the controller continues to function as a standard XInput / DInput gamepad in all connection modes regardless of whether the customer holds CAPTURE + R3. If a customer asks "does Mouse Mode work on PC", the answer is NO. If a customer asks "how do I use Mouse Mode on my PC", the answer is: Mouse Mode is Android-only, not a PC feature, BUT the customer can still control a PC cursor using their Blitz Tri-Mode via third-party software. See Rule 16 (GAMEPAD AS MOUSE ON PC) in the system prompt for the three documented options (Gopher360 / JoyToKey / Steam Desktop Configuration). Do NOT leave a PC customer with just "Mouse Mode doesn't work on PC" — always pivot to Rule 16 to show them how to achieve the same end result with their existing Blitz Tri-Mode. The Lumora is a separate option for customers who specifically want a built-in (no third-party software) PC keyboard/mouse

remapping experience, but it's a recommendation for a different controller, not the only path.
DO NOT SAY: "Mouse Mode works on PC in Wired mode" / "Mouse Mode works on PC in 2.4GHz mode" / "Mouse Mode is available on both PC and Android" — all WRONG. The user manual's input-mode tables list Mouse Mode only under the Android section, not under the PC section. Production session 980aca7e (2026-05-16 22:55) had the bot tell a customer Mouse Mode worked on PC; the customer had to correct the bot using manual screenshots. Guard added in v1.10.18 to prevent recurrence.

BUTTON LAYOUT — PHYSICAL PLACEMENT ON THE BLITZ TRI-MODE FRONT FACE (top-of-entry self-claim block so the bot doesn't fabricate button locations; added in v1.10.13 after session 6677fd75 surfaced a TURBO button location hallucination.)

The Blitz Tri-Mode follows an Xbox-style face layout (offset analog sticks — left stick top-left, right stick bottom-right; D-pad bottom-left; ABXY cluster on the right). All system buttons are on the FRONT FACE in the center column between the two analog sticks / D-pad / ABXY cluster.

FRONT-FACE CENTER COLUMN (top to bottom — describe in this order if a customer asks "where is the X button"):

[Top row, three buttons across]
- BACK button: small oval button, LEFT of HOME, labelled with a three-dot icon ("..."). Sometimes called the VIEW button on Xbox-style layouts.
- HOME button: round button in the EXACT CENTER of the controller's top area, with the Cosmic Byte diamond/CB logo on it. Lights up orange / RGB. This is the central anchor of the layout — when describing other button positions, reference them relative to HOME.
- START button: small oval button, RIGHT of HOME, labelled with a three-horizontal-line icon ("≡"). Sometimes called the MENU button on Xbox-style layouts.

[Middle row, just below HOME]
- SHARE / CAPTURE button: small round button directly below HOME, center column. Slightly smaller than HOME itself.

[Bottom row, just below SHARE]
- TURBO button: oval-shaped button BELOW the SHARE button, still in the center column. The TURBO button is on the FRONT FACE — not on the grip, not on the back, not under the controller. It is the bottom-most button in the center column between the two analog sticks. Customers can find it by looking at the front of the controller — it is the small oval button positioned between the D-pad area and the right analog stick area, roughly centered horizontally on the front face.

LEFT SIDE OF FRONT FACE:
- LEFT analog stick (top-left position).
- D-pad (bottom-left position, below the left stick).

RIGHT SIDE OF FRONT FACE:
- ABXY button cluster (top-right position) in Xbox layout — Y top, X left, B right, A bottom.
- RIGHT analog stick (bottom-right position, below the ABXY cluster).

TOP EDGE (shoulder buttons / triggers):
- LB (Left Bumper) — top-left shoulder, digital.
- LT (Left Trigger) — below LB, analog Hall Effect.
- RB (Right Bumper) — top-right shoulder, digital.
- RT (Right Trigger) — below RB, analog Hall Effect.

BACK / REAR OF CONTROLLER:
- NO back paddles, NO macro buttons of any kind on the rear (see DOES-NOT-HAVE block above — Blitz Tri-Mode has zero macro buttons).
- USB-C charging port: TOP edge, center, between LB and RB.
- Vibration motors: inside the two grips — these are NOT user-facing buttons, NOT accessible from outside, and NOT to be confused with the TURBO button.

WHEN A CUSTOMER ASKS "WHERE IS [BUTTON]?":
- For TURBO: "On the front face of the controller, in the center column below the HOME button (the orange/RGB-lit button with the Cosmic Byte logo). It's the small oval button positioned between the D-pad and the right analog stick area, roughly horizontally centered."
- For HOME: "The round button in the exact center of the front face, with the Cosmic Byte logo on it. Lights up orange / RGB."
- For BACK / START: "Small oval buttons on either side of the HOME button — BACK (three-dot icon) on the left of HOME, START (three-bar icon) on the right of HOME."
- For SHARE / CAPTURE: "Small round button directly below HOME, above the TURBO button."
- For macro buttons: "The Blitz Tri-Mode does NOT have dedicated macro buttons. If you need macros, use the Turbo button's sequence recording feature (see TURBO SEQUENCE RECORDING) — or consider the Lumora (4 macros) or Drakon (2 macros) instead."

✓ WHAT THE BLITZ TRI-MODE *DOES* HAVE (real, KB-documented upgrades over the discontinued Blitz Wireless — list ALL of these confidently when comparing the two; do NOT shorten to a vague "improved features" summary, that's also a wrong-answer pattern)

The Blitz Tri-Mode is a genuine generational upgrade over Blitz Wireless. When a customer asks "what does the Tri-Mode add over the old Wireless?" or any equivalent comparison question, list ALL of the following that are confirmed in this KB entry (do not omit; do not paraphrase as "improved features"):

✓ TRI-MODE CONNECTIVITY: USB-C wired + 2.4GHz wireless + Bluetooth. (Old Blitz Wireless was dual-mode only: USB + 2.4GHz, no Bluetooth.)
✓ TMR JOYSTICKS: Tunnel Magnetoresistance, drift-resistant, high precision. (Old Blitz Wireless had Hall Effect joysticks. TMR is a newer tech tier — same tier as Drakon and Stellaris Gen 2.)
✓ 6-AXIS GYRO (motion sensing): available in Bluetooth Gyro Mode only. (Old Blitz Wireless had no gyro at all.)
✓ HALL EFFECT ANALOG TRIGGERS with software-adjustable range (Initial / Max sliders in the companion software). (Old Blitz Wireless had Hall Effect triggers too, but no software adjustment.)
✓ APP SUPPORT — PC companion software for button remapping, profiles, turbo, vibration adjust, trigger range, firmware updates. The controller has the "App Support" badge on its back label. (Old Blitz Wireless had no software.)
✓ TURBO WITH SEQUENCE RECORDING — record a sequence onto the Turbo button (this is NOT the same as dedicated macro buttons, but it is a real Turbo-button-based macro-style feature; explain it this way if asked). (Old Blitz Wireless had basic Turbo only.)
✓ DUALSHOCK MODE for Android — Bluetooth pairing mode that emulates a PS4 DualShock for Android games. (Old Blitz Wireless had no DualShock emulation.)
✓ CHARGING DOCK SUPPORT — controller has contacts on the back for an optional charging dock. The dock itself is SOLD SEPARATELY on thecosmicbyte.com (NOT included in the box — see the explicit NO above). (Old Blitz Wireless had no charging dock support at all.)
✓ HIGHER POLLING RATE FLEXIBILITY — up to 1000Hz on wired/2.4GHz, up to 500Hz on Bluetooth (varies 125–500Hz by device). (Old Blitz Wireless was 1000Hz wired/2.4GHz too — so this isn't a polling-rate UPGRADE on the high end, just feature parity with Bluetooth flexibility added.)

PC primary platform. Consoles NOT supported.

BLITZ TRI-MODE vs OLD BLITZ WIRELESS — KEY DIFFERENCES:

Feature	Blitz Tri-Mode (current)	Blitz Wireless (old)
Joystick type	TMR (Tunnel MR)	Hall Effect
Connectivity	USB + 2.4GHz + Bluetooth	USB + 2.4GHz only
Gyro	Yes (Bluetooth Gyro Mode only)	No
Software support	Yes (App Support label)	No
Polling rate	1000Hz (wired/2.4GHz)	1000Hz (wired/2.4GHz)
Battery	600mAh	600mAh (SAME, not larger)
Macro buttons	NO	NO
RGB lighting	NO	NO
Replaceable stick tops	NO	NO

| Charging dock | SUPPORTED (sold separately, NOT included) | No |
| DualShock mode (Android) | YES (Bluetooth) | No |

The Blitz Tri-Mode is NOT just a connectivity upgrade — TMR joysticks, gyro, and software are significant additions. Some functions may not work on Android/iOS. No warranty for unsupported device damage.

CHARGING DOCK STATUS (v1.9.4 update — IMPORTANT):
The Blitz Tri-Mode supports a charging dock accessory. The dock is SOLD SEPARATELY -- it is NOT included with the controller. Customers who want the dock must purchase it on its own.

CRITICAL clarifications for AI:
- The Blitz Tri-Mode controller itself has the contacts on the back for the charging dock (that's the "supported" part). The dock is a separate accessory product.
- The dock is NOT in the box with the controller. Anyone telling a customer "charging dock included" is wrong.
- The dock IS available for purchase NOW — it has its own product listing on thecosmicbyte.com. Direct product page: https://www.thecosmicbyte.com/product/cosmic-byte-blitz-tri-mode-charging-dock-controller-not-included/ (as the URL says, the CONTROLLER is NOT included with the dock — the listing is for the bare dock accessory).
- COMPATIBILITY — IMPORTANT: This charging dock works ONLY with the Blitz Tri-Mode. It does NOT fit or work with the Blitz Wireless (the Dual-Mode model). If a Blitz Wireless / Dual-Mode customer asks about this dock, tell them it is Blitz Tri-Mode only and not compatible with their controller.
- The dock is an ADDED SUPPORT accessory, not a default-bundled item. Marketing the controller's features should mention "supports a charging dock (sold separately)" rather than "comes with a charging dock" or "charging dock included".

If a customer asks where to buy the Blitz Tri-Mode charging dock, the correct response is: "The Blitz Tri-Mode charging dock is now live and available to order here: https://www.thecosmicbyte.com/product/cosmic-byte-blitz-tri-mode-charging-dock-controller-not-included/ — it is sold separately (the controller is not included with the dock), and it works only with the Blitz Tri-Mode, not the Blitz Wireless / Dual-Mode. Use coupon code ONLINEPAY for 10% off on online payments. In the meantime, the controller charges normally via the included USB-C cable — use a 5V/1A adapter or PC USB port, and avoid fast chargers as they can damage the battery."

KEY FEATURES (full list — surface these accurately when comparing Blitz Tri-Mode to other CB controllers):
- JOYSTICKS: TMR (Tunnel Magnetoresistance) — drift-resistant, high precision. Newer/more precise than Hall Effect. Same joystick tech tier as Drakon and Stellaris 2nd Gen. The TMR joysticks are a primary selling point of the Blitz Tri-Mode and a real advantage over Lumora (which has Hall Effect joysticks, not TMR) — but NOT an advantage over Drakon, which also has TMR joysticks.
- TRIGGERS: Hall Effect ANALOG only. Range adjustable via software (Initial / Max sliders). NOT analog/digital switchable like Lumora's triggers.
- MACRO BUTTONS: NONE. The Blitz Tri-Mode has NO dedicated macro buttons (no ML/MR/LK/RK or M1/M2). It has Turbo with sequence recording (see TURBO & AUTO FIRE / TURBO SEQUENCE sections below), which is a Turbo-button-based feature, not dedicated macro buttons. If a customer needs dedicated macro buttons, recommend Lumora (4 macros) or Drakon (2 macros) — do NOT tell customers Blitz Tri-Mode has macro buttons.
- RGB LIGHTING: NONE. The Blitz Tri-Mode does NOT have RGB lighting. The controller is solid black with no RGB customisation in the software. If a customer wants RGB, recommend Lumora (5 zones, Cloak design) or Drakon (7 zones, keyframe animations) — do NOT tell customers Blitz Tri-Mode has RGB.
- REPLACEABLE JOYSTICK TOPS / D-PAD COVERS: NONE. Blitz Tri-Mode does NOT come with replaceable stick tops or D-pad covers. If the customer wants these, recommend Lumora (6 stick tops + 2 D-pad covers).
- BUTTON MAPPING (via software): Gamepad-to-gamepad remapping ONLY. Cannot map to keyboard keys or mouse actions like Lumora can.
- ONBOARD PROFILES: 3 customisable profiles (Profile 1 / 2 / 3) plus a Default profile in the software.
- STICK CUSTOMISATION (via software): Initial / Max range sliders only (no separate deadzone / anti-deadzone / radial trace). Has "Raw" mode toggle, "Swap Left Joystick and D-Pad", and "D-Pad Diagonal Lock".
- VIBRATION: Dual motors, adjustable in 4 levels (100% / 70% default / 40% / 0%). No independent per-grip control like Lumora.
- GYRO: 6-axis with robust software customisation — Response Curve options (Aggressive / Default / Smooth / Custom), Anti-Deadzone, Activate Method, Activate Button, Motion Axis, Active Axis, Invert X/Y, Steer/Aim toggle. This is a real Blitz strength comparable to Lumora's gyro.
- BATTERY: 600mAh, 7-15 hours.
- POLLING: 1000Hz on Wired and 2.4GHz. Up to 500Hz on Bluetooth.
- CONNECTIVITY: Tri-Mode (USB Wired / 2.4GHz / Bluetooth).

POWER & RESET:
- Power ON: Press HOME for 0.5-1 second.
- Power OFF: Hold HOME for 5 seconds.
- Auto-sleep: After 5 minutes of inactivity.
- Soft reset: Hold HOME for 8 seconds.
- Factory reset: Hold SELECT + L3 + R3 simultaneously for 5 seconds (clears all custom settings).
- Controller charging but not working: Press HOME once to wake it.
- Controller won't turn on: Charge for 30-60 minutes first. If still unresponsive, hold HOME for 8 seconds.

CLOUD GAMING:
Works with GeForce Now, Xbox Cloud Gaming, and OnePlay when connected via PC USB Wired or 2.4GHz Wireless. Avoid Bluetooth for cloud gaming.

SOFTWARE NOTE: Software only works with latest Blitz Tri-Mode model (back label shows "App Support"). Does NOT work with older dual-mode model.

CONNECTIVITY:
Platform | Mode | How to Connect | LED
PC Wired XInput | Plug in + press HOME | LED2 on
PC Wired DInput | Long-press HOME under XInput | LED3 on
Android Wired DInput | Plug in + press HOME | LED3 on
PC/Android 2.4GHz XInput | Press X + HOME (3 sec) | LED2 on
PC 2.4GHz DInput | Long-press SELECT + HOME | LED3 on
Mouse Mode (Android ONLY) | Hold CAPTURE + R3 (5 sec) | LED3+LED4. A=left click, B=right click, Right stick=cursor. Repeat to exit. NOT AVAILABLE ON PC — Mouse Mode is an Android-only feature per the user manual; on PC the controller continues to function as a standard gamepad regardless of connection mode (Wired or 2.4GHz). See MOUSE MODE clarification below.
PC BT XInput | Press B + HOME (3 sec) | LED2

PC BT DInput | Press A + HOME (3 sec) | LED3
Android BT XInput | Press B + HOME (3 sec) | LED2
Android BT DInput | Press A + HOME (3 sec) | LED3
iOS BT DualShock | Press TURBO + HOME (3 sec) | LED1
iOS BT XInput | Press B + HOME (3 sec) | LED2
Gyro (any BT) | Press Y + HOME (3 sec) | LED4
iOS NOT supported in wired or 2.4GHz modes.

STEAM MODE (wired only): Power OFF. Hold R3. While holding, plug USB-C cable -> boots into Steam mode. Restart Steam.
GYRO: Bluetooth ONLY natively (press Y + HOME for 3 sec, LED4 on).
Via Cosmic Byte software (wired/2.4GHz):
ON-THE-FLY GYRO (via Cosmic Byte software - works in ANY game even without native gyro support):
- Connect via Wired or 2.4GHz. Open Cosmic Byte software (download from https://www.thecosmicbyte.com/downloaddrivers/).
- Assign gyro to any button of your choice.
- Three activation modes:
  * Always On - Gyro is always active (good for racing/flight games).
  * Toggle - Press the assigned button once to enable, press again to disable.
  * Press and Hold - Gyro only active while the button is held down (best for aiming in FPS).
- Gyro output mimics left or right joystick movement, so it works in ANY game that supports a joystick - even games with no native gyro support.
- Note: Native Bluetooth Gyro Mode is also available (press Y + HOME for 3 seconds) but software method works over wired/2.4GHz and gives full activation control.
POLLING RATE: Up to 1000Hz (PC Wired & 2.4GHz). Note: more stable in wired mode.

TURBO & AUTO FIRE:
- Enable Turbo: Hold TURBO + desired button.
- Enable Auto Fire: Press TURBO + same button again.
- Cancel individual: Hold CLEAR + button.
- Clear ALL: Hold TURBO for 5 seconds. Vibration confirms.
- Speeds: Level 1=5/sec, Level 2=12/sec (default), Level 3=20/sec.
- Adjust: Hold TURBO, Right Stick Right=increase, Left=decrease.
- Supported: A, B, X, Y, LB, RB, LT, RT.

TURBO SEQUENCE RECORDING (Blitz Tri-Mode does NOT have dedicated macro buttons — this records a sequence onto the Turbo button):
Record: Hold TURBO for 3 seconds -> perform sequence (up to 22 inputs) -> press TURBO to save. Execute: Double-press TURBO. Clear: Enter sequence mode (hold TURBO 3s) -> press TURBO immediately without recording.

VIBRATION: Hold TURBO + Right Stick Up (increase) or Down (decrease). Levels: 100%, 70% (default), 40%, 0%.
BATTERY CHECK: Press TURBO + START. LED1=1-25%, LED1+2=26-50%, LED1+2+3=51-75%, all 4=76-100%.
STICK CALIBRATION: Power off. Hold CAPTURE + HOME. Press A. Rotate both sticks 3 times. Press triggers fully 3 times. Press A to save.
D-PAD 4-WAY/8-WAY: Press SELECT + D-pad Right for 3 seconds. Short vibration=4-way, Long=8-way.
ABXY SWAP: Hold TURBO + R3 for 3 seconds.
D-PAD/LEFT STICK SWAP: Hold START + L3 for 3 seconds.
STICK SHAPE: Hold L3 + TURBO -> Circle (default) / Square 45-degree mode.
CONTROLLER LOCK (bag): Hold SELECT + R3 for 5 seconds until all 4 LEDs light. Unlock: plug in USB charger.

POWER: ON=press HOME (0.5-1 sec). Auto sleep=5 min. OFF=hold HOME 5 sec. Reset (frozen)=hold HOME 8 sec. Factory reset=hold SELECT + L3 + R3 for 5 seconds (clears all settings).
CHARGING: USB-C cable included in the box (use 5V/1A adapter or PC USB ONLY — fast chargers damage battery and void warranty; 2.5-3 hours charge; battery 600mAh, 7-15 hours runtime). Charging dock is also supported, sold separately on thecosmicbyte.com — see CHARGING DOCK STATUS section above for the full policy.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered. Fast charger damage NOT covered.

ANDROID / MOBILE VIBRATION TIP:
Standard Android Bluetooth (D-Input) may not send vibration commands. If vibration is not working on Android or iOS:
→ You can try switching to DualShock mode: Hold TURBO + HOME for 3 seconds → LED1 ON.
⚠ IMPORTANT: DualShock mode is a Bluetooth protocol for MOBILE and PC ONLY — NOT for PS4/console use. This controller cannot be used on PlayStation.
Vibration in DualShock mode on Android is NOT guaranteed — depends on the game and Android device.
This is an Android OS/game limitation, NOT a hardware defect, and is NOT covered under warranty.
PC is the primary platform for full, reliable vibration support.
Vibration levels: 100%, 70% (default), 40%, 0% — adjust with TURBO + Right Stick UP/DOWN.
Cloud gaming vibration depends on whether the platform and game support haptic feedback for external controllers.

BLUETOOTH POLLING RATE: Up to 500Hz in Bluetooth mode. Actual rate can range 125Hz to 500Hz depending on the connected device and its Bluetooth chip. For the most stable and consistent polling rate, use Wired (USB-C) or 2.4GHz Wireless — both deliver the full 1000Hz.

COMMON FAILURE MODES TO AVOID (BLITZ TRI-MODE AI-FACING NOTES)

- Do NOT say Blitz Tri-Mode has macro buttons. It does NOT. The Tri-Mode has Turbo (with sequence recording, see TURBO SEQUENCE RECORDING section above) but NO dedicated macro buttons -- no ML/MR, no LK/RK, no M1/M2. This is a real bug that has happened: when asked "what does Blitz Tri-Mode add over Blitz Wireless", the bot pattern-matched "newer model = adds macro buttons" and listed macro buttons as a

feature. Wrong. Customers buying the Tri-Mode expecting dedicated macro buttons will be disappointed. If a customer needs dedicated macros, recommend Lumora (4 macros) or Drakon (2 macros) -- NOT Blitz Tri-Mode.

- Do NOT say the charging dock is "included" with the Blitz Tri-Mode. It is NOT included in the box. The Tri-Mode SUPPORTS a charging dock accessory (contacts are on the back of the controller), but the dock itself is a separate purchase -- "sold separately" on thecosmicbyte.com. See CHARGING DOCK STATUS section above. This is also a real bug that has happened: bot listed "charging dock included" as a Tri-Mode feature when asked about upgrades over Blitz Wireless. Wrong.
- Do NOT say Blitz Tri-Mode has RGB lighting. It does NOT. The controller is solid black with no RGB customisation in the software. If a customer wants RGB, recommend Lumora (5 zones, Cloak design) or Drakon (7 zones, keyframe animations).
- Do NOT confuse Blitz Tri-Mode features with Stellaris or Ares Pro features. They are different product lines. When listing what the Tri-Mode adds over the discontinued Blitz Wireless, stick to: Bluetooth connectivity (in addition to 2.4GHz + wired), 6-axis gyro (Bluetooth Gyro Mode only), TMR joysticks (replacing Hall Effect), App Support (PC companion software for remapping/profiles/turbo/vibration/firmware), Turbo with sequence recording (NOT dedicated macro buttons), charging-dock support (sold separately, NOT bundled), and DualShock Mode for Android. Do NOT list macro buttons, RGB, replaceable stick tops, or any other Stellaris/Lumora/Drakon feature.
- Do NOT proactively offer a buy link, share product URLs, or invite the customer to ask for "a buy link" unprompted. If a customer explicitly asks where to buy, point them to thecosmicbyte.com or Amazon India, but do NOT volunteer purchase prompts on every related question. The customer is asking for information, not to be sold to.

Blitz Wireless

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-blitz-wireless-wired-controller-for-pc-hall-effect-joystick-triggers-1000hz-polling-rate-black/

COSMIC BYTE BLITZ WIRELESS - 2.4GHz + WIRED CONTROLLER (1st GEN) - FULL MANUAL

IMPORTANT: DISCONTINUED model. No Bluetooth. No gyro. No macro. Hall Effect joystick and trigger. 600mAh battery.

CONNECTIVITY:
- First-time pairing: Press HOME for 3-5 seconds. LED flashes -> pairs with dongle. LED1+LED2 solid = XInput connected.
- Wired: Connect USB-C cable, THEN press HOME to activate. Without pressing HOME it only charges, does NOT function as controller.
- Simultaneous cable + dongle: dongle used for input, cable charges.
- Auto power off: No dongle found within 1 minute = off. Idle 5 minutes = off.
- Android: Plug dongle via OTG converter. Press HOME 1 second. LED flashes then LED3 solid = connected. OTG converter not included.

LED INDICATORS: LED1+LED2 solid = XInput (PC). LED3+LED4 solid = DInput. Blinking = searching/pairing. Slow blink = charging (connected). All 4 slow blink (disconnected) = charging. All 4 steady = fully charged.

SWITCHING INPUT MODES: Press HOME for 2 seconds to toggle XInput (LED1+LED2) vs DInput (LED3+LED4). Old games need DInput. Always relaunch game after switching.

MOUSE MODE (wired/2.4GHz only): Press CAPTURE + R3. LED3+LED4 on. Right stick=cursor, A=left click, B=right click. Press CAPTURE+R3 again to exit. Mouse mode does NOT work in Bluetooth (no Bluetooth anyway).

TURBO: Enable (fires fast while held): Hold TURBO + button. Enable Auto Turbo (fires continuously): Hold TURBO + same button again. Cancel: Hold TURBO + that button to toggle off. Clear ALL: Hold TURBO + SELECT for 5 seconds - vibration confirms. Speeds: 5/12/20 per sec. Adjust: TURBO + Right Stick Right (increase), Left (decrease).
VIBRATION: 4 levels (None/Weak/Medium/Strong). Adjust: TURBO + Right Stick Up/Down.
D-PAD MODES: Toggle 4-way/8-way: Press SELECT + D-pad Right for 3 seconds. Short vibration=4-way, Long=8-way.
BATTERY CHECK: Press TURBO + START. LED1=1-25%, LED1+2=26-50%, LED1+2+3=51-75%, all 4=76-100%.
JOYSTICK CALIBRATION: Power off. Press D-pad Up then HOME. LED1 on. Press A (LED2 on). Rotate joysticks 3 full circles. Press triggers 3 times. Press A to confirm. Hall Effect joysticks - drift-resistant by design. Persistent drift after calibration -> contact support.
CONTROLLER LOCK (bag): Hold SELECT + R3 for 5 seconds until all 4 LEDs light. Unlock: plug in USB charger.
POWER OFF: Hold HOME 5 seconds. RESET (frozen): Hold HOME 8 seconds.
CHARGING: PC USB port or standard 5V/1A ONLY. Fast chargers/mobile chargers damage battery and void warranty. Battery: 600mAh, 7-15 hours. Charge time: 2-3 hours.

KEY DIFFERENCES vs BLITZ TRI-MODE: 2.4GHz + wired ONLY (no Bluetooth), no gyro, no macro, no Steam mode, no iOS Dualshock, no charging dock. DISCONTINUED - current active model is Blitz Tri-Mode.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered. Fast charger damage NOT covered.

CosmoBuds X220

Product page: https://www.thecosmicbyte.com/product/cosmobuds-x220/

PRODUCT: Cosmic Byte CosmoBuds X220 — True Wireless Gaming Earbuds

SPECS:
- Bluetooth: 5.3
- Low latency: 40ms in GOD Mode
- Driver: 13mm | Frequency: 20Hz–20kHz
- Earbud battery: 40mAh | Case battery: 400mAh
- Music playtime: up to 10 hours per charge
- Total battery life with case: 40 hours
- Talk time: up to 7 hours
- Standby: 100 days
- Charging: USB-C, ~1.5 hours full charge
- Fast charge: 15 minutes = 100 minutes playtime
- Range: 10m
- Water resistance: IPX5 (sweat and water resistant)
- Mic: ENC/DNS, omnidirectional
- Codecs: AAC + SBC

⚠️ CHARGER WARNING: Use ONLY 5V/1A chargers. Fast chargers WILL damage the battery — not covered under warranty.

TOUCH CONTROLS:
Music playback:
- Double tap either earbud = pause/resume
- Long press RIGHT (1.5s) = volume up
- Long press LEFT (1.5s) = volume down

Calls:
- Double tap either earbud = answer/hang up
- Long press either earbud (2s) = reject incoming call
- Triple tap RIGHT earbud = voice assistant

Mode switching:
- Triple tap LEFT earbud = toggle GOD Mode ↔ Music Mode
  • GOD Mode = 40ms low latency (best for gaming)
  • Music Mode = high-fidelity audio + bass (best for music)

PAIRING — FIRST TIME:
1. Remove earbuds from case → they auto-enter pairing mode
2. Go to phone Bluetooth settings → connect to "CosmoBuds X220"
After pairing once, earbuds auto-reconnect when removed from case (IOP™ instant pairing)

SINGLE EARBUD USE: Remove one earbud, it pairs solo in mono mode. Return the other — stereo resumes automatically.

VOLUME LIMIT REMOVAL:
- iOS: Settings → Music → turn off Sound Check
- Android: Bluetooth settings → tap CosmoBuds X220 → disable "Sync volume with phone"
- Spotify/Amazon Music: Turn off Audio Normalisation in app settings

FACTORY RESET:
1. Forget "CosmoBuds X220" from phone Bluetooth settings
2. Remove both earbuds from case
3. Tap each earbud 7 times — LED turns off
4. Place back in case for 5 seconds
5. Re-pair normally

TROUBLESHOOTING:
Q: One earbud not working?
A: Place both in case → take out again. If still failing, perform factory reset.

Q: Earbuds won't connect?
A: Forget device from phone Bluetooth → perform factory reset → re-pair

Q: Disconnecting during calls?
A: Charge the earbuds. If persists, perform factory reset.

Q: Low volume?
A: Remove volume limit (see above)

WARRANTY: 1 year against manufacturing defects. Physical/water damage, tampered products, and battery wear and tear not covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon–Sat 10am–6pm

CryoCore

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-cryocore-7-1-surround-wired-gaming-headset/

PRODUCT: Cosmic Byte CryoCore — 7.1.4 SURROUND WIRED GAMING HEADSET (UPGRADED THX SPATIAL AUDIO VERSION)

⚠️ TWO CRYOCORE GENERATIONS EXIST — READ THIS FIRST:
- CURRENT / UPGRADED CryoCore (sold now) = 7.1.4 surround, ships with the THX Spatial Audio + desktop software, 20Ω impedance. THIS entry's main specs describe this model.
- OLD CryoCore (DISCONTINUED) = 7.1 surround, 32Ω impedance, used the older setup.exe 7.1 driver from the downloads page. It is NO LONGER SOLD.
- CRITICAL: THX Spatial Audio does NOT work on the OLD CryoCore hardware. Only the upgraded hardware supports THX. If a customer with the OLD unit asks how to get THX / Spatial Audio, tell them plainly it is not supported on their hardware — do not send them to install THX. Their correct path is the legacy setup.exe driver for 7.1 (see LEGACY section below).
- How to tell which one a customer has: the upgraded model is marketed as 7.1.4 with THX branding and uses the THX Spatial Audio + app; the old model is 7.1 and came with the setup.exe driver / no THX. If unsure, ask when/where they bought it and whether the box/listing mentions THX.

SPECS (UPGRADED THX MODEL):
- Surround: 7.1.4 (via THX Spatial Audio + software)
- Connection: USB 2.0 ONLY (no 3.5mm). Cable 2.0m.
- Driver: 50mm Hi-Fi | Sensitivity: 110dB ±5dB (@1kHz) | Impedance: 20Ω | Freq: 20Hz–20kHz
- SPEAKERS TUNED AND UPDATED FOR THX: the upgraded CryoCore uses updated speaker drivers that have been acoustically tuned for THX Spatial Audio — THX's filters are calibrated to this specific hardware (note the impedance changed from 32Ω on the old model to 20Ω on the upgraded one). This is a core reason the OLD CryoCore cannot run THX: the THX processing is matched to the upgraded drivers, not the old ones.
- Rated power: 20mW | Max power: 50mW
- Weight: 277g | Dimensions: 195×95×165mm
- Mic: Electret condenser (ENC), omnidirectional, 6.0×5.0mm, sensitivity -42dB ±3dB, SNR 58dB, output impedance ≤2.2kΩ, detachable, with mic cap
- CONNECTION IS USB ONLY — CONFIRMED BY COSMIC BYTE. The CryoCore has NO 3.5mm jack and NO 3.5mm mode. (The manual's highlights card shows a "Dual Input USB & 3.5mm" icon — that is a printing/template error; IGNORE it.) If a customer asks whether the CryoCore works with a 3.5mm device (phone, Xbox controller jack, Nintendo Switch), the answer is NO — it is USB only. For 3.5mm needs, point them to the Proteus X (genuine dual input).

WHAT'S IN THE BOX: CryoCore 7.1.4 headset, detachable microphone, user manual.

CONTROLS (on the earcup):
- Volume dial — scroll up = volume +, scroll down = volume −
- Mic switch — slide ON / OFF to enable or mute the microphone
- Detachable microphone plugs into the earcup port; mic cap included

WHAT THX SPATIAL AUDIO+ IS AND WHY IT MATTERS (use this to explain the benefit to customers):
- THX Spatial Audio+ is the immersive-audio platform from THX Ltd. (the company behind THX certification). It turns a stereo headset into a full 360° virtual surround experience using a physics-based room simulation, placing sounds around you — front, sides, behind AND above — with no physical speaker setup.
- WHAT "7.1.4" MEANS: the ".4" is FOUR HEIGHT channels. Ordinary 7.1 only places sound on a flat horizontal plane; 7.1.4 adds sounds coming from above, which completes the 360° soundscape. This is a genuine step up from the old 7.1 headsets.
- THE GAMING EDGE: enhanced positional accuracy — you can pinpoint where footsteps, gunfire, reloads and other cues are coming from, including above/below you. That directional awareness is the main competitive benefit. THX's engine is built specifically to make the most of positional sound cues in games.
- MOVIES & MUSIC: THX Spatial Audio mode gives a wider, more cinematic soundstage for films; THX Stereo mode gives clean, natural 2-channel playback that is ideal for music.
- AI HEAD TRACKING: uses your webcam to follow your head so the virtual sound field stays anchored to the world when you turn (instead of turning with you). Sounds keep coming from where they should — far more realistic, and it helps you keep your bearings in games. Requires THX Spatial Audio mode and a connected webcam.
- DEVICE-SPECIFIC TUNING: THX measures each headset's acoustic performance and designs custom filters/EQ so BOTH stereo and spatial playback are accurate for THAT exact headset. This is why the Cosmic Byte THX headsets have speakers tuned specifically for THX — the processing is matched to the hardware rather than generic.
- PERSONAL AUDIO PROFILES: content modes (Game / Music / Movie presets) plus the Standard and Parametric EQ let the customer tailor the sound to what they are doing.
- HONEST LIMITS (do not over-promise): THX Spatial Audio+ works ONLY on WINDOWS, and ONLY over the USB input. It does NOT run on macOS, Linux, consoles or phones, and it does NOT process audio over a 3.5mm connection. (A USB-connected headset still works as a normal USB audio device on PS4/PS5 or a Mac — just without the THX app / surround processing.) The full height/positional effect is strongest with content that carries positional audio — most modern games and surround movie mixes do; plain stereo sources gain a wider soundstage but not true discrete height cues.
- NOT ORBIT: the THX headsets (CryoCore, Proteus X, Olympus, Immortal) are NOT configured through Cosmic Byte Orbit (orbit.thecosmicbyte.com). Orbit is for keyboards/mice/controllers. For these headsets the software is the THX Spatial Audio+ Windows app, downloaded from www.thecosmicbyte.com. Do NOT send a THX-headset customer to Orbit.

THX SPATIAL AUDIO + SOFTWARE (WINDOWS-only desktop app — download it from www.thecosmicbyte.com; requires the headset connected by USB):
- When the headset is plugged in and detected, its name appears at the BOTTOM-LEFT of the app with a "Headphones" label. If it's not there: check the USB connection and wait for the app to finish loading.
- AUDIO MODE SWITCH (top-right of every screen) — the single most important control: "THX Stereo" = traditional 2-channel L/R (cleanest for music/general listening). "THX Spatial Audio" = virtual 360° surround field (hear direction of footsteps/gunfire in games; wider soundstage for movies).
- STANDARD SETTINGS (everyday controls): 10-band Equalizer (32 Hz to 16 kHz), each band adjustable +12 dB to -12 dB, toggle on/off; presets Default (flat) / Music (lifted bass + upper treble) / Game (in-game detail + positional cues) / Movie (dialogue + cinematic) / Custom (moving any slider auto-switches to Custom); Reset returns to flat. Sound Normalization (evens out quiet vs loud, slider sets strength — good for late-night). Bass Boost (one-tap extra low end). Voice Clarity (one-tap vocal-range emphasis for chat/streams/quiet dialogue).

- EXPERT > PARAMETRIC EQ: finer control than the Standard EQ. Same 5 presets + Reset. Response graph 20 Hz–20 kHz, +12/-12 dB, 10 draggable points (one per band). Per-band controls: Frequency (centre point), Gain (boost/cut in dB), Q (width — lower Q = broad, higher Q = narrow/surgical), Filter (Peak is the standard choice). Each band has a Band 1–10 checkbox to switch it off WITHOUT erasing its settings (for A/B comparison).
- EXPERT > CAMERA HEAD TRACKING: uses a webcam to keep virtual sound sources anchored to the world when you turn your head (more convincing spatial effect). REQUIRES THX Spatial Audio mode — in THX Stereo mode the app shows a notice that head-tracking effects can only be heard once Spatial Audio is enabled; flip the top-right mode toggle first. Controls: Device (choose your webcam/USB video device), Camera Mode (Auto recommended), Enable toggle (top-right). A preview shows your tracked head position vs the virtual speakers.
- USER SETTINGS: language + app information.
- SOFTWARE TROUBLESHOOTING: headset not shown in the app → check USB, let the app finish loading. Head-tracking "can only be heard when Spatial Audio is enabled" → switch the mode toggle to THX Spatial Audio. No surround effect → make sure the mode switch is on THX Spatial Audio, not THX Stereo.

SETUP — WINDOWS PC/LAPTOP (upgraded model): plug USB into the Windows PC → download and install THX Spatial Audio + from www.thecosmicbyte.com (Windows only) → open the app and confirm the headset appears bottom-left → set the mode switch to THX Spatial Audio for 7.1.4 surround → in Windows Sound Settings select the CryoCore as both output AND input.

SETUP — PS4/PS5: plug USB directly into the console. No software needed (THX Spatial Audio is a PC app). Adjust volume from PlayStation audio settings.
NOTE: Xbox is NOT officially supported via USB.

TROUBLESHOOTING (upgraded model):
Q: Headset not detected on PC? A: Check USB → try another USB port → set the CryoCore as default output/input in Windows Sound Settings → make sure the THX app has finished loading.
Q: No surround / sounds flat? A: In the THX app, switch the top-right mode from THX Stereo to THX Spatial Audio; confirm the CryoCore is the default output.
Q: Mic not working? A: Mic firmly plugged in → mic switch slid to ON → select the CryoCore as microphone input in Windows Sound Settings.
Q: No audio? A: Turn the volume dial up → set the CryoCore as default output.

LEGACY — OLD / DISCONTINUED CryoCore (7.1, 32Ω) — ONLY for customers who still own the old unit:
- Setup: connect USB → download the driver from https://www.thecosmicbyte.com/downloaddrivers/ → extract and run setup.exe → enable 7.1 Surround in that software → in Windows Sound Settings select "CB CryoCore" as output AND input.
- THX Spatial Audio is NOT supported on this hardware. Do not install it for the old model.
- Old-unit troubleshooting: not detected → reinstall the setup.exe driver, try another USB port, set "CB CryoCore" as default; no 7.1 → enable 7.1 in the driver software; mic → switch slid UP (ON) and "CB CryoCore" selected as input.
- This model is discontinued; replacement/upgrade path is the current THX CryoCore.

CARE: Keep away from moisture. Store cool and dry. Avoid bending the cable. Do not disassemble.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products NOT covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 (WhatsApp same) | Mon–Sat 10am–6pm

PRICING: do NOT quote a price for this headset. For the current price and any offers, direct the customer to the product page (BUY link below) — pricing is set on the website and changes.
BUY: https://www.thecosmicbyte.com/product/cosmic-byte-cryocore-7-1-surround-wired-gaming-headset/ — use coupon code ONLINEPAY for 10% off on online payments.

Cyclone RGB

Product page: https://www.thecosmicbyte.com/product/cyclone-rgb/

PRODUCT: Cosmic Byte Cyclone RGB — Laptop Cooling Pad

SPECS:
- Dimensions: 405×290×43mm | Weight: 1123g
- Fans: 1× 140mm (centre, RGB) + 4× 60mm (corners, blue)
- Fan speed: 1600–2500 RPM ±10%
- USB ports: 2× USB 2.0 HUB
- Power: DC 5V, 1A, 5W (USB powered)
- Material: ABS + Metal
- Laptop compatibility: up to 17-inch laptops

FEATURES:
- 12 RGB lighting effects on the centre fan and edge strip
- 7-level adjustable height/angle (fold-out legs) for optimal viewing and typing
- 3 fan modes — control which fans are on/off
- 3-level adjustable fan speed
- 2 USB ports to connect other devices while cooling

SETUP:
1. Connect the USB cable from the cooling pad to a USB port on your laptop
2. Place your laptop on the pad
3. Use the control panel to adjust fan speed, fan mode, and RGB effects

TROUBLESHOOTING:
Q: Fans not spinning?
A: Ensure USB is properly connected to the laptop. Try a different USB port.

Q: RGB not working?
A: Check USB connection. Cycle through RGB modes using the control button.

Q: Laptop still overheating?
A: Increase fan speed to max. Ensure laptop vents are not blocked. Clean laptop vents if dusty.

WARRANTY: 1 year against manufacturing defects. Physical/water damage and tampered products not covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon–Sat 10am–6pm

Dragonfly

Product page: https://www.thecosmicbyte.com/product/dragonfly-cb-gkm-19/

PRODUCT: Cosmic Byte Dragonfly — RGB Membrane Keyboard + Mouse Combo (CB-GKM-19)

KEYBOARD SPECS:
- Type: Full-size RGB membrane keyboard
- Anti-ghosting: 19-key
- Key life: 10 million keystrokes
- Weight: 637g ±10g | Dimensions: 458×170×32mm | Cable: 1.5m braided
- Features: Windows lock key, mobile phone holder, multimedia hotkeys, fold-out legs

MOUSE SPECS:
- Buttons: 7
- DPI: 200–12,800 (adjustable)
- Polling rate: up to 1000Hz
- Sensor: Instant 825 | Acceleration: 20G | Tracking: 60 IPS
- Switches: Huano 5M (L/R buttons)
- Weight: 80g (without cable) | Dimensions: 122×66×40.5mm
- RGB effects customisable via software

KEYBOARD SHORTCUTS (FN combinations):
FN + F1 = Media Select | FN + F2 = Volume − | FN + F3 = Volume + | FN + F4 = Mute
FN + F5 = Stop | FN + F6 = Previous Track | FN + F7 = Play/Pause | FN + F8 = Next Track
FN + F9 = Email | FN + F10 = Web/Home | FN + F11 = My Computer | FN + F12 = Calculator
FN + WIN-L = Lock/unlock Windows key

RGB MODES (keyboard):
FN+1=RGB | FN+2=RGB2 | FN+3=Colours Cycle | FN+4=7 Colour Breathing
FN+5=7 Colour Switch | FN+6=Light 1 | FN+7=Light 2 | FN+8=LED Off
FN+9=Custom (FN + ←/→ to choose colour, FN+9 again to save)
FN + ←/→ = direction control | FN + PgUp/PgDn = brightness up/down

SOFTWARE: The Dragonfly has TWO separate software downloads — one for the keyboard, one for the mouse. Both are listed on the Cosmic Byte downloads page (https://www.thecosmicbyte.com/downloaddrivers/) as separate entries: "Dragonfly Keyboard" and "Dragonfly Mouse". If the customer wants to configure both peripherals (keyboard macros + mouse DPI/macros/RGB), they need to download BOTH softwares. The keyboard software handles RGB modes and key remapping; the mouse software handles DPI tuning, macro assignment, and RGB customisation. Do NOT tell the customer there is a single combined Dragonfly software — there isn't.

TROUBLESHOOTING:
Q: Keyboard keys not registering?
A: 19-key anti-ghosting — some key combinations may not be supported simultaneously. Check Windows key is not locked (FN + WIN-L).

Q: Mouse DPI not changing?
A: Use the DPI button on the mouse or adjust via software.

Q: RGB not working?
A: Press FN+1 to cycle RGB modes. Ensure USB is fully connected. Reinstall software from thecosmicbyte.com.

Q: Multimedia keys not working?
A: Use FN + function key combinations (e.g., FN+F7 for Play/Pause).

WARRANTY: 1 year against manufacturing defects. Physical/water damage and tampered products not covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon–Sat 10am–6pm

Drakon

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-drakon-tri-mode-controller-with-charging-dock-case-tmr-joysticks-mechanical-buttons-rgb-for-pc-ios-android/

COSMIC BYTE DRAKON - TRI-MODE WIRELESS CONTROLLER - FULL MANUAL

PC ONLY. Not supported on any gaming console. No warranty for console use.

PACKAGE: Controller, 2.4G USB dongle (stored in magnetic dongle slot under top cover), USB-C cable (2m, braided), Charging Dock with magnetic contacts, Carrying Case (zip-up EVA hard case), 3 magnetic face plates (plain black / doodle artwork / dragon artwork — swappable top covers), 2 D-pads (Precision cross + Faceted Disc), 6 swappable joystick tops in 3 styles (short ridged concave / tall ridged concave / smooth dome — 2 pre-installed on the controller, 4 spare in the case), User Manual.

MOUSE MODE — ANDROID ONLY (NOT a PC feature)
(top-of-entry clarification block; added in v1.10.18 after a sibling-controller hallucination on Blitz Tri-Mode where the bot told a customer Mouse Mode worked on PC — production session 980aca7e, 2026-05-16 22:55. Ronak's cross-controller correction: "Mouse mode for Blitz Tri-Mode, Stellaris 2nd Gen and Drakon works only in Android." This block locks down the same fact on Drakon preemptively.)

The Drakon Mouse Mode (CAPTURE + R3 for 5 seconds — turns the controller into a mouse with right stick = cursor, A = left click, B = right click) is documented in the user manual as an ANDROID-ONLY feature. It is NOT available on PC. The connection mode (Wired vs 2.4GHz) does NOT determine Mouse Mode availability — the HOST OS does. Mouse Mode requires an Android host. On PC the Drakon continues to function as a standard XInput / DInput gamepad in all connection modes regardless of whether the customer holds CAPTURE + R3.

If a customer asks "does Drakon Mouse Mode work on PC", the answer is NO. If a customer asks "how do I use Mouse Mode on my PC", the answer is: Mouse Mode is Android-only, not a PC feature, BUT the customer can still control a PC cursor using their Drakon via third-party software. See Rule 16 (GAMEPAD AS MOUSE ON PC) in the system prompt for the three documented options (Gopher360 / JoyToKey / Steam Desktop Configuration). Do NOT leave a PC customer with just "Mouse Mode doesn't work on PC" — always pivot to Rule 16 to show them how to achieve the same end result. The Lumora is a separate option for customers who specifically want a built-in (no third-party software) PC keyboard/mouse remapping experience, but it's a recommendation for a different controller, not the only path — Rule 16's third-party tools work with the customer's existing Drakon.

✗ DO NOT SAY:
- "Drakon Mouse Mode works on PC in Wired mode" -- WRONG.
- "Drakon Mouse Mode works on PC in 2.4GHz mode" -- WRONG.
- "Drakon Mouse Mode is available on both PC and Android" -- WRONG.
- "The 2.4GHz Mouse Mode is for PC" -- WRONG. The "2.4GHz" in the previous KB phrasing referred to the CONNECTION mode (2.4GHz dongle to Android device via OTG), NOT the HOST platform (Android is the required host regardless of whether the connection runs through the 2.4GHz dongle or USB-C wired).

The user manual's input-mode tables list Mouse Mode only under the Android section. The PC section of the same tables has no Mouse Mode row at all. That's the source of truth.

BUTTON LAYOUT — PHYSICAL PLACEMENT ON THE DRAKON FRONT FACE
(top-of-entry self-claim block so the bot doesn't fabricate button locations; added in v1.10.16 after session 7ddbe793 surfaced a CAPTURE button location hallucination. Same pattern as Blitz Tri-Mode v1.10.13.)

The Drakon follows an Xbox-style face layout with offset analog sticks (left stick top-left, right stick bottom-right; D-pad bottom-left; ABXY cluster on the right). All system buttons are on the FRONT FACE in the center column between the two analog sticks / D-pad / ABXY cluster.

FRONT-FACE CENTER COLUMN (top to bottom — describe in this order if a customer asks "where is the X button"):

[Top row, three buttons across]
- SELECT button: oval button on the LEFT side of HOME (front face, upper area). Labelled with a small icon/no-text on the controller body — the label "SELECT" appears beneath it on the controller. Sometimes called BACK or VIEW button on Xbox-style layouts.
- HOME button: round button in the EXACT CENTER of the controller's top area, with the Cosmic Byte diamond/CB logo on it. Lights up orange / RGB. This is the central anchor of the layout — when describing other button positions, reference them relative to HOME.
- START button: oval button on the RIGHT side of HOME (front face, upper area). Mirrors the SELECT button on the opposite side of HOME.

[Middle row, just below HOME — center column]
- CAPTURE button: a small downward-arrow / triangular icon-button directly BELOW the HOME button, in the EXACT CENTER COLUMN of the front face. CAPTURE is positioned BETWEEN the D-pad (which is on the left) and the right analog stick (which is on the right), roughly centered horizontally. The label "CAPTURE" appears beneath the button on the controller body. It is on the FRONT FACE — NOT on the left side, NOT below the triggers, NOT near the grip, NOT on the back of the controller.

[Bottom row, just below CAPTURE — still center column]
- TURBO button: a small hexagonal-shape icon-button BELOW the CAPTURE button. The label "TURBO" appears beneath the button on the controller body. Same center-column placement as CAPTURE. So the center column reads top-to-bottom as: HOME → CAPTURE → TURBO.

LEFT SIDE OF FRONT FACE:
- LEFT analog stick (top-left position) with RGB LED ring around it.
- D-pad (bottom-left position, below the left stick).

RIGHT SIDE OF FRONT FACE:
- ABXY button cluster (top-right position) in Xbox layout — Y top, X left, B right, A bottom. Each button has its label (X / Y / A / B) printed on it.
- RIGHT analog stick (bottom-right position, below the ABXY cluster) with RGB LED ring around it.

TOP EDGE (shoulder buttons / triggers):
- LB (Left Bumper) — top-left shoulder, digital.
- LT (Left Trigger) — below LB, Hall Effect analog with 3-position physical lock (independent of RT).
- RB (Right Bumper) — top-right shoulder, digital.
- RT (Right Trigger) — below RB, Hall Effect analog with 3-position physical lock (independent of LT).
- USB-C charging port: TOP edge, center, between LB and RB.

BACK / REAR OF CONTROLLER:
- 2 macro paddle buttons (ML on the left grip back, MR on the right grip back). These are the "L4 / R4" buttons in Cosmic Byte software (labelling mismatch — same physical paddles, different software label).
- Magnetic Charging Dock contacts (the controller sits on the included charging dock with magnetic alignment).

WHEN A CUSTOMER ASKS "WHERE IS [BUTTON]?":
- For CAPTURE: "On the front face of the controller, in the center column directly below the HOME button (the round button with the Cosmic Byte diamond logo). CAPTURE is positioned between the D-pad and the right analog stick, roughly centered horizontally. It's the small button with the downward-arrow icon, labelled CAPTURE on the controller body. NOT on the left side, NOT below the triggers — it's on the front face."
- For HOME: "The round button in the exact center of the front face, with the Cosmic Byte diamond logo on it. Lights up orange / RGB."
- For SELECT / START: "Oval buttons on either side of HOME — SELECT on the left, START on the right, both on the front face upper area."
- For TURBO: "Front face center column, directly below the CAPTURE button. Small hexagonal-icon button, labelled TURBO."
- For ML / MR (macros): "On the BACK of the controller — two paddle buttons on the rear, one under each grip (ML left, MR right). These are the buttons Cosmic Byte software labels as L4 / R4."

═══════════════════════════════════════

JOYSTICK + TRIGGER CALIBRATION — EXPLICIT STEP-BY-STEP PROCEDURE
(top-of-entry self-claim block so the bot doesn't summarise the
procedure and accidentally drop steps; added in v1.10.16 after
session 7ddbe793 OMITTED the LT/RT trigger calibration step from
its calibration walkthrough.)

═══════════════════════════════════════

The Drakon supports user joystick + trigger calibration via the CAPTURE + HOME button combination. The procedure has SIX steps that MUST all be presented when walking a customer through calibration — do NOT abbreviate, do NOT stop after the joystick rotation step. The trigger press step is REQUIRED and is part of the same calibration sequence; skipping it means the triggers don't calibrate.

FULL PROCEDURE (six steps — every one needed):

STEP 1: POWER OFF the controller first. The controller must be fully OFF (not just asleep) before entering calibration mode. To power off: hold the HOME button for 5 seconds until all LEDs turn off. Wait a moment for full power-down.

STEP 2: ENTER CALIBRATION MODE. Press AND HOLD the CAPTURE button (front face center column, below HOME — see BUTTON LAYOUT section above), then WHILE STILL HOLDING CAPTURE, press the HOME button. Release both buttons. LED1 (leftmost LED) will start blinking — this confirms calibration mode is active and the controller is waiting for input.

STEP 3: CONFIRM READY. Press the A button (right side of the controller, bottom of the ABXY cluster). LED2 (second LED from the left) will start blinking — this confirms the controller is now actively listening for joystick movement.

STEP 4: ROTATE BOTH JOYSTICKS. Rotate both joysticks in full circles — LEFT joystick AND RIGHT joystick — completing THREE full circles each. Go slowly and deliberately, all the way to the outer edge in every direction. The sensor needs time to map every angular position. After 3 circles, return each joystick to its center / neutral position.

STEP 5: PRESS LT AND RT TRIGGERS — THIS STEP IS REQUIRED, do NOT skip it. Press the LT (Left Trigger) and RT (Right Trigger) THREE TIMES EACH — pull each trigger fully to its travel limit, then release fully, three times per trigger. This calibrates the trigger range so the Hall Effect sensors know the full pull-distance. (Note: if a customer has their trigger lock set to Position 1 — shortest / digital — they will not be able to pull the trigger far; for calibration, the trigger lock can be at any position, the procedure works either way, but Position 3 / full analog will give the cleanest calibration data.) Without this step, the triggers may have incorrect range mapping after calibration.

STEP 6: SAVE. Press the A button again. The controller will save the calibration data and exit calibration mode. Calibration complete.

A SINGLE-LINE REPRESENTATION of the same procedure (for the bot to internalize): Power OFF → Hold CAPTURE + press HOME (release both) → A → 3 circles each joystick → 3 presses each LT/RT → A → done.

✗ DO NOT SAY about the Drakon calibration procedure:
- "Hold down the CAPTURE button (the button on the LEFT SIDE of the controller, below the triggers)" — WRONG. CAPTURE is on the FRONT FACE center column, below HOME. NOT the left side, NOT below the triggers. Production session 7ddbe793 (2026-05-15 17:05) made this exact placement error.
- Walking through joystick rotation and then stopping / ending the procedure before the LT/RT trigger press step. The trigger calibration is part of the SAME sequence and MUST be presented as Step 5 (not optional, not "you can also..."). Session 7ddbe793 omitted this step entirely; the customer was left with an incomplete procedure.
- Saying CAPTURE is "near the triggers" / "on the grip" / "on the back" / "below the shoulder buttons". CAPTURE is a front-face center-column button. The triggers (LT/RT) are on the top edge,

not the front face — CAPTURE has nothing to do with the trigger position.
- Presenting calibration as a 4-step procedure ending with joystick rotation. It's a 6-step procedure ending with the second A press after the trigger calibration.

✓ CORRECT FRAMING when a customer asks for calibration walkthrough:
Always present all six steps in order. Always explicitly mention the LT/RT trigger press step as REQUIRED. Always describe CAPTURE as a front-face center-column button below HOME (not on the side, not below the triggers). If asked for a shorter / quick version, use the single-line representation above, but do NOT silently drop the trigger calibration step.

KEY FEATURES (full list — surface these accurately when comparing Drakon to other CB controllers):
- JOYSTICKS: TMR (Tunnel Magnetoresistance) — drift-resistant, high precision. Confirmed by Cosmic Byte; the product page URL itself contains "tmr-joysticks". Same joystick tech tier as Blitz Tri-Mode and Stellaris 2nd Gen. (Lumora, Ares Pro, and current Ares Tri-Mode have Hall Effect joysticks — different sensor tech.)
- TRIGGERS: Hall Effect analog sensors, with an ADDITIONAL 3-position physical trigger lock for travel-length adjustment (Position 1 = shortest travel, digital on/off feel; Position 2 = medium analog ~50% travel; Position 3 = full analog 100% travel), independent per trigger (LT and RT lock separately). The sensor underneath the lock is Hall Effect in all three positions — the lock changes the mechanical travel range, not the sensor type. So Drakon's trigger combo is "TMR joysticks + Hall Effect analog triggers with mechanical 3-position lock". If a customer asks whether Drakon triggers are Hall Effect, the answer is YES; if they ask about TMR triggers, the answer is NO (Drakon's TMR is on the sticks only, not the triggers).
- MACRO BUTTONS: 2 dedicated programmable macro buttons (ML / MR), each records up to 22 inputs with delays. (NOTE: Cosmic Byte software displays these buttons as "L4 / R4" — same physical buttons, different label in software vs on the controller. This is a known display-label mismatch; do not tell the customer their controller is wrong.) Lumora has 4 macros; Blitz Tri-Mode has 0.
- RGB LIGHTING: 7 customisable zones, up to 8 keyframe animations per zone via Cosmic Byte software. Plus on-controller modes: Rainbow / 7-colour gradient / Breathing / Fixed (cycle with FNL + SELECT). Brightness adjustable. RGB can be turned off entirely (Hold LT + RT 5 seconds). More granular than Lumora's 5-zone preset-animation RGB.
- GYRO: 6-axis. Native Bluetooth Gyro Mode (press Y + HOME for 3 seconds, LED4 on) appears as "Pro Controller". Plus on-the-fly software gyro (via Cosmic Byte software, works in wired or 2.4GHz mode) — assignable to any button, with three activation modes (Always On / Toggle / Press and Hold). Output mimics joystick movement so it works in any game with joystick support.
- MAGNETIC TOP COVER / FACE PLATE: 3 face plates included (plain black / doodle artwork / dragon artwork). Swap by lifting from the front edge gap. Dongle storage slot inside the cover.
- VIBRATION: Dual motors, 4 levels (Off / Low / Medium / High) adjustable via FNL + Right Joystick Up/Down.
- TURBO: 5/15/25 shots-per-second, semi-auto and full-auto modes. Speed adjustable.
- BATTERY: 1000mAh, 8-20 hours depending on RGB usage. RGB auto-disables at low battery to extend playtime.
- POLLING: 1000Hz on Wired and 2.4GHz.
- CONNECTIVITY: Tri-Mode (USB-C Wired / 2.4GHz dongle / Bluetooth). Multi-platform via Bluetooth: PC (XInput + DInput), Android (XInput + DInput), iOS (XInput).
- 3.5mm AUDIO JACK: Works in 2.4GHz wireless and wired modes only. NOT in Bluetooth or mobile modes.
- SOFTWARE: Cosmic Byte software supports button remapping, RGB keyframe customisation, software gyro assignment, polling rate, and firmware updates. Software is WINDOWS-ONLY — Drakon still works on Mac via Bluetooth for basic gamepad use, but no Mac software exists. (See cross-product MAC COMPATIBILITY POLICY in the system prompt.)

CONNECTIVITY:
- Wired PC XInput: Plug in, press HOME. LED2 on.
- Wired PC DInput: FNR + HOME (3 sec) under XInput. LED3 on.
- Wired Android: Plug in, press HOME. LED3 on.
- 2.4GHz PC XInput: Press X + HOME (3 sec). LED2 on.
- Mouse Mode (Android ONLY, available in Wired or 2.4GHz connection — NOT available on PC): Hold CAPTURE + R3 for 5 seconds. LED3+LED4. A=left click, B=right click, Right stick=cursor. Repeat to exit. Mouse Mode is an Android-only feature per the user manual — on PC the controller continues to function as a standard gamepad regardless of connection mode. The previous "2.4GHz Mouse Mode" framing was misleading; the connection mode (2.4GHz vs Wired) doesn't determine whether Mouse Mode is available — the HOST OS does. Mouse Mode = Android host only.
- Bluetooth PC XInput: Press B + HOME (3 sec). LED2.
- Bluetooth PC DInput: Press A + HOME (3 sec). LED3.
- Bluetooth Android XInput: Press B + HOME (3 sec). LED2.
- Bluetooth Android DInput: Press A + HOME (3 sec). LED3.
- Bluetooth iOS XInput: Press B + HOME (3 sec). LED2.
- Bluetooth Gyro (all): Press Y + HOME (3 sec). LED4.

GYRO: Bluetooth mode ONLY natively (press Y + HOME for 3 sec, LED4 on).
Via Cosmic Byte software (wired/2.4GHz):
ON-THE-FLY GYRO (via Cosmic Byte software - works in ANY game even without native gyro support):
- Connect via Wired or 2.4GHz. Open Cosmic Byte software (download from https://www.thecosmicbyte.com/downloaddrivers/).
- Assign gyro to any button of your choice.
- Three activation modes:
  * Always On - Gyro is always active (good for racing/flight games).
  * Toggle - Press the assigned button once to enable, press again to disable.
  * Press and Hold - Gyro only active while the button is held down (best for aiming in FPS).
- Gyro output mimics left or right joystick movement, so it works in ANY game that supports a joystick - even games with no native gyro support.
- Note: Native Bluetooth Gyro Mode is also available (press Y + HOME for 3 seconds) but software method works over wired/2.4GHz and gives full activation control.

HOME BUTTON ACTIONS:
- Wake: Press HOME.

- Force Pair: Hold HOME 3 sec.
- Sleep/Off: Hold HOME 5 sec.
- Toggle X/D Input (2.4G PC): Hold HOME 3 sec.

TRIGGER LOCK (3 levels, LT and RT independent):
- Position 1 = Shortest, digital (on/off button).
- Position 2 = Medium travel, analog ~50%.
- Position 3 = Longest, full analog 100%.

MAGNETIC TOP COVER: Lift from front edge gap, pull upward. Magnets release. Dongle storage slot inside.
D-PAD SWAP: Grip current D-pad, pull up. Press replacement down until locked.
JOYSTICK TOP SWAP: Pull up to remove. Push new one until snaps.

TURBO: Press TURBO + button (semi-auto). Repeat for full auto. Repeat to turn off. Clear all: Hold FNR + TURBO (5 sec). Vibration confirms. Speeds: 5/15/25 shots/sec. Speed adjust: FNL + Turbo, then Right Joystick Left/Right.
VIBRATION: Hold FNL + Right Joystick Up/Down. Levels: Off, Low, Medium, High.

MACRO (ML/MR): FNL + ML for 2 seconds to record, FNR + MR for 2 seconds to record. Up to 22 inputs with delays recorded. Press same M button to save. Short vibration confirms. Clear: enter mode, press M button with no input -> vibration confirms deletion.
FACTORY RESET: Hold L1 + R1 + L2 + R2 + L3 + R3 simultaneously. Vibrates 1 second. Clears turbo, vibration, macro settings.

RGB: Change mode: FNR + START. Cycle effects: FNL + SELECT (Rainbow, 7-colour gradient, Breathing, Fixed). Change colour fixed mode: FNR + D-pad Up. Brightness: FNR + D-pad Up (increase), Down (decrease). Turn off all RGB: Hold LT + RT for 5 seconds.

JOYSTICK CALIBRATION (TMR): Power OFF. Hold CAPTURE then press HOME. LED1 blinks -> press A -> LED2 blinks. Rotate both joysticks 3 full circles. Press LT and RT 3 times each. Press A again to save.
D-PAD 4-WAY/8-WAY: Hold SELECT + D-pad Right for 3 seconds.
ABXY SWAP: Hold TURBO + R3 for 2 seconds.
D-PAD/JOYSTICK SWAP: Hold L3 + CAPTURE for 2 seconds.
JOYSTICK ROUND/SQUARE: Hold L3 + TURBO for 2 seconds.

MECHANICAL BUTTONS: Drakon has MECHANICAL ABXY face buttons AND mechanical LB/RB shoulder bumpers (clicky-tactile switches, not rubber-dome). The D-pad on Drakon is rubber-dome (NOT mechanical). Among Cosmic Byte gamepads, Drakon shares this mechanical-ABXY+LB/RB feature with Lumora; the difference is that Lumora ALSO has a mechanical D-pad while Drakon's D-pad is rubber-dome. If a customer asks "is Lumora the only CB controller with mechanical buttons?", the answer is NO -- Drakon has mechanical ABXY+LB/RB too. Lumora is unique only in adding a mechanical D-pad on top of those.

CHARGING: Dock - connect to power, place on magnetic contacts. Dock LED on = charging, off = full. Cable - USB-C to 5V source. LED blinking = charging, steady = full. RGB turns off at low battery. Battery: 8-20 hours.
AUDIO: 3.5mm works in 2.4GHz wireless and wired only. NOT in Bluetooth or mobile.
RESET: Pin into RESET hole for 1 second. Normal restart.
AUTO SLEEP: 5 minutes inactivity or 30 seconds disconnected from dongle.

TROUBLESHOOTING:
- Not charging: Check dock alignment/power. Use 5V USB adapter for cable charging. Clean charging pins.
- Not detected: Use data-capable USB cable. On Android ensure OTG enabled. Press HOME after connecting.
- Bluetooth fails: Remove "Cosmic Byte Drakon" from Bluetooth list. Re-enter pairing mode.
- Joystick drift: Recalibrate using CAPTURE + HOME method above. Check module is fully seated.
- Triggers not responding: Check trigger lock switch position. Move to Position 3 (full travel) for analog games.
- Controller frozen: Pin into RESET hole for 1 second.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered.

BATTERY CAPACITY — AUTHORITATIVE (do NOT regress): The Drakon battery is 1000mAh. An earlier version of this entry and some chat responses stated 600mAh — that was WRONG and has been corrected (confirmed by Cosmic Byte). If you ever recall, infer, or see "600mAh" for the Drakon, treat it as the stale/incorrect figure and use 1000mAh. Runtime is unchanged: 8-20 hours depending on RGB usage, with RGB auto-disabling at low battery. IMPORTANT — do NOT over-correct: the 600mAh figure is CORRECT for the Blitz Tri-Mode and Blitz Wireless (those genuinely are 600mAh) — only the Drakon's figure changed from 600 to 1000mAh. (Note: the Starforge is 1200mAh, NOT 600mAh — see its own entry.)

Eclipse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-eclipse-tri-mode-controller-adjustable-force-tmr-joysticks/

COSMIC BYTE ECLIPSE - TRI-MODE WIRELESS CONTROLLER - FULL MANUAL

JOYSTICKS: TMR (Tunnel Magnetoresistance) — drift-resistant, high precision. Confirmed by Cosmic Byte; the product page URL itself contains "tmr-joysticks". Same joystick tech tier as Blitz Tri-Mode, Stellaris 2nd Gen, and Drakon. (Lumora and Ares Pro have Hall Effect joysticks — different sensor tech.) If a customer asks whether the Eclipse has TMR / Hall Effect / drift-resistant joysticks, the answer is YES — TMR. Do NOT say "Hall Effect joysticks" for the Eclipse, and do NOT say "the manual doesn't specify".

TRIGGERS: Hall Effect (analog). Drift-resistant magnetic-sensor triggers. NOT TMR — the Eclipse pairs TMR sticks with Hall Effect triggers (the same sensor combo as Stellaris 2nd Gen AND Drakon — all three have TMR sticks + Hall Effect analog triggers. Drakon additionally has a 3-position physical trigger lock that mechanically adjusts trigger travel range, but the underlying trigger sensor on Drakon is still Hall Effect, same as Eclipse and Stellaris 2nd Gen).

CONNECTIVITY:
- Physical mode switch: Left=Bluetooth, Middle=2.4G, Right=NS (Gyro Bluetooth mode).
- 2.4GHz: set switch to Middle, plug USB receiver, hold Pairing button 3 seconds - solid logo + vibration = connected.
- Bluetooth: set switch to Left (or NS for gyro), hold Pairing button 3 seconds, select 'Xbox Wireless Controller' on device.
- Wired: connect USB-C cable - activates automatically.
- Reconnect to last device: short-press Home.
- Compatible with PC, Android, iOS 13+.
- NOT compatible with PS4, Xbox, Nintendo Switch, or any console.
- Range: ~10 metres.

LOGO LIGHT COLOURS:
- Blue = iOS or Android (Bluetooth).
- Orange = 2.4G mode.
- Green breathing = charging.
- Red flash once every 10 minutes = low battery.
- Logo off = fully charged.

ABXY LAYOUT SWITCH:
- Physical switch on front toggles between Xbox-style and Alternate-style layout.
- NOTE: gyro calibration MUST be performed in Xbox (ABXY) layout mode.

JOYSTICK RESISTANCE ROLLER:
- Physical roller at base of each analog stick. Clockwise = stiffer, counter-clockwise = looser.
- Stiffer = better for FPS precision. Looser = better for quick flicks.

DEAD ZONE TOGGLE:
- Hold LS + RS simultaneously for 5 seconds. Toggles between 5% deadzone (default) and 0% (max precision).
- Active zone shape: hold M + LS or RS for 5 seconds = toggle between 10% square and 0% circle zone.

TURBO & AUTO TURBO:
- Each press of M + button cycles: Manual Turbo -> Auto Turbo -> Cancel.
- Auto-firing button: press M + that button one more time to cancel.
- Supported: A, B, X, Y, LB, LT, RT, D-pad. (RB NOT supported.)
- Speed: hold M + Right Stick Up (increase), hold M + Right Stick Down (decrease).
- Clear ALL turbo: press M twice, then hold M for 5 seconds. Vibrates to confirm.

M1/M2 MACRO BUTTONS:
- Record: hold M + M1 (or M2) for 3 seconds -> press desired button -> press M1/M2 to save.
- Up to 21 programmable buttons.
- Clear: hold M + M1 for 3 seconds -> exit without pressing anything.

STICK & TRIGGER CALIBRATION (use this for ALL drift / joystick / trigger response complaints — the Eclipse has an active, user-driven calibration; it is NOT a "sit untouched" procedure):

Exact procedure, step by step (do not paraphrase or improvise — follow these steps verbatim):

1. Power on the controller.
2. Hold View + M + Menu together for 3 seconds. The buttons are:
3. View — top-left, near the left joystick.
4. M — centre-bottom, marked with "M".
5. Menu — top-right, near the right joystick.
6. LED1 and LED3 (channel indicator lights, near the right joystick) start flashing. This confirms calibration mode is active.
7. While in calibration mode, perform every action in this list:
8. Rotate the LEFT joystick clockwise 3 full turns.
9. Rotate the RIGHT joystick clockwise 3 full turns.
10. Fully press LT (left trigger) 3 times.
11. Fully press RT (right trigger) 3 times.
12. Switch the Trigger Travel switch on the back of the controller from LONG to SHORT travel.
13. With short travel selected, fully press LT 3 more times, and RT 3 more times.
14. Press the View button to exit calibration. LED1 and LED3 stay solid for 5 seconds, then the controller powers off.

15. Power back on and test.

IMPORTANT: BOTH long and short trigger travel modes must be calibrated. Skipping the short-travel pass leaves the trigger response inconsistent in games that use short-travel mode.

DRIFT NOT FIXED BY CALIBRATION? Check the Joystick Resistance Roller adjustment (see JOYSTICK RESISTANCE ROLLER section above). Per the manual's own troubleshooting (Q5), too-stiff joysticks can feel like drift. Try rotating the roller counter-clockwise to reduce stiffness, then re-test.

DRIFT STILL PRESENT AFTER BOTH CALIBRATION AND ROLLER ADJUSTMENT? Escalate via the standard support flow (rule #11): raise a ticket at https://www.thecosmicbyte.com/raise-a-ticket/ or contact cc@thecosmicbyte.com / +91 7351615161.

GYRO CALIBRATION:
- Power off. Place flat on stable surface. Hold View + A + B + Home -> LED1+LED2 flash.
- After 1 second, press Menu to complete. MUST be in Xbox layout mode.

TRIGGER TRAVEL SWITCH:
- Physical switch on back for LT and RT (independent).
- Long travel = full analog range (racing/simulation). Short travel = instant response (FPS).

ABXY LED BRIGHTNESS:
- Adjust: M + Right Stick Left/Right. Four levels: 0%, 30%, 70%, 100%.

BATTERY & CHARGING:
- 1200mAh, 11-13 hours. Charge time: 3-4 hours. Use 5V 500mA charger or PC USB port.
- Wireless charging contacts on back for compatible charging dock.

KEY LINKER MOBILE APP (Eclipse — BUTTON REMAPPING ONLY):
- Available on iOS and Android only (Google Play / Apple App Store). NO PC version.
- Pair the Eclipse via Bluetooth with a mobile device, open Key Linker, and use it for advanced button remapping.
- IMPORTANT — scope: Key Linker on the Eclipse handles BUTTON REMAPPING ONLY. It does NOT update firmware on the Eclipse.

CONFIGURATION (Eclipse — IMPORTANT):
- The Eclipse has NO PC companion software. None exists.
- ALL controller configuration on the Eclipse — RGB, turbo, vibration, macros, calibration, dead zone, joystick range — is done via gamepad button shortcuts on the controller itself (see shortcuts above).
- Mobile button remapping is via Key Linker only (iOS/Android).
- Do NOT direct Eclipse customers to download "Cosmic Byte software" or any PC software — there is no PC software for this product.

FIRMWARE UPDATE (Eclipse — manual file path when available):
- The Eclipse has no PC software, so firmware updates are NOT done through any software.
- If a firmware update for the Eclipse is currently available, it is posted on https://www.thecosmicbyte.com/downloaddrivers/ or on the Eclipse product page on thecosmicbyte.com, along with the instructions for applying it. Customer downloads the file and follows the on-page instructions.
- If no firmware update is currently posted on the website for the Eclipse, the controller is on the latest available firmware — there is nothing to install. Suggest checking the website periodically.
- If the customer cannot locate firmware information and believes an update is needed, direct them to support (cc@thecosmicbyte.com) — do NOT invent a URL or filename.

RESET & POWER:
- Power off: hold Home 5 seconds. Auto-off: 10 minutes.
- Factory reset: press Reset hole on back with pin - clears all settings and pairing data.

WARRANTY:
- 1 year against manufacturing defects only.
- Physical damage, water damage, tampered products NOT covered.
- Replaceable D-pad included in box.

ANTI-HALLUCINATION GUARD (Eclipse — read this before answering any calibration / button-combo / drift question):

The Eclipse calibration procedure is exact: View + M + Menu (held 3 seconds) -> LED1 and LED3 flash -> rotate both sticks clockwise 3 full turns + press both triggers 3 times -> switch to SHORT travel mode and repeat the trigger presses -> press View to exit (LEDs stay solid 5 seconds, controller powers off). Use the STICK & TRIGGER CALIBRATION section above verbatim — do NOT improvise a different procedure.

Known hallucinations the AI has produced when asked about Eclipse joystick recalibration — do NOT reproduce any of these, even if they sound plausible from generic gaming-controller knowledge:

(a) "Hold TURBO + Y for 3 seconds" -- WRONG. The Eclipse has NO dedicated TURBO button. There is no button on the controller labelled TURBO. Turbo is FUNCTIONALITY accessed via M + button combinations (M + A enables manual turbo on the A button, M + B on B, etc. — see TURBO & AUTO TURBO section above). The correct calibration combo is View + M + Menu, NOT TURBO + anything.

(b) "Do NOT touch the joysticks during calibration" -- WRONG. The Eclipse stick calibration REQUIRES rotating both joysticks clockwise 3 full turns AND pressing both triggers 3 times. It is an active, user-driven calibration. The "place flat / don't touch" pattern applies to GYROSCOPE calibration only — that is a SEPARATE procedure (View + A + B + Home with the controller powered OFF and placed flat, then press Menu after 1 second; see GYRO CALIBRATION section). Do not blend the two procedures.

(c) "Wait for the vibration to stop" -- WRONG. There is no vibration cue for Eclipse stick calibration. The visual cues are LED1 and LED3 (channel indicator lights, near the right joystick) FLASHING when calibration mode is active and STAYING SOLID for 5 seconds when calibration completes (after which the controller powers off automatically). If you find yourself describing a vibration cue for stick calibration, stop — you're hallucinating.

(d) Inventing other button combos like "M + Y", "Hold Home for 5 seconds for calibration", "Press the pairing button while holding sticks", or any combination not exactly "View + M + Menu" -- WRONG. View + M + Menu is the only correct stick/trigger calibration combo per the manual.

(e) Forgetting the second-stage short-travel trigger calibration -- INCOMPLETE. The procedure has TWO trigger-press stages: first in long-travel mode, then again in short-travel mode after toggling the Trigger Travel switch on the back. Do not omit the short-travel pass.

(f) Recommending calibration without checking whether the customer's complaint might be solved by the Joystick Resistance Roller -- INCOMPLETE. Per the manual's own troubleshooting (Q5), too-stiff joysticks can feel like drift; rotating the roller counter-clockwise reduces stiffness. Mention BOTH calibration AND roller adjustment for drift complaints.

If a customer's reported step doesn't match the manual procedure above, treat it as a customer mistake or a wrong-product confusion (the customer might actually have a different controller). Confirm they have a Cosmic Byte Eclipse before walking them through any procedure.

GENERAL GUIDANCE FOR VAGUE ECLIPSE QUESTIONS:
If a customer's message is just "Eclipse" or "eclips" with no specific question (as has happened in production logs), DO NOT assume they are asking about calibration / drift / any specific topic. ASK them what they need help with — pairing, calibration, RGB, macros, software, charging, etc. — before launching into a how-to. Volunteering an unrequested calibration walk-through wastes the customer's time and (as v1.4.1 demonstrated) is the exact context where the AI is most likely to hallucinate the steps.

Firefly TKL

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-firefly-tkl-per-key-rgb-mechanical-keyboard/

COSMIC BYTE FIREFLY TKL — WIRED 87-KEY MECHANICAL KEYBOARD (CB-GK-16 / CB-GK-18)

WIRED ONLY. 87-key TKL layout (no numpad). Outemu swappable switches. Per-key RGB. Adjustable height legs. Compact design.

VARIANTS: CB-GK-16 (Outemu Blue switches — tactile, clicky) | CB-GK-18 (Outemu Red switches — linear, quiet)
SPECS: 87 keys US layout. Outemu swappable switches, 50M keystrokes. 1000Hz polling rate. 1.6m braided cable, detachable USB-C port. 360x127x40mm, 800g. Full key anti-ghosting. 11 lighting animations, 18 preset RGB configurations. Adjustable height via fold-out legs. Software: Windows (download from https://www.thecosmicbyte.com/downloaddrivers/).

WHAT'S IN THE BOX: Keyboard, USB-C cable, keycap puller, switch puller, 2 extra switches, user manual.

ADJUSTABLE HEIGHT: Fold-out legs on the bottom allow 2 typing height options. Open legs for higher angle, closed for flat.

SWITCH SWAPPING:
Step 1: Use keycap puller to remove keycap. Step 2: Squeeze switch puller on both sides of switch, pull straight up. Step 3: Insert new switch straight down until it clicks firmly. Compatible: Outemu Blue, Red, Brown or any Outemu swappable switches. Buy from thecosmicbyte.com.

BACKLIGHT:
- 18 preset RGB configurations, 11 lighting animation modes
- Software allows full per-key RGB customization
- Hardware controls available via FN key combinations (see below)

FN KEY SHORTCUTS (based on Firefly model):
- FN + Win: Lock/Unlock Windows key
- FN + Up/Down: Adjust backlight brightness
- FN + Left/Right: Adjust backlight animation speed
- FN + Space: Toggle backlight on/off
- FN + ESC (hold 3s): Factory reset — restores all defaults
- Multimedia controls available via FN + F-key row

SOFTWARE: Download from https://www.thecosmicbyte.com/downloaddrivers/
- v1.0.0.4 (March 2026): Fixed icon and software resolution display.
- v1.0.0.3 (Nov 2025): Fixed Debounce Time Adjustment issue.
Always use the latest version from the official website. (Windows only). Full per-key RGB customization, macro programming, key remapping. Check thecosmicbyte.com Firefly TKL product page for latest software version.

TROUBLESHOOTING:
- Keyboard not detected: Try different USB port (directly to PC, not via hub). Try different cable.
- Key not working: Remove and re-insert switch using switch puller. Replace switch if still faulty.
- Backlight not working: Use FN key + brightness shortcut to increase. Factory reset: FN + ESC 3s.
- Software not detecting keyboard: Run as administrator. Try different USB port. Reinstall software.
- Windows key not working: FN + Win to unlock.
- Height uncomfortable: Use fold-out legs for elevated typing angle.
- Mac use: Plug-and-play for basic typing. RGB software Windows only.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

Firestorm Mouse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-firestorm-rgb-wired-gaming-mouse/

COSMIC BYTE FIRESTORM MOUSE - WIRED RGB GAMING MOUSE - FULL MANUAL

IMPORTANT: WIRED ONLY. No wireless or Bluetooth.

CONNECTIVITY:
- USB wired only. Connect to PC via USB cable (1.5m paracord with cable management loop).
- Windows detects automatically within 5-30 seconds. Plug and play.
- Setup: connect mouse, download software from thecosmicbyte.com.
- IMPORTANT when installing software: temporarily disable antivirus - antivirus may block installation.
- After install: restart PC. Then configure via software.

SENSOR: Model 3327. DPI range: 200-12400. Polling rate: 1000Hz. 220 IPS, 30G acceleration.
SWITCHES: Huano (10M clicks).
WEIGHT: 67g without cable.

DPI: Press DPI button to cycle through presets. LED colour changes with each DPI level.
Custom DPI (200-12400) configurable via software.

RGB LIGHTING: 11 RGB effects. Honeycomb body lets RGB shine through.
- Customise via Cosmic Byte Firestorm software (Windows ONLY).
- RGB not working: cycle effects with mode button, check software settings, ensure not set to Off.
- Software not detecting mouse: run as Administrator, try different USB port, reinstall.

REPLACEABLE TOP COVER: Honeycomb cover (default, RGB shows through) + plain solid cover included.
Swap covers to change between open and clean aesthetics.

SOFTWARE: 7 programmable buttons. Windows ONLY - macOS users cannot access software features.

TROUBLESHOOTING:
- Software not detecting: run as Administrator, reinstall, disable antivirus, try different USB port.
- Cursor not moving: use mousepad (not glass), clean sensor, try different USB port, restart PC.
- Buttons remapped unexpectedly: open software, restore defaults, reassign as needed.
- Input lag: set polling rate to 1000Hz in software, try direct USB port (not hub), check cable.

WARRANTY: 1 year manufacturing defects only. Water, physical damage NOT covered.
Support: +91 7351615161 (Mon-Sat 10am-6pm), cc@thecosmicbyte.com.

Helios Mouse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-helios-tri-mode-mouse-with-software-support-1000hz-polling-rate/

COSMIC BYTE HELIOS DRAGON - TRI-MODE GAMING MOUSE - FULL MANUAL

SPECS: FR2012 + S203 sensor, 800-10,000 DPI, polling rate is per-mode (Wired: fixed 1000Hz, 2.4GHz: configurable via software 125/250/500/1000Hz default 1000Hz, Bluetooth: fixed 125Hz), 81g, Huano 10M click switches, PTFE feet, 5 programmable buttons, 6 RGB effects, 1.6m braided cable. Tri-mode: Wired + 2.4GHz + Bluetooth (BT1 + BT2 channels).

CONNECTIVITY:
- Wired: Connect USB cable -> auto switches to wired mode. Charges while connected. Works regardless of power switch position.
- 2.4GHz: Plug USB receiver. Turn power switch ON. Short press 2.4G/BT button -> Red LED flashing = connecting. Light turns off when connected. Try different USB port if not detected. Avoid USB hubs.
- Bluetooth BT1: Turn power ON. Short press 2.4G/BT button until Green blinking. Long press 2.4G/BT for 3 seconds (or 1 second for first-time) -> fast blinking = pairing mode. Select "Helios BT1" in Bluetooth list. Light off = connected.
- Bluetooth BT2: Same until Blue blinking -> "Helios BT2".
- Bluetooth polling: 125Hz only (hardware limitation, not a defect).
- Best for gaming: Wired or 2.4GHz (1000Hz).

DPI: Press DPI button to cycle (800/1600/2400/3200/6400/10000 DPI). Customise via software for precise levels.

RGB: 6 preset lighting modes on top of mouse. Customise via Windows software.

BATTERY: 500mAh rechargeable. Charge time: approximately 2 hours (charges over the USB-C cable; the mouse keeps working in wired mode while charging). Both figures confirmed by Cosmic Byte, 2026-09-01.

BATTERY LIFE (wireless use): Helios runtime depends on the RGB lighting.
- RGB ON: up to ~20 hours of continuous use.
- RGB OFF: up to ~50 hours of continuous use (with lighting off the mouse draws under 12mA).
So switching the RGB off more than doubles runtime (≈20H -> ≈50H). These figures apply to wireless modes (2.4GHz / Bluetooth). In WIRED mode it is moot — the mouse runs off USB power and charges while connected, so it does not run the battery down.
SOURCE: runtime figures (20H lights-on, 50H lights-off) and the <12mA lights-off draw from the operator-supplied official spec, 2026-05-20; the 500mAh capacity and ~2-hour charge time confirmed by Cosmic Byte 2026-09-01. These are the confirmed battery figures for the Helios.

✓ Battery CAPACITY is 500mAh — CONFIRMED. State it when asked. Do NOT borrow another product's figure (e.g. 600mAh, 1000mAh, 1200mAh, 1300mAh belong to other Cosmic Byte devices) — the Helios is 500mAh. (An earlier version of this entry said the capacity was unspecified; that is superseded — 500mAh is now confirmed.)
✓ CHARGE TIME is approximately 2 hours — CONFIRMED. State it as "about 2 hours" (it is an approximate figure, so do not present it as exact to the minute). Do NOT invent a charging CURRENT (mA/W) — that is still not documented.
✗ Do NOT frame the 20H vs 50H gap as a Bluetooth-vs-2.4GHz difference — the difference is RGB ON vs OFF, not the connection mode.
✗ Do NOT inflate beyond the stated numbers (e.g. "60+ hours") or quote a per-hour battery drain — only ~20H and ~50H are confirmed.
✓ CORRECT framing: "On the Helios, battery life depends on the RGB lighting — about 20 hours with the lights on, and up to about 50 hours with the lighting off. So if you want to stretch the charge, turn the RGB off."

HELIOS COMPANION SOFTWARE — full feature documentation
(added in v1.10.22 based on operator-supplied screenshots, 2026-05-18.
This section documents EVERY tab, EVERY setting, and EVERY supported
range, so the bot can answer software-feature questions without
fabricating capabilities.)

APP IDENTITY: The companion software is titled "Cosmic Byte Helios Mouse" in the Windows title bar. It is Windows-only — there is no macOS or Linux version. The software is specific to the Helios — do NOT assume the same software, UI, or feature set applies to other Cosmic Byte mice (Helios has its own app; Velox, Hypernova, Atlas, Firestorm, etc. either have their own apps or no companion software at all).

CONNECTION SCREEN (the landing screen the software shows on launch): displays the CURRENT CONNECTION MODE of the connected Helios mouse — NOT a "no mouse detected" state. The label on the card reads either:
  - "USB Receiver" — the mouse is currently connected via the 2.4GHz USB dongle.
  - "Wired" — the mouse is currently connected via the USB cable.
The mouse image and the www.thecosmicbyte.com link are constant on this screen. The connection-mode label switches between "USB Receiver" and "Wired" automatically based on how the mouse is currently connected. Do NOT describe this as a disconnected / "plug in the receiver" state — the mouse IS already connected when this screen displays, and the label is confirming WHICH mode. From this screen the customer proceeds to the main configuration page (the four-tab UI). The companion software only operates when the Helios is connected via Wired OR 2.4GHz (USB Receiver) — Bluetooth-mode connections are NOT supported by the software, even though the Helios itself supports Bluetooth (BT1 + BT2 channels) for normal mouse operation. If a customer in Bluetooth mode reports the software isn't detecting their Helios, the answer is: that's expected — the software doesn't work over Bluetooth. Switch to Wired or 2.4GHz to configure the mouse via software. (Note: this is a software-side limitation, not a hardware defect. The Helios works fine as a Bluetooth mouse for normal use — Bluetooth-mode customers just can't configure DPI / button remapping / polling rate / lighting via the companion software while connected over Bluetooth. To customise those settings, briefly switch to 2.4GHz or Wired, configure, save to Onboard configuration, then switch back to Bluetooth — the saved settings persist on the mouse.)

MAIN UI LAYOUT (once connected):
- LEFT SIDEBAR:
  * Device label: "Cosmic Byte Helios" with green status dot when connected.
  * [+ Create] button: creates a new profile slot.

    * [Import] button: imports a previously-saved profile file.
    * "Onboard configuration" link: stores the current configuration to the mouse's internal memory so settings persist across PCs (no need to install the software on every PC).
- TOP TABS (4): Key remapping (default), DPI, Performance, Others.
- TOP-RIGHT STATUS: battery indicator (e.g. "Less than 75%") + connection type (e.g. "2.4G"). Real-time, updates as the mouse status changes.

TAB 1 — KEY REMAPPING:
Lets the customer reassign what each of the 6 mouse buttons does.

Mappable buttons (6 total, shown as callouts on a mouse diagram):
- Left Button
- Right Button
- Middle Button (scroll wheel click)
- Forward (side button, front)
- Backward (side button, rear)
- DPI (the DPI cycle button on top of the mouse)

Four sub-tabs determine WHAT the button gets reassigned to:
(a) SYSTEM — assign a built-in mouse function. Options include: Left Button, Right Button, Middle Button, Forward, Backward, Scroll wheel up, Scroll wheel down (and likely more — the screenshot showed an expandable "Mouse" category, so the bot should expect a small additional list of system functions beyond these, but should NOT fabricate specific names beyond what's listed here without seeing them in a customer screenshot).
(b) KEYBOARD — assign a keyboard key (single key or modifier combination). Useful for FPS/strategy bindings (e.g. mapping a side button to spacebar for jump, or to a keybind for an in-game ability).
(c) INSTRUCTION — assign a system instruction or shortcut. The screenshot didn't show this sub-tab expanded, so the bot should NOT fabricate specific instruction options. If a customer asks what's under Instruction, the honest answer is "I don't have the full list of options in my documentation for that sub-tab — if you can share a screenshot of it expanded, I can help more specifically, or check the software itself which has the full list available."
(d) MACRO — assign a recorded macro sequence. Macros can be created and stored in the software, then assigned to any button.

Workflow (per the on-screen instruction "Drag or click the system button to the target device button for allocation"): the customer selects a function from the left panel (e.g. "Scroll wheel up" under System), then either drags it onto the target button callout in the mouse diagram on the right, or clicks the target button. The assignment is then saved to the active profile.

Reset: each button has a "Reset to default" button at the bottom of the page that restores original assignments for the current profile.

TAB 2 — DPI:
Lets the customer customise the 6 DPI presets that the on-mouse DPI button cycles through.

Six preset slots, factory defaults observed in the screenshot:
Slot 1: 1600 DPI
Slot 2: 1600 DPI (currently active, highlighted in green)
Slot 3: 3000 DPI
Slot 4: 3200 DPI
Slot 5: 6400 DPI
Slot 6: 10000 DPI

NOTE: the existing Helios KB entry above says the on-mouse DPI button cycles "800/1600/2400/3200/6400/10000" — this is the factory default that older units may ship with. The screenshot shows a slightly different default (1600/1600/3000/3200/6400/10000) on a 2026-batch unit. Either set of defaults is correct depending on batch; the POINT is that ALL six slots are customisable via this software, so any specific number the customer sees on their unit is what they (or the factory default for their batch) has set.

DPI range: 200 to 10,000 in 200-step increments via the on-screen slider. The slider shows tick marks at 200, 1000, 2000, 3000, 4000, 5000, 6000, 7000, 8000, 9000, 10000.

Each preset slot can be set to any value in this range independently.

"Restore default settings" button at top-right resets all 6 slots to factory defaults.

Tip from the software: "DPI indicates mouse sensitivity. Use the DPI button to adjust swiftly."

TAB 3 — PERFORMANCE:
Three settings on this tab:

(a) LIGHT SETTING:
Dropdown menu — "change the light effect of the mouse". One visible option in the screenshot: "Touring Flash". The dropdown contains the full list of the mouse's 6 RGB preset modes (and possibly more). The KB entry above already lists "6 preset lighting modes on top of mouse" — those are the options here. If a customer wants to know all dropdown options by name, acknowledge that "Touring Flash" is one confirmed name and offer to help them find others by exploring the dropdown.

(b) POLLING RATE SETTING (Hz):
Four radio button options: 125, 250, 500, 1000. The 1000 Hz option is selected by default in the screenshot.

```
IMPORTANT — this software setting applies ONLY to 2.4GHz mode.
The other two connection modes have hardware-fixed polling
rates that are NOT user-configurable:
  - WIRED mode: polling rate is HARDWARE-FIXED at 1000 Hz.
    The four radio buttons in this UI do not change wired
    polling rate. Wired is always 1000 Hz regardless of
    what's selected here.
  - 2.4GHz mode: polling rate is USER-CONFIGURABLE via this
    setting (125 / 250 / 500 / 1000 Hz). Default is 1000 Hz.
    Lower polling rates trade a small amount of responsiveness
    for slightly better battery life on the rechargeable
    mouse.
  - BLUETOOTH mode: polling rate is HARDWARE-FIXED at 125 Hz.
    (Same as the existing Bluetooth polling line in the SPECS
    section above.) The four radio buttons in this UI do not
    change Bluetooth polling rate. Also: the companion
    software doesn't operate in Bluetooth mode at all (see
    CONNECTION SCREEN section above) — so the customer can't
    even reach this UI while connected via Bluetooth. The
    125 Hz Bluetooth rate is a Bluetooth-mode hardware
    characteristic, not a software setting.

Practical implication: changing the radio button affects ONLY
the 2.4GHz polling rate. If a customer asks "I set polling
rate to 500 Hz in the software but I'm playing wired and I
think the rate didn't actually change" — the correct answer
is "Wired mode is fixed at 1000 Hz regardless of this setting;
the radio button you set will take effect the next time
you connect via the 2.4GHz dongle."

A higher 2.4GHz polling rate reduces input lag at the cost of
slightly more battery drain. The software text just says "A
higher mouse polling rate can reduce the impact of input lag"
— accurate.
```

(c) ROLLER DIRECTION SETTING:
Two radio options: Forward / Reverse. "Switch the functions of mouse wheel up and mouse wheel down."
Forward (default): scroll up = page up, scroll down = page down (standard).
Reverse: inverts the scroll direction. Useful for customers coming from macOS who prefer "natural scrolling" feel on Windows.

TAB 4 — OTHERS:
One control on this tab:
"Restore factory settings" with a Restore button.
Description text: "All settings will be restored to factory defaults, please proceed with caution."
Resets ALL software-configurable settings to factory defaults:
- All 6 DPI preset slots → factory defaults
- All button remappings → factory defaults
- Light setting → factory default effect
- Polling rate → factory default

- Roller direction → Forward (default)
Does NOT affect: firmware, pairing memory (Bluetooth BT1/BT2 channels), or any onboard configuration that was saved to a different PC.

PROFILE MANAGEMENT:
The [+ Create] and [Import] buttons in the left sidebar handle profile management. Customers can create multiple profiles (e.g. one for FPS games with sniper DPI presets, one for productivity with custom button mappings) and switch between them. The "Onboard configuration" link saves the current profile to the mouse's internal memory so it travels with the mouse to any PC — without needing to install the software on that PC. The mouse will use the onboard-saved configuration even when the software isn't running.

✗ DO NOT SAY about the Helios software:
- "The polling rate setting in the software changes polling rate for Wired and 2.4GHz" -- WRONG (corrected in v1.10.24). The software's polling rate radio buttons apply ONLY to 2.4GHz mode. Wired is hardware-fixed at 1000Hz; Bluetooth is hardware-fixed at 125Hz.
- "The Helios software works in Bluetooth mode" / "Configure your Helios via the software while connected over Bluetooth" -- WRONG (corrected in v1.10.24). The companion software only operates over Wired or 2.4GHz connections. Bluetooth-mode customers must briefly switch to 2.4GHz or Wired to configure, save settings to Onboard configuration, then switch back to Bluetooth — the saved settings persist on the mouse hardware.
- "The Helios software supports per-LED RGB programming" -- WRONG. The software has 6 preset RGB effects (the same 6 visible on the mouse without software). The dropdown lets the customer PICK which preset is active and possibly adjust brightness/speed for it — but it does NOT support per-LED colour assignment.
- "Each of the mouse's buttons can be remapped to any keyboard or mouse function via the software" -- TRUE in broad strokes, but do NOT fabricate specific options under the Instruction sub-tab without confirmation. Stick to System / Keyboard / Macro capabilities which are confirmed.
- "The software supports macOS" -- WRONG, Windows only.
- "The software supports all Cosmic Byte mice" -- WRONG, this app is specific to the Helios. Other Cosmic Byte mice have their own software (or none at all). If a customer asks about software for a different CB mouse, route them to that mouse's own KB entry or to support.
- Inventing specific Light Setting dropdown effect names beyond "Touring Flash" (the only confirmed name from the screenshot).
- Inventing specific Instruction sub-tab options under Key Remapping (sub-tab wasn't shown expanded in the screenshots).

✓ CORRECT FRAMING for "what can the Helios software do?":
"The Helios companion software (Windows only) gives you four configuration tabs:
1. **Key remapping** — reassign any of the 6 mouse buttons (Left, Right, Middle, Forward, Backward, DPI button) to a system function, keyboard key, instruction, or recorded macro.
2. **DPI** — customise all 6 DPI preset slots (200–10,000 range, 200-step increments) that the on-mouse DPI button cycles through.
3. **Performance** — pick from the 6 RGB lighting effects, set polling rate (125/250/500/1000 Hz for Wired and 2.4GHz — Bluetooth is hardware-locked at 125Hz), and invert scroll direction if you prefer that.
4. **Others** — restore all software settings to factory defaults.
Plus profile management: create multiple profiles, save them to the mouse's onboard memory so they travel to any PC."

SOFTWARE TROUBLESHOOTING (Windows only): Run as Administrator if not detecting mouse. Use wired mode for first detection. Reconnect mouse after installing the software. The "Cosmic Byte Helios Mouse" software is downloadable from thecosmicbyte.com/downloaddrivers/ — confirm the customer has the Helios-specific download, NOT a generic CB mouse driver.

TROUBLESHOOTING:
- Not powering on: Charge 30 minutes. Check power switch is ON. Wired mode works regardless of switch position.
- 2.4GHz not connecting: Check switch is ON. Short press 2.4G/BT (red flash). Try different USB port. Avoid hubs.

- Bluetooth not pairing: Green=BT1, Blue=BT2. Long press 2.4G/BT 3 seconds for fast blink. Remove old pairing first. Restart Bluetooth on device.
- Cursor lag/stuttering: Reduce interference. Use within range. Increase polling rate via software. Use wired for competitive gaming. Clean sensor and feet.
- DPI button not working: May be remapped in software. Reset DPI profile. Reinstall software.
- Software not detecting: Windows only. Run as Administrator. Use wired mode. Reconnect after install.
- RGB not working: Check software settings. Reset. Recharge if battery low.
- Random disconnections: Low battery. Receiver interference. Keep line-of-sight. Avoid metal surfaces near receiver.
- Care: Clean with dry microfiber cloth. Avoid liquids and heat. Do not disassemble.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered.

Hydrus Tri-Mode

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-hydrus-controller-for-pc-compact-symmetrical-tmr-sticks/

PRODUCT: Cosmic Byte Hydrus Tri-Mode Controller — compact symmetrical PC-first controller (USB Wired / 2.4GHz / Bluetooth, TMR sticks, Hall-Effect triggers)

⚠️ TWO HYDRUS MODELS EXIST — ALWAYS ASK FIRST:
Cosmic Byte sells TWO different Hydrus controllers: the HYDRUS WIRED and the HYDRUS TRI-MODE. If the customer has not said which one they own (they just say "Hydrus"), ASK which variant BEFORE giving any product-specific answer — do not guess and do not answer from the wrong entry. Quick tell-apart to help the customer identify theirs:
- HYDRUS WIRED: permanently attached 3m USB-A cable, NO battery, THREE macro buttons (ML + MR on the back AND a round "C" button on the front face), no wireless of any kind.
- HYDRUS TRI-MODE: USB-C port with detachable 1m cable, 2.4GHz USB receiver + Bluetooth, 600mAh battery, TWO macro buttons (ML/MR only — NO C button).
Shared platform on both: compact symmetrical design, TMR joysticks + dual Hall-Effect analog triggers, up to 1000Hz polling, Turbo/Auto (5/12/20 per sec), 4-level vibration (100/70/40/0, default 70), 22-input macros, circle/45°-square stick modes, stick calibration, keyboard & mouse mode, Android mouse mode, factory reset SELECT + L3 + R3 (5s).

⚠️ PC-ONLY — CONSOLES ARE NOT SUPPORTED (both Hydrus models): the manual states the Hydrus is designed for PC use only; consoles are NOT supported, and warranty is NOT applicable for damage/malfunction caused by use with unsupported devices (including consoles). Some functions work on Android/iOS, but PC is the primary supported platform. The Tri-Mode's Bluetooth "Pro Controller" (Gyro) and "DualShock" modes are EMULATION for PC/Android/iOS feature support — they do NOT make it console-compatible. Do not confuse the Hydrus with the Sensa (the Sensa is the PS5-compatible controller).

KEY FEATURES: Tri-mode connectivity (USB wired / 2.4GHz via USB receiver / Bluetooth), high-precision TMR joysticks (drift-resistant), dual Hall-Effect analog triggers, up to 1000Hz polling (PC Wired & 2.4GHz), X-Input & D-Input (PC), Bluetooth Gyro (NS/Pro-Controller) and DualShock emulation modes, 6-axis gyro (via BT Gyro Mode), Turbo & Auto Fire, ML/MR macro back buttons (22 inputs), 4-level vibration, Capture button, keyboard & mouse mode (PC — dongle & wired only), Android mouse mode, PC Steam mode (wired), joystick Circle / 45°-Square modes (circle error can reach 0%), 600mAh battery, auto-sleep.

SPECS: Connectivity USB Wired / 2.4GHz / Bluetooth. Polling up to 1000Hz (PC Wired & 2.4GHz — Bluetooth rate NOT published, do not quote one). TMR sticks; Hall-Effect analog triggers. Buttons: D-Pad, A/B/X/Y, LB/RB/LT/RT, L3/R3, SELECT, START, HOME, TURBO, CAPTURE, MR/ML. Vibration 4 levels (100/70/40/0%). Battery 600mAh; usage >10–12 hours; charging 2 hours via USB Type-C; 1m USB-A-to-Type-C data cable included. Macros: ML/MR, up to 22 inputs each. Auto sleep: 5 minutes of inactivity. Technical: sleep current ≤17µA, operating 3.7V / ≈30–180mA (vibration on), input DC 4.5–5.5V 300mA, operating −10°C to 55°C, 20–80% RH. Built-in protection: over-voltage cutoff above 6V (auto-resumes below 5.8V); NTC charging protection stops charging at 45°C or −10°C (EN62368).

NOTE ON LEDs: the Hydrus has a multi-colour RGB STATUS LED that indicates mode/state — it is NOT decorative RGB lighting with zones/effects. Do not market "RGB lighting" on the Hydrus.

SUPPORTED MODES BY CONNECTION:
- Wired: PC X-Input / PC D-Input / Android
- 2.4GHz: PC X-Input / PC D-Input / Android
- Bluetooth: PC X-Input / Android D-Input / Gyro Mode / DualShock Mode
- iOS: Bluetooth ONLY (Gyro Mode or DualShock Mode) — iOS is NOT supported over wired or 2.4GHz, and the iOS app must support external controllers.

INPUT MODES EXPLAINED: X-Input = standard/best-compatibility PC mode (default). D-Input = legacy DirectInput for PC and Android. Gyro Mode = detected as a Pro Controller; use on PC/Android/iOS to enable gyro / motion controls (e.g. gyro aiming in Steam). DualShock Mode = detected as a DualShock controller; enables vibration and native Android/iOS feedback. IMPORTANT: Gyro and DualShock modes emulate those controllers for PC/Android/iOS — NOT compatible with consoles.

WIRED MODE (CRITICAL QUIRKS):
- Connect the USB cable and PRESS HOME ONCE to activate data transfer — otherwise the cable only CHARGES the controller. ("Charging but not working" over cable = customer didn't press HOME.)
- If a 2.4GHz connection is active it takes PRIORITY — the USB cable then only charges. Remove the 2.4GHz receiver if wired data is needed.
- PC X-Input (default): connect + HOME → RGB GREEN solid. PC D-Input: under X-Input, long-press HOME 3s → PURPLE solid. Android wired D-Input: connect + HOME → GREEN solid. Android X-Input: after connection long-press SELECT + HOME 3s (short vibration confirms). Android Mouse Mode: hold CAPTURE + R3 5s.

2.4GHZ WIRELESS MODE: insert the USB receiver into the device. With the controller POWERED OFF, hold X + HOME 3 seconds to enter pairing — RGB ORANGE flashes rapidly (16Hz), stays solid on success. D-Input: under X-Input long-press HOME 3s (PURPLE solid). Android and Mouse Mode combos same as wired.

BLUETOOTH MODE (controller powered off, hold combo 3 seconds):
- X-Input (PC): B + HOME — CYAN flashes, solid on success. Bluetooth name: "Xbox Bluetooth Controller".
- D-Input (Android): A + HOME — WHITE flashes. Name: "Gamepad Controller".
- Gyro Mode (PC/Android/iOS): Y + HOME — RED flashes. Name: "Pro Controller".
- DualShock Mode (PC/Android/iOS): START + HOME — BLUE flashes. Name: "Wireless Controller" (Android) / "DUALSHOCK 4 Wireless Controller" (iOS).
Remove any old pairing entry before re-pairing if connection fails.

RECONNECTION & POWER: press HOME 1 second to wake — flashes in last-used mode and reconnects to the last device; if reconnection fails within 30 seconds it sleeps (wake again to retry). Power ON: short press HOME. Power OFF: hold HOME 5 seconds. Auto-sleep after 5 minutes of inactivity.

PC STEAM MODE (WIRED ONLY): with the controller powered off, press and hold R3, then plug the USB cable into the PC while holding — boots directly into Steam-compatible mode.

KEYBOARD & MOUSE MODE (PC — DONGLE AND WIRED ONLY, NOT Bluetooth): hold TURBO + CAPTURE 3 seconds to toggle. The controller then acts as keyboard+mouse. Key map highlights: left stick & D-pad = WASD, A=Space, B=C, X=F, Y=R, LB=Q, RB=E, LT=Right mouse, RT=Left mouse, L3=Shift, R3=Middle mouse, SELECT=Caps, START=Tab, HOME=ESC.

MOUSE MODE (ANDROID — wired/2.4GHz ONLY, not Bluetooth): hold CAPTURE + R3 for 5 seconds. A = left click, B = right click, right stick = pointer. Repeat combo to exit.

TURBO & AUTO FIRE: applies to A/B/X/Y/LB/LT/RB/RT. Hold the button + TURBO = Turbo ON (channel LED blinks when used); press the same button + TURBO again = AUTO fire; again/hold together = clear that button. Clear ALL: hold TURBO alone 5 seconds (vibration confirms). Speeds: Level 1 = 5/sec, Level 2 = 12/sec (default), Level 3 = 20/sec — hold TURBO + push Right Stick fully RIGHT (faster) / LEFT (slower); setting remembered.

VIBRATION STRENGTH: hold TURBO + Right Stick fully UP (stronger) / DOWN (weaker). Levels 100% / 70% (default) / 40% / 0% (off). Each change buzzes; remembered.

ADVANCED FUNCTIONS: A/B/X/Y swap — hold TURBO + R3 3s (swaps A↔B and X↔Y). D-Pad ↔ Left-Stick swap — hold START + L3 3s. Stick shape — hold L3 + TURBO 3s to toggle Circle Mode (default) / 45-Degree Square Mode (joystick circle error can reach 0%). All cleared by factory reset.

MACRO PROGRAMMING (ML / MR — the Tri-Mode has NO C button; a customer mentioning the C macro button owns the HYDRUS WIRED): programmable inputs A/B/X/Y, LB/RB/LT/RT, L3/R3, D-Pad, both sticks. Hold ML or MR ~2 seconds — channel LED blinks slowly + vibration = programming mode. Press the sequence (LED flashes fast while held; press AND interval timing are recorded). Press the same ML/MR again to save (LED solid + vibration). Max 22 inputs per macro; exits automatically after 30 seconds of no input. Single-key = direct mapping; multi-key = macro playback (pressing the other back button can interrupt playback). CLEAR ALL MACROS: hold SELECT + START + R3 for 5 seconds (vibration confirms).

STICK CALIBRATION: power the controller OFF → hold CAPTURE + HOME to enter calibration (RGB PURPLE blinks) → briefly press A (PURPLE flashes rapidly) → rotate BOTH sticks fully 3+ circles (no excessive force) → press each trigger fully 3 times → briefly press A again to save (returns to normal mode).

FACTORY RESET: hold SELECT + L3 + R3 for 5 seconds. Clears: all Turbo + speeds, vibration strength, Auto functions, stick-mode swap, D-Pad/left-stick swap, ABXY swap, keyboard & mouse function, joystick deadzone/stick shape, mode switching defaults, and programming functions.

BATTERY & CHARGING: 600mAh, >10–12 hours use, 2-hour charge via USB Type-C. Charging while in use: current mode LED breathes, solid when full. Charging while powered off: GREEN LED breathes, solid when full. LOW BATTERY: below 3.5V ±0.1V the RED LED flashes rapidly 10 seconds, repeating every minute; below 3.35V ±0.1V the controller auto-powers-off; insufficient battery may prevent power-on — charge promptly. Charging stops automatically at 45°C or −10°C (NTC protection) — charge within normal temperatures.

FIRMWARE: the Tri-Mode manual documents NO firmware-update procedure — do NOT invent one (the HYDRUS WIRED has a documented upgrade mode; do not transfer it to the Tri-Mode). If firmware is ever needed, check https://www.thecosmicbyte.com/downloaddrivers/ or contact support.

SOFTWARE — COSMIC BYTE ORBIT (web-based): the Hydrus is fully configurable through Orbit, the free browser-based configurator at https://orbit.thecosmicbyte.com — nothing to download. Connect via USB cable or the 2.4GHz dongle (NOT Bluetooth), use Chrome/Edge/Brave/Opera on a DESKTOP computer, select the device, adjust and Apply (settings save to the device).

TROUBLESHOOTING:
Q: Not powering on? A: Battery likely drained (insufficient battery can prevent power-on) — charge promptly.
Q: Charging over cable but not working as a controller? A: Press HOME once after connecting the USB cable — otherwise it only charges. Also, an active 2.4GHz connection takes priority — remove the receiver if you want wired data.
Q: Won't connect wirelessly? A: Use the correct pairing combo for your platform/mode (see above); remove any previous Bluetooth pairing and re-pair.
Q: Doesn't reconnect after waking? A: Press HOME 1s to wake; if reconnection fails within 30s it sleeps — wake and retry.
Q: No gyro / motion controls? A: Connect via Bluetooth in GYRO MODE (Y + HOME) so it's detected as a Pro Controller; enable motion input in the software (e.g. Steam Input).
Q: No/weak vibration? A: Raise the level (TURBO + Right Stick up). On Android/iOS connect in DUALSHOCK MODE (START + HOME) for vibration and native feedback.
Q: Buttons behaving incorrectly? A: ABXY swap or D-Pad↔stick swap may be active — factory reset (SELECT + L3 + R3, 5s).
Q: Stick drift? A: Run stick calibration (see above).
Q: Macro (ML/MR) not working? A: ML/MR have NO function by default — they must be programmed first, and saved by pressing ML/MR after recording.
Q: Android mouse mode not working? A: Works only in wired/2.4GHz — Bluetooth does not support mouse mode.
Q: iOS not detecting the controller? A: iOS works over Bluetooth ONLY (Gyro or DualShock mode), and the app must support external controllers.
Q: Steam not detecting it? A: Use Steam Mode (wired only — hold R3 while plugging the cable); restart Steam after connecting.
Q: Charging stops unexpectedly? A: NTC protection stops charging at 45°C or −10°C — charge within the normal temperature range.
Q: Can I use it on PS5/PS4/Xbox/Switch? A: No — the Hydrus is PC-only; consoles are not supported (the DualShock/Pro-Controller Bluetooth modes are emulation for PC/Android/iOS, not console support). For PlayStation 5, recommend the Cosmic Byte SENSA instead.

ANTI-FABRICATION GUARDS (Hydrus Tri-Mode): ✗ No console support — ever. ✗ Do NOT quote a Bluetooth polling rate (1000Hz is PC Wired/2.4GHz only; BT figure not published). ✗ Do NOT claim decorative RGB lighting — the LED is a status indicator. ✗ No "C" macro button on this model (that's the Hydrus Wired). ✓ Battery 600mAh is correct for THIS model (same figure as Blitz Tri-Mode — don't cross-correct either). ✓ Warranty 1 year.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products are NOT covered; regular battery wear and tear is NOT covered; damage or malfunction caused by use with unsupported devices (including consoles) is NOT covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 (WhatsApp same) | Mon–Sat 10am–6pm

BUY: https://www.thecosmicbyte.com/product/cosmic-byte-hydrus-controller-for-pc-compact-symmetrical-tmr-sticks/ — the SAME product page covers both Hydrus models; the customer selects Wired or Tri-Mode on the page. Use coupon code ONLINEPAY for 10% off on online payments.

Hydrus Wired

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-hydrus-controller-for-pc-compact-symmetrical-tmr-sticks/

PRODUCT: Cosmic Byte Hydrus Wired Controller — compact symmetrical PC-first wired controller (USB-A, 3m cable, TMR sticks, Hall-Effect triggers, 3 macro buttons)

⚠️ TWO HYDRUS MODELS EXIST — ALWAYS ASK FIRST:
Cosmic Byte sells TWO different Hydrus controllers: the HYDRUS WIRED and the HYDRUS TRI-MODE. If the customer has not said which one they own (they just say "Hydrus"), ASK which variant BEFORE giving any product-specific answer — do not guess and do not answer from the wrong entry. Quick tell-apart to help the customer identify theirs:
- HYDRUS WIRED: permanently attached 3m USB-A cable, NO battery, THREE macro buttons (ML + MR on the back AND a round "C" button on the front face), no wireless of any kind.
- HYDRUS TRI-MODE: USB-C port with detachable 1m cable, 2.4GHz USB receiver + Bluetooth, 600mAh battery, TWO macro buttons (ML/MR only — NO C button).
Shared platform on both: compact symmetrical design, TMR joysticks + dual Hall-Effect analog triggers, up to 1000Hz polling, Turbo/Auto (5/12/20 per sec), 4-level vibration (100/70/40/0, default 70), 22-input macros, circle/45°-square stick modes, stick calibration, keyboard & mouse mode, Android mouse mode, factory reset SELECT + L3 + R3 (5s).

⚠️ PC-ONLY — CONSOLES ARE NOT SUPPORTED (both Hydrus models): the manual states the Hydrus is designed for PC use only; consoles are NOT supported, and warranty is NOT applicable for damage/malfunction caused by use with unsupported devices (including consoles). Some functions work on Android/iOS, but PC is the primary supported platform. The Tri-Mode's Bluetooth "Pro Controller" (Gyro) and "DualShock" modes are EMULATION for PC/Android/iOS feature support — they do NOT make it console-compatible. Do not confuse the Hydrus with the Sensa (the Sensa is the PS5-compatible controller).

KEY FEATURES: USB-A wired (permanently attached 3m cable — NO battery, NO wireless), high-precision TMR joysticks, dual Hall-Effect analog triggers, BUILT-IN SIX-AXIS GYRO (via Gyro/Steam Mode), up to 1000Hz polling, X-Input (default) & D-Input (PC), auto-recognition on connection, dedicated keyboard & mouse mode, Android Controller + Android Mouse modes, THREE macro buttons — ML + MR back buttons AND the front "C" button (22 inputs each), Turbo & Auto Turbo (3 speeds), 4-level vibration, Circle/45°-Square stick modes, on-demand stick calibration.

SPECS: 20 digital buttons + 2 Hall-Effect analog triggers — D-Pad, A/B/X/Y, LB/RB/LT/RT, L3/R3, − (SELECT), + (START), HOME, CAPTURE, TURBO, C, ML/MR back buttons; two TMR analog 3D joysticks; built-in 6-axis gyro. Polling up to 1000Hz. Cable 3m, USB-A interface. Vibration 4 levels (100/70/40/0%). Macros: ML, MR and C — up to 22 key entries each. Operating 5V / input DC 4.5–5.5V; −10°C to 45°C; 20–80% RH (non-condensing). NO battery — it is powered by the cable (ignore battery/charging questions for this model; if the customer asks about battery/charging, they probably own the HYDRUS TRI-MODE — ask).

NOTE ON LEDs: multi-colour RGB STATUS LED only (solid ORANGE = connected and ready; PURPLE = D-Input active) — not decorative RGB lighting.

MODES & HOW TO SWITCH:
- PC X-Input (default): connect the USB-A cable and press HOME — auto-recognition; RGB stays solid ORANGE when detected and ready. (If nothing happens after plugging in, PRESS HOME.)
- PC D-Input: hold HOME 3 seconds — LED turns solid PURPLE.
- Keyboard & Mouse Mode (PC): press TURBO + CAPTURE together 3 seconds to toggle. Key map highlights: left stick & D-pad = WASD, A=Space, B=C, X=F, Y=R, LB=Q, RB=E, LT=Right mouse, RT=Left mouse, L3=Shift, R3=Middle mouse, SELECT=Caps, START=Tab, HOME=ESC.
- Gyro Mode / Steam Mode (PC & Android): hold R3 (right-stick click) DOWN while plugging in the USB cable — enters Gyro Mode at connection. Enables the built-in 6-axis motion sensor as an input axis in software that supports motion (e.g. Steam Input). To EXIT Gyro Mode, unplug the cable and reconnect normally.
- Android Controller Mode (default on Android): connect the cable and press HOME.
- Android X-Input: hold SELECT + HOME 3 seconds (short vibration confirms).
- Android Mouse Mode: hold CAPTURE + R3 for 5 seconds — right stick becomes an on-screen pointer, A = left click, B = right click. Repeat combo to return.
- iOS: NOT supported (the wired Hydrus has no Bluetooth; iOS support exists only on the Hydrus Tri-Mode via Bluetooth).

TURBO & AUTO TURBO: applies to A/B/X/Y/LB/RB/LT/RT. Hold the button + TURBO = Turbo (channel LED flashes); same button + TURBO a second time = Auto Turbo (continuous); a third time = removes Turbo from that button. Clear ALL: hold TURBO alone 5 seconds (vibration confirms). Speeds: Level 1 = 5/sec, Level 2 = 12/sec (default), Level 3 = 20/sec — hold TURBO + push Right Stick fully RIGHT/LEFT to adjust (short vibration per step; remembered).

VIBRATION STRENGTH: hold TURBO + Right Stick fully UP/DOWN. Levels 100% / 70% (default) / 40% / 0% (off). Each step buzzes; the level is remembered after power off.

ADVANCED FUNCTIONS (NOTE: none of these three are retained after power off — unplugging and replugging also clears them):
- A/B/X/Y swap: hold TURBO + R3 3s (swaps A↔B and X↔Y; vibration confirms).
- D-Pad ↔ Left Stick swap: hold START + L3 3s (vibration confirms).
- Circle / 45°-Square stick mode: hold L3 + TURBO 3s (Circle is default; vibration confirms).

MACRO PROGRAMMING (ML / MR / C — THREE macro buttons; the front C button is EXCLUSIVE to the wired model): programmable inputs A/B/X/Y, LB/RB/LT/RT, L3/R3, D-Pad, both joysticks. Hold ML, MR or C for ~2 seconds — channel LED blinks slowly + motor vibrates = programming mode. Press the buttons in sequence (LED flashes quickly while held; both presses AND the intervals between them are recorded). Briefly press the SAME macro button again to save (LED stays on + vibration) — that button is now the macro trigger. Max 22 key entries per macro (vibration warning when full). If no button is pressed for 30 seconds, it exits and SAVES what was recorded. Macros are RETAINED after power off. Single-key = direct mapping (two mapped buttons pressed together trigger both); multi-key macro playback can be interrupted by pressing another macro button. Example: hold ML 2s → press B, wait 1s, press A, wait 3s, press X → press ML to save; pressing ML now replays B·(1s)·A·(3s)·X. CLEAR ALL MACROS: hold SELECT + START + R3 for 5 seconds (vibration confirms).

STICK CALIBRATION (for drift / off-centre input): with the controller CONNECTED, press CAPTURE + HOME — RGB PURPLE flashes = calibration mode → briefly press A (LED flashes rapidly) → rotate both sticks through 3+ full circles (no excessive force) → press each trigger fully 3 times → briefly press A again to exit. Success returns it to normal mode.

FIRMWARE UPGRADE MODE (PC): hold SELECT + START while plugging the USB cable into the computer — the controller enters upgrade mode. Firmware files/tools: https://www.thecosmicbyte.com/downloaddrivers/.

FACTORY RESET: hold SELECT + L3 + R3 for 5 seconds — restores ALL settings to factory defaults (Turbo assignments + speed, vibration strength, Auto Turbo, circle/square mode, D-Pad/stick swap, A/B/X/Y swap, keyboard & mouse mode, input-mode defaults, and all macro programming).

SOFTWARE — COSMIC BYTE ORBIT (web-based): fully configurable through Orbit at https://orbit.thecosmicbyte.com — nothing to download. Connect via the USB cable, use Chrome/Edge/Brave/Opera on a DESKTOP computer, select the device, adjust and Apply.

TROUBLESHOOTING:
Q: Not detected, or in the wrong mode? A: Reconnect the USB cable and PRESS HOME. Switch modes manually with the combos above if needed.
Q: Buttons behaving incorrectly? A: The ABXY swap or D-Pad↔stick swap may be active — toggle it off or factory reset (SELECT + L3 + R3, 5s). Neither swap survives power off, so unplugging and replugging also clears them.
Q: Stick drift / off-centre? A: Run stick calibration (CAPTURE + HOME → follow steps).
Q: No vibration / too weak? A: Hold TURBO + Right Stick fully up to increase strength.
Q: Turbo too fast/slow? A: Hold TURBO + Right Stick fully right/left.
Q: Keyboard/mouse input instead of controller input? A: Keyboard & Mouse mode is active — press TURBO + CAPTURE 3 seconds to switch back.
Q: Macro button (ML/MR/C) not working? A: They have no function until programmed — record a macro and SAVE it by pressing the same button after recording.
Q: On-screen pointer instead of controller input (Android)? A: Mouse Mode is active — hold CAPTURE + R3 5 seconds to return to controller mode.
Q: No gyro / motion controls? A: Gyro Mode must be entered AT CONNECTION — unplug, then hold R3 while plugging back in; also enable motion input in the software (e.g. Steam Input).
Q: Settings behaving unexpectedly? A: Factory reset — SELECT + L3 + R3 for 5 seconds.
Q: Can I use it wirelessly / on Bluetooth? A: No — this is the wired model. For wireless, the HYDRUS TRI-MODE is the 2.4GHz + Bluetooth version.
Q: Can I use it on PS5/PS4/Xbox/Switch? A: No — PC-only; consoles are not supported, and console-caused damage is not covered by warranty. For PS5, recommend the Cosmic Byte SENSA.

ANTI-FABRICATION GUARDS (Hydrus Wired): ✗ NO battery, NO charging, NO wireless/Bluetooth/dongle — never invent these for the wired model. ✗ No console support — ever. ✗ Do NOT claim decorative RGB lighting — the LED is a status indicator. ✓ The C macro button exists ONLY on this wired model. ✓ Warranty 1 year.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products are NOT covered; damage or malfunction caused by use with unsupported devices (including consoles) is NOT covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 (WhatsApp same) | Mon–Sat 10am–6pm

BUY: https://www.thecosmicbyte.com/product/cosmic-byte-hydrus-controller-for-pc-compact-symmetrical-tmr-sticks/ — the SAME product page covers both Hydrus models; the customer selects Wired or Tri-Mode on the page. Use coupon code ONLINEPAY for 10% off on online payments.

Hypernova Mouse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-hypernova-wireless-bluetooth-wired-tri-mode-gaming-mouse/

COSMIC BYTE HYPERNOVA — WIRELESS + BLUETOOTH + WIRED TRI-MODE GAMING MOUSE — FULL MANUAL

SPECS:
- Sensor: PixArt 3395 (premium-tier optical gaming sensor).
- DPI: 200 to 26000, fully customisable via software.
- Polling Rate: Wired 8000Hz / 2.4GHz Wireless 4000Hz / Bluetooth 250Hz.
- Weight: 55g without cable.
- Switches: Omron 100 million click rated (gaming-grade).
- Mouse Feet: 0.6mm PTFE.
- Cable: 1.8m paracord with loop (extremely lightweight, gives the mouse a near-wireless feel even in wired mode).
- Buttons: 5 programmable buttons (Left, Right, scroll-wheel click, plus 2 side buttons on the left).
- Tracking Speed: 650 IPS max.
- Acceleration: 50G.
- Surface: ABS plastic.
- Battery: REPLACEABLE. Hypernova ships with TWO removable batteries -- the in-mouse battery and a spare.
- Software: Windows ONLY. No macOS / Linux / Android software build.

CONNECTIVITY (Tri-Mode: Wired + 2.4GHz + Bluetooth):
- Wired (USB-C): Connect the included paracord cable to the mouse's USB-C port, plug the other end into a PC USB port. 8000Hz polling rate available -- this is the highest of any Hypernova mode.
- 2.4GHz Wireless: Slide the mode switch on the bottom of the mouse to "2.4G". Plug the dongle into a PC USB port. 4000Hz polling rate. The dongle is pre-paired at the factory in most cases -- works on first plug-in.
- Bluetooth: 250Hz polling rate (hardware-limited at low frequency by the BT protocol; this is normal and NOT a defect).
- Best for competitive gaming: Wired (8000Hz) or 2.4GHz (4000Hz). Bluetooth is for productivity / battery-saving / multi-device use, not gaming.

DONGLE PAIRING (only needed if the dongle is NOT pre-paired or pairing is lost):
The dongle is typically pre-paired with the mouse at the factory. If the dongle does not detect the mouse, follow these steps:
1. Open the Hypernova companion software on the PC (Windows only -- download from https://www.thecosmicbyte.com/downloaddrivers/).
2. Slide the mouse's bottom switch to 2.4G mode.
3. Connect the dongle to the PC via USB cable.
4. Follow the on-screen pairing instructions in the software.
5. ON THE MOUSE: press Left + Middle + Right Mouse Buttons together. The LED will blink YELLOW -- this indicates pairing mode is active.
6. ON THE KEYBOARD: press the Spacebar key to start the pairing process (the software handles the actual pairing once Spacebar is pressed).
This combo is documented in the Hypernova manual exactly as above. Do NOT extrapolate pairing combos from other Cosmic Byte mice -- the Hypernova combo is specifically Left+Middle+Right -> Spacebar.

INITIAL CONNECT-TO-PC FLOW (per the Hypernova user manual):
1. Unpack the mouse, remove any plastic film from the mouse feet.
2. Connect the mouse via USB cable, OR plug the dongle into a PC USB port.
3. The mouse will be detected by Windows within 5-30 seconds.
4. Download the Hypernova software from the Cosmic Byte website (https://www.thecosmicbyte.com/downloaddrivers/).
5. Install the software. NOTE: some antivirus programs may try to block the install because the software may not be in their database yet. The manual explicitly recommends temporarily disabling the antivirus during install. This is documented behaviour, NOT malware.
6. Once installed, RESTART the PC for the driver to fully load.
7. The mouse is now ready. Customise via the software.

DPI:
- Range: 200 to 26000 DPI, set in the software.
- Customers can configure preset DPI stages and cycle through them via a hardware DPI button.
- Specific recommended values vary by use case -- ask the customer what they're optimising for (gaming sensitivity, productivity, design work) before suggesting specific DPI values.

POLLING RATE — IMPORTANT DETAILS:
- Wired: 8000Hz max (configurable in software; can be reduced to 4000 / 2000 / 1000 / 500 / 250 / 125 Hz via software dropdown if needed).
- 2.4GHz: 4000Hz max (configurable, can be reduced).
- Bluetooth: 250Hz (hardware-fixed; not adjustable via software).
- High polling rates (8000Hz) require a high-spec PC -- see SYSTEM REQUIREMENTS below.

SYSTEM REQUIREMENTS FOR 8000Hz POLLING (per the Hypernova user manual, page 5):
To get the full 8000Hz experience, the PC needs to meet these minimums:
- CPU: Intel Core i7 9700K or above, OR AMD Ryzen 7 3700X or above.
- Monitor: refresh rate 240Hz or above.
- GPU: NVIDIA GTX 1080 or above, OR AMD RX 5700 or above.
- RAM: 16GB or above.
If the customer's PC does NOT meet these specs and they experience stuttering or lag at 8000Hz, the manual EXPLICITLY recommends reducing the polling rate. This is documented expected behaviour at high polling rates on lower-spec hardware -- NOT a defect of the mouse. Customers should not be told their stutter is a hardware fault until the polling rate has been reduced to 4000Hz or 2000Hz to confirm it's PC-specs related vs an actual mouse fault.

BUTTONS:
- 5 programmable buttons total: Left click, Right click, scroll-wheel click (middle button), and 2 side buttons on the left side of the mouse.

- All 5 buttons fully customisable via the Windows software (remap to any keystroke / mouse function / macro).
- Switch type: Omron 100 million click rated.

CHARGING — CRITICAL WARNING (manual page 6):
- USE STANDARD CHARGER ONLY. The manual explicitly says: "Use only standard chargers to avoid damaging the battery. Chargers with high output can harm the battery."
- Recommended output: 5V/1A or 5V/2A. Standard PC USB ports are always safe (always 5V output).
- DO NOT use fast chargers. The manual explicitly states: "The warranty will be void if the mouse is damaged by using fast chargers."
- Recommended method: plug the included USB-C cable into a PC USB port. PC USB is always 5V standard output.
- Charging duration: a few hours depending on battery state.
- The mouse can be used in WIRED mode while charging (charging happens in the background while the cable carries the data signal).
- A "battery full" indicator appears in the software once the battery is fully charged. Disconnect the cable at that point if charging from a wall adapter.

SPARE BATTERY (per manual):
- The Hypernova ships with TWO removable batteries -- the one inside the mouse, and a spare.
- The spare battery has its OWN USB-C port. Plug the mouse's USB-C cable directly into the spare battery to charge the spare INDEPENDENTLY of the mouse.
- This is convenient: customer can have one battery in the mouse while charging the other separately, then hot-swap when needed.
- Same fast-charger restriction applies to the spare battery -- standard charger only.

SOFTWARE (Windows ONLY):
- Download from https://www.thecosmicbyte.com/downloaddrivers/.
- Configure: DPI levels and presets, polling rate, button remapping, macros, RGB lighting, lift-off distance, debounce time.
- Antivirus may flag the installer (per manual). Temporarily disable antivirus during install if this happens.
- After install, restart the PC for the driver to fully load.
- There is no macOS / Linux / Android version. If a customer asks about non-Windows software, the answer is "no, the Hypernova companion software is Windows only -- the mouse itself works as a standard plug-and-play mouse on macOS / Linux / Android via the dongle or USB cable, but advanced features (custom DPI levels, button remapping, RGB customisation) require the Windows software."

TROUBLESHOOTING (per manual page 8):
1. CHECK THE BASICS:
   - Battery fully charged? Mouse turned on?
   - Dongle properly inserted into the PC?
   - Mouse bottom switch set to 2.4G mode?
2. RESTART THE CONNECTION:
   - Unplug dongle, wait a few seconds, plug back in.
   - If the dongle is not detected by the mouse, run the dongle pairing procedure (see DONGLE PAIRING above).
3. TEST THE USB PORT:
   - Try a different USB port.
   - Test the dongle on another computer to isolate whether the issue is mouse-side or PC-side.
4. CHECK FOR INTERFERENCE:
   - Remove physical obstructions between the mouse and the dongle.
   - Move other 2.4GHz devices (Wi-Fi router, USB 3.0 devices, other wireless mice) away from the dongle.
5. UPDATE DRIVERS:
   - Open Device Manager > Mice and other pointing devices > update the driver.
   - Or download the latest software from the Cosmic Byte website.
6. CHECK THE SURFACE:
   - Try the mouse on a different surface or a mouse pad.
   - Clean the sensor on the bottom of the mouse with a dry microfiber cloth.
7. SOFTWARE ISSUES:
   - Restart the PC.
   - Check for conflicts with other mouse drivers.
8. BATTERY ISSUES:
   - Confirm battery is fully charged. Or use the SPARE battery to test (see SPARE BATTERY above) -- this isolates whether the issue is the battery or the mouse itself.
9. TEST ON ANOTHER COMPUTER:
   - Useful for confirming whether the issue is the mouse or the PC.
10. HARDWARE ISSUES:
    - Inspect the dongle and mouse for any visible damage.
    - If physical damage is present (drop, port broken off, visible cracks), this is NOT covered under standard warranty -- direct the customer to raise a support ticket per rule #11.

STUTTERING / LAG SPECIFICALLY AT 8000Hz:
- This is likely PC-specs-related, NOT a mouse defect. See SYSTEM REQUIREMENTS above.
- First, try reducing polling rate to 4000Hz (via software). If stuttering goes away, the cause is confirmed: the customer's PC can't sustain 8000Hz throughput. They can either upgrade hardware or run the mouse at 4000Hz, which is still very high.
- If stuttering persists at 4000Hz and 1000Hz, then it's likely a different cause (interference, surface, driver) -- continue troubleshooting per the standard list.

WARRANTY:
- 1 year warranty against manufacturing defects only.
- Physical damage, water damage, tampered or modified products NOT covered.
- Regular wear and tear from battery usage NOT covered.
- Damage from using fast chargers NOT covered (per the manual's explicit warranty void clause).
- Standard CB warranty exclusions also apply.

SUPPORT (per Hypernova manual page 9):
- Phone: 07969273222 (Mon-Sat 10am to 6pm) -- printed in the Hypernova manual.
- Email: cc@thecosmicbyte.com.
- FAQ portal: support.thecosmicbyte.com.

IMPORTANT FOR THE AI -- which support number to actually give customers:

The Hypernova manual prints the phone number "07969273222". HOWEVER, this number is NOT currently operational. The phone line that IS operational and that customers should be given is the standard Cosmic Byte support number: +91 7351615161 (Mon-Sat 10am-6pm). This is the same number used in rule #11 (warranty escalation routing) and across every other product entry in this KB.

Treat the Hypernova manual's "07969273222" as a print error -- DO NOT give it to customers, even if they specifically ask for the number printed in their manual. If a customer mentions they tried the manual's number and it didn't work, confirm: "yes, that number isn't currently operational -- please use +91 7351615161 instead, which is our active support line for all Cosmic Byte products including Hypernova."

The AI should always default to:
  Email: cc@thecosmicbyte.com
  Phone: +91 7351615161 (Mon-Sat 10am-6pm)
  Raise a ticket: https://www.thecosmicbyte.com/raise-a-ticket/

These three channels work for every CB product including Hypernova.

Ignis Mouse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-ignis-tri-mode-gaming-mouse-pixart-3311-sensor-1000hz-polling-software-support/

COSMIC BYTE IGNIS MOUSE - TRI-MODE GAMING MOUSE - FULL MANUAL

DESIGN: Stealth/zero RGB design - NO LED lighting on top during use. This is intentional, not a defect.
Only LEDs are charging indicators (Red = charging, Green = fully charged). Clean professional look by design.

CONNECTIVITY - BOTTOM SWITCH:
- Left = 2.4GHz wireless. Centre = Power OFF. Right = Bluetooth.
- Wired: connect USB-C paracord cable - activates automatically regardless of switch position. Charges simultaneously.
- 2.4GHz: slide switch LEFT, plug USB receiver. Re-sync if not connecting: hold Left + Right + Scroll for 3 seconds.
- Bluetooth: slide switch RIGHT. Pair: hold Left + Right + Scroll for 3 seconds - indicator blinks. Select 'CB Ignis' on device.
- Always turn OFF (centre) when not in use to preserve battery.

DPI BUTTON LOCATION: On the BOTTOM of the mouse (not on top). Press to cycle 6 levels:
400 / 800 / 1600 / 3200 / 6400 / 12000 DPI. Via software: up to 24000 DPI.

BATTERY:
- 400mAh built-in. ~52 hours battery life (one of the longest in the range).
- Charge time: 2-3 hours. Red steady = charging. Green steady = fully charged.
- Connect USB-C to use in wired mode while charging simultaneously.

SENSOR: PixArt 3311, 1000Hz polling, Huano switches (20M clicks).

SLEEP: Auto-sleep after inactivity. Press any button to wake. Centre switch = OFF when storing.

SOFTWARE: DPI up to 24000, macros, button customisation. Windows XP/Vista/7/8/10/11.
Download from https://www.thecosmicbyte.com/downloaddrivers/. macOS not officially supported for software.

TROUBLESHOOTING:
- No RGB is normal - by design.
- DPI button not found: it is on the BOTTOM of the mouse.
- 2.4G not working: check switch is LEFT, re-sync (hold L+R+Scroll 3s), try USB 2.0 port.
- Bluetooth not pairing: switch RIGHT, hold L+R+Scroll 3s, remove old pairing first.
- Battery draining fast: always switch to centre (OFF) when not in use. Avoid leaving in pairing mode.

WARRANTY: 1 year manufacturing defects only. Water, physical damage NOT covered.
Support: +91 7351615161 (Mon-Sat 10am-6pm), cc@thecosmicbyte.com.

Immortal

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-immortal-2-4ghz-wireless-bluetooth-wired-headphone-black/

PRODUCT: Cosmic Byte Immortal — 7.1.4 SURROUND TRI-MODE WIRELESS GAMING HEADSET (UPGRADED THX SPATIAL AUDIO + VERSION, Bluetooth 6.0 with LE Audio)

⚠️ TWO IMMORTAL GENERATIONS EXIST — READ THIS FIRST:
- CURRENT / UPGRADED Immortal (shipping now) = THX Spatial Audio + support (7.1.4 virtual surround via the THX desktop software), Bluetooth 6.0 with LE Audio (JL7106 chipset), 800mAh battery, up to 50 hours play time. THIS entry's main specs describe this model.
- EARLIER / PRE-THX Immortal (previous production) = Bluetooth 5.3, 1000mAh battery, 40 hours, NO THX support. Same product name, SAME UPC and SAME product page/links — the upgrade did NOT change the listing, so the listing alone does not tell you which unit a customer has.
- CRITICAL: THX Spatial Audio + does NOT work on the EARLIER Immortal hardware. Only the upgraded hardware supports THX. If a customer with an earlier unit asks how to get THX / Spatial Audio / 7.1.4, tell them plainly it is not supported on their hardware — do not send them to install the THX app and do not troubleshoot "THX not detecting my headset" on an older unit as if it were a defect. Their headset still works exactly as before (2.4GHz / Bluetooth / wired, Game & Music EQ modes).
- HOW TO TELL WHICH ONE THE CUSTOMER HAS (ask them to check):
  (a) THX branding — the upgraded headset and its box/manual carry THX branding and the words "THX Spatial Audio +". The earlier unit has no THX branding anywhere.
  (b) Bluetooth version / battery on the box or manual — upgraded = "Bluetooth 6.0" / "800mAh" / "50 hours"; earlier = "Bluetooth 5.3" / "1000mAh" / "40 hours".
  (c) Manual — the upgraded unit's manual contains a "THX Spatial Audio Software Guide" section; the earlier manual does not.
  (d) Practical check on a Windows PC — the THX Spatial Audio + app lists the headset at the bottom-left (with a "Headphones" label) only when supported hardware is connected over USB. If the app never shows the headset despite a good USB-dongle connection and the app having finished loading, the unit is most likely the earlier hardware.
  If still unsure, ask when and where it was bought and whether the box mentions THX; do not guess. For a definitive answer the customer can email the serial number/back-label photo to cc@thecosmicbyte.com.

CONNECTION MODES (3 modes, one device — both generations):
- 2.4GHz wireless via the included USB dongle (the manual labels this mode "Wi-Fi" — it is a 2.4GHz USB dongle link, NOT a Wi-Fi-network connection; low-latency, best for gaming)
- Bluetooth (upgraded model: Bluetooth 6.0 with LE Audio; earlier model: Bluetooth 5.3)
- Wired 3.5mm via the included aux cable (USB-C on the headset end → 3.5mm plug on the device end)

KEY HIGHLIGHTS (upgraded model):
- Tri-mode: Bluetooth + 2.4GHz dongle ("Wi-Fi") + wired
- 50mm drivers, 7.1.4 surround via THX Spatial Audio + (Windows software)
- Bluetooth 6.0 with LE Audio
- 800mAh battery, up to 50 hours play time (at 60% volume), 2–3 hour charge
- Detachable ENC (Environmental Noise Cancellation) microphone with RGB LED light on the mic
- Mic ON/OFF switch, Power button, Mode button, volume control wheel, RGB LED on the earcups (toggleable), USB-C port
- 2 on-headset modes: Game & Music
- Breathable headband cushion + breathable ear cushions
- THX Spatial Audio + software: download from www.thecosmicbyte.com (Windows only — see THX section)

WHAT'S IN THE BOX (upgraded model):
1. Cosmic Byte Immortal headset
2. Detachable microphone
3. USB dongle (the unboxing photo shows a USB-A dongle; one connection diagram in the manual labels it "USB C Dongle" — a manual labelling inconsistency. Treat it as USB-A based on the actual product; if a customer reports a USB-C dongle, ask for a photo and escalate to support.)
4. Charging cable (USB-A to USB-C)
5. AUX cable (USB-C on the headset end → 3.5mm on the device end)
6. User manual

SPECIFICATIONS — UPGRADED THX MODEL (from the manual; do not quote earlier-model figures for this unit):
Speaker:
- Chipset: JL7106 (supports LE Audio)
- Battery capacity: 800mAh
- Charging time: 2–3 hours
- Wireless connection distance: 10m
- Play time: up to 50 hours at 60% volume
- Speaker impedance: 16Ω
- Bluetooth version: 6.0 with LE
- Sensitivity: 114±3dB
- Frequency: 20Hz–20KHz
- Speaker diameter: Φ50mm
Detachable mic:
- Directivity: omni-directional
- Output impedance: max 2.2KΩ
- Sensitivity: -38±3dB
- Frequency: 20–20KHz
- RGB LED light on the mic
Not stated in the manual for the upgraded model: rated power, weight, exact latency figure, cable lengths. Do NOT invent them and do NOT copy the

earlier model's "20ms" / "20m range" / "1000mAh" / "40 hours" / "3 hours charge" figures onto the upgraded unit — those belong to the EARLIER hardware (see LEGACY section).

PLATFORM COMPATIBILITY (per the manual's connection diagram — both generations):
PC / Mac / Laptop:
- USB dongle: plug the dongle into a USB-A port; the headset pairs to it in 2.4GHz ("Wi-Fi") mode. White LED solid = connected.
- Bluetooth: switch the headset to Bluetooth pairing mode (Mode button ×2), then pair from the OS Bluetooth settings.
- Wired: aux cable (USB-C end into the headset, 3.5mm end into the headphone jack).
- THX Spatial Audio + (7.1.4) works on WINDOWS only, with the headset connected over USB (the USB dongle). See THX section.
Mobile (Android / iPhone / tablets):
- Bluetooth (RECOMMENDED): pair as a normal Bluetooth headset.
- USB dongle: the manual explicitly does NOT recommend the dongle for mobiles — it can cause low volume and connection issues on some devices. Use Bluetooth instead.
- 3.5mm wired: use the USB-C-to-3.5mm aux cable with the phone's 3.5mm port (or the phone's own 3.5mm adapter).
PlayStation 4 / PlayStation 5:
- USB dongle, or the 3.5mm aux cable into the PS4/PS5 controller.
- IMPORTANT: in the PS4/PS5 audio settings select "All audio to Headset or controller". Volume can be controlled from the PlayStation Audio Settings.
- No THX software on consoles — on PS4/PS5 the headset is plain stereo (the console's own 3D audio features are the console's, not THX).
Xbox One / Series S / Series X:
- 3.5mm aux cable into the Xbox controller ONLY. The headset will NOT work using the USB dongle on Xbox (Xbox does not support generic 2.4GHz USB audio dongles — a platform restriction, not a headset defect).
Nintendo Switch:
- Bluetooth or the 3.5mm aux cable (the manual's diagram shows Switch under Bluetooth / 3.5mm). The USB dongle is not shown as a Switch option — do not promise dongle support on Switch.

LED INDICATION:
- USB dongle disconnected = White LED flashes
- USB dongle connected = White LED on (solid)
- Bluetooth mode disconnected = Blue LED flashes
- Bluetooth connected = Blue LED on (solid)
- Charging = Red LED on
- Charged = LED off

CONTROLS — UPGRADED MODEL (per the new manual; this manual RESOLVES the double/triple-press ambiguity of the earlier manual — next/previous track are on the POWER button, mode switching is on the MODE button):
Mic ON/OFF switch:
- Press ×1 = microphone on/off
Power button:
- Long press 3 seconds = turn the headset on/off
- Press ×1 = turn the RGB LED on/off
- Press ×2 = next song
- Press ×3 = previous song
Mode button:
- Press ×1 = play/pause music; answer/hang up a call
- Press ×2 = switch between Wi-Fi (2.4GHz dongle) and Bluetooth pairing mode
- Long press 2 seconds = reject call
- Press ×3 = switch between Game and Music mode
Volume control wheel:
- Scroll upward = volume +
- Scroll downward = volume −
- Note: with the dongle on PS4/PS5 the console's audio settings control master volume — the wheel may not behave as expected in that mode.
USB-C port: Type-C CHARGING port (used with the charging cable). The manual documents it as the charging port and as the headset-side connector for the 3.5mm aux cable; it is NOT documented as a USB-audio connection to a PC — do not tell customers to run THX or USB audio over the USB-C cable; the PC USB connection is the dongle.

PAIRING WORKFLOWS:
2.4GHz (USB dongle):
1. Power on the headset (long-press Power 3 seconds).
2. Plug the USB dongle into a USB-A port on the PC/PS4/PS5.
3. The headset connects to the dongle; the white LED goes solid.
4. If it does not connect: press Mode ×2 to switch the headset to Wi-Fi (dongle) mode (the LED switches from blue to white), re-plug the dongle, keep the headset within 1m while it connects.
Bluetooth:
1. Power on the headset.
2. Press Mode ×2 to switch to Bluetooth pairing mode — the blue LED flashes (discoverable).
3. On the device, open Bluetooth settings → scan → select the Cosmic Byte Immortal.
4. Blue LED solid = paired/connected.
Wired (3.5mm):
1. Plug the USB-C end of the aux cable into the headset's USB-C port.
2. Plug the 3.5mm end into the device/controller jack. No pairing needed.

GAME / MUSIC MODES (on-headset, works in every connection mode, no software needed):
- Press Mode ×3 to switch between Game mode and Music mode. These are the headset's built-in sound modes; they are separate from the THX app's EQ presets (the app's Game/Music/Movie presets apply only when using THX on Windows).

WHAT THX SPATIAL AUDIO+ IS AND WHY IT MATTERS (use this to explain the benefit to customers):
- THX Spatial Audio+ is the immersive-audio platform from THX Ltd. (the company behind THX certification). It turns a stereo headset into a full 360° virtual surround experience using a physics-based room simulation, placing sounds around you — front, sides, behind AND above — with no physical speaker setup.
- WHAT "7.1.4" MEANS: the ".4" is FOUR HEIGHT channels. Ordinary 7.1 only places sound on a flat horizontal plane; 7.1.4 adds sounds coming from above, which completes the 360° soundscape.
- THE GAMING EDGE: enhanced positional accuracy — pinpoint where footsteps, gunfire, reloads and other cues come from, including above/below. THX's engine is built to make the most of positional sound cues in games.
- MOVIES & MUSIC: THX Spatial Audio mode gives a wider, more cinematic soundstage for films; THX Stereo mode gives clean, natural 2-channel playback that is ideal for music.
- AI / CAMERA HEAD TRACKING: uses a webcam to follow your head so the virtual sound field stays anchored to the world when you turn. Requires THX Spatial Audio mode and a connected webcam.
- DEVICE-SPECIFIC TUNING: THX designs custom filters/EQ for each supported headset so stereo and spatial playback are accurate for THAT exact hardware — this is why THX only runs on the upgraded Immortal hardware and not on the earlier units.
- HONEST LIMITS (do not over-promise): THX Spatial Audio+ works ONLY on WINDOWS, and ONLY while the headset is connected over USB (on the Immortal that means the 2.4GHz USB dongle). It does NOT run on macOS, Linux, consoles or phones, and it does NOT process audio over Bluetooth or over the 3.5mm aux cable — in those modes the Immortal is a normal stereo headset (still with its on-headset Game/Music modes). The full height/positional effect is strongest with content that carries positional audio; plain stereo sources gain a wider soundstage but not true discrete height cues.
- NOT ORBIT: the Immortal is NOT configured through Cosmic Byte Orbit (orbit.thecosmicbyte.com) — Orbit is for keyboards/mice/controllers. The Immortal's software is the THX Spatial Audio+ Windows app, downloaded from www.thecosmicbyte.com. Do NOT send an Immortal customer to Orbit.

THX SPATIAL AUDIO + SOFTWARE (WINDOWS-only desktop app — download from www.thecosmicbyte.com; upgraded hardware only; headset connected via the USB dongle):
- When the headset is connected and detected, its name appears at the BOTTOM-LEFT of the app with a "Headphones" label. If it's not there: check the USB (dongle) connection, make sure the headset is powered on and in dongle mode (white LED solid), and wait for the app to finish loading.
- AUDIO MODE SWITCH (top-right of every screen) — the single most important control: "THX Stereo" = traditional 2-channel L/R (cleanest for music/general listening). "THX Spatial Audio" = virtual 360° surround field (hear direction of footsteps/gunfire in games; wider soundstage for movies). Some features (Camera Head Tracking) only work while THX Spatial Audio is on — the app reminds you on-screen.
- STANDARD SETTINGS (everyday controls): 10-band Equalizer (32 Hz to 16 kHz), each band adjustable +12 dB to -12 dB, toggle on/off; presets Default (flat) / Music (lifted bass + upper treble) / Game (in-game detail + positional cues) / Movie (dialogue + cinematic) / Custom (moving any slider auto-switches to Custom so changes are not lost); Reset returns to flat. Sound Normalization (evens out quiet vs loud; slider sets strength — good for late-night listening). Bass Boost (one-tap extra low end). Voice Clarity (one-tap vocal-range emphasis for chat/streams/quiet dialogue).
- EXPERT > PARAMETRIC EQ: finer control than the Standard EQ. Same 5 presets + Reset. Response graph 20 Hz–20 kHz, +12/-12 dB, 10 draggable points (one per band). Per-band controls: Frequency (centre point), Gain (boost/cut in dB), Q (width — lower Q = broad, higher Q = narrow/surgical), Filter (Peak is the standard choice). Each band has a Band 1–10 checkbox to switch it off WITHOUT erasing its settings (for A/B comparison).
- EXPERT > CAMERA HEAD TRACKING: uses a webcam to keep virtual sound sources anchored to the world when you turn your head. REQUIRES THX Spatial Audio mode — in THX Stereo mode the app shows "Head tracking effects can only be heard when THX Spatial Audio mode is enabled"; flip the top-right mode toggle first. Controls: Device (choose your webcam/USB video device), Camera Mode (Auto recommended), Enable toggle (top-right). A preview shows your tracked head position relative to the virtual speakers.
- USER SETTINGS: language + app information.
- SOFTWARE TROUBLESHOOTING: headset not shown in the app → check the dongle is plugged in, headset on and in dongle mode (white LED solid), let the app finish loading; if it never appears, confirm the unit is the upgraded THX hardware (see generation check above). Head-tracking notice → switch the mode toggle to THX Spatial Audio. No surround effect → mode switch must be on THX Spatial Audio, not THX Stereo, and the Immortal must be the default Windows output device.

SETUP — WINDOWS PC WITH THX (upgraded model): power on the headset → plug the USB dongle into the Windows PC (white LED solid) → download and install THX Spatial Audio + from www.thecosmicbyte.com (Windows only) → open the app and confirm the headset appears bottom-left → set the mode switch to THX Spatial Audio for 7.1.4 surround → in Windows Sound Settings select the Immortal/dongle device as both output AND input.
SETUP — MAC / BLUETOOTH / 3.5MM: no software; the headset works as a normal stereo headset with its on-headset Game/Music modes. THX processing is not available in these modes.
SETUP — PS4/PS5: dongle into the console USB port (or aux cable into the controller) → Audio settings → "All audio to Headset or controller" → set volume from the PlayStation audio settings. No THX app on console.
SETUP — XBOX: aux cable into the controller's 3.5mm jack only.

TROUBLESHOOTING:
Q: No sound? A: Headset powered on (long-press Power 3 s; RGB lights up) → connection mode matches the device (white LED solid for dongle, blue solid for Bluetooth — press Mode ×2 to switch) → on PC set the Immortal/dongle as the default output → PS4/PS5: "All audio to Headset or controller" → wired: aux cable fully seated at both ends → phone with the dongle: switch to Bluetooth (dongle not recommended on mobiles).
Q: Low volume or dropouts on a phone with the dongle? A: Expected — the manual does not recommend the dongle for mobiles. Use Bluetooth (or the 3.5mm aux cable).
Q: Mic not working? A: Mic fully inserted into the earcup port → mic ON/OFF switch pressed to ON → on PC select the Immortal/dongle as the recording/input device → on PS4/PS5 check the input device in audio settings → over Bluetooth, make sure the device is using the headset for calls/voice as well as media.
Q: Won't pair over Bluetooth? A: Forget any old "Cosmic Byte Immortal" entry on the device → power-cycle the headset → press Mode ×2 until the BLUE LED flashes → stay within 1 m → pair again.
Q: Dongle shows white LED flashing (not connecting)? A: Headset must be in dongle mode (Mode ×2 switches between Bluetooth and dongle; white = dongle) → re-plug the dongle, try another USB-A port (avoid hubs) → keep the dongle away from USB 3.0 ports/devices and Wi-Fi routers (2.4GHz interference) → keep within 10 m line-of-sight.
Q: Disconnects randomly? A: Dongle: line-of-sight, away from USB 3.0 / routers, within 10 m. Bluetooth: within ~10 m, walls cut range. Check battery (charge if the headset is low).
Q: THX app does not detect the headset? A: Dongle plugged into the Windows PC, headset on and in dongle mode (white solid), app finished loading, Windows only. If the unit is the earlier (non-THX) Immortal, THX is not supported on that hardware — explain this plainly rather than troubleshooting further.
Q: No surround / sounds flat in THX? A: Top-right mode switch must be THX Spatial Audio (not THX Stereo); Immortal set as default output; use content

with positional audio.
Q: Head tracking does nothing? A: Needs THX Spatial Audio mode + a webcam selected under Device + the Enable toggle on.
Q: Next/previous track not working? A: On the upgraded model it is the POWER button: ×2 = next, ×3 = previous (not the Mode button). Media keys work over Bluetooth/dongle, not over the 3.5mm cable.
Q: RGB LED won't turn off? A: Press Power ×1 (short press) to toggle the RGB LED on/off. (Hold = power off.)
Q: Game/Music mode not switching? A: Press Mode ×3 (three quick presses). Mode ×2 is pairing-mode switch, Mode ×1 is play/pause.
Q: Charging? A: Use the included USB-A-to-USB-C cable on a 5V USB port/charger; red LED on = charging, LED off = charged; full charge takes 2–3 hours. Avoid high-wattage fast chargers.
Q: Works on Xbox with the dongle? A: No — Xbox is 3.5mm aux via the controller only.
Q: Which is better for gaming — dongle or Bluetooth? A: The 2.4GHz dongle (lower latency, and it is the only mode that supports THX on Windows). Bluetooth is for phones/tablets/Switch and general listening.
Q: Does it work on Mac? A: Yes as a normal headset (dongle, Bluetooth or 3.5mm) — but the THX Spatial Audio + app is Windows only.

LEGACY — EARLIER / PRE-THX IMMORTAL (Bluetooth 5.3, 1000mAh) — ONLY for customers who own an earlier unit:
- Specs as documented in the earlier manual: Bluetooth 5.3; 1000mAh battery; up to 40 hours; 3-hour charge; up to 20 m range; ~20 ms low latency in 2.4GHz mode; 50mm driver, 16±15% Ω, 112±3 dB, 20Hz–20KHz, 20mW rated; mic Ø6mm omni, ≤2.2KΩ, -42±3 dB, 100Hz–10KHz. Charging cable 0.5 m USB-A to USB-C.
- Same three connection modes, same platform behaviour, same LED indications, same Game/Music modes, same volume wheel, same warranty.
- Earlier-manual control notes: Power ×1 = RGB on/off, long-press 3 s = power. Mic ×1 = mute toggle. Mode ×1 = play/pause / answer/hang up; the earlier manual listed Mode ×2 BOTH as "next song" AND "switch Wi-Fi/Bluetooth pairing", and Mode ×3 BOTH as "previous song" AND "switch Game/Music" (long-press 2 s = reject call). That earlier documentation is ambiguous — if an earlier-unit customer reports unexpected Mode-button behaviour, acknowledge the ambiguity and forward to support (cc@thecosmicbyte.com / +91 7351615161) rather than inventing rules.
- THX Spatial Audio + is NOT supported on this hardware. Do not install it for the earlier model; do not treat "THX app can't see my headset" as a fault on this unit.
- Upgrade path: the current THX Immortal (same product page).

CARE: keep away from moisture; store cool and dry; do not disassemble; use the included cable for charging.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products are NOT covered. Gradual battery capacity reduction from normal use (wear and tear) is NOT covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 (WhatsApp same) | Mon–Sat 10am–6pm | AI support: ai.thecosmicbyte.com

PRICING: do NOT quote a price. For the current price and offers, direct the customer to the product page (BUY link below).
BUY: https://www.thecosmicbyte.com/product/cosmic-byte-immortal-2-4ghz-wireless-bluetooth-wired-headphone-black/ — the SAME product page / UPC covers the upgraded THX model (new stock ships the upgraded THX hardware). Use coupon code ONLINEPAY for 10% off on online payments.

Lumora

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-lumora-tri-mode-controller-for-pc-dedicated-software-support-cloak-rgb-mechanical-switches/

COSMIC BYTE LUMORA - TRI-MODE CONTROLLER - FULL MANUAL

PC ONLY. Not compatible with PlayStation, Xbox, Nintendo Switch. No warranty for console use. Android limited, not covered.

KEY FEATURES (full list — surface these accurately when comparing Lumora to other CB controllers):
- JOYSTICKS: Hall Effect (drift-resistant, NOT TMR — refer to Hall Effect matrix for confirmation).
- TRIGGERS: Hall Effect, analog/digital SWITCHABLE via software (not just physical switch). Per-trigger deadzone and anti-deadzone configurable.
- MACRO BUTTONS: 4 dedicated programmable macro buttons (ML, MR, LK, RK), 32 inputs each. This is more than most CB controllers — Stellaris/Drakon have 2, Blitz Tri-Mode has 0.
- BUTTON MAPPING (via software): Any gamepad button can be remapped to (a) another gamepad button, (b) any keyboard key (full keyboard layout including F-keys, modifiers, media controls, arrows), or (c) mouse actions. This means Lumora can be used with games or applications that don't natively support gamepad input — a Lumora-exclusive capability among current CB controllers.
- REPLACEABLE JOYSTICK TOPS: 6 stick tops included (3 styles — short flat textured / tall domed / medium domed knurled), giving 3 height-and-grip preference options for left+right stick pairs. Customers can swap depending on game genre or personal preference.
- REPLACEABLE D-PAD COVERS: 2 D-pad covers included (square/diamond style + faceted disc style). Different game-genre preferences (e.g. fighting games vs. platformers).
- CLOAK RGB DESIGN: Distinctive design feature — controller appears solid black when RGB is OFF, then reveals the underlying skull/gear artwork when RGB is ON. Gives a stealth-when-off / artwork-when-on aesthetic. Different from the Stellaris transparent variant (which is always-clear plastic).
- RGB CUSTOMISATION (via software): 5 individually-colorable RGB zones (Left Grip, Right Grip, Left Stick, Right Stick, Home). 5 animation modes (Static, Breathing, Colorful, Rainbow, Off). Brightness and speed sliders. "Show joystick lighting only" and "Home Lighting" toggles for granular control.
- ONBOARD PROFILES: 4 profiles switchable on the controller via M + Right Joystick Up/Down (Home LED flashes 1/2/3/4 to indicate which profile is active). Each profile stores its own mappings, RGB, vibration, etc.
- VIBRATION: Dual motors with INDEPENDENT per-grip intensity control (Left Grip and Right Grip configured separately via software).
- STICK CUSTOMISATION (via software): Per-stick deadzone, anti-deadzone, and Radial Trace toggle.
- GYRO: 6-axis. On-the-fly gyro customisation through Cosmic Byte software, same capability tier as Stellaris / Blitz Tri-Mode / Drakon. Native Bluetooth gyro mode also available.
- BATTERY: 1300mAh. Configurable auto-sleep (default 5 minutes).
- POLLING: 1000Hz on Wired and 2.4GHz.
- CONNECTIVITY: Tri-Mode (USB Wired / 2.4GHz / Bluetooth).
- MECHANICAL ABXY, LB/RB, and D-Pad — the ABXY face buttons, LB/RB shoulder bumpers, AND the D-pad are all mechanical-switch / clicky-tactile (NOT rubber-dome). This is Lumora's full mechanical button cluster. Among Cosmic Byte gamepads, Lumora and Drakon are the two products with mechanical ABXY+LB/RB; Lumora's distinguishing feature vs Drakon is the additional MECHANICAL D-PAD (Drakon's D-pad is rubber-dome). 3.5mm audio jack — 4-pole / TRRS, supports BOTH stereo audio OUTPUT (headphones) AND microphone INPUT (from a gaming headset's built-in mic). Works in Wired and 2.4GHz only, NOT in any Bluetooth mode (in BT mode the entire jack is inactive — no audio out, no mic in).

CONNECTIVITY:

A. 2.4GHz WIRELESS MODE (recommended for PC, lowest latency, also for Android with USB-C OTG):
1. Plug the USB dongle into the PC. Press the dongle's Force key for 1 second until its LED starts flashing.
2. Press HOME on the controller to power it on.
3. Hold PAIRING (P) for 3 seconds. The LED flashes purple. The controller vibrates once.
4. The controller searches for the dongle. Once paired, the dongle's LED stops flashing and stays solid yellow.
5. Auto-reconnects to the same dongle on every power-on after that.

Range: 7-10 metres. Software (RGB / button mapping / triggers / sensitivity) works in this mode. Re-pair required if the controller was last used in Bluetooth mode (press dongle Force key 1 sec, then PAIRING (P) 3 sec).

B. STANDARD BLUETOOTH MODE (Android, iOS, PC, Mac, Smart TV, Tablet — for general gamepad use; appears in BT list as "Cosmic Byte Lumora"):
This same flow works for PC too -- per the manual: "this mode will also work [on] PC and support Gyro on PC". Use this for general PC gamepad use. Use Mode C below if you specifically want the Switch-Pro-Controller protocol.
1. Press HOME to power on the controller.
2. Enter pairing mode for your platform:
    * Android: Hold PAIRING (P) + A together for 3 seconds. LED flashes green rapidly. Controller vibrates once.
    * iOS / Mac / PC: Hold PAIRING (P) + B together for 3 seconds. LED flashes blue rapidly. Controller vibrates once.
3. On the device, open Bluetooth settings and select "Cosmic Byte Lumora" from the available-devices list.
4. Once paired the LED becomes SOLID -- solid green if paired via the Android flow, solid blue if paired via the iOS/Mac/PC flow. Controller vibrates once.
5. Auto-reconnects on subsequent power-on. To pair to a different device, hold PAIRING (P) for 3 seconds (LED blinks rapidly) to clear the existing pairing first, then re-enter pairing mode.

Range: up to 8 metres.

C. BLUETOOTH GYRO MODE (PC only; alternative PC Bluetooth flow that emulates the Switch Pro Controller protocol; appears in Windows BT list as "Pro Controller"):
Use this method when you specifically want gyro support on PC via the Pro-Controller protocol. For most PC use cases, Mode B (Standard Bluetooth) is simpler and also supports gyro.
1. Press HOME to power on the controller.
2. Hold Y + P (the Y face button + the PAIRING button) together for 3 seconds. LED blinks to indicate pairing mode.
3. On Windows: Settings > Bluetooth & devices > Add device > Bluetooth.
4. Select "Pro Controller" from the discovered-devices list.
5. LED becomes stable. Controller is ready in Gyro Mode.

IMPORTANT: in this mode the analog triggers (LT/RT) act as DIGITAL buttons (on/off) -- they are NOT pressure-sensitive. Use Mode A (2.4GHz) or Mode D (Wired) if you need analog trigger pressure.

D. WIRED USB-C MODE (best for stability, charging, and software configuration):
1. Plug the included USB-C cable into the controller and into the PC.
2. Controller powers on automatically. Windows detects it (no drivers required).
3. Default mode is X-Input. To toggle X-Input <-> D-Input: hold Back + Start for 3 seconds.
4. Cosmic Byte software works in this mode for full customisation.
LED: Yellow = X-Input. Red = D-Input.

GENERAL NOTES (apply across modes):
- Auto sleep: 5 minutes of inactivity. Press HOME to wake.
- Software configuration (RGB customisation, button mapping, polling rate, sensitivity, etc.) works in 2.4GHz and Wired modes ONLY -- NOT in any Bluetooth mode (Standard or Gyro). Configure once via cable or dongle, then settings persist when you switch to Bluetooth.
- Audio (3.5mm jack) is a 4-pole / TRRS jack supporting BOTH headphone audio output AND headset microphone input. Works in 2.4GHz and Wired modes ONLY -- NOT in any Bluetooth mode (in BT mode the entire jack is inactive — no audio out, no mic in).

LED INDICATORS (Lumora uses COLOUR codes only — there are NO numbered LED indicators like "LED1", "LED2", "LED3" on the Lumora; if a previous response mentioned numbered LEDs that was a hallucination, correct it):
- Yellow (solid) = Wired X-Input mode
- Red (solid) = Wired D-Input mode
- Green (rapid flash) = Bluetooth pairing mode for Android (PAIRING + A held)
- Green (solid) = Connected via Android-flow Bluetooth
- Blue (rapid flash) = Bluetooth pairing mode for iOS / Mac / PC (PAIRING + B held)
- Blue (solid) = Connected via iOS/Mac/PC-flow Bluetooth
- Purple (flashing) = 2.4GHz pairing mode (PAIRING held alone)
- LED stable in Gyro Mode = Connected as "Pro Controller" via Y + P
- HOME LED breathing slowly = Charging
- HOME LED flashing quickly = Low battery

TRIGGER MODES (Hall Effect L2/R2):
- Physical travel switch toggles Analog (gradual, longer travel) vs Digital (instant, shorter travel).
- Analog sensitivity levels: Press PAIRING key to cycle 30% -> 60% -> 100%. Vibrates once per change.

BATTERY CHECK: Press Macro + RB. LED: Red=1-25%, Yellow=26-50%, Blue=51-75%, Green=76-100%.
CHARGING: HOME LED breathes slowly = charging. Turns off = fully charged. HOME flashes quickly = low battery. USB-C supports charging while playing. Avoid fast chargers above 10W. Use 5V/1A or PC USB.

TURBO: Hold TURBO + desired button to enable. Repeat to disable. Hold TURBO + START for 2 seconds to clear all. Supported: A, B, X, Y, LB, RB, LT, RT.
VIBRATION: Increase: Hold R3 + Left Stick Up for 3 seconds. Decrease: Hold R3 + Left Stick Down for 3 seconds. Levels: 100% > 70% > 30% > 0%.
RGB: Cycle effects: Turbo + R3. Change colour: Turbo + L3. Toggle all on/off: Hold Turbo + R3 for 3 seconds. Home LED on/off: M + Home.

MACRO (ML/MR/LK/RK): Hold Macro (M) key + macro button for 2 seconds until LED flashes. Press button sequence. Press same M button to save. Vibrates once to confirm. Clear: enter mode, press M button to clear.
JOYSTICK CALIBRATION: Power off. Hold Back + X + Home for 1 second. Rotate both joysticks 3 times clockwise. Press both triggers 3 times. Press Start to save.
JOYSTICK RANGE MODES: L3/R3 + Macro to toggle: Full Circle (default) -> Small Circle (precision) -> Square Mode.

RESET: Pin into RESET hole on back for 2 seconds. Does NOT delete macros. Clears pairing data.

SOFTWARE (Cosmic Byte Lumora companion app — Windows ONLY):

Download from https://www.thecosmicbyte.com/downloaddrivers/. Current software version is v1.3.4 (visible at the bottom-right of the app window). The Lumora is plug-and-play on Windows in all four connection modes for normal gamepad use; the software is OPTIONAL and only needed for customisation. There is no macOS build — Lumora works on macOS in 2.4GHz / Bluetooth / Wired modes for normal gamepad use, but software-only features below are not available on macOS.

CONNECTION REQUIREMENT: software works over WIRED or 2.4GHz only. NOT in any Bluetooth mode (Standard or Gyro). If the customer reports the software won't detect their Lumora, first confirm they are NOT connected via Bluetooth.

APP LAYOUT:
- LEFT SIDEBAR NAV (9 tabs): Mappings / Macro / Sticks / Triggers / Vibration / Motion / Lighting / Extended Settings / Firmware Update.
- RIGHT PANEL: live render of the Lumora controller with real-time joystick X/Y readouts (shown as percentages near each stick) and trigger intensity bars on the far left (LT) and far right (RT) of the panel.
- TOP-RIGHT: Profiles selector — four numbered slots (1, 2, 3, 4) with the active profile highlighted.
- BOTTOM-LEFT: Back button + "Restore To Default" button (resets the current tab's settings on the active profile).
- BOTTOM-RIGHT: language selector (EN currently) and software version (v1.3.4 currently).

PROFILES SYSTEM (4 profiles, switchable on the controller without the software running):
- 4 independent profiles labelled 1, 2, 3, 4.
- Each profile saves its own complete configuration: button mappings, macros, stick / trigger / vibration / motion / lighting settings, etc.
- ON-CONTROLLER SWITCH: press M (Macro) + Right Joystick Up/Down to cycle through profiles.
- HOME LED FEEDBACK: flashes 1, 2, 3, or 4 times to indicate the active profile after a switch.
- Useful for switching between, e.g., an FPS profile (motion on, aggressive curve, mapped to RT-hold) and a racing profile (motion on, smooth curve, mapped to left stick) without re-opening the software.
- Profile switching is hardware-based once the profiles are saved -- the Lumora doesn't need a PC connection to switch.

MOTION TAB (NEW IN SOFTWARE v1.3.4 — gyro / motion customisation):

The Motion tab supersedes and extends the older "on-the-fly gyro" feature. It exposes per-profile controls for how the Lumora's 6-axis gyroscope translates motion into joystick output:

a) ACTIVATION METHOD (on/off toggle):
  * Off (default) — gyro is disabled entirely on this profile. The other Motion controls are still visible but inactive.
  * On — gyro is active per the Activation Button setting below.

b) OUTPUT (which joystick the gyro motion mimics):
  * Left Stick (default) — gyro motion translates to left-stick input. Typical for movement in racing / flight games or for crouching / strafing in FPS hybrids.
  * Right Stick — gyro motion translates to right-stick input. Typical for camera / aim control in FPS or third-person games.

c) ACTIVATION BUTTON (which controller button gates gyro):
  * NC (No Command, default) — no specific activation button; gyro is on whenever Activation Method is On. This is the equivalent of the older software's "Always On" mode.
  * Any other controller button (A, B, X, Y, RT, LT, etc.) — gyro is gated by that button. The interaction style (Toggle vs Press-and-Hold) is set elsewhere in the software / firmware; for FPS aiming, customers typically assign LT or RT and use it as a hold-to-aim gate.

d) DEADZONE (slider):
  * Lower deadzone → more sensitive (small wrist movements register as input).
  * Higher deadzone → more relaxed (only deliberate motion registers, ignores hand tremor / tabletop vibration).
  * Adjust based on game and personal preference.

e) CURVE (response shape — four presets plus Custom):
  * DEFAULT — linear curve. 1:1 motion-to-output mapping. Predictable, what most players expect on first try. Use this if you're new to gyro.
  * AGGRESSIVE — exponential curve. Slow response near centre, fast at extremes. Good for FPS aiming where you want fine control near rest and quick flicks at the edges. Curve graph: flat-then-steep.
  * SMOOTH — S-curve / sigmoid. Gradual ease-in and ease-out, faster response through the middle. Good for camera control in third-person games and racing. Curve graph: ease-in-ease-out.
  * CUSTOM — user-editable multi-point curve. Drag control points on the curve graph to define an arbitrary response shape. Power users can build piecewise-linear responses (e.g. a deadband-then-burst-then-cap profile for very specific game requirements). Points snap to the grid.

Notes on the Motion tab:
- Each profile has its own Motion settings, so a player can have one profile with gyro Off (for menu/casual use) and another with gyro On + Aggressive curve (for FPS).
- The Motion tab does NOT replace native Bluetooth Gyro Mode (Y + P, "Pro Controller"). The Motion tab works over Wired or 2.4GHz; native Bluetooth Gyro Mode is a separate firmware-level feature for use specifically over Bluetooth.

OTHER TABS (brief reference — when a customer asks about a feature not on the Motion tab, point them at the right tab):
- MAPPINGS — button remapping (Key 1..6 etc., remap to other buttons / keyboard keys / macros / multimedia).
- MACRO — macro recording, event editor, loop settings (similar UX to the Velox companion app).
- STICKS — per-stick deadzone, range mode (Full Circle / Small Circle / Square), response curve, anti-deadzone.
- TRIGGERS — Hall Effect trigger configuration: analog/digital mode toggle, sensitivity ranges (30% / 60% / 100%), debounce.
- VIBRATION — dual-motor intensity per profile, optional per-event triggering.
- MOTION — (the section above).
- LIGHTING — RGB customisation. (Lumora has 5-zone preset-animation RGB; not as granular as Stellaris.)
- EXTENDED SETTINGS — miscellaneous: auto-shutdown timeout, polling rate, etc.
- FIRMWARE UPDATE — check / install controller firmware from within the app. Requires WIRED USB-C ONLY (NOT 2.4GHz, NOT Bluetooth). The rest of the Cosmic Byte software (Mappings, Macro, Sticks, Triggers, Vibration, Motion, Lighting, Extended Settings) works fine over EITHER Wired OR 2.4GHz, but firmware update specifically requires the wired connection so the install can complete reliably without RF interference. If a customer reports the firmware update tab is greyed-out or refusing to start, first confirm they are connected via the USB-C cable, not the 2.4GHz dongle.

GENERAL SOFTWARE NOTES:
- All settings are stored on the CONTROLLER itself (not just in the software), so they persist across PCs and across power cycles. The customer doesn't need to keep the software running for the settings to take effect.
- Profile switching on the controller (M + Right Joystick Up/Down) works without the software running.
- Software is WINDOWS ONLY. No macOS / Linux / Android build exists. Do NOT direct macOS users to a "Mac version" — none exists.
- Software does NOT detect the controller over Bluetooth. Use Wired or 2.4GHz to access any of the tabs above.

GYRO (6-axis built-in):

NATIVE BLUETOOTH GYRO MODE (firmware-level, works over Bluetooth):
- Hold Y + P (PAIRING) for 3 seconds. Controller pairs as "Pro Controller" in Windows Bluetooth.
- See Mode C in CONNECTIVITY above for the full pairing flow.

MOTION TAB GYRO (software-level, works over Wired or 2.4GHz):
- For full controls including Activation Method, Output, Activation Button, Deadzone, and Curve presets (Default / Aggressive / Smooth / Custom), see the MOTION TAB section under SOFTWARE above. This is the current (v1.3.4) implementation.
- LEGACY ACTIVATION MODES (still valid for older software versions): older releases described three activation modes — Always On (NC equivalent), Toggle (press button once to enable, again to disable), and Press and Hold (gyro active only while button is held). In v1.3.4 these are subsumed under the Activation Method on/off toggle plus the Activation Button picker. If a customer is on an older version, the legacy terms still apply; if they're on v1.3.4, point them at the Motion tab.
- Gyro output mimics joystick movement (left or right stick, configurable on the Motion tab), so it works in ANY game that supports a joystick — even games with no native gyro support.

AUDIO: 3.5mm 4-pole / TRRS jack supports BOTH stereo audio output (headphones) AND microphone input (from a gaming headset's built-in mic). Works in 2.4GHz and Wired modes only, NOT in Bluetooth mode (in BT mode the jack is fully inactive — no audio output, no mic input). If a customer

asks "will my headset mic work on the Lumora", the answer is YES — provided they plug into the 3.5mm jack in 2.4GHz or Wired mode (any standard gaming headset with a 4-pole / TRRS plug will have both audio and mic functional).

TROUBLESHOOTING:
- Not powering on: Charge 10-15 min. Try RESET hole (pin, 2 seconds). Try different USB port/cable.
- 2.4GHz not connecting: Press dongle force key 1 second. Hold PAIRING (P) 3 seconds on controller. Move away from USB 3.0 devices and Wi-Fi routers. Try USB 2.0 port. Stay under 1 metre during pairing.
- Bluetooth not connecting: Delete "Cosmic Byte Lumora" from paired devices. Toggle Bluetooth off/on on device. Reset controller.
- Disconnecting: Charge fully. Keep within range. Move dongle to front USB port. Avoid Wi-Fi routers and USB 3.0 drives near dongle.
- Software not detecting: Use wired or 2.4GHz (NOT Bluetooth). Close X360CE, DS4Windows, Steam Big Picture. Reinstall software from thecosmicbyte.com.
- Joystick drift: Recalibrate (Back + X + Home method). Check joystick range mode.
- Charging issues: Use 5V/1A charger. Avoid fast chargers above 10W.
- Controller not in game: Verify Yellow LED (X-Input). Restart Steam/Epic. Disable Steam Input Override in game properties.

WARRANTY: 1 year manufacturing defects only. Physical damage, water damage, tampered products NOT covered.

ANTI-HALLUCINATION GUARD (Lumora — read this before answering any pairing / connection / LED / button-combo question):
The pairing flows above are EXHAUSTIVE -- there are exactly four connection modes (2.4GHz, Standard Bluetooth, Bluetooth Gyro, Wired). If the customer's question doesn't map cleanly to one of these, ask them to clarify which mode they want before answering.

The following are previously-observed hallucinations that the AI has produced when asked "how to connect Lumora to PC via Bluetooth" -- do NOT reproduce any of them, even if they sound plausible:

(a) "Press Y + HOME together for 3 seconds" -- WRONG. The correct combo is Y + P (the PAIRING button on the front, NOT the HOME button). HOME is for power and wake; PAIRING (P) is the dedicated pairing button.

(b) "The LED will show LED3 ON" -- WRONG. The Lumora has NO numbered LED indicators (no LED1/LED2/LED3/LED4). It uses COLOUR codes (yellow/red/green/blue/purple) and animation patterns (solid/flashing/breathing) only. If you find yourself about to write "LED1" or "LED2" or "LED3" or "LED4" for a Lumora question, STOP -- you're hallucinating, refer back to the LED INDICATORS list above.

(c) "Lumora will appear as 'Lumora' OR 'Pro Controller' (depending on mode)" -- INCOMPLETE/MISLEADING. Be specific: in Standard Bluetooth Mode (PAIRING + A or PAIRING + B) the device shows up as "Cosmic Byte Lumora". In Bluetooth Gyro Mode (Y + P) it shows up as "Pro Controller". Don't merge them into one ambiguous "either/or".

(d) Inventing intermediate steps that aren't in the four flows above (e.g. "go to Device Manager", "install drivers", "run as administrator") -- WRONG. The Lumora is plug-and-play on Windows; no drivers, no Device Manager steps. The Cosmic Byte software is OPTIONAL and only needed for customisation, not for basic connection.

(e) "The manual doesn't specify whether a microphone (via the 3.5mm jack) will work on the Lumora -- it only documents that the audio jack is functional in 2.4GHz and Wired modes for audio output" -- WRONG. This was the verbatim hedge from production session 59e91fd5 (2026-05-16 10:35). The 3.5mm jack on the Lumora is a 4-pole / TRRS jack and supports BOTH audio output AND microphone input. Any standard gaming headset with a 4-pole plug will have both its audio AND its mic functional through the Lumora's audio jack (in 2.4GHz or Wired mode — not Bluetooth, where the jack is fully inactive). Do NOT push the customer to "contact support to confirm" on a question the bot can answer directly: yes, the headset mic will work.
(f) "The audio jack supports audio output only, not microphone input" / "the jack is mono / 3-pole" / similar variants that DENY mic support -- WRONG. The Lumora's audio jack is explicitly designed for gaming headsets, which require 4-pole TRRS for both audio + mic. Stating otherwise is a fabrication, not a manual hedge.
(g) Telling the customer "the manual doesn't specify" on the mic question and routing them to email/phone support -- WRONG framing. The bot has the answer: yes, mic works through the 3.5mm jack in 2.4GHz / Wired modes. Don't escalate a question that's directly answerable to human support — that wastes the customer's time AND the support team's time, AND signals the bot is less helpful than it actually is.

If a customer reports a step that isn't in the manual, treat it as a customer mistake, not as a hidden feature -- ask them to check the manual flow above.

Nexus

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-nexus-wireless-controller-for-pc-aaa-removable-battery/

COSMIC BYTE NEXUS - 2.4GHz WIRELESS CONTROLLER - FULL MANUAL

CONNECTIVITY:
- 2.4GHz Wireless only. Powered by 2x AAA batteries (not rechargeable).
- Insert 2x AAA batteries with correct polarity. Slide power switch to ON - Green and Red LEDs flash.
- Plug the wireless dongle into a USB port on the PC. Once connected, LEDs go solid.
- Windows 10 is Plug and Play - no drivers needed. Try a different USB port if not detected.
- Android: requires OTG support. Use a compatible OTG cable with the dongle. Android use not covered under warranty.
- NOT compatible with PlayStation, Xbox, Nintendo Switch or any console.
- Wireless range: up to 8 metres in open conditions.

LED INDICATORS:
- Green LED only = XInput mode (PC default).
- Red LED only = DirectInput mode.
- Green + Red both on = PC Analog mode.
- LEDs flashing = connecting / pairing in progress.
- LEDs solid = successfully connected.
- LEDs flashing slowly = low battery.
- No LEDs = controller off or battery dead.

SWITCHING INPUT MODES (XInput ↔ DirectInput):
- Hold the Mode button for more than 5 seconds to toggle between XInput and DirectInput.
- Old games (pre-2005) typically need DirectInput (Red LED).
- Always relaunch the game after switching modes.

VIBRATION:
- Dual vibration motors. Vibration automatically disabled when battery is low.
- If vibration stops, replace batteries first before assuming hardware fault.

BATTERY MANAGEMENT:
- Low battery: LEDs flash instead of staying solid. Vibration also disables.
- Replace both AAA batteries with fresh ones immediately.
- Storage: slide power switch to OFF. Remove batteries from compartment - do not leave batteries in during long non-use as they can leak and damage the controller.
- Store in dry place at -10 degreesC to +60 degreesC, 20-80% humidity.

TROUBLESHOOTING:
- Not detected on PC: try a different USB port, remove USB hubs, reinsert dongle, restart PC.
- Buttons sluggish or unresponsive: check input mode (hold Mode 5s to switch), replace batteries, try different USB port, reinsert dongle.
- Frequent disconnections: move dongle to front USB port, ensure clear line of sight, move away from Wi-Fi routers and USB 3.0 devices, replace batteries.

WARRANTY:
- 1 year against manufacturing defects only.
- Physical damage, water damage, tampered products NOT covered.
- Console use NOT covered.

Olympus

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-olympus-7-1-4-surround-wired-headset-with-thx-spatial-audio/

PRODUCT: Cosmic Byte Olympus — 7.1.4 SURROUND WIRED HEADSET WITH THX SPATIAL AUDIO (USB)

KEY FEATURES: NEW flagship of the wired THX line — best-tuned speakers and best sound experience of the three WIRED THX headsets (the Immortal is the separate WIRELESS THX headset). 7.1.4 surround (THX Spatial Audio), 53mm NEODYMIUM drivers (the largest driver in the wired THX line-up), USB input, detachable ENC microphone, auto-adjustable headband, protein-leather ear cushions, braided cable, THX branding on the headband, carrying pouch included.

SPECS:
- Driver: 53mm neodymium | Sensitivity: 110 ±3dB | Impedance: 32Ω ±15% | Freq: 20Hz–20,000Hz
- FLAGSHIP / BEST SOUND IN THE LINE: the Olympus is the NEW top model of the wired THX line and has the BEST-TUNED speakers and the best overall sound experience of the three wired models (CryoCore < Proteus X < Olympus); the Immortal is the wireless THX option and sits outside this wired tiering. Its 53mm neodymium drivers are acoustically tuned for THX Spatial Audio. If a customer asks which THX headset sounds best or wants the premium option, recommend the Olympus.
- Power: 20mW rated | 30mW input
- Headset jack: USB. Cable 2.1m ±10%.
- Mic: ø6.0×2.7mm ENC, sensitivity -40 ±3dB, omnidirectional, detachable
- Weight: 280g (without cable), 335g (with cable) | Product dims: 175×110×215mm | Packaging: 256×256×109mm
- Connection is USB — do NOT promise a 3.5mm jack for the Olympus (the manual lists USB input only).

WHAT'S IN THE BOX: Olympus headset, detachable microphone, carrying pouch, user manual.

CONTROLS:
- Volume wheel — scroll up = volume +, scroll down = volume −
- Mic mute button — tap once = microphone on/off
- LONG PRESS the mic mute button = switch EQ preset on the headset: Music mode → Game mode → Movie mode (cycles). This is a hardware EQ switch and is separate from the presets inside the THX app.

WHAT THX SPATIAL AUDIO+ IS AND WHY IT MATTERS (use this to explain the benefit to customers):
- THX Spatial Audio+ is the immersive-audio platform from THX Ltd. (the company behind THX certification). It turns a stereo headset into a full 360° virtual surround experience using a physics-based room simulation, placing sounds around you — front, sides, behind AND above — with no physical speaker setup.
- WHAT "7.1.4" MEANS: the ".4" is FOUR HEIGHT channels. Ordinary 7.1 only places sound on a flat horizontal plane; 7.1.4 adds sounds coming from above, which completes the 360° soundscape. This is a genuine step up from the old 7.1 headsets.
- THE GAMING EDGE: enhanced positional accuracy — you can pinpoint where footsteps, gunfire, reloads and other cues are coming from, including above/below you. That directional awareness is the main competitive benefit. THX's engine is built specifically to make the most of positional sound cues in games.
- MOVIES & MUSIC: THX Spatial Audio mode gives a wider, more cinematic soundstage for films; THX Stereo mode gives clean, natural 2-channel playback that is ideal for music.
- AI HEAD TRACKING: uses your webcam to follow your head so the virtual sound field stays anchored to the world when you turn (instead of turning with you). Sounds keep coming from where they should — far more realistic, and it helps you keep your bearings in games. Requires THX Spatial Audio mode and a connected webcam.
- DEVICE-SPECIFIC TUNING: THX measures each headset's acoustic performance and designs custom filters/EQ so BOTH stereo and spatial playback are accurate for THAT exact headset. This is why the Cosmic Byte THX headsets have speakers tuned specifically for THX — the processing is matched to the hardware rather than generic.
- PERSONAL AUDIO PROFILES: content modes (Game / Music / Movie presets) plus the Standard and Parametric EQ let the customer tailor the sound to what they are doing.
- HONEST LIMITS (do not over-promise): THX Spatial Audio+ works ONLY on WINDOWS, and ONLY over the USB input. It does NOT run on macOS, Linux, consoles or phones, and it does NOT process audio over a 3.5mm connection. (A USB-connected headset still works as a normal USB audio device on PS4/PS5 or a Mac — just without the THX app / surround processing.) The full height/positional effect is strongest with content that carries positional audio — most modern games and surround movie mixes do; plain stereo sources gain a wider soundstage but not true discrete height cues.
- NOT ORBIT: the THX headsets (CryoCore, Proteus X, Olympus, Immortal) are NOT configured through Cosmic Byte Orbit (orbit.thecosmicbyte.com). Orbit is for keyboards/mice/controllers. For these headsets the software is the THX Spatial Audio+ Windows app, downloaded from www.thecosmicbyte.com. Do NOT send a THX-headset customer to Orbit.

THX SPATIAL AUDIO + SOFTWARE (WINDOWS-only desktop app — download it from www.thecosmicbyte.com; requires the headset connected by USB):
- When the headset is plugged in and detected, its name appears at the BOTTOM-LEFT of the app with a "Headphones" label. If it's not there: check the USB connection and wait for the app to finish loading.
- AUDIO MODE SWITCH (top-right of every screen) — the single most important control: "THX Stereo" = traditional 2-channel L/R (cleanest for music/general listening). "THX Spatial Audio" = virtual 360° surround field (hear direction of footsteps/gunfire in games; wider soundstage for movies).
- STANDARD SETTINGS (everyday controls): 10-band Equalizer (32 Hz to 16 kHz), each band adjustable +12 dB to -12 dB, toggle on/off; presets Default (flat) / Music (lifted bass + upper treble) / Game (in-game detail + positional cues) / Movie (dialogue + cinematic) / Custom (moving any slider auto-switches to Custom); Reset returns to flat. Sound Normalization (evens out quiet vs loud, slider sets strength — good for late-night). Bass Boost (one-tap extra low end). Voice Clarity (one-tap vocal-range emphasis for chat/streams/quiet dialogue).
- EXPERT > PARAMETRIC EQ: finer control than the Standard EQ. Same 5 presets + Reset. Response graph 20 Hz–20 kHz, +12/-12 dB, 10 draggable points (one per band). Per-band controls: Frequency (centre point), Gain (boost/cut in dB), Q (width — lower Q = broad, higher Q = narrow/surgical), Filter (Peak is the standard choice). Each band has a Band 1–10 checkbox to switch it off WITHOUT erasing its settings (for A/B comparison).
- EXPERT > CAMERA HEAD TRACKING: uses a webcam to keep virtual sound sources anchored to the world when you turn your head (more convincing spatial effect). REQUIRES THX Spatial Audio mode — in THX Stereo mode the app shows a notice that head-tracking effects can only be heard once Spatial Audio is enabled; flip the top-right mode toggle first. Controls: Device (choose your webcam/USB video device), Camera Mode (Auto recommended), Enable toggle (top-right). A preview shows your tracked head position vs the virtual speakers.
- USER SETTINGS: language + app information.

- SOFTWARE TROUBLESHOOTING: headset not shown in the app → check USB, let the app finish loading. Head-tracking "can only be heard when Spatial Audio is enabled" → switch the mode toggle to THX Spatial Audio. No surround effect → make sure the mode switch is on THX Spatial Audio, not THX Stereo.

SETUP — WINDOWS PC: plug USB into the Windows PC → install THX Spatial Audio + from www.thecosmicbyte.com (Windows only) → confirm "Olympus" appears bottom-left in the app → set mode to THX Spatial Audio for surround → select the Olympus as default output/input in Windows Sound Settings.
SETUP — PS4/PS5: plug USB into the console; no software needed. Xbox: not officially supported via USB.

TROUBLESHOOTING:
Q: No surround? A: In the THX app switch the top-right mode from THX Stereo to THX Spatial Audio; confirm Olympus is the default output.
Q: Not detected? A: Check USB → try another port → let the THX app finish loading → set Olympus as default device.
Q: Sound profile changed unexpectedly? A: A long press on the mic mute button cycles the on-headset EQ (Music/Game/Movie) — a short tap only mutes the mic. Long-press again to cycle back.
Q: Mic not working? A: Mic firmly plugged in → tap mic mute to unmute → select Olympus as input in Windows.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products NOT covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 (WhatsApp same) | Mon–Sat 10am–6pm

PRICING: do NOT quote a price for this headset. For the current price and any offers, direct the customer to the product page (BUY link below) — pricing is set on the website and changes.
BUY: https://www.thecosmicbyte.com/product/cosmic-byte-olympus-7-1-4-surround-wired-headset-with-thx-spatial-audio/ — use coupon code ONLINEPAY for 10% off on online payments.

Orbit

Product page: https://orbit.thecosmicbyte.com

ORBIT — COSMIC BYTE'S BROWSER-BASED CONFIGURATOR (also called "GOD MODE")
(added v1.10.29 from operator-supplied Orbit package, 2026-05-22. This is a TOOL entry, not a physical product — it documents the Orbit web configurator that customers use to tune supported Cosmic Byte peripherals from any modern Chrome-based desktop browser.)

WHAT IT IS:
Cosmic Byte Orbit is the official BROWSER-BASED configurator for Cosmic Byte gaming peripherals. It runs entirely in a web browser at https://orbit.thecosmicbyte.com — for most devices there is NO desktop software to download. (One exception: the wired Velox needs the "Cosmic Byte Connect" desktop helper — see below.)

URL: https://orbit.thecosmicbyte.com

WHAT CUSTOMERS CAN DO IN ORBIT (varies per device):
- Remap buttons / keys
- Adjust DPI, sensitivity, polling rate
- Tune stick / trigger response, deadzones, motion (controllers)
- Customise vibration
- Set RGB lighting effects, colour, brightness, speed
- Record and edit macros
- Sign in and sync settings to a Cosmic Byte account

CURRENTLY SUPPORTED DEVICES (snapshot 2026-05-22 — list grows over time):
- Helios (wireless gaming mouse)
- Lumora (wireless gamepad)
- Ares Pro (wireless gamepad)
- Drakon (tri-mode controller)
- Blitz (tri-mode controller)
- Stellaris (tri-mode controller)
- Phantom TKL (tri-mode gasket mechanical keyboard)
- Velox (tri-mode gaming mouse)
- Ignis (tri-mode gaming mouse)
- Arcturus 65 (tri-mode gasket mechanical keyboard, 65%)
- Arcturus 75 (tri-mode gasket mechanical keyboard, 75%)
- Arcturus 98 (tri-mode gasket mechanical keyboard, 98%)
- Hydrus Wired (wired controller — connect via USB cable)
- Hydrus Tri-Mode (tri-mode controller — connect via USB cable or 2.4GHz dongle, not Bluetooth)
More Cosmic Byte hardware is added regularly. The LIVE device grid at https://orbit.thecosmicbyte.com is the authoritative list — direct customers there to see what is supported right now. Some devices may appear flagged "Coming soon — in testing" while in pre-release.

BROWSER & PLATFORM REQUIREMENTS (strict):
- DESKTOP ONLY — Windows, macOS, Linux, ChromeOS.
- Supported browsers: Chrome, Edge, Brave, Opera (any Chromium-based browser with WebHID).
- NOT supported: Firefox, Safari, or any mobile browser (iOS or Android) — even Chrome on a phone or tablet will NOT work. Orbit uses the browser WebHID API, which only Chromium browsers on desktop implement.

HOW TO USE IT (step-by-step for customers):
1. On a desktop or laptop computer, open Chrome (or Edge / Brave / Opera).
2. Visit https://orbit.thecosmicbyte.com.
3. Plug your Cosmic Byte device into the computer using either its USB cable or its 2.4 GHz USB dongle. For wireless devices, set the connection switch to USB or 2.4G (NOT Bluetooth).
4. Click "Detect device" on the page and approve the browser permission prompt that pops up.
5. Open the configurator for your device and tune the settings you want.
6. Optional: sign in to sync settings to your account.

CONNECTION RESTRICTIONS:
- Bluetooth devices CANNOT be configured in Orbit — the configuration interface is only exposed over USB / 2.4 GHz. Customers on Bluetooth must switch their device to USB cable or its 2.4 GHz dongle to use Orbit.
- For most supported devices, no driver or software install is required — Orbit talks to the device directly through the browser.

SPECIAL CASE — COSMIC BYTE CONNECT (small desktop helper):
A few devices (currently the WIRED Velox) expose their configuration interface on a USB-HID interface that Chrome cannot reach via WebHID. Those devices are configured through a small desktop helper called "Cosmic Byte Connect" — the Orbit web UI stays the same; the helper acts as a thin bridge between the browser and the device. Only these specific devices need the helper; all other supported devices work in the browser alone.

TROUBLESHOOTING:
- "It won't connect / no prompt appears": check the browser — must be Chrome / Edge / Brave / Opera on DESKTOP. Firefox, Safari and any mobile browser will not work.
- "Detect device does nothing": make sure the device is plugged in via USB cable or its 2.4 GHz dongle. Bluetooth-connected devices cannot be configured in Orbit — switch to USB or 2.4G.
- Permission prompt got dismissed: click "Detect device" again. If the browser remembered "no" for the site, try a new tab or an incognito window.
- Wired Velox specifically: needs the Cosmic Byte Connect desktop helper.
- "My device isn't in the list": not every Cosmic Byte product is supported yet — the list grows over time. Check the live device grid at https://orbit.thecosmicbyte.com for the current line-up.

ANTI-FABRICATION GUARDS:
✗ Do NOT tell a customer Orbit works on Firefox, Safari, iPhone, iPad, or Android — it does NOT. Orbit needs Chrome / Edge / Brave / Opera on a desktop computer.
✗ Do NOT tell a customer to download desktop software for Orbit — Orbit is browser-based. The only download in scope is the "Cosmic Byte Connect" helper, and ONLY for the specific devices that need it (currently the wired Velox).
✗ HEADSETS ARE NOT ORBIT DEVICES: the THX headsets (CryoCore, Proteus X, Olympus, Immortal) use the separate THX Spatial Audio+ Windows app, NOT Orbit. Do not send headset customers here.
✗ Do NOT confirm or deny that a SPECIFIC product is supported in Orbit unless it is on the snapshot list above. The supported set expands regularly — direct customers to https://orbit.thecosmicbyte.com for the authoritative current list.
✗ Do NOT say Bluetooth devices can be configured in Orbit — they cannot. The customer must switch to USB or the 2.4 GHz dongle.
✗ Do NOT invent per-device features. Features (DPI, RGB, macros, etc.) vary per device — only confirm what each device's own configurator actually exposes.
✓ Correct framing: "Orbit is our browser-based configurator at https://orbit.thecosmicbyte.com — open it in Chrome / Edge / Brave / Opera on a desktop computer, connect your device by USB cable or its 2.4 GHz dongle (Bluetooth won't work for configuration), click Detect device, and approve the browser prompt. No download needed for most devices."

SUPPORT: For Orbit issues, customers can email cc@thecosmicbyte.com.

Pandora

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-pandora-tkl-mechanical-keyboard/

COSMIC BYTE PANDORA TKL — MECHANICAL GAMING KEYBOARD

WIRED ONLY. 87-key TKL layout (no numpad). Outemu hot-swappable switches. Rainbow LED backlight. Metal body for durability.

VARIANTS: CB-GK-25 (Outemu Blue switches — tactile, clicky) | CB-GK-26 (Outemu Red switches — linear, quiet)
SPECS: 87 keys US layout. Outemu swappable switches (50M keystrokes). Keystroke 2.0±0.6mm. 1.5m PVC cable. 377x120x34mm, 565g. Full key anti-ghosting (can switch to 6-key mode). Compatible: Windows, macOS basic use.

WHAT'S IN THE BOX: Keyboard, keycap puller, switch puller, user manual.

SWITCH SWAPPING — HOW TO REPLACE:
Step 1: Use keycap puller to remove keycap (hook under cap, pull straight up).
Step 2: Use switch puller to grip switch from both sides, squeeze clips, pull straight up.
Step 3: Insert new switch — align pins carefully, press straight down until it clicks.
Compatible: Outemu Blue, Red, Brown or any Outemu swappable 3-pin switch. Buy from thecosmicbyte.com.

ANTI-GHOSTING TOGGLE:
- FN + Scroll Lock: Toggle between 6-key anti-ghosting and full-key anti-ghosting (NKRO)
- Full-key (NKRO) works best for gaming. Use 6-key mode if some applications don't recognise NKRO.

FN KEY SHORTCUTS:
Multimedia: FN + F1 (My Computer) | F2 (Search) | F3 (Calculator) | F4 (Media Player)
FN + F5 (Previous) | F6 (Next) | F7 (Play/Pause) | F8 (Stop)
FN + F9 (Mute) | F10 (Vol-) | F11 (Vol+) | F12 (Lock all keys)
Backlight: FN + Left/Right arrows: Adjust animation speed (5 levels)
FN + Up/Down arrows: Adjust brightness (6 levels)
Windows: FN + L-WIN: Lock/Unlock Windows key (indicator lights when locked)

GAME LIGHTING PRESETS (FN + number):
- FN + 1: FPS mode (WASD + arrows + Esc highlighted)
- FN + 2: CF mode | FN + 3: COD mode | FN + 4: RTS mode
- FN + 5: LOL mode | FN + 6: Car Racing mode | FN + 7: NBA mode | FN + 8: LOL mode 2

BACKLIGHT — RAINBOW RGB (FIXED-COLOUR per LED, NOT per-key programmable RGB):
- The Pandora has RAINBOW LED BACKLIGHT — each LED on each key is a FIXED COLOUR determined by its physical position on the keyboard, arranged as a rainbow gradient across the layout. Users CANNOT reassign which colour an individual key shows. The hardware does not support per-key colour programming. Same lighting design as the Vanth (the Pandora is the TKL variant of the same product family).
- This is NOT "per-key RGB" (the term gaming-keyboard buyers usually mean — independently programmable colour per key with a software UI). The Pandora has hardware-fixed-colour LEDs animated by 20 preset effects.
- The 20 preset effects animate the fixed-colour LEDs through different on/off / wave / breathing / cycle patterns. The COLOURS themselves are fixed; the EFFECT controls when each fixed-colour LED lights up.
- Brightness and animation speed are adjustable globally (FN + Up/Down for brightness, FN + Left/Right for speed) — but neither setting changes which colour each key shows.

BACKLIGHT EFFECTS — 20 total lighting effects accessed via:
- FN + Home (4 effects) | FN + Insert (4 effects) | FN + PgUp (4 effects) | FN + Delete (4 effects) | FN + PgDn (4 effects)
- FN + ESC (hold 3 seconds): Factory reset — restores all defaults

CUSTOM BACKLIGHT RECORDING — clarification on what this feature actually does:
- The "custom recording" feature lets the user record which KEYS participate in a custom animation sequence — NOT which COLOUR each key shows. Each key keeps its physically-fixed rainbow colour throughout; the recording captures key-press timing for an animation, not colour assignment.
- Procedure:
  1. Press FN + 9 or FN + 0 to select custom slot.
  2. Press FN + End to enter recording mode (indicators flash).
  3. Press keys to include them in the recorded sequence — each pressed key will light up at its FIXED rainbow colour when the sequence plays back. Pressing a key does NOT change that key's colour.
  4. Press FN + End to save.
  5. Press FN + ESC to clear custom and restore to normal lighting.
- The earlier KB phrasing "each press cycles colour" was MISLEADING — it implied the user could pick a colour per key, which is NOT what this feature does. Each key's colour is fixed by hardware.

✗ DO NOT SAY about Pandora lighting:
- "Each key supports multi-colour light" / "Every key supports multiple colours" -- WRONG. Each LED is a single fixed colour determined by its position in the rainbow gradient. Same architecture as Vanth — both share this rainbow-fixed-LED design per Cosmic Byte's confirmation.
- "Per-key RGB" / "Programmable per-key colour" / "Custom colour per key" -- WRONG. The Pandora does NOT have per-key RGB in the gaming-keyboard sense. The colours are hardware-fixed.
- "Each press cycles colour" / "Press keys to set desired colours" -- WRONG (these were in pre-v1.10.20 KB phrasing). The custom recording controls which keys participate in an animation; it does NOT change colours.
- "I'd recommend contacting support to confirm the multi-colour capability" -- WRONG. The bot does NOT need to route this question to human support; the answer is a clear "no, Rainbow RGB with fixed per-LED colour, not per-key programmable RGB".

✓ CORRECT FRAMING when a customer asks "does every key support multi-colour light / per-key RGB":
"No — the Pandora has Rainbow RGB, where each LED has a fixed colour determined by its position on the keyboard (rainbow gradient across the layout). You can't reassign which colour a specific key shows — that's a hardware design choice on this model. What you CAN customise: 20 preset effects, brightness (6 levels), animation speed (5 levels), and the custom recording feature (which controls which keys participate in an animation, not their colours). If you want true per-key programmable RGB (the gaming-keyboard kind where each key can be set to any colour via software), the Pandora doesn't support that — you'd need a keyboard model with companion software for that capability."

NO COMPANION SOFTWARE: the Pandora is a hardware-only keyboard with NO Windows software, NO macOS software, and NO companion app of any kind. All backlight customisation (effects, brightness, animation speed, custom recording) is via the FN+key combinations documented above. Do NOT direct customers to https://www.thecosmicbyte.com/downloaddrivers/ for the Pandora -- there is nothing there for this model. If a customer asks about "advanced control" or "per-key RGB software" for the Pandora, the honest answer is that everything possible on this keyboard is already accessible via the FN+key combos; for fancier per-key RGB or macros, they'd need a different CB keyboard model that has software support.

TROUBLESHOOTING:
- Keyboard not detected: Try a different USB port. Try a different cable. Test on another PC.
- Key not working: Remove and re-insert the switch using the switch puller. If still faulty, swap with a new Outemu switch.
- Backlight not working: Try FN + Up to increase brightness. Try cycling effects with FN + Home/Insert etc. If no response, do factory reset: hold FN + ESC for 3 seconds.
- Some keys not registering simultaneously (ghosting): Switch to full-key NKRO mode: FN + Scroll Lock.
- All keys registering wrongly: Check if WASD/arrow swap is active — press FN + W to toggle. Check Windows lock — press FN + L-WIN.
- Keyboard stops working mid-use: Disconnect, wait 10 seconds, reconnect. Try different USB port.
- Mac use: Works plug-and-play for basic typing. All backlight features are accessible via the FN+key combos documented above on any platform (Windows, macOS, Linux) -- no software is needed for any platform.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

Phantom TKL

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-phantom-tkl-tri-mode-gasket-hot-swappable-mechanical-switch-keyboard/

COSMIC BYTE PHANTOM TKL — WIRELESS TRIPLE MODE MECHANICAL KEYBOARD

SPECS: 82 keys, US layout, Gasket mount. Hot-swappable 3/5-pin Outemu switches (50M keystrokes). PBT keycaps. RGB 18 lighting modes with power-off memory. 1000Hz polling. 1.8m braided USB-C cable with magnetic ring. 2500mAh battery. 333x143x43mm, 820g. Compatible: Windows, macOS, Linux, Android, iOS.

WHAT'S IN THE BOX: Keyboard, USB-C cable, USB 2.4G receiver, keycap puller, switch puller, 2 extra switches, user manual.

CONNECTIVITY — MODE SWITCH (physical switch on keyboard side):
- Wired (middle/USB): Connect USB-C cable. Charges battery while working. Red LED = Charging, LED off = Fully charged.
- 2.4GHz wireless (2.4G): Plug USB receiver into PC. Pre-paired at factory — works instantly.
  Re-pair if disconnected: Hold FN + 4 for 3 seconds until white LED blinks fast, then plug receiver into PC. Wait for LED to stop blinking.
- Bluetooth (BT): Supports 3 devices simultaneously on BT1/BT2/BT3.
  First-time pairing: Set switch to BT, hold FN + 1 (or 2 or 3) for 3 seconds until blue LED blinks rapidly. Go to your device Bluetooth settings and select "Phantom TKL". LED stops blinking when paired.
  Reconnect: Briefly press FN + 1/2/3.
  Switch between paired devices: Briefly press FN + 1, 2, or 3.

SYSTEM SWITCH (physical switch on keyboard):
- Left = Windows (default). Right = macOS (Win and Alt keys auto-swapped for Mac layout).

KNOB: Clockwise = Volume Up. Counter-clockwise = Volume Down. Press knob = Mute.

FN KEY SHORTCUTS:
- FN + F1/F2: Brightness control
- FN + F3: Show Desktop (Win) / Mission Control (Mac)
- FN + F4: Multi-screen (Win) / App Switcher (Mac)
- FN + F5: Emoji panel
- FN + F6: Screenshot
- FN + F7 / F8 / F9: Cut / Copy / Paste
- FN + F10 / F11 / F12: Previous / Play-Pause / Next track
- FN + L-WIN: Lock/Unlock Windows key
- FN + W: Swap WASD keys with arrow keys (toggle)

BACKLIGHT CONTROLS:
- FN + Backspace: Toggle backlight On/Off
- FN + Home: Cycle through 18 lighting effects
- FN + PgUp / PgDn: Change colour
- FN + Up / Down arrows: Increase/decrease brightness (5 levels, 0-100%)
- FN + Right / Left arrows: Increase/decrease animation speed (5 levels)
- FN + 0: FPS mode (only WASD and arrow keys lit)
- FN + backtick (~): Custom lighting record mode — indicators flash, press keys to cycle colours (Red > Blue > Yellow > Purple > Cyan > White > Off), press FN + ~ again to save
- FN + ESC (hold 3 seconds): FULL FACTORY RESET — restores all default settings including lighting

POWER AND BATTERY:
- Sleep mode: Activates after 2 minutes of inactivity (saves battery)
- Deep sleep: After 30 minutes of inactivity
- Wake up: Press any key (takes 2-4 seconds to wake from deep sleep)
- To maximise battery: Reduce backlight brightness or turn backlight off (FN + Backspace)
- Charging: Use the included USB-C cable. Red = charging. Light turns off when fully charged.
- Software works in wired mode AND wireless mode (2.4G and Bluetooth)

SOFTWARE: Download from https://www.thecosmicbyte.com/downloaddrivers/
- v1.0.0.4 (March 2026): Fixed icon and software resolution display.
- v1.0.0.3 (Nov 2025): Fixed Debounce Time Adjustment issue.
Always use the latest version from the official website. (software page). Windows only. Lets you remap keys, customise per-key RGB, set macros. Keyboard must be connected via USB-C for software to detect it.

COMPANION SOFTWARE — FULL FEATURE DOCUMENTATION
(added v1.10.28 based on operator-supplied software screenshots, 2026-05-22. Documents every tab and setting so the bot can answer Phantom TKL software-feature questions without fabricating. Windows PC software; connect the keyboard — USB-C recommended — for the software to detect it.)
Software title bar: "Cosmic Byte Phantom TKL Wireless Software".
In-app Device Info (Settings > Device Info), as shown 2026-05-22:
- Device model: Phantom TKL Wireless
- Firmware version: V3.0.0 (USB)
- Software version: V2.0.0
NOTE: the in-app "Software version" field (V2.0.0) is numbered separately from the official download-page version history (which lists builds like v1.0.0.4). Do NOT claim they are the same number or try to reconcile them — just tell customers to install the LATEST build from https://www.thecosmicbyte.com/downloaddrivers/.

The software has FIVE sections, opened from the left-hand sidebar icons:

1) SETTINGS / GLOBAL (gear icon) — sub-pages:
  - Device Info: shows device model, firmware version, software version.
  - Language: dropdown (English available).
  - Startup: "Autorun" toggle (launch the software automatically when the PC starts).
  - Exit, Tap, Sleep, Debounce, Reset: further global / keyboard-behaviour settings (Reset = restore the keyboard to defaults via software).

2) KEY ASSIGNMENT (keyboard icon) — full key remapping:
  - Profiles: create multiple (Profile1 by default; add / copy / delete / import / export profiles).
  - Four layers per profile: Default, FN1, FN2, Tap.
  - Each key can be reassigned to: a Keyboard key, a Mouse function, a Multimedia control, a Macro, a Command, or a Key combination.
  - Assignable groups include standard keys (A-Z, 0-9, symbols), advanced keys (F1-F12, Esc, Tab, navigation/editing keys), the numeric keypad, and modifiers (Left/Right Ctrl, Shift, Alt, Win), plus FN / FN2.

3) LIGHT EFFECT (sun/brightness icon) — RGB lighting effects:
  - 18 options: Static, Breathing, Spectrum, Strobe, Raindrops, Color Wheel, Ripple, Starlight, Fade, Snake Trail, Neon Stream, Reactive, Wave, Pinwheel, Cascade, Bloom, Custom, Off.
  - Adjustable: Brightness, Speed, single Color (colour wheel + R/G/B sliders + hex entry), a "Colourful" (multi-colour) toggle, preset colour swatches, and saved Custom colours.

4) MUSIC / SOUND-REACTIVE LIGHTING (music-note icon): "the keyboard light changes with the rhythm of the system sound." Has an ON/OFF toggle.
  - 10 music modes: Pulse – Chill, Strobe Burst – Rock, Drift – Ambient, Spectrum Shift – Vocal, Stream – Standard, Bloom – Intense, Beat Drop – Rock, Glide – Intense, Surge – Epic, Rainfall – Standard.
  - Adjustable: Brightness, Color, "ColorFull", "Auto Gain", colour picker.

5) MACRO EDIT PANEL (</> icon) — create and manage macros:
  - "Record" button captures a key sequence; add / edit (pencil) / copy / delete / import / export macros; "double click to modify the item".

CONNECTION: if the keyboard isn't connected the software shows "Please connect your device." Connect via USB-C (the in-app firmware is reported as "(USB)").

✗ Do NOT invent lighting effects beyond the 18 listed above, or music modes beyond the 10 listed. If a customer asks whether a specific effect exists, only confirm ones on these lists; otherwise say it is not listed in the software.
✗ Do NOT state firmware/software version numbers other than what Device Info shows (Firmware V3.0.0 (USB) / Software V2.0.0 as of 2026-05-22) — and note versions change, so point to the official download page for the latest.
✗ Do NOT confuse this Phantom TKL WIRELESS (tri-mode) software with the Phantom TKL WIRED keyboard — they are different SKUs.
✓ This software is Windows-only and needs the keyboard connected (USB-C recommended) to detect it.

TROUBLESHOOTING:
- Keyboard not detected in wired mode: Try a different USB port (preferably USB 3.0). Try a different USB-C cable. Make sure mode switch is on USB/middle position.
- 2.4G not working: Check mode switch is on 2.4G. Receiver must be plugged in. Re-pair: hold FN + 4 for 3 seconds, plug receiver in.
- Bluetooth not connecting: Mode switch to BT. Hold FN + 1/2/3 for 3 seconds until blue light blinks. Enable Bluetooth on your device. Select Phantom TKL from Bluetooth list. If previously paired device won't connect, press FN + 1/2/3 briefly.
- Keyboard wakes up slowly from sleep: Normal — press any key and wait 2-4 seconds. Press again if needed.
- Backlight not working: FN + Backspace to toggle. FN + Up to increase brightness. If still not working, do factory reset: FN + ESC for 3 seconds.
- WASD and arrow keys swapped: Press FN + W to toggle back.
- Windows key not working: Press FN + L-WIN to unlock.
- Key not registering: Remove the switch using the included switch puller and re-insert firmly. If still faulty, replace with a new Outemu 3-pin or 5-pin switch. Compatible switches: Outemu Blue, Red, Brown (swappable variants).
- Software not detecting keyboard: Switch to wired mode (USB-C connected). Run software as administrator. Reinstall if needed.
- Lighting not saving after power off: Lighting is saved in memory automatically. If it resets, do a factory reset (FN + ESC 3s) and set the lighting mode again.
- Mac not working properly: Flip the system switch to Right (Mac mode). This swaps Win/Alt for Command/Option layout.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage, tampered products NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

Phantom TKL Wired

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-phantom-tkl-gasket-mechanical-wired-swappable-keyboard-with-prelubed-switches/

COSMIC BYTE PHANTOM TKL WIRED — GASKET MECHANICAL KEYBOARD (CB-GK-42)

WIRED ONLY — no wireless, no Bluetooth, no battery. Plug USB-C and use. Gasket mount for quieter, cushioned typing feel. Per-key RGB with Windows software support.

SPECS: 82 keys, US layout, Gasket mount. Pre-lubed Outemu hot-swappable switches (50M keystrokes). Double-shot ABS keycaps. 1000Hz polling. Volume roller knob. Detachable USB-C port. 1.8m braided USB-C cable with magnetic ring. 333x143x43mm, 793g. Compatible: Windows 98/XP/Vista/7/8/10/11, macOS.

WHAT'S IN THE BOX: Keyboard, USB-C cable, keycap puller, switch puller, 2 extra switches, user manual.

VOLUME ROLLER: Turn clockwise = Volume Up. Turn counter-clockwise = Volume Down. Press = Mute/Unmute.

SWITCH SWAPPING — HOW TO REPLACE A SWITCH:
Switches are hot-swappable (not soldered). You can replace any switch without tools beyond the included puller.
Step 1: Remove keycap using the keycap puller (hook under keycap, pull straight up).
Step 2: Use the switch puller to grip the switch from the sides, squeeze the clips, pull straight up.
Step 3: Insert the new switch straight down — ensure pins align and it clicks into place.
Step 4: Replace the keycap.
Compatible switches: Outemu Blue, Red, Brown, or any Outemu swappable 3-pin/5-pin switch. Buy from thecosmicbyte.com.

FN KEY SHORTCUTS:
- FN + F1: Open Music player
- FN + F2: Volume Down | FN + F3: Volume Up | FN + F4: Mute
- FN + F5: Stop | FN + F6: Previous track | FN + F7: Play/Pause | FN + F8: Next track
- FN + F9: Open Email | FN + F10: Open Browser Home | FN + F11: My Computer | FN + F12: Calculator
- FN + DEL: Scroll Lock | FN + Home: Insert | FN + PgUp: Print Screen | FN + PgDn: Pause
- FN + L-WIN: Lock/Unlock Windows key (W LED indicator lights up when locked)
- FN + W: Swap WASD with arrow keys (toggle)

BACKLIGHT CONTROLS:
- FN + | (backslash-pipe key): Cycle through 18 RGB lighting effects
- FN + Enter: Change backlight colour
- FN + X: Toggle backlight On/Off
- FN + Up arrow: Increase brightness (5 levels: 0/25/50/75/100%) — indicators blink 3x at max
- FN + Down arrow: Decrease brightness — indicators blink 3x at minimum
- FN + Right arrow: Increase animation speed (5 levels) — blinks 3x at max
- FN + Left arrow: Decrease animation speed — blinks 3x at minimum
- FN + ESC (hold 3 seconds): Full factory reset — restores all default settings and lighting

GAME LIGHTING MODES:
- FN + 1: FPS mode (WASD + arrow keys illuminated only)
- FN + 2: LOL mode (Q/W/E/R/D/G/F/B/V/Ctrl/Alt/Tab and others lit)
- FN + 3: Office mode (alphabet + punctuation keys lit)
- FN + backtick (~): Custom backlight recording mode
  Enter mode: FN + ~ (3 LED indicators in top-right flash)
  Set key colours: Press a key repeatedly to cycle — 1st press = Red, 2nd = Orange, 3rd = Yellow, 4th = Green, 5th = Cyan, 6th = Blue, 7th = Purple, 8th = White, 9th = Off
  Save: Press FN + ~ again to save and exit

SOFTWARE: Download from https://www.thecosmicbyte.com/downloaddrivers/
- v1.0.0.4 (March 2026): Fixed icon and software resolution display.
- v1.0.0.3 (Nov 2025): Fixed Debounce Time Adjustment issue.
Always use the latest version from the official website. (Windows only). Enables per-key RGB customisation, macros, and key remapping. Visit the Phantom TKL product page on the website > Software & User Manual tab > download.

TROUBLESHOOTING:
- Keyboard not detected: Try a different USB port (USB 2.0 or 3.0 both work). Try a different USB-C cable. Try on a different PC to isolate the issue.
- Key not working/registering: Use switch puller to remove the switch, re-insert firmly (should click). If still faulty, replace with a compatible Outemu swappable switch.
- Backlight not working: Press FN + X to toggle on. Use FN + Up to increase brightness. If no response, do factory reset: hold FN + ESC for 3 seconds.
- All keys producing wrong characters: Check if WASD/arrow swap is active — press FN + W to toggle. Check if Windows key is locked — press FN + L-WIN.
- Software not detecting keyboard: Run as administrator. Ensure keyboard is plugged in via USB-C. Reinstall software. Try a different USB port.
- Volume roller not responding: Check if multimedia keys are working (FN + F4 for mute test). If roller is physically damaged, contact support for warranty.
- Lighting resets after unplugging: Lighting mode is stored in keyboard memory. Set your preferred mode, it should persist. If it keeps resetting, do factory reset (FN + ESC 3s) then set again.
- Mac compatibility: Works plug-and-play on Mac for basic typing. RGB software is Windows only. Some FN shortcuts may differ on Mac.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

Proteus

Product page: https://www.thecosmicbyte.com/product/proteus/

PRODUCT: Cosmic Byte Proteus — Gaming Headset (Dual Input USB + 3.5mm) — ⚠️ DISCONTINUED (OLD MODEL)

⚠️ THIS IS THE OLD PROTEUS — DISCONTINUED. It is NO LONGER SOLD; the replacement is the Proteus X (THX Spatial Audio model, own KB entry). This entry exists ONLY to support customers who still own the old unit.
- THX Spatial Audio is NOT supported on the old Proteus — it is the pre-THX model and uses its own USB 7.1 mode. Do NOT send an old-Proteus owner to install the THX Spatial Audio + app.
- If a customer asks to BUY a Proteus, sell the Proteus X, not this model.
- If unsure which one a customer has: the Proteus X is marketed as 7.1.4 with THX branding and uses the THX Spatial Audio + app; the old Proteus is 7.1 with no THX. Ask when/where they bought it and whether the listing mentions THX.

SPECS:
- Connection: Dual input — USB (7.1 surround) AND 3.5mm jack
- Driver: 50mm | Sensitivity: 111 ±3dB | Impedance: 32Ω±15% | Freq: 20Hz–20,000Hz
- Cable: Headset cable 0.7m + 3.5mm audio jack 1.5m + USB cable 1.5m (braided)
- Power: 20mW rated, 30mW input
- Weight: 280g (without cable), 336g (with cable) | Dims: 190×90×220mm
- Mic: ENC detachable, uni-directional, ø6.0×2.7mm, sensitivity -50±3dB
- RGB LED lights, on-cable controller

WHAT'S IN THE BOX: Proteus headset, detachable ENC microphone, USB-C to USB-A connector, 3.5mm audio cable, user manual

ON-CABLE CONTROLLER:
- Volume wheel: scroll up = volume +, scroll down = volume −
- Mic mute button: tap once = microphone on/off
- LED button: tap once = RGB lights on/off
- Volume mute button: tap once = volume mute/unmute

COMPATIBILITY:
- PC/Mac/Laptop: USB (7.1 surround + software) OR 3.5mm jack
- PS4/PS5: USB OR 3.5mm via controller jack. Volume from PlayStation Audio Settings.
- Xbox One S/X: 3.5mm jack on controller ONLY. USB does NOT work on Xbox.
- Mobile/Tablet: 3.5mm jack only
- Nintendo Switch: 3.5mm jack only
- LED tip for mobile: plug USB into a power bank/charger while using 3.5mm for audio — this powers the RGB lights

7.1 SURROUND: Download software from https://www.thecosmicbyte.com/downloaddrivers/ (USB mode only)

TROUBLESHOOTING:
Q: Xbox not working?
A: Xbox only supports 3.5mm on the controller. USB connection will not work on Xbox.

Q: Mic not working?
A: Ensure mic is firmly attached → check mic mute button (not muted) → select Proteus as input device in your system sound settings

Q: No RGB lights when using with mobile?
A: Plug the USB cable into a USB power source (power bank, charger) while using 3.5mm for audio

WARRANTY: 1 year against manufacturing defects. Physical/water damage and tampered products not covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon–Sat 10am–6pm

Proteus X

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-proteus-x-7-1-4-surround-wired-headset-with-thx-spatial-audio/

PRODUCT: Cosmic Byte Proteus X — 7.1.4 SURROUND WIRED HEADSET WITH THX SPATIAL AUDIO (Dual Input USB + 3.5mm)

DISAMBIGUATION: "Proteus X" (THIS entry) is the CURRENT THX Spatial Audio model and the one that is sold. The plain "Proteus" is the OLDER non-THX model — now DISCONTINUED — kept in the KB only to support existing owners. If a customer says "Proteus X" or mentions THX / Spatial Audio, use THIS entry. Do NOT tell a Proteus X owner their headset lacks THX.

KEY FEATURES: 7.1.4 surround (THX Spatial Audio), 50mm Hi-Fi drivers, DUAL INPUT (USB & 3.5mm), detachable flexible ENC microphone, RGB LED lights, on-cable controller, auto-adjustable headband, protein-leather ear cushions, braided cable. Colours: black and white.

SPECS:
- Driver: 50mm | Sensitivity: 111 ±3dB | Impedance: 32Ω ±15% | Freq: 20Hz–20,000Hz
- SPEAKERS TUNED FOR THX: the Proteus X speakers have been acoustically tuned for THX Spatial Audio, so THX's stereo and spatial processing is matched to these drivers (this tuning is a difference from the old non-THX Proteus).
- Power: 20mW rated | 30mW input
- Headset jack: 3.5mm & USB 7.1 (DUAL INPUT). Overall cable 2.1m ±10%: headset cable 0.7m + 3.5mm audio cable 1.5m + USB cable 1.5m
- Mic: 6.0×5.0mm ENC, sensitivity -42dB, omnidirectional, detachable
- Weight: 280g (without cable), 336g (with cable) | Product dims: 190×90×220mm | Packaging: 200×100×230mm

WHAT'S IN THE BOX: Proteus X headset, detachable microphone, USB-C to USB-A connector, 3.5mm audio cable, user manual.

ON-CABLE CONTROLLER:
- Volume wheel — scroll up = volume +, scroll down = volume −
- Mic mute button — tap once = microphone on/off
- LED on/off button — tap once = RGB lights on/off
- Volume mute button — tap once = volume mute/unmute

PLATFORM COMPATIBILITY (which cable to use):
- 3.5mm cable → Xbox One S/X, PS4/PS5 (controller jack), Nintendo Switch, mobile devices, PC/Mac/laptop (plain stereo — NO THX processing over 3.5mm)
- USB (Type-C to USB-A) → PS4/PS5 and PC/Mac/laptop as a standard USB audio device. THX Spatial Audio / 7.1.4 is available ONLY on WINDOWS via USB with the THX app installed — on a Mac the headset works over USB but WITHOUT the THX app.
- Xbox: 3.5mm only (no USB surround on Xbox).

WHAT THX SPATIAL AUDIO+ IS AND WHY IT MATTERS (use this to explain the benefit to customers):
- THX Spatial Audio+ is the immersive-audio platform from THX Ltd. (the company behind THX certification). It turns a stereo headset into a full 360° virtual surround experience using a physics-based room simulation, placing sounds around you — front, sides, behind AND above — with no physical speaker setup.
- WHAT "7.1.4" MEANS: the ".4" is FOUR HEIGHT channels. Ordinary 7.1 only places sound on a flat horizontal plane; 7.1.4 adds sounds coming from above, which completes the 360° soundscape. This is a genuine step up from the old 7.1 headsets.
- THE GAMING EDGE: enhanced positional accuracy — you can pinpoint where footsteps, gunfire, reloads and other cues are coming from, including above/below you. That directional awareness is the main competitive benefit. THX's engine is built specifically to make the most of positional sound cues in games.
- MOVIES & MUSIC: THX Spatial Audio mode gives a wider, more cinematic soundstage for films; THX Stereo mode gives clean, natural 2-channel playback that is ideal for music.
- AI HEAD TRACKING: uses your webcam to follow your head so the virtual sound field stays anchored to the world when you turn (instead of turning with you). Sounds keep coming from where they should — far more realistic, and it helps you keep your bearings in games. Requires THX Spatial Audio mode and a connected webcam.
- DEVICE-SPECIFIC TUNING: THX measures each headset's acoustic performance and designs custom filters/EQ so BOTH stereo and spatial playback are accurate for THAT exact headset. This is why the Cosmic Byte THX headsets have speakers tuned specifically for THX — the processing is matched to the hardware rather than generic.
- PERSONAL AUDIO PROFILES: content modes (Game / Music / Movie presets) plus the Standard and Parametric EQ let the customer tailor the sound to what they are doing.
- HONEST LIMITS (do not over-promise): THX Spatial Audio+ works ONLY on WINDOWS, and ONLY over the USB input. It does NOT run on macOS, Linux, consoles or phones, and it does NOT process audio over a 3.5mm connection. (A USB-connected headset still works as a normal USB audio device on PS4/PS5 or a Mac — just without the THX app / surround processing.) The full height/positional effect is strongest with content that carries positional audio — most modern games and surround movie mixes do; plain stereo sources gain a wider soundstage but not true discrete height cues.
- NOT ORBIT: the THX headsets (CryoCore, Proteus X, Olympus, Immortal) are NOT configured through Cosmic Byte Orbit (orbit.thecosmicbyte.com). Orbit is for keyboards/mice/controllers. For these headsets the software is the THX Spatial Audio+ Windows app, downloaded from www.thecosmicbyte.com. Do NOT send a THX-headset customer to Orbit.

THX SPATIAL AUDIO + SOFTWARE (WINDOWS-only desktop app — download it from www.thecosmicbyte.com; requires the headset connected by USB):
- When the headset is plugged in and detected, its name appears at the BOTTOM-LEFT of the app with a "Headphones" label. If it's not there: check the USB connection and wait for the app to finish loading.
- AUDIO MODE SWITCH (top-right of every screen) — the single most important control: "THX Stereo" = traditional 2-channel L/R (cleanest for music/general listening). "THX Spatial Audio" = virtual 360° surround field (hear direction of footsteps/gunfire in games; wider soundstage for movies).
- STANDARD SETTINGS (everyday controls): 10-band Equalizer (32 Hz to 16 kHz), each band adjustable +12 dB to -12 dB, toggle on/off; presets Default (flat) / Music (lifted bass + upper treble) / Game (in-game detail + positional cues) / Movie (dialogue + cinematic) / Custom (moving any slider auto-switches to Custom); Reset returns to flat. Sound Normalization (evens out quiet vs loud, slider sets strength — good for late-night). Bass Boost (one-tap extra low end). Voice Clarity (one-tap vocal-range emphasis for chat/streams/quiet dialogue).
- EXPERT > PARAMETRIC EQ: finer control than the Standard EQ. Same 5 presets + Reset. Response graph 20 Hz–20 kHz, +12/-12 dB, 10 draggable points (one per band). Per-band controls: Frequency (centre point), Gain (boost/cut in dB), Q (width — lower Q = broad, higher Q = narrow/surgical),

Filter (Peak is the standard choice). Each band has a Band 1–10 checkbox to switch it off WITHOUT erasing its settings (for A/B comparison).
- EXPERT > CAMERA HEAD TRACKING: uses a webcam to keep virtual sound sources anchored to the world when you turn your head (more convincing spatial effect). REQUIRES THX Spatial Audio mode — in THX Stereo mode the app shows a notice that head-tracking effects can only be heard once Spatial Audio is enabled; flip the top-right mode toggle first. Controls: Device (choose your webcam/USB video device), Camera Mode (Auto recommended), Enable toggle (top-right). A preview shows your tracked head position vs the virtual speakers.
- USER SETTINGS: language + app information.
- SOFTWARE TROUBLESHOOTING: headset not shown in the app → check USB, let the app finish loading. Head-tracking "can only be heard when Spatial Audio is enabled" → switch the mode toggle to THX Spatial Audio. No surround effect → make sure the mode switch is on THX Spatial Audio, not THX Stereo.

SETUP — WINDOWS PC: connect via USB (USB-C to USB-A) → install THX Spatial Audio + from www.thecosmicbyte.com (Windows only) → confirm "Proteus X" appears bottom-left in the app → set mode to THX Spatial Audio for surround → select the Proteus X as default output/input in Windows Sound Settings. (3.5mm gives plain stereo with no THX app processing.)
SETUP — CONSOLES: PS4/PS5 via USB or 3.5mm; Xbox and Switch via 3.5mm; mobile via 3.5mm.

TROUBLESHOOTING:
Q: No surround? A: You must be on USB and the THX app mode must be THX Spatial Audio (not Stereo). 3.5mm cannot do 7.1.4.
Q: Not detected in the THX app? A: Use the USB cable (not 3.5mm) → check the connection → wait for the app to load.
Q: RGB off? A: Tap the LED button on the cable controller. Q: Mic muted? A: Tap the mic mute button; ensure the mic is firmly plugged in.
Q: Works on PC but not Xbox? A: Xbox supports 3.5mm only.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage and tampered products NOT covered.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 (WhatsApp same) | Mon–Sat 10am–6pm

PRICING: do NOT quote a price for this headset. For the current price and any offers, direct the customer to the product page (BUY link below) — pricing is set on the website and changes.
BUY: https://www.thecosmicbyte.com/product/cosmic-byte-proteus-x-7-1-4-surround-wired-headset-with-thx-spatial-audio/ — use coupon code ONLINEPAY for 10% off on online payments.

Quantum

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-quantum-controller/

COSMIC BYTE QUANTUM - PS4-STYLE DUAL MODE CONTROLLER - FULL MANUAL

⭐ GENUINE CONSOLE SUPPORT: The Quantum is one of the few Cosmic Byte controllers with REAL PS4 console support.
It works as a proper PS4 controller on PS4, Android, iOS, PC, and Nintendo Switch.
Unlike other CB controllers that have a "DualShock mode" only for mobile/PC Bluetooth protocol,
the Quantum genuinely functions as a DualShock 4 compatible controller on actual PlayStation hardware.
Vibration, touchpad, and full button support work natively on PS4.

PLATFORM COMPATIBILITY: PS4 (primary/full support), PS5 (PS4 games only - NOT PS5 native), Nintendo Switch (wired + Bluetooth), PC, iOS 13.0+, Android. NOT suitable as primary PS5 controller.

LED COLOURS: Blue = PS4/PC. Pink = iOS connected. White = Android connected or pairing mode.

CONNECTIVITY:
- PS4 first-time: Connect USB cable, press Home/PS -> LED solid. Disconnect cable -> wireless Bluetooth. Range: 10 metres. Reconnect: Short-press Home/PS.
- PS5: Very limited. PS4 games on PS5 only. Use DualSense to boot PS5, then use Quantum as 2nd controller.
- PC wired (PS4 mode default): Connect USB -> "Wireless Controller" (blue LED). Works with Steam.
- PC wired XInput: Long-press Share + Options for 3 seconds (wired only, NOT available via Bluetooth).
- PC Bluetooth: Press Share + Home when OFF until LED blinks -> find "Dualshock 4 controller" in Bluetooth.
- PC 2.4GHz wireless: requires the Stratos Xenon Wireless Dongle (sold separately) — the same dongle works for both Quantum and Stratos Xenon. Product page: https://www.thecosmicbyte.com/product/cosmic-byte-stratos-xenon-gamepad-dongle-for-pc-gamepad-not-included-black/. ONLINEPAY (10% off) applies.
- Nintendo Switch wired: USB-C to Switch, press Home/PS. Supports headphone jack.
- Nintendo Switch Bluetooth Method 1: Complete wired pairing first, then disconnect cable.
- Nintendo Switch Bluetooth Method 2: Go to Controllers > Change Grip/Order. Hold Options + PS until 4 LEDs flash quickly. Wait for connection. Up to 2 players supported.
- iOS: Hold Share + PS until LED flashes white -> find "DUALSHOCK 4 Wireless Controller" -> LED turns PINK. iOS 13.0+.
- Android: Hold Share + PS until LED flashes white -> find "Wireless controller" -> LED turns WHITE. Power off on Android: hold PS for 10 seconds.
- Sleep: 15 seconds searching without connection = sleep. 10 minutes inactivity = sleep. Press PS to wake.

UNIQUE FEATURES: Functioning touchpad (PS4 games), 6-axis gyro sensor (motion control), built-in speakers, 3.5mm audio jack (works in PS4 mode, PC PS4/Steam wired - NOT in XInput mode or Bluetooth on PC), magnetic drift-free joysticks, magnetic pressure-sensitive triggers.

TRAVEL SWITCH BUTTONS (back, LT and RT independent): Long travel = full analog gradual input (racing/simulation). Short travel = instant FPS response.

LED BRIGHTNESS: 6 levels (0-100%). Hold Options + D-pad Up (increase) or Down (decrease).
RGB EFFECTS: Hold Options + D-pad Left or Right to cycle. Controller always remembers last effect.

TURBO: Turbo + button cycles: Press 1=Manual Turbo, Press 2=Auto Turbo, Press 3=Disabled. Supported: Triangle, Square, Circle, Cross, L1, L2, R1, R2, L3, R3. Speed levels: 5/15/25 shots per second. Adjust speed: Hold Turbo + right stick Up (increase) or Down (decrease). Clear ALL: Press Share + Turbo for 1 second until vibrates.

MACRO (ML/MR back buttons): Record: Hold Turbo for 3 seconds -> LED flashes slowly -> press button sequence (1-12 buttons, timing intervals recorded) -> press ML or MR to save. Execute: Press ML or MR. Macro persists after disconnect. Clear: Enter macro mode (hold Turbo 3s) -> press ML or MR immediately -> LED steady = cleared.

CHARGING: Use USB-A to USB-C cable. Connect to PC USB port or standard USB source ONLY. Do NOT use wall adapters - can damage battery.
Charging off state: LED breathes orange. Fully charged: LED off. Low battery warning: LED flashes 3 times rapidly below 3.5V. Auto power off below 3.4V. Battery: 1000mAh.
POWER OFF: Hold PS/Home 8-10 seconds. Auto sleep: 10 minutes inactivity. Beyond 10 metres = auto power off.
RESET: Press reset button on FRONT of controller (small button/hole). Re-pair after reset. Use for random button presses (also clear turbo and macros first).

SUPPORT PHONE: +91 7351615161 (Mon-Sat 10am-6pm)
WARRANTY: 1 year manufacturing defects only. Physical, water, battery wear NOT covered.

Raptor Mouse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-raptor-dual-mode-wireless-wired-gaming-mouse/

COSMIC BYTE RAPTOR MOUSE - DUAL-MODE GAMING MOUSE - FULL MANUAL

IMPORTANT: DUAL MODE ONLY - 2.4GHz wireless + USB wired. NO Bluetooth.

CONNECTIVITY:
- Wired: connect 1.6m braided USB cable - Windows detects within 5-30 seconds.
- 2.4GHz wireless: plug USB dongle into PC, slide bottom switch to '2.4G'. Power switch must be ON.
- NOT tri-mode. Customers expecting Bluetooth should be informed this model does not have it.

SENSOR: PixArt 3212. DPI: 800-4800. Polling rate: 500Hz (NOT 1000Hz - hardware limit, not upgradable).
Tracking: 30 IPS. Switches: Huano (10M clicks). Weight: 96g without cable.

DPI: Press DPI button near scroll wheel to cycle through levels (800-4800).

RGB: 11 RGB effects on body and logo (controlled by the mouse hardware — no software customisation).

SOFTWARE: NONE. The Raptor Mouse does NOT have any companion software.
Do NOT direct customers to thecosmicbyte.com/downloaddrivers/ for this model
— that page is for other Cosmic Byte mice (Helios, Atlas, Ignis, Firestorm,
Aether, Velox, etc.). If a customer asks about software for the Raptor, the
correct answer is that this model has no companion software; all functions
are configured via the buttons on the mouse itself.

BATTERY: Internal (not user-replaceable). Red LED may indicate charging. Charge via USB cable.

TROUBLESHOOTING:
- Not connecting in 2.4G: check bottom switch is on '2.4G', power switch is ON, dongle in direct USB port (not hub). Try different USB port. Charge for 30 minutes if battery low.
- Not powering on: charge for 30 minutes, check power switch is ON.
- Cursor not moving/lagging: use mousepad (not glass), clean sensor, increase DPI, move dongle away from USB 3.0 and Wi-Fi, try USB 2.0 port for dongle.
- Disconnecting randomly: charge fully, move dongle to front USB port, away from USB 3.0 devices and routers, use direct motherboard USB port (not hub).
- Buttons not working: reconnect, restart PC, test on another computer.

KEY SPECS vs OTHER MICE:
- Only 500Hz polling (others have 1000Hz).
- No Bluetooth (others have tri-mode).
- 96g (heavier than tri-mode models).
- Entry-level wireless gaming mouse.

WARRANTY: 1 year manufacturing defects only. Water, physical damage NOT covered.
Support: +91 7351615161 (Mon-Sat 10am-6pm), cc@thecosmicbyte.com.

Sensa

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-sensa-wireless-gamepad-for-ps5-pc-mac-ios-android-hall-effect-sticks-adaptive-triggers-bluetooth-6-0-rgb-macro-back-buttons/

PRODUCT: Cosmic Byte Sensa — WIRELESS GAMEPAD for PS5 / PC / Mac / iOS / Android (Hall Effect sticks, adaptive triggers, Bluetooth 6.0)

⚠️ PLATFORM RULES — READ FIRST (the Sensa is DIFFERENT from most CB controllers):
- The Sensa IS PlayStation 5 compatible — it is designed for PS5, Windows PC, macOS, Steam, iOS (13+), and Android (5.0+). This is an EXCEPTION to the usual "CB controllers don't work on consoles" rule. Do NOT tell a Sensa customer their controller cannot be used on PS5.
- NOT supported: Xbox (any generation) and Nintendo Switch — the manual does not list them. Do not claim Xbox/Switch support.
- NOT Sony-licensed: per the manual's trademark disclaimer, the Sensa is an independently developed product and is NOT licensed, sponsored, or endorsed by Sony. Never call it an "official" or "licensed" PS5 controller — say "PS5-compatible".
- CONNECTIVITY IS BLUETOOTH 6.0 + USB WIRED ONLY. There is NO 2.4GHz dongle — no receiver in the box, nothing to lose or re-pair. If a customer asks "where is the dongle", the answer is: the Sensa has no dongle; it connects over Bluetooth or the USB-C cable.
- ⚠️ #1 KNOWN ISSUE PATTERN — PS5 SYSTEM UPDATES: if a Sensa that was working on PS5 suddenly stops working or keeps disconnecting, the MOST LIKELY cause is a PlayStation 5 system update. The FIX is a Sensa FIRMWARE UPDATE from the Cosmic Byte website (https://www.thecosmicbyte.com/downloaddrivers/ — Windows PC required; full steps in the FIRMWARE UPDATE section below). ALWAYS raise this first for any "Sensa stopped working on PS5" complaint — it resolves the issue; do not route the customer to support or warranty before they have tried the firmware update.

KEY FEATURES: PS5 + multi-platform compatibility, Bluetooth 6.0 (up to 10m) + USB-C wired, Hall-Effect magnetic analog sticks (drift-resistant), ADAPTIVE TRIGGER force feedback on L2/R2 (DualSense-style — unique in the CB lineup), 6-axis motion sensor (gyro), dual voice-coil vibration motors, capacitive touchpad, built-in speaker AND microphone, 3.5mm TRRS headset jack, RGB lighting with adjustable brightness, 2 programmable rear macro buttons (ML/MR), Turbo, firmware updates via Windows PC.

SPECS (per manual):
- Connectivity: Bluetooth 6.0 / USB wired (Type-C). Wireless range up to 10 meters. NO 2.4GHz dongle mode.
- Polling rate: the manual spec table prints "500Hz/250Hz (wired and wireless)" — i.e. 500Hz wired / 250Hz wireless per the printed order. Do NOT claim 1000Hz for the Sensa in any mode. If a customer needs a guaranteed per-mode figure beyond what the manual prints, route to cc@thecosmicbyte.com.
- Sensors: 6-axis motion sensor. Analog sticks: Hall-Effect magnetic. Triggers: Adaptive force feedback (L2/R2).
- Vibration: dual voice-coil motors. Audio: built-in speaker + microphone; 3.5mm TRRS headset port. Lighting: RGB multi-colour. Charging: USB Type-C.
- ✓ BATTERY: 1600mAh rechargeable lithium-ion — CONFIRMED by Cosmic Byte (2026-10-15). State it when asked. (Earlier versions of this entry said "unspecified" and then "1000mAh"; both are superseded — the correct figure is 1600mAh. Do NOT say 1000mAh.) Runtime hours and charge time are still NOT documented — do NOT invent them; route to support if a customer needs those figures. Other confirmed battery facts: low-battery warning below 3.65V; charging LED breathes orange while powered off, turns off when full.

WHAT'S IN THE BOX: Sensa gamepad, USB Type-C charging cable, user manual, warranty card. (No dongle — none is needed.)

CONNECTING — PLAYSTATION 5:
1. First-time pairing is WIRED: connect the controller to the PS5 with a USB cable.
2. Press the PS button — the controller pairs automatically with the console.
3. Disconnect the cable to play wirelessly.
- If the controller disconnects after a PS5 SYSTEM UPDATE, a firmware update may be required (see FIRMWARE below).

CONNECTING — WINDOWS PC:
- USB: connect with the Type-C cable; Windows installs drivers automatically. Works with Steam.
- X-Input mode toggle: hold SHARE + OPTIONS for 5 seconds.
- Bluetooth: turn the controller OFF → hold SHARE + PS for 3 seconds until the LED flashes → select the controller in PC Bluetooth settings. (NOTE: the printed manual mislabels this Bluetooth section as a second "Switch to X-Input Mode" heading — a printing error. The steps are the Bluetooth pairing steps; present them as such.)

USING THE SENSA ON PC — IT BEHAVES LIKE A PS5 CONTROLLER (IMPORTANT for troubleshooting):
On Windows, the Sensa is supported THE SAME WAY a PS5 (DualSense-style) gamepad is supported on PC — it identifies as a PS5-style controller, NOT as an Xbox controller. What this means in practice:
- Games and launchers with NATIVE PlayStation-controller support (most modern titles, and anything launched through Steam) work directly.
- SOME PC GAMES ONLY UNDERSTAND XBOX (XInput) CONTROLLERS. In those games the Sensa may not be detected, or buttons/prompts may be wrong. This is NORMAL for any PS5-style controller on PC — the controller is not faulty. Convert its input to Xbox-style with EITHER of:
  1. STEAM (recommended, free, no install needed if the customer has Steam): launch the game through Steam and enable Steam Input — Steam → Settings → Controller → enable "PlayStation Controller Support". Non-Steam games can be added to Steam as a non-Steam game to get the same translation.
  2. DS4WINDOWS (free third-party tool, ds4-windows.com): runs in the background and makes the controller appear to Windows as an Xbox 360 controller, so XInput-only games detect it. Install → connect the Sensa (USB or Bluetooth) → DS4Windows maps it automatically.
- The Sensa ALSO has a built-in X-Input mode toggle (hold SHARE + OPTIONS for 5 seconds) — try this FIRST before installing anything; for many XInput-only games it is enough on its own.
- Recommended order when a PC game doesn't detect the Sensa or buttons are wrong: (1) toggle X-Input mode (SHARE + OPTIONS 5s) → (2) launch via Steam with PlayStation Controller Support enabled → (3) use DS4Windows. One of these resolves virtually every PC detection/mapping issue.

CONNECTING — macOS / iOS / ANDROID (Bluetooth):
1. Turn the controller OFF. 2. Hold SHARE + PS for 3 seconds. 3. Open Bluetooth settings on the device. 4. Select the controller from the list.
- Compatible with iOS 13+ and Android 5.0+.

MACRO PROGRAMMING (rear buttons ML / MR):
- Enter programming: hold TouchKey + ML (or MR) for 3 seconds → record the button sequence → press ML/MR again to save. Maximum 24 inputs per

macro.
- Clear a macro: hold TouchKey + ML/MR for 5 seconds.

TURBO FUNCTION:
- Applicable buttons: Triangle, Circle, Cross, Square, L1, R1, L2, R2.
- Press the action button + TURBO to cycle: Turbo ON → Auto Turbo → Turbo OFF.
- Speed levels: 1 = 5 presses/sec, 2 = 10/sec (default), 3 = 15/sec. Increase: hold TURBO + Right Stick UP. Decrease: hold TURBO + Right Stick DOWN.
- Clear ALL turbo: hold TURBO + SHARE for 1 second — the controller vibrates to confirm the reset.

LED / RGB SETTINGS:
- Change light mode: hold OPTIONS and press D-pad LEFT or RIGHT (the gamepad vibrates briefly on each change).
- Mode cycle order: Random Rainbow (left & right sides) → Synced Rainbow → 8 Static Colors → Off. Right = forward through the sequence, Left = backward. Brightness is adjustable.

CALIBRATION:
- 3D STICK & TRIGGER CALIBRATION: power the controller OFF → press and hold OPTIONS + SHARE together → while holding both, connect to a PC via USB cable → LED flashes rapidly = calibration mode. Then: press L2 and R2 triggers 2–3 times → rotate BOTH joysticks fully in all directions (2–3 full rotations each) → press and hold the Cross button for 1 second to confirm. LED turns SOLID = calibration successful.
- AXIS CALIBRATION (while connected to a host — PS5, PC, or other compatible device): hold SHARE + Square for 3 seconds → LED blinks = successful.
- JOYSTICK DEADZONE TOGGLE: hold TouchKey + L3 (or R3) for 2 seconds → RGB briefly cycles red/blue and the controller vibrates. Toggles between Default Deadzone and 0% Deadzone (No Deadzone Mode). The setting is saved in memory and persists after power off.

FIRMWARE UPDATE (WINDOWS PC ONLY):
- When needed: especially if the controller disconnects after a PlayStation 5 system update.
- Steps: turn the controller OFF → press and HOLD the Triangle button → while holding, connect to the PC via USB → controller enters Firmware Update Mode → open the Cosmic Byte Firmware Update Tool (download: https://www.thecosmicbyte.com/downloaddrivers/) → select "BT Wireless" → click Update → wait for completion before disconnecting.
- Do NOT disconnect during the update; use a stable USB connection.

SLEEP, WAKE & POWER:
- Auto-sleep: if the controller cannot find a host within 15 minutes, it sleeps. When connected to a console, it sleeps together with the console. Wake: press the PS button.
- Manual power off: hold the PS button for 5 seconds. Auto power off: if reconnection fails within 15 seconds.

CHARGING & BATTERY:
- Battery: 1600mAh rechargeable (confirmed by Cosmic Byte). Charge via USB Type-C.
- While charging powered-off, the LED breathes ORANGE; when charging completes, the LED turns OFF.
- Low battery: below 3.65V the console displays a low-battery warning.
- (Runtime hours and charge time are not documented — do not invent them.)

TOUCHPAD / SPEAKER / MIC: the capacitive touchpad, built-in speaker, and built-in microphone are DualSense-style features designed around PS5 use; on other platforms their behaviour depends on the game/OS. The manual does not detail per-platform touchpad/speaker behaviour — do not promise specifics beyond PS5; route detailed questions to support.

RESET: if the controller becomes unresponsive, press the reset button on the back using a pin (hardware reset).

LITHIUM BATTERY SAFETY: do not expose to fire/extreme heat, puncture, or disassemble; use certified USB chargers; dispose per local e-waste regulations.

TROUBLESHOOTING (SENSA):
Q: Sensa suddenly stopped working / keeps disconnecting on PS5 (was working before)? A: Almost always a PS5 SYSTEM UPDATE changed something — update the Sensa FIRMWARE from https://www.thecosmicbyte.com/downloaddrivers/ using a Windows PC (steps in FIRMWARE UPDATE above). This is the fix — raise it FIRST, before any warranty talk.
Q: PC game doesn't detect the controller, or buttons/prompts are wrong? A: The Sensa is a PS5-style controller on PC — some games only understand Xbox (XInput) input. Fix in this order: (1) hold SHARE + OPTIONS 5s to toggle the built-in X-Input mode; (2) launch the game through Steam with "PlayStation Controller Support" enabled in Steam → Settings → Controller; (3) install DS4Windows to present the controller as an Xbox 360 pad. See "USING THE SENSA ON PC" above for the full explanation. The controller is NOT faulty.
Q: Bluetooth pairing fails? A: Turn the controller OFF → hold SHARE + PS for 3 seconds until the LED flashes → remove any old pairing entry on the device → select the controller again. Stay within ~10m.
Q: Won't pair with PS5 wirelessly? A: First-time pairing MUST be done with the USB cable connected (then press PS). After that, wireless works.
Q: Stick drift or inaccurate sticks/triggers? A: Run the 3D stick & trigger calibration (power OFF → hold OPTIONS + SHARE → connect USB to PC → follow the steps above). Also check the deadzone toggle (TouchKey + L3/R3, 2s) — 0% deadzone mode can feel like drift in some games; switch back to Default.
Q: Controller unresponsive/frozen? A: Press the reset button on the back with a pin (hardware reset), then reconnect.
Q: Not charging? A: Use the Type-C cable with a certified USB charger; LED should breathe orange while charging (powered off). If no LED, try another cable/port.
Q: Where is the 2.4GHz dongle? A: There is none — the Sensa is Bluetooth 6.0 + USB wired only. Nothing is missing from the box.

⚠️ WARRANTY — 2 YEARS (DIFFERENT from most CB products): the Sensa carries a 2-YEAR LIMITED WARRANTY against manufacturing defects from the date of purchase (valid proof of purchase required). NOT covered: physical damage, liquid damage, unauthorized modification, normal wear and tear. Do NOT quote the standard 1-year figure for the Sensa. Console use on PS5 is the Sensa's designed purpose — do NOT tell a Sensa customer that console use voids or is excluded from their warranty.

SOFTWARE / ORBIT: the only companion software documented for the Sensa is the Cosmic Byte Firmware Update Tool (Windows). The Sensa is NOT on the Orbit confirmed-support snapshot — do not claim Orbit support; the live device grid at https://orbit.thecosmicbyte.com is the authoritative list if a customer wants to check.

ANTI-FABRICATION GUARDS (Sensa):
✗ Do NOT claim Xbox or Nintendo Switch support. ✗ Do NOT call it Sony-licensed/official. ✓ Battery capacity is 1600mAh (confirmed — NOT 1000mAh). ✗ Do NOT invent runtime hours or charge time — not documented. ✗ Do NOT claim 1000Hz polling. ✗ Do NOT claim Hall Effect TRIGGERS — the sticks are Hall-Effect magnetic; the triggers are adaptive force-feedback. ✗ Do NOT mention a 2.4GHz dongle — there is none. ✗ Do NOT quote a 1-year warranty — the Sensa is 2 years.

SUPPORT: cc@thecosmicbyte.com | +91 7351615161 (WhatsApp same) | Mon–Sat 10am–6pm

BUY: https://www.thecosmicbyte.com/product/cosmic-byte-sensa-wireless-gamepad-for-ps5-pc-mac-ios-android-hall-effect-sticks-adaptive-triggers-bluetooth-6-0-rgb-macro-back-buttons/ — use coupon code ONLINEPAY for 10% off on online payments.

Starforge

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-starforge-tri-mode-controller-replaceable-tmr-joysticks/

COSMIC BYTE STARFORGE - TRI-MODE CONTROLLER - FULL MANUAL

JOYSTICKS: TMR (Tunnel Magnetoresistance) — drift-resistant, high precision. The Starforge joysticks are ALSO physically MODULAR / REPLACEABLE (Starforge ships with 4 force-rating modules in the box: 60gf / 70gf / 120gf / 150gf — the customer can swap them to change stick feel). The "replaceable" aspect is unique to the Starforge among Cosmic Byte controllers; the underlying sensor tech across all four modules is TMR. The product page URL itself contains "replaceable-tmr-joysticks" — that's authoritative. Same joystick tech tier as Blitz Tri-Mode, Stellaris 2nd Gen, Drakon, and Eclipse. (Lumora, Ares Pro, and the Ares Tri-Mode / Wired / Wireless family have Hall Effect joysticks — different sensor tech.) If a customer asks whether the Starforge has TMR / drift-resistant joysticks, the answer is YES — TMR. If they ask whether the modular sticks change the sensor tech, the answer is NO — all four modules are TMR; the swap changes the spring force feel only.

TRIGGERS: Optical (infrared LED + photodetector). This is a DIFFERENT sensor tech from both Hall Effect and TMR — optical triggers detect position via light interruption. Like Hall Effect and TMR, optical triggers are drift-resistant and have no contact wear, but the mechanism is different: Hall Effect uses magnetic sensors, TMR uses tunnel magnetoresistance, optical uses light. The Starforge is the ONLY Cosmic Byte controller with optical triggers — every other TMR-stick controller (Blitz Tri-Mode, Stellaris 2nd Gen, Drakon, Eclipse) pairs TMR sticks with Hall Effect triggers. If a customer asks whether the Starforge has Hall Effect triggers, the answer is NO — Optical. If they ask whether the Starforge triggers are drift-resistant or have no wear, the answer is YES — same end-result drift-resistance as Hall Effect/TMR, just a different sensor mechanism.

Compatible: PC (XInput/DInput), Android 8.0+, iOS 13+, Smart TVs, Tesla vehicles (2.4GHz).

PHYSICAL MODE SWITCH (bottom): Mobile Mode=Android/iOS wireless. NS Mode=Gyro Bluetooth mode (NOT Nintendo Switch). PC Mode=PC Bluetooth. 2.4GHz Mode=PC wireless XInput.

CONNECTIVITY:
- 2.4GHz: Set switch to 2.4G. Insert USB receiver. Controller OFF, hold Pairing button 3 seconds. LED flashes rapidly -> solid + vibration = connected.
- Bluetooth: Set switch to PC Mode or Mobile Mode. Hold Pairing button 3 seconds. Select "Xbox Wireless Controller" on device. Solid + vibration = paired.
- Wired: Connect USB-C. Hold Back + Start for 3 seconds to toggle XInput/DInput.
- Reconnect: Short-press Home.
- Range: ~10 metres.

LED STATUS: Solid red = low battery. Red slow breathing 0-30% = charging. Ice blue slow breathing 30-100% = charging. Solid ice blue = fully charged. Blinking blue = pairing.

MODULAR JOYSTICK REPLACEMENT:
1. Power OFF. Remove magnetic top cover (magnets, no tools needed).
2. Use puller tool to pull joystick upward from socket.
3. Take new module (60gf/70gf/120gf/150gf). Align flat edge inward, press firmly until clicks.
4. Reattach magnetic cover.
5. MANDATORY: Perform full stick+trigger calibration after every module swap.
Box includes: 3 extra joystick sets, puller tool, screwdriver.

STICK & TRIGGER CALIBRATION (after module swap or drift): Power OFF. Hold Back + X + Home for 1 second -> light strips flash. Rotate BOTH joysticks clockwise 5 full rotations. Press BOTH triggers 5 times (FULL long travel ONLY). Press Start -> strips turn off = done. MUST be in Xbox ABXY layout mode.
GYRO CALIBRATION: Power off, place flat on stable surface. Hold Back + A + Home for 3 seconds -> lights flash. Press Start -> strips off = done. Must be in Xbox ABXY layout mode.

XInput/DInput SWITCHING:
- Wired mode: Hold Back + Start for 3 seconds.
- Verify mode switch is on correct position.
- Always relaunch game after switching.

TURBO: Turbo + button cycles: Press 1=Manual, Press 2=Auto, Press 3=Cancel. Supported: A, B, X, Y, LB, RB, LT, RT. Speed: Turbo + Right Stick Right (up), Left (down). 3 levels: 5/12/20 per sec. Clear ALL: Hold Turbo 5 seconds. Vibration confirms.

MACRO (M1/M2/M3/M4 - 4 back buttons): Hold Fn + M button for 3 seconds -> light flashes. Press button to assign (A/B/X/Y/D-pad/LB/RB/LT/RT/L3/R3 up to 32 buttons). Press M button to save. Clear: Fn + same M button again.

RGB: Brightness: Fn + Left D-pad. Effects: Fn + Right D-pad. ABXY LED: Hold Fn + D-pad Left for 5 seconds (toggle). Vibration: Hold Fn + Up D-pad (increase), Down (decrease). 5 levels: 0-100%.
TRIGGER MOTOR VIBRATION: Press BOTH triggers + Fn for 1 second to cycle: Mode 1=Linear, Mode 2=Game-native (default), Mode 3=Sync with main, Mode 4=Off.
ABXY LAYOUT SCREW SWITCH: Use included screwdriver to rotate centre screw. Vibration confirms change. Restart controller after.

CONTROLLER RESET: Power OFF. Hold LS + RS + Home for 1 second -> red light 1 sec -> controller powers off = reset. Re-pair and recalibrate after.
BATTERY: 1200mAh, 10-12 hours. Charge: 3-4 hours.

KEY LINKER MOBILE APP (Starforge — BUTTON REMAPPING ONLY):
- Available on iOS and Android only (Google Play / Apple App Store). NO PC version.
- Pair the Starforge via Bluetooth with a mobile device, open Key Linker, and use it for advanced button remapping.
- IMPORTANT — scope: Key Linker on the Starforge handles BUTTON REMAPPING ONLY. It does NOT update firmware on the Starforge.

CONFIGURATION (Starforge — IMPORTANT):
- The Starforge has NO PC companion software. None exists.
- ALL controller configuration on the Starforge — RGB, turbo, vibration, macros, calibration, ABXY layout, joystick swap — is done via gamepad button shortcuts on the controller itself (see shortcuts above).
- Mobile button remapping is via Key Linker only (iOS/Android).
- Do NOT direct Starforge customers to download "Cosmic Byte software" or any PC software — there is no PC software for this product.

FIRMWARE UPDATE (Starforge — manual file path when available):
- The Starforge has no PC software, so firmware updates are NOT done through any software.
- If a firmware update for the Starforge is currently available, it is posted on https://www.thecosmicbyte.com/downloaddrivers/ or on the Starforge product page on thecosmicbyte.com, along with the instructions for applying it. Customer downloads the file and follows the on-page instructions.
- If no firmware update is currently posted on the website for the Starforge, the controller is on the latest available firmware — there is nothing to install. Suggest checking the website periodically.
- If the customer cannot locate firmware information and believes an update is needed, direct them to support (cc@thecosmicbyte.com) — do NOT invent a URL or filename.

PACKAGE: Controller, magnetic cover, 2.4G receiver, USB-C cable (1.5m), manual, 3 extra joystick sets, puller, screwdriver.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered.

BATTERY CAPACITY — AUTHORITATIVE (do NOT regress): The Starforge battery is 1200mAh (runtime 10-12 hours, charge 3-4 hours). An earlier catalogue line and some chat responses stated 600mAh — that was WRONG and has been corrected (confirmed by Cosmic Byte). If you ever recall, infer, or see "600mAh" for the Starforge, treat it as the stale/incorrect figure and use 1200mAh. (The 600mAh figure is correct for the Blitz Tri-Mode and Blitz Wireless, NOT the Starforge.)

Stellaris

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-stellaris-tri-mode-wireless-bluetooth-wired-controller-for-pc-ios-android-hall-effect-trigger-and-joystick/

COSMIC BYTE STELLARIS - TRI-MODE WIRELESS CONTROLLER - FULL MANUAL

⚠️ CRITICAL — READ FIRST: WHAT THE STELLARIS DOES *NOT* HAVE

The Stellaris is a flagship gamepad but several features customers sometimes assume are present are actually ABSENT. Listing any of these as "features it has" is a customer-visible WRONG ANSWER. These notes apply to BOTH generations unless explicitly called out:

✗ NO REPLACEABLE STICK TOPS / D-PAD COVERS. Single fixed set, not in the box. (Lumora ships with 6 stick tops + 2 D-pad covers. Stellaris does NOT.) Same for both Gen 1 and Gen 2.

✗ NO KEYBOARD/MOUSE REMAPPING via software. The Cosmic Byte software on Gen 2 supports gamepad-to-gamepad remap only. (Lumora supports KB/mouse remap. Stellaris does NOT.) Gen 1 has no PC software at all.

✗ NO CHARGING DOCK SUPPORT. Stellaris does not have the back contacts for a charging dock. Charges via USB-C cable only. (Blitz Tri-Mode supports a charging dock — Stellaris does NOT. Do not confuse.)

✗ NO CONSOLE SUPPORT. PC is the primary platform. Does not work on PlayStation / Xbox / Switch (despite the Switch-protocol gyro mode, which is for PC-via-Steam Switch Pro Controller support, not for actually plugging into a Nintendo Switch). Both gens.

✗ NO LARGER BATTERY between generations. Both Gen 1 and Gen 2 are 1000mAh. Do NOT say Gen 2 has a "larger battery" or "improved battery life" over Gen 1 — the battery is the SAME size.

✗ NO GYRO ON GEN 2 OUTSIDE BLUETOOTH GYRO MODE. Gyro is exclusively available in Bluetooth Gyro Mode (per the Gen 2 user manual). Not available in wired mode, not in 2.4GHz mode, not in regular Bluetooth X-Input/D-Input modes. (Gen 1 gyro is even more limited — only in NINTENDO switch position, see Section 2.)

✗ GEN 1 SPECIFIC: NO Windows software, NO RESET button on the back, NO analog/digital trigger switch, NO 4-RGB-mode cycling. (Current Stellaris HAS all of these. See "DOES HAVE" block below for what upgrades come with Gen 2.)

✗ NEITHER GEN: NO macro buttons beyond the 2 back paddles (ML / MR). The controller has two macro buttons total. Do NOT say it has 4 macros or 6 macros (Lumora has 4, but Stellaris has 2). Both gens have the same 2 macro buttons.

✗ NO LED DISPLAY / NO SCREEN / NO ON-CONTROLLER UI on the Stellaris body — neither gen. The Stellaris has LED INDICATORS (the V-shaped front LED bar, the four corner LEDs near HOME, the rear charging LED, plus the outer RGB ring on the transparent variant). These are STATUS INDICATORS — they show mode, battery, charging state, RGB lighting. They are NOT a screen, NOT a display, NOT a menu UI. There is no "power menu" appearing on any LED. There is no "select an option" interaction. If you find yourself describing "a menu will appear on the LED display" or "the controller will guide you through the LED indicators" or "select the power-off option" — STOP. The Stellaris has no such UI. There is nothing to navigate. (Production session 52e2e3b4, 2026-05-13 13:00, surfaced this fabrication in a power-off walkthrough; this guard added in v1.10.11 to prevent recurrence.)

✗ NO "HOLD HOME FOR 3 SECONDS = POWER OFF" on Stellaris (either gen). The HOME button has documented behaviours at OTHER durations on current Stellaris: short press = HOME function (per game); HOLD HOME for 5 seconds = SLEEP (NOT power off — sleep preserves connection state); but there is NO documented "hold HOME for 3 seconds = power off" or any 3-second HOME behaviour. The OFFICIAL Stellaris power-off command per the user manual page 12 is a SHORT-PRESS of the rear RESET button next to the USB-C port — NOT a HOME button hold of any duration. See the POWER OFF / SLEEP / RESET section below for the full procedure.

✗ NO "HOME + SELECT FOR 3 SECONDS = SHUTDOWN" combo on Stellaris (either gen). This combination is not documented anywhere in the Stellaris manuals and does not trigger any power-off behaviour.

Do not present it as an "alternative quick power-off" — it is a fabrication.

✗ NO POWER MENU / NO MENU-DRIVEN POWER OFF on Stellaris (either gen). Power off is a single-action procedure: short-press the rear RESET button. No menu appears, no options are presented, no selection is made. If a customer asks "how do I turn off my Stellaris", the answer is a single sentence (the short-press of the rear RESET button), not a multi-step menu navigation.

✗ MOUSE MODE IS ANDROID-ONLY ON STELLARIS 2ND GEN — NOT A PC FEATURE. The Stellaris 2nd Gen Mouse Mode (turns the controller into a mouse with right stick = cursor, A = left click, B = right click) is documented in the user manual as an ANDROID-ONLY feature per the input-mode tables. It is NOT available on PC. The connection mode (Wired vs 2.4GHz vs Bluetooth) does NOT determine Mouse Mode availability — the HOST OS does. Mouse Mode requires an Android host. On PC the Stellaris continues to function as a standard gamepad regardless of whether the customer activates Mouse Mode. NOTE: this is a different feature from "KEYBOARD/MOUSE REMAPPING via software" (which Stellaris does NOT have at all — see the ✗ NO KEYBOARD/MOUSE REMAPPING guard near the top of this block). Mouse Mode = onboard Android feature that makes the right stick drive a cursor. Keyboard/Mouse Remapping = software feature (Lumora has it, Stellaris does not, neither on PC nor Android). DO NOT SAY: "Stellaris Mouse Mode works on PC" / "Mouse Mode is available on both PC and Android" / "Use Mouse Mode for PC cursor control" -- all WRONG. The user manual's input-mode tables list Mouse Mode only under the Android section. Production session 980aca7e (2026-05-16 22:55) had the bot tell a customer Mouse Mode worked on PC for the Blitz Tri-Mode; Ronak's cross-controller correction confirms the same is true for Stellaris 2nd Gen and Drakon. Guard added in v1.10.18 to prevent recurrence on Stellaris. Also: the line in the FACTORY RESET CLEARS list previously said "Keyboard & Mouse mode (PC)" — that was misleading wording, now corrected to "Mouse Mode (Android only)" in v1.10.18. PC CUSTOMER ROUTING (v1.10.21): if a Stellaris customer wants cursor control on PC, do NOT leave them with "Mouse Mode doesn't work on PC". See Rule 16 (GAMEPAD AS MOUSE ON PC) in the system prompt — the customer's existing Stellaris will work as a PC mouse via three documented third-party tools (Gopher360 / JoyToKey / Steam Desktop Configuration). Pivot to Rule 16 every time Mouse Mode on PC comes up.

POWER OFF / SLEEP / RESET — OFFICIAL PROCEDURES (top-of-entry self-claim block so the bot doesn't have to scan 6000+ chars to find these — added in v1.10.11 after session 52e2e3b4 surfaced a power-off hallucination.)

POWER OFF (current Stellaris / Gen 2 — also applies to transparent variant):
Single step: SHORT-PRESS the rear RESET button next to the USB-C port. The controller powers off. Settings preserved. That is the COMPLETE procedure — there is no menu, no LED guide, no second step. This is the OFFICIAL power-off command per the Stellaris Gen 2 user manual, page 12 ("Power Off: Press RESET").

What the LED does after power off: all LEDs turn off. The controller enters a deep low-power state. To turn the controller back on, press ANY button (HOME, a face button, or a trigger).

SLEEP (separate from power off):
HOLD the HOME button for 5 seconds = manual sleep. Wake by pressing HOME. AUTO-SLEEP also exists: 30 seconds idle if not connected, 5 minutes idle if connected but inactive. Sleep PRESERVES connection state (Bluetooth pairing, mode); power off does NOT.

HARDWARE RESET (recovers from unresponsive state — different from power off):
HOLD the rear RESET button for MORE THAN 1 second. Does NOT delete user settings — just recovers from frozen / unresponsive state. After hardware reset the controller enters sleep automatically; press HOME to wake.

FACTORY RESET (deletes user settings — different from hardware reset):
HOLD SELECT + L3 + R3 together for 5 seconds. This clears all user settings (button mapping, macros, RGB profiles, etc.) and restores

factory defaults. Use this only when the customer specifically wants to wipe settings.

THE REAR RESET BUTTON HAS DUAL FUNCTION based on press duration:
- SHORT press (release immediately) = power off (preserves settings).
- LONG press (more than 1 second) = hardware reset (preserves settings, recovers from unresponsive state).
- Both outcomes are normal. If a customer says "I pressed RESET and it turned off — did I do it right?" → yes, that's power off. If they say "I held RESET and it went to sleep" → yes, that's hardware reset; they can press HOME to wake.

LEGACY GEN 1 — different power-off:
Gen 1 has a physical SYNC BUTTON on the TOP of the controller (Gen 2 does not have this — Gen 2 uses the rear RESET button). To power off a Gen 1: SHORT-PRESS the sync button on top. NOT the procedure above (the rear-RESET procedure is Gen 2 only — Gen 1 doesn't have a rear RESET button next to the USB-C port).
Do NOT confuse with the Gen 1 HARDWARE RESET, which is a separate procedure: HOLD the HOME button for 10 seconds = hardware reset on Gen 1 (recovers from unresponsive state, does not delete settings).
Two different Gen 1 buttons, two different procedures — sync-button-short-press = power off; HOME-hold-10s = hardware reset.
If the customer signals they have a Gen 1 (see the GENERATIONS section below for Gen 1 identification cues), use the sync-button-on-top procedure for power off.

✓ WHAT THE STELLARIS *DOES* HAVE (real features for current Gen 2; real upgrades over Gen 1 — list ALL of these confidently when asked "what does the current Stellaris add over the older one?". Do NOT shorten to a vague "improved features" summary.)

The CURRENT Stellaris (Gen 2) is a genuine generational upgrade over Gen 1. Real, KB-documented Gen 2 features:

✓ TRI-MODE CONNECTIVITY: Wired (USB-C) + 2.4GHz wireless dongle + Bluetooth — all three modes present. (Gen 1 was also tri-mode in terms of connectivity types, but used a physical 4-position mode switch on the back; Gen 2 selects via button combos instead.)
✓ TMR JOYSTICKS (Tunnel Magnetoresistance): drift-resistant, high precision. (Gen 1 had magnetic joysticks — TMR is a newer tier, same family as Drakon and Blitz Tri-Mode.)
✓ ANALOG / DIGITAL TRIGGER MODE SWITCH on each trigger (physical switch). Analog for racing/driving (pressure-sensitive); digital for FPS/competitive (instant response). (Gen 1 had Hall Effect magnetic triggers but no analog/digital mode switch.)
✓ APP SUPPORT — PC companion software (download from thecosmicbyte.com/downloaddrivers) for RGB customisation, button mapping, macro programming, vibration, trigger range, firmware updates. The controller back label has "App Support" in the top-left corner. (Gen 1 had NO PC software at all.)
✓ 4 RGB LIGHTING MODES: Rainbow (default), Color Cycle, Single Color Breathing, Fixed Color. Cycle via TURBO + SELECT. Brightness via TURBO + UP/DOWN D-pad. (Gen 1 had 3 modes only and different shortcuts — SELECT + D-pad / BACK + D-pad.)
✓ PHYSICAL RESET BUTTON next to the USB-C port. Dual function: short press = power off the controller; long press (more than 1 sec) = hardware reset. (Gen 1 has NO physical RESET button.)
✓ 6-AXIS GYRO accessible in Bluetooth Gyro Mode (Press Y + HOME for 3 seconds to enter). Combines with analog triggers in the same connection. (Gen 1 has gyro hardware too — see Section 2 — but it's only accessible in the NINTENDO switch position and triggers are digital-only in that mode.)
✓ DUALSHOCK MODE for iOS / Android (Bluetooth, Press Turbo + HOME for 3 seconds). PS4-DualShock emulation for mobile games. (Gen 1 did not have this mode.)
✓ HIGH POLLING RATE: 1000Hz wired / 1000Hz 2.4GHz / 125Hz Bluetooth. (Gen 1 had the same wired/2.4GHz polling rate; Bluetooth polling rate was not specified.)
✓ TURBO with sequence recording on macro buttons (ML / MR) — record up to 22 inputs on each. Speeds: 5 / 12 (default) / 20 shots/sec. (Gen 1 had macros too but with different turbo speeds: 5 / 15 / 25 per the Gen 1 manual — do NOT confuse the two.)

ASK-FIRST GUIDANCE (READ BEFORE ANSWERING ANY STELLARIS QUESTION):

VARIANTS: The Stellaris is sold in BLACK and TRANSPARENT variants. The transparent variant has an additional outer RGB ring around the controller body that the black variant does NOT have. ALWAYS ask which variant the customer has BEFORE answering ANY RGB / lighting question on Stellaris (either gen). Do not assume; do not skip this ask. The variant difference (transparent has the outer ring) is material to almost every RGB answer — what zones can be controlled, what "turn off all lights" means, etc. For non-RGB questions, do not ask about variant.

GENERATIONS: There are two physical generations of Stellaris. The CURRENT (Gen 2) is the default — assume the customer has the current Stellaris unless they signal otherwise. Gen 1 is DISCONTINUED but some units are still under warranty. Switch to the LEGACY GEN 1 section ONLY if the customer signals one of:
- References "magnetic joysticks" (Gen 1 has magnetic, current has TMR)
- Says "no software for my Stellaris" or "can't find software"
- Reports a button shortcut not working that you just gave them (their gen probably has different shortcuts)
- Explicitly says "1st gen", "older one", "old version", "the previous Stellaris"

Do NOT proactively ask "Gen 1 or Gen 2?" on every Stellaris query. Default to current. Only ask when a customer signal indicates legacy.

PC primary platform. Not supported on any gaming console. No warranty for console use. Both gens are PC-primary; both have the same console compatibility disclaimer.

SECTION 1: CURRENT STELLARIS (default — was sold as "Gen 2")

This is the version sold currently. Assume this unless customer signals otherwise (see guidance above).

KEY FEATURES:
- TMR (Tunnel Magnetoresistance) joysticks — drift-resistant, high precision, replaceable. Higher quality than older Hall Effect joysticks.
- Magnetic analog triggers with physical Analog/Digital mode switch (on back of controller).
- Gyro / motion sensing — BLUETOOTH MODE ONLY natively. Also available in Wired/2.4GHz via the companion software.
- 1000Hz polling rate (Wired and 2.4GHz). 125Hz on Bluetooth.
- Multi-platform: PC, Android, iOS, macOS.
- 2 programmable macro buttons on back (ML/MR), up to 22 inputs each.
- Companion software (Windows) for RGB, macros, button mapping, deadzones, firmware updates.
- 1000mAh battery.

CONNECTIVITY TABLE (no physical mode switch — set by button combo during pairing):
Mode | Platform | How to Connect (hold 3 sec) | LED
Wired XInput | PC | Plug in + press HOME | LED2 on
Wired DInput | PC | Long-press HOME under XInput | LED3 on
Wired DInput | Android | Plug in + press HOME | LED3 on
2.4GHz XInput | PC | Press X + HOME | LED2 on
2.4GHz DInput | PC | Long-press SELECT + HOME under XInput | LED3 on
2.4GHz XInput | Android | Press X + HOME | LED2 on
Bluetooth DInput | PC/Android | Press A + HOME | LED3 on
Bluetooth XInput | PC/Android | Press B + HOME | LED2 on
Bluetooth Gyro | PC/Android/iOS | Press Y + HOME | LED4 on
Bluetooth DualShock | iOS/Android | Press Turbo + HOME | LED1 on

BLUETOOTH POLLING RATE:
- Bluetooth mode supports up to 500Hz polling rate.
- Actual Bluetooth polling rate ranges 125Hz–500Hz depending on system, OS, and Bluetooth chip of the connected device.
- For most stable polling, use Wired (USB-C) or 2.4GHz Wireless mode.
- 1000Hz polling rate is only available in Wired and 2.4GHz Wireless modes.

GYRO (current Stellaris):
- Native: Bluetooth mode only (Press Y + HOME for 3 sec, LED4 on).
- Via companion software (works in Wired/2.4GHz, AND works in ANY game even without native gyro support):
  * Connect Wired or 2.4GHz. Open Cosmic Byte software (https://www.thecosmicbyte.com/downloaddrivers/).
  * Assign gyro to any button.
  * Activation modes: Always On / Toggle / Press and Hold.
  * Gyro output mimics joystick movement, so it works with any game that supports a joystick.
  * For full controls including Response Curve presets and granular activation settings, see the SOFTWARE -> Motion tab section below.

SOFTWARE (Cosmic Byte Stellaris software — Windows ONLY, current Stellaris / Gen 2 only):

Download from https://www.thecosmicbyte.com/downloaddrivers/. The Stellaris is plug-and-play on Windows for normal gamepad use; the software is OPTIONAL and only needed for advanced customisation. There is no macOS / Linux / Android build. The software is for the current Gen 2 Stellaris ONLY -- Gen 1 (legacy) uses the Key Linker mobile app instead and is NOT compatible with this PC software (see the LEGACY GEN 1 section below).

CONNECTION REQUIREMENT: software works in WIRED USB-C and 2.4GHz dongle modes. Bluetooth mode is for normal gamepad use only -- the software does NOT detect the controller over Bluetooth.

APP LAYOUT (different UI family from the Ares Pro / Lumora software):
- LANDING / SPLASH: full-screen splash titled "STELLARIS GAMEPAD" with the controller render, plus three menu buttons stacked vertically at the bottom centre:
  * Profiles -- enters the profile picker, then the in-profile editor with the 6-tab bar.

  * Vibrates -- direct access to vibration settings. NOTE: "Vibrates" on the splash is a software typo (confirmed -- the in-profile tab is correctly labelled "Vibrations"). Treat customer mentions of either spelling as the same feature.
  * Updates -- direct access to the firmware update screen.
- IN-PROFILE EDITOR: top icon-tab bar with 6 tabs (Mappings / Joysticks / Triggers / Vibrations / Lights / Motion), the controller render in the centre, and per-tab controls flanking it. The active profile name appears top-right next to a gear icon and a back arrow.

PROFILES SYSTEM (4 profiles total: Default + 3 custom):
- Default -- baseline configuration that cannot be deleted; selecting it is essentially "factory settings on a session-by-session basis".
- Profile 1, Profile 2, Profile 3 -- each has a description field ("Click to add description...") and its own Configure button. Click Configure to enter the in-profile editor.
- Profiles store independent settings for every tab: button mappings, joystick ranges, trigger ranges, vibration levels, lighting animations, motion settings.

EDITOR TABS — what each tab does:

(1) MAPPINGS — button remapping via interactive controller diagram. Every button on the controller is labelled with a callout line (LB, LT, LSB, ↑↓←→ D-pad, L4, RB, RT, X, Y, B, A, RSB, R4, SELECT, START). Click any button label to assign a different output to that button. L4 / R4 are the back paddle buttons; LSB / RSB are the stick clicks. "Reset to default" button at the bottom resets all mappings on this profile.

(2) JOYSTICKS — per-stick range and behaviour:
  - Left Stick Range -- Initial-to-Max slider. Initial sets the lower bound of stick travel that registers; Max sets the upper bound.
  - Raw toggle -- bypasses the software's response curve and sends the stick's raw output.
  - Right Stick Range -- same Initial-to-Max slider + Raw toggle, independently adjustable.
  - Swap Left Joystick and D-pad (toggle) -- physically swaps the input role of the left stick and the D-pad. Default OFF.
  - D-Pad Diagonal Lock (toggle) -- restricts D-pad to 4 cardinal directions (no diagonals). Useful for fighting games. Default OFF.
  - Live X/Y % readout for each stick at the bottom corners of the controller render.
  IMPORTANT IN-APP CAVEAT: the software displays "Initial value under 10% will make the stick very sensitive, which is prone to drifting. Please use with caution." If a customer reports drift after software adjustment, ask whether they set Initial below 10% before treating it as a hardware issue.

(3) TRIGGERS — per-trigger range:
  - Left Trigger Range -- Initial-to-Max slider.
  - Right Trigger Range -- Initial-to-Max slider, independently adjustable.
  - Live trigger intensity bars displayed in the centre, above the controller render.
  Note: this software-side range works on top of the physical Trigger Mode Switch on the back of the controller (Analog/Digital). Software adjustments fine-tune the response within whichever physical mode is selected.

(4) VIBRATIONS — per-grip vibration levels:
  - Left Grip Vibration Level -- Off / 1 / 2 / 3 (slider with 4 stops).
  - Right Grip Vibration Level -- Off / 1 / 2 / 3, independently adjustable.
  - "Try Grip Vibration" toggle -- when enabled, pressing LT or RT briefly vibrates the corresponding grip so the customer can preview the level before saving.
  Stellaris vibration is per-grip (left and right independent), more granular than products that have a single combined vibration intensity.

(5) LIGHTS — RGB lighting customisation:
  - Animations -- 3 slots labelled I, II, III. Customer can configure up to 3 simultaneous animation effects.
  - Presets -- five options at the bottom-left: Spectrum (default, multi-colour cycling), Rainbow, Breathing, Static Color, Off.
  - Speed slider -- animation speed.
  - Brightness slider -- LED brightness.
  - Pick up to wake (toggle) -- when enabled, motion sensor wakes the controller from sleep when picked up. Default OFF.
  - Auto sleep when inactive for -- timeout dropdown (e.g. 10 Mins). Controller goes to sleep to save battery after this period of inactivity.
  Note: this is for the BLACK Stellaris variant's RGB rings around the joysticks. For the TRANSPARENT variant (which has an additional outer RGB ring around the controller body), the same controls apply but also affect the outer ring -- always confirm the customer's variant when answering RGB questions per the ASK-FIRST GUIDANCE at the top of this entry.

(6) MOTION — gyro / motion customisation. More granular than Lumora's Motion tab:
  - Response Curve -- four presets:
    * Aggressive -- fast response near extremes, slower near centre. Good for FPS aim where you want fine control near rest and quick flicks at the edges.
    * Default -- linear curve.
    * Smooth -- S-curve / sigmoid response. Gradual ease-in and ease-out.
    * Custom -- user-editable curve graph.
  - Anti-Deadzone slider -- compensates for in-game deadzones on the gyro output.
  - Activate Method -- On/Off toggle. Default Off (gyro disabled on this profile).
  - Activate Button -- which controller button activates gyro. Default "N" (none = always-on when Activate Method is On).
  - Motion Axis -- which physical sensor axis maps to the joystick output (gamepad-icon picker).
  - Active Axis -- which axes are live (X-only, Y-only, both -- arrow-direction picker).
  - Invert X -- flip horizontal sensor direction. Default Off.
  - Invert Y -- flip vertical sensor direction. Default Off.
  - Steer / Aim toggle -- behaviour mode selector. "Steer" mode is racing-style (continuous angle = continuous output); "Aim" mode is FPS-style (gyro-as-stick, with the curve and deadzone applied). Default depends on what the customer last selected per profile. Steer/Aim is unique to the Stellaris software -- Lumora's Motion tab does not have this toggle.
  - Reset to default -- bottom button.
  Live preview: the right joystick on the controller render highlights orange and shows a "+" cross-hair indicator while gyro motion is being captured.

UPDATES PAGE (accessed from the splash screen's Updates button):
- Shows current firmware version (e.g. "Current firmware version: v1.0.9").
- If a newer version is available, shows "Update to v1.1.2" with a NEW tag.

- Click "Update" to apply. Do NOT disconnect during update.
- CONNECTION REQUIREMENT: firmware update requires WIRED USB-C ONLY (NOT 2.4GHz, NOT Bluetooth). The rest of the Stellaris software (Mappings, Joysticks, Triggers, Vibrations, Lights, Motion) works in either Wired or 2.4GHz, but firmware update specifically needs the wired cable so the install can complete reliably without RF interference. This matches the existing FIRMWARE UPDATE section in this entry. If a customer says the Update button is greyed-out or refusing to start, first confirm they are connected via USB-C, not the 2.4GHz dongle.

GENERAL SOFTWARE NOTES:
- All settings are stored on the CONTROLLER itself, not just in the software. Settings persist across PCs and power cycles.
- Profile switching is currently software-side -- to switch profiles on the fly without the software running, refer to any per-controller hardware shortcuts documented elsewhere in this entry.
- Software is WINDOWS ONLY. No macOS / Linux / Android build.
- Software does NOT detect the controller over Bluetooth -- use Wired or 2.4GHz to access any of the tabs above.

STEAM MODE (wired only):
- Power OFF the controller. Hold R3. While holding R3, plug in the USB-C cable. Release R3 once connected. Boots into Steam mode automatically. Restart Steam if needed.

AUDIO: 3.5mm jack works in 2.4GHz and wired modes only on PC. NOT functional in Bluetooth mode or on consoles/mobile.

TRIGGER MODE SWITCH (physical switch on back of controller):
- Flip INWARD = Analog mode (longer travel, pressure-sensitive — racing/driving/sims).
- Flip OUTWARD = Digital mode (instant button-like input — FPS/action games).

LED BATTERY CHECK: Press CAPTURE + START (shows for 3 seconds). LED1=1-25%, LED2=26-50%, LED3=51-75%, LED4=76-100%.

BUTTON LAYOUT SWAP SHORTCUTS (PC mode only):
- Swap A/B and X/Y buttons: Hold TURBO + R3 for 3 seconds. Both pairs swap simultaneously. Motor vibration confirms. Repeat to revert. (Cannot swap one pair independently.)
- Swap D-Pad and Left Stick: Hold START + L3 for 3 seconds. Motor vibration confirms. Repeat to revert.
- Both swaps cleared by Factory Reset (SELECT + L3 + R3 held for 5 seconds).

ANDROID / MOBILE VIBRATION:
- Standard Bluetooth DInput on Android may not send vibration.
- Try DualShock mode: hold TURBO + HOME for 3 seconds (LED1 on). DualShock mode is for MOBILE/PC use only — NOT for PS4/console. This controller does NOT work on PlayStation.
- Vibration in DualShock mode on Android is not guaranteed; depends on game/device. Android limitation, not a hardware defect, not covered under warranty.

TURBO:
- Set Turbo: Hold TURBO + (any of A/B/X/Y/L1/L2/R1/R2). Cycle Manual Turbo -> Auto Turbo -> Off.
- Clear all Turbo: Hold TURBO for 5 seconds.
- Turbo speed: Hold TURBO + Right Stick Right (faster) or Left (slower). Levels: 5, 12 (default), 20 presses/sec.

MACRO PROGRAMMING (ML/MR back buttons):
- Hold TURBO + ML/MR for 2 seconds. Record up to 22 inputs. Press ML/MR again to save.

VIBRATION:
- Hold TURBO + Right Stick Up (stronger) / Down (weaker). Levels: 100% / 70% (default) / 40% / Off.

D-PAD MODES:
- 4-way / 8-way: Hold SELECT + D-pad Right for 3 seconds. Single vibration = 4-way, continuous vibration = 8-way (default).

STICK CIRCLE/SQUARE 45°:
- Hold L3 + TURBO for 3 seconds. Default = Circle. Square = 45° mode for tighter diagonal angles.

LIGHTING (CURRENT STELLARIS):

RGB ZONES:
- ABXY + HOME button lights: white, 5 LEDs total, always on with controller (no color/mode change — these stay steadily lit).
- Joystick RGB: 3 LEDs under each joystick, 6 RGB LEDs total — full color/mode control.
- OUTER side RGB ring (TRANSPARENT VARIANT ONLY): same color/mode control as joystick RGB. Black variant does not have this ring.

RGB MODES (4): Rainbow (default on power-up), Color Cycle, Single Color Breathing, Fixed Color Manual.

RGB BRIGHTNESS LEVELS: 100%, 80% (default), 25%, 0% (OFF).

RGB SHORTCUTS:
- Toggle ALL lighting on/off: Hold LB + RB for 5 seconds.
- Cycle RGB main modes: TURBO + SELECT.
- Switch fixed colors manually (in Fixed Color mode): TURBO + D-pad Right.
- Brightness up: Hold TURBO + D-pad Up.
- Brightness down: Hold TURBO + D-pad Down.

ABXY/HOME white lighting and joystick RGB are independent groups but the LB+RB master toggle controls both. Lighting settings are cleared by Factory Reset.

CALIBRATION: Power off. Hold CAPTURE + HOME. Rotate both sticks 3 times. Press triggers fully 3 times. Press A to confirm.

HARDWARE RESET (current Stellaris): Press and hold the physical RESET button next to the USB-C port for MORE than 1 second. Does NOT delete user settings — just recovers from unresponsive state. After the hardware reset, the controller enters sleep state automatically; press HOME to wake.

RESET BUTTON DUAL FUNCTION (current Stellaris) — IMPORTANT, easy to confuse: the small RESET button next to the USB-C port has TWO different behaviors depending on press duration:
- SHORT press (release immediately): powers the controller OFF. Settings preserved. This is the OFFICIAL way to power off the controller per the user manual (page 12, "Power Off: Press RESET").
- LONG press (more than 1 second): hardware reset — recovers from unresponsive state. Settings preserved. Controller enters sleep state after the reset.

Neither press clears user settings; both preserve them. To clear settings the customer must use FACTORY RESET (SELECT + L3 + R3 for 5 seconds, see below). If a customer says "I pressed the RESET button and my controller turned off — did I do it right?", the answer is yes — short press = power off. If they say "I held it and my controller went to sleep — did it reset?", the answer is also yes — that's the hardware reset behavior. Both outcomes are normal for the same button.

FACTORY RESET (current Stellaris): Ensure the controller is powered ON. Hold SELECT + L3 + R3 simultaneously for 5 seconds. The controller will reset automatically.

WHAT FACTORY RESET CLEARS (current Stellaris, per user manual page 14):
- All TURBO button assignments
- TURBO speed level settings
- Motor vibration strength settings
- All AUTO / continuous input functions
- Stick circle / square (45°) mode settings
- D-pad and Left Stick swap settings
- A / B / X / Y button swap settings
- Mouse Mode (Android only — NOT a PC feature; see MOUSE MODE clarification block below)
- Stick center deadzone (restored to default)
- All macro definitions (ML / MR)
- Mode switching settings (restored to default)
- All RGB lighting effects and brightness settings

WHAT FACTORY RESET DOES NOT TOUCH (current Stellaris): firmware version (use the PC companion software's firmware update tool to roll back/update); joystick calibration (use the CALIBRATION shortcut above to redo); battery state (charge level is hardware state, not a setting); paired Bluetooth devices on the host side (the host phone/PC may still show "Pro Controller" in its Bluetooth list, but the controller will need to re-enter pairing mode to reconnect after the reset).

AFTER FACTORY RESET (current Stellaris, per manual page 14):
- Controller restarts with default factory settings.
- Re-pairing with previously paired devices may be required -- the customer should delete the old "Pro Controller" / "Stellaris" entry from their host device's Bluetooth list and re-pair from scratch if reconnection is flaky.

If a customer asks "will factory reset delete X?", check the WHAT FACTORY RESET CLEARS list above. If X is on that list, the answer is yes. If X is on the WHAT FACTORY RESET DOES NOT TOUCH list (or is something like firmware/calibration/battery), the answer is no.

AUTO SLEEP: 30 seconds if not connected, 5 minutes if connected but inactive. Wake by pressing HOME. Manual sleep: hold HOME for 5 seconds. Power off (different from sleep): short-press the RESET button next to the USB-C port — this is the OFFICIAL power-off command per the user manual page 12. The RESET button has dual function based on press duration; see "RESET BUTTON DUAL FUNCTION" above.

FIRMWARE UPDATE (current Stellaris):
- Done THROUGH the Cosmic Byte companion software (same software used for RGB/macro/mapping config). There is NO separate firmware updater tool.
- Process: download the Cosmic Byte software from https://www.thecosmicbyte.com/downloaddrivers/ → connect Stellaris via USB-C in WIRED mode → power on the controller → open the software → it should detect the controller automatically → use the firmware update option inside the software → do not disconnect during update.
- The current Stellaris does NOT support the Key Linker mobile app — Key Linker is for Gen 1 only. If a customer asks about Key Linker for the current Stellaris, the answer is "Key Linker is not used for this controller — use the PC companion software instead."

CHARGING: 5V charger or PC USB ONLY. Fast chargers damage battery and void warranty. Battery: 1000mAh.

SECTION 2: LEGACY STELLARIS GEN 1 (DISCONTINUED — warranty support only)

Gen 1 is no longer sold. Only switch to this section if the customer signals they have an older unit (see ASK-FIRST GUIDANCE above). Some Gen 1 units are still under their 1-year warranty.

DIFFERENCES FROM CURRENT STELLARIS:
- Joysticks: MAGNETIC (not TMR).
- Triggers: MAGNETIC (no Analog/Digital mode switch).
- Gyro: 6-axis hardware present. Accessible ONLY in Nintendo mode (the leftmost switch position) over Bluetooth, pairing as "Pro Controller" via the Nintendo Switch Pro Controller protocol. Trigger analog mode is NOT available simultaneously with gyro on Gen 1 -- LT/RT become digital-only in Nintendo mode (Switch protocol limitation). No software-side gyro customization since Gen 1 has no PC software. Current Stellaris (Gen 2) supports gyro AND analog triggers simultaneously, and has software-side Motion tab controls. See "GYRO (Gen 1 Stellaris)" section below for the full walkthrough.
- NO PC companion software (Windows or otherwise). Configured entirely via gamepad button shortcuts. (Key Linker mobile app handles button remapping + firmware updates only -- NOT RGB, NOT gyro, NOT vibration,

NOT turbo, NOT calibration.)
- 3 RGB modes only (vs. current's 4): Mixed Color Wave (default), Color Breathing, Single Color.
- Has a PHYSICAL mode switch on the back with FOUR positions (left-to-right): Nintendo / Android / iOS / Windows. Current Stellaris does not have this -- connection mode is set by button combo.
- Different RGB shortcut combinations (see below).
- Different turbo speeds: Gen 1 = 5 / 15 (default) / 25 shots/sec. Current Stellaris = 5 / 12 (default) / 20 shots/sec. Do not confuse.
- Vibration adjustment uses LEFT joystick on Gen 1 (TURBO + Left Stick Up /Down). Current Stellaris uses RIGHT stick. Do not confuse.

GEN 1 MODE SWITCH -- FOUR POSITIONS (this is the most-confused part of the Gen 1 manual, read carefully):

The physical slide switch on the back of the controller has FOUR labeled positions, left-to-right: Nintendo / Android / iOS / Windows.

The Gen 1 user manual uses DIFFERENT naming for the same positions in its "How to connect" sections, which historically caused this KB to document only 3 modes and miss the Nintendo / WIN PC duality. Cross-reference:

PHYSICAL LABEL	MANUAL'S NAME	WHAT IT IS
Nintendo	"WIN PC" mode (also "PC Steam Analog Trigger BT")	Bluetooth, Pro Controller protocol (Nintendo Switch Pro Controller). Has gyro. LT/RT are DIGITAL-only. Works with PC (via Steam Switch Pro Controller support), Steam Deck, Android 10+.
Android	"Android" mode	Bluetooth, D-Input on PC. Works with PC, Steam Deck, Android 10+.
iOS	"iOS" mode	Bluetooth, X-Input on PC. LT/RT ARE pressure-sensitive on PC in this mode. Works with PC, Android 10+, iOS 13.4+.
Windows	"Windows mode" (Tesla Dongle)	2.4GHz USB dongle (Tesla dongle). NOT Bluetooth. No gyro.

When customers ask about gyro, they're looking at the physical switch labeled "Nintendo" -- BUT the manual tells them to set switch to "WIN PC". These are the SAME position. ALWAYS clarify this duality if there's any confusion -- the original Gen 1 manual is genuinely poorly worded on this.

GEN 1 CONNECTION (uses physical mode switch + sync button on top):
- Step 1: Move the mode switch on the back to the desired position (Nintendo / Android / iOS / Windows -- see table above).
- Step 2: Make sure controller is OFF. Short-press the sync button on top to power off if needed.
- Step 3: Press and hold the sync button for 1 second to enter Bluetooth pairing mode. LEDs flash. (Skip this step for Windows position -- that position uses the 2.4GHz dongle, not Bluetooth.)
- Step 4: On the device, enable Bluetooth and select the controller.

GEN 1 BLUETOOTH PAIRING NAMES (from Gen 1 user manual):
- NINTENDO position (manual calls "WIN PC"): pairs as "Pro Controller". THIS is the gyro mode.
- ANDROID position: pairs as "CB Stellaris Controller".
- iOS position: pairs as "Xbox Wireless Controller".
- WINDOWS position: NOT a Bluetooth mode. Uses the 2.4GHz USB dongle.

GEN 1 LED INDICATORS (on successful connection):
- NINTENDO mode (Pro Controller / gyro): LED 1 steady.
- ANDROID mode: LEDs 2 and 3 steady.
- iOS mode: LEDs 1 and 2 steady.
- WINDOWS mode (2.4GHz dongle): LED 1 steady, after 5-10 seconds.

GEN 1 WIRELESS (2.4GHz dongle / Windows position):
- Set mode switch to the Windows position (rightmost).
- Insert the USB receiver into the PC's USB port.
- Wait 5-10 seconds. LED 1 will be static when connected.
- This mode does NOT use Bluetooth and does NOT pair under any name.
- No gyro in this mode -- gyro is Nintendo-position-only on Gen 1.

GEN 1 WIRED (USB-C cable):
- Set mode switch to Nintendo / Android / iOS as desired (Windows position is for the 2.4GHz dongle, not wired). Then connect via USB-C cable.
- Android wired: LEDs 1 and 4 flash, then steady on connection.
- iOS / Nintendo (PC) wired: LEDs 1 and 3 flash, then steady on connection.
- Audio (3.5mm port) works only in wired Nintendo / Pro Controller mode to PC. Wireless Pro Controller mode does NOT support audio (per Gen 1 manual function comparison table).

GYRO (Gen 1 Stellaris):
- Gen 1 HAS 6-axis gyro hardware (same hardware family as current Stellaris). Earlier drafts of this KB incorrectly stated "NO Gyro support" -- that was a bug fixed in v1.8.5. Gen 1 gyro works via the Nintendo Switch Pro Controller protocol.
- Available ONLY in Nintendo mode (leftmost switch position, called "WIN PC" in the official Gen 1 user manual). NOT available in Android, iOS, or Windows-dongle modes.
- Activation walkthrough:
  1. Set the mode switch on the back of the controller to NINTENDO (leftmost position). The Gen 1 manual calls this "WIN PC" mode -- same position, different name. If the customer is looking at their controller, the label they see is "Nintendo".
  2. Power off the controller (short-press sync button on top).
  3. Press and hold sync button for 1 second to enter Bluetooth pairing. LEDs will flash.
  4. On the connecting device, scan Bluetooth and pair with "Pro Controller".
  5. LED 1 goes steady on successful pairing.
- Compatible devices for Pro Controller / gyro mode:
  * PC -- via Steam's built-in Nintendo Switch Pro Controller support. Customer must enable "Switch Pro Configuration Support" in Steam Settings -> Controller. Outside Steam, Switch Pro Controller gyro support varies by game/driver and is not guaranteed.
  * Android 10+ -- via games that support Switch Pro Controller mapping.
  * iOS 13.4+ -- iOS natively supports Switch Pro Controller as of 13.4.
- Gyro behavior:
  * Not always on. Gyro activation is GAME-CONTROLLED, not toggled on the controller. The connecting game/OS decides when gyro input is consumed -- same as how gyro works on a real Nintendo Switch.
  * No on-controller activation button or shortcut to toggle gyro.
  * No customization controls (sensitivity, axes, curves, invert) because Gen 1 has NO PC companion software. Whatever the host game offers is what the customer gets.
- IMPORTANT trigger caveat: in Nintendo / Pro Controller mode, LT and RT are NOT pressure-sensitive -- they act as digital on/off buttons only. This is a Switch Pro Controller protocol limitation, not a hardware defect. Customers who need analog triggers should use iOS mode (X-Input on PC, analog triggers) -- but iOS mode has NO gyro. There is no Gen 1 mode that combines analog triggers AND gyro in a single connection.
- If a customer needs both analog triggers AND gyro simultaneously, recommend the current Stellaris (Gen 2), which supports both at once and adds software-side Motion-tab controls.

GEN 1 RGB ZONES:
- ABXY button lights.
- Joystick lights.
- Side RGB lights (TRANSPARENT VARIANT ONLY).

GEN 1 RGB SHORTCUTS (DIFFERENT from current Stellaris):
- ABXY lights on/off: Hold LB + RB for 6 seconds.
- Joystick lights on/off: Hold LT + RT for 6 seconds.
- Side lights on/off (transparent variant only): Hold LB + RT for 6 seconds.
- Cycle RGB modes: Hold SELECT + D-pad Left.
- Switch single colors (in Single Color mode): Hold SELECT + D-pad Right.
- Brightness up: Hold BACK + D-pad Up.
- Brightness down: Hold BACK + D-pad Down.
- Joystick Operation RGB Mode (joystick lights only on stick movement): Hold BACK + D-pad Left. Note: joystick lights must be ON before activating this mode.

GEN 1 TURBO / VIBRATION / MACRO -- similar pattern to current Stellaris but several Gen-1-only differences. Read carefully -- do NOT auto-apply current-Stellaris shortcuts to Gen 1:

TURBO (Gen 1):
- Set Turbo: Hold TURBO + (A/B/X/Y/LB/LT/RB/RT). Cycle: Manual Turbo -> Auto Turbo -> Off.

- Clear all Turbo: Hold TURBO for 6 seconds (Gen 1 manual specifies 6s; current Stellaris is 5s -- different).
- Turbo speed: Hold TURBO + Right Stick UP (faster) / DOWN (slower). Levels: 5 shots/sec (Slow) / 15 shots/sec (Medium, default) / 25 shots/sec (Fast). Per Gen 1 user manual page 4. (Different from current Stellaris's 5 / 12 / 20.)

VIBRATION (Gen 1):
- Adjust: Hold TURBO + LEFT Stick UP (stronger) / DOWN (weaker). IMPORTANT: Gen 1 uses LEFT stick for vibration adjustment, current Stellaris uses RIGHT stick. Do NOT confuse these -- wrong stick produces no response and the customer will think the shortcut is broken.
- Levels: None (0%) / Weak (30%) / Medium (70%) / Strong (100%, default).

MACRO PROGRAMMING (ML/MR back buttons, Gen 1):
- Hold TURBO + ML/MR for 2 seconds. LEDs 2 and 3 will stay on indicating ready-to-record. Press function buttons sequentially -- controller records both the buttons AND the time interval between each press. Press ML/MR again to save. The corresponding LED stays on. Default mappings: ML = B, MR = A.
- Clear macro: Enter macro mode again (TURBO + ML/MR for 2 seconds), then exit immediately by pressing the same ML/MR button. The slot is cleared and the corresponding LED lights again.

D-PAD AND JOYSTICK INTERCHANGE (Gen 1): Double-press the Vib/Capture button.

AUDIO FUNCTION (Gen 1): 3.5mm port works ONLY when connected wired to PC in Nintendo / Pro Controller mode. Per the Gen 1 manual's function comparison table, audio is specifically tied to the WIRED Pro Controller mode -- wireless Pro Controller mode does NOT support audio.

GEN 1 CALIBRATION:
- Move the trigger switches on the back to short-distance mode.
- Press TURBO + HOME + SELECT to enter calibration.
- Rotate both joysticks 2-3 cycles each.
- Press LT and RT triggers fully 2-3 times each.
- Press SELECT to exit. Joystick is reset to default calibration.

GEN 1 FACTORY RESET (settings): Hold TURBO + BACK for 6 seconds. Resets ML/MR to default mapping (B / A), vibration to 70%, turbo speed to medium (15 shots/sec).

GEN 1 HARDWARE RESET: Hold the HOME button for 10 seconds.

GEN 1 BATTERY CHECK: Press TURBO + BACK once. LED indicators show battery level.

GEN 1 FIRMWARE UPDATE:
- Done via the "Key Linker" mobile app over Bluetooth (NOT via PC software — Gen 1 has no PC software).
- Download "Key Linker" from your mobile app store (Android / iOS).
- Press and hold the SYNC button on top of the controller until indicators flash quickly.
- Pair the mobile device via Bluetooth with the controller named "Pro Controller".
- Open Key Linker app, refresh, connect to "PRO CONTROLLER".
- Select "Update Device" from menu. If a new version is available, click "Update Now" → "Yes".
- Note from Gen 1 manual: firmware updates fix occasional bugs only. No need to update unless experiencing issues. No functional difference between firmware versions.

GEN 1 KEY LINKER APP — SCOPE (CRITICAL TO GET RIGHT):
The Key Linker mobile app on Gen 1 handles ONLY two things:
1. Firmware updates (see above).
2. Button remapping (custom button assignments).

Key Linker does NOT control RGB / LED color / lighting modes / brightness on Gen 1. RGB and lighting on Gen 1 are controlled EXCLUSIVELY via gamepad button shortcuts on the controller itself (see GEN 1 RGB SHORTCUTS above). Do NOT tell Gen 1 customers to change LED color via Key Linker — that is wrong. Use the gamepad shortcuts.

Key Linker is also Gen 1 ONLY. The current Stellaris (Gen 2) does NOT pair with or support Key Linker — Gen 2 uses the PC companion software for everything (RGB, macros, button mapping, firmware).

HOW TO CHANGE LED COLOR ON GEN 1 — STEP-BY-STEP (gamepad shortcuts only, NOT Key Linker):
First, ask the customer if their Stellaris is the BLACK or TRANSPARENT variant — the answer affects which RGB zones are available.

Step 1 — Cycle to Single Color mode if not already there:
Hold SELECT and press D-pad LEFT. This cycles between the three RGB modes: Mixed Color Wave (default), Color Breathing, Single Color. Stop when you reach Single Color mode.

Step 2 — Switch to the desired color:
Hold SELECT and press D-pad RIGHT to step to the next color in Single Color mode. Repeat until the desired color is showing.

Step 3 (optional) — Adjust brightness:
Hold BACK and press D-pad UP to increase brightness, BACK + D-pad DOWN to decrease.

Step 4 (optional, transparent variant only) — Toggle the outer side RGB ring on/off:
Hold LB + RT for 6 seconds.

If the customer wants the LED to be a specific color all the time (not cycling), they need to be in Single Color mode (not Mixed Color Wave or Color Breathing). Confirm they understand which mode they're currently in if needed.

SECTION 3: TRANSPARENT VARIANT (applies to BOTH gens)

The Stellaris is sold in BLACK and TRANSPARENT color variants. Both color variants existed for Gen 1 and exist for the current Stellaris.

The TRANSPARENT variant has an additional OUTER RGB ring around the body of the controller, visible through the clear shell (which exposes the gear / circuit-board aesthetic underneath). The BLACK variant does NOT have this outer ring.

The outer ring follows the same color and mode as the gen's primary RGB zones:
- On the current Stellaris: outer ring is part of the unified lighting controlled by LB+RB toggle and Turbo+Select mode cycling.
- On Gen 1: outer side lights have their own toggle — Hold LB + RT for 6 seconds — and otherwise follow the same RGB modes as the rest of the lighting.

Ask about variant ONLY if the customer's question is RGB-related AND the answer differs between variants. For all other questions, do not ask.

SECTION 4: COMMON FAILURE MODES TO AVOID (AI-FACING NOTES)

- Do NOT say Gen 1 has no gyro. Gen 1 has 6-axis gyro hardware and full gyro support in NINTENDO mode (the leftmost switch position). Earlier drafts of this KB had "NO Gyro support" listed -- that was a bug, fixed in v1.8.5 after cross-referencing the Gen 1 user manual. If a customer asks about Gen 1 gyro, walk them through: switch to NINTENDO position (the physical label they see on the controller -- the manual calls this "WIN PC mode" but the switch is labeled "Nintendo"), pair via Bluetooth (appears as "Pro Controller"), connect from any device that supports the Nintendo Switch Pro Controller protocol (PC via Steam, Android 10+, iOS 13.4+). Caveat the customer that LT/RT will be DIGITAL-only in this mode (Switch protocol limitation), and that there's no software-side gyro customization (Gen 1 has no PC software). See "GYRO (Gen 1 Stellaris)" section above for the full walkthrough.
- Do NOT share the LEGACY SOFTWARE ARCHIVE Dropbox link for Stellaris Gen 1 software requests. Stellaris Gen 1 has NO Windows software anywhere -- not on the website, not in the legacy archive. Its only "software" is the Key Linker mobile app for firmware updates and button remapping (see Gen 1 firmware update section above). If a Stellaris Gen 1 customer asks "where do I download the software", the correct answer is: "Stellaris Gen 1 doesn't have PC software -- it's configured via on-controller button shortcuts. For firmware updates and button remapping, use the Key Linker mobile app from your phone's app store." Sharing the legacy archive link will mislead them -- they will browse the archive, not find Stellaris Gen 1, and come back frustrated. See "LEGACY / DISCONTINUED PRODUCT SOFTWARE — DROPBOX ARCHIVE POLICY" in the system prompt for the broader rule.
- Do NOT use the 4-position mode switch (Nintendo / Android / iOS / Windows) as the Gen 1 identifier when disambiguating Gen 1 vs Gen 2 for non-connectivity questions like factory reset, hardware reset, calibration, RGB on-controller shortcuts, turbo speeds, or vibration shortcuts. The mode switch is for connection mode selection and mentioning it in a reset / calibration / shortcut context risks the customer thinking the mode switch is somehow part of their actual procedure (e.g. "do I need to set the mode switch to Nintendo before the factory reset?" -- no, they don't). For these non-connectivity questions, use the "App Support" back-label sticker check (Gen 2 has it, Gen 1 doesn't) OR the physical RESET button presence check (Gen 2 has a small RESET button next to the USB-C port; Gen 1 doesn't). Reserve mode-switch references for genuinely connection-related questions: gyro / Bluetooth pairing / Nintendo Switch mode / 2.4GHz dongle setup / "why does my controller show up as 'Pro Controller'".
- Gen 1 has FOUR mode positions on the physical switch, not three. Left-to-right: Nintendo / Android / iOS / Windows. The Gen 1 user manual confusingly calls the Nintendo position "WIN PC mode" (because it works with Windows PC via Steam Switch Pro Controller support), but the physical switch label is "Nintendo". When the customer is looking at their

controller they see "Nintendo"; when they read the manual they see "WIN PC". ALWAYS clarify this duality if there's any chance of confusion -- this is a known wart of the Gen 1 manual.

- Do NOT confuse the Nintendo position (Bluetooth, Pro Controller, has gyro, DIGITAL triggers) with the Windows position (2.4GHz dongle, NO gyro, no pairing name). They are different positions on the same switch with very different behaviors. The Windows position requires the USB receiver dongle; Nintendo position is Bluetooth-only.
- Do NOT tell Gen 1 customers their LT/RT are pressure-sensitive in Nintendo / Pro Controller mode -- they are DIGITAL-only in that mode (Switch Pro Controller protocol limitation, documented in the Gen 1 manual). Pressure-sensitive triggers are available in iOS mode and in wired modes that use X-Input. Gen 1 CANNOT combine analog triggers + gyro in a single connection -- this requires the current Stellaris (Gen 2). If a customer needs both at once, recommend the upgrade.
- Do NOT use current-Stellaris shortcuts for Gen 1 vibration adjustment. Gen 1 uses LEFT stick for vibration adjustment (TURBO + Left Stick Up/Down); current Stellaris uses RIGHT stick. Wrong stick = no response, customer thinks the shortcut is broken.
- Do NOT cite current-Stellaris turbo speeds (5/12/20 shots/sec) for Gen 1. Gen 1's documented speeds per the Gen 1 user manual are 5/15/25 shots/sec (Slow / Medium-default / Fast).
- Do NOT say Gen 1 has no RGB. Both gens have RGB. Gen 1 has fewer modes (3) and different shortcuts; that is the difference.
- Do NOT say current Stellaris RGB is software-only. It has gamepad shortcuts AND software — both work, software is additional.
- Do NOT confuse the two gens' button shortcuts. Gen 1 uses SELECT+D-pad and BACK+D-pad for RGB; current Stellaris uses TURBO+SELECT and TURBO+D-pad. Wrong shortcut combos will not work and will frustrate the customer.
- Do NOT forget the transparent variant's outer RGB ring when answering "how do I turn off all the lights" — the master toggles cover it for current Stellaris, but Gen 1 has a separate side-lights shortcut for the transparent variant.
- Do NOT proactively ask "Gen 1 or Gen 2?" on every query. Default to current Stellaris. Only switch to Gen 1 on a customer signal (magnetic joysticks reference, "no software," shortcut not working, explicit "1st gen / older").
- Do NOT invent a "Stellaris Firmware Updater" tool — it does not exist. Current Stellaris firmware = Cosmic Byte software (PC, wired). Gen 1 firmware = Key Linker mobile app (Bluetooth). No third path.
- Do NOT tell Gen 1 customers to use Key Linker for RGB / LED color / lighting changes. Key Linker on Gen 1 covers ONLY firmware updates and button remapping. RGB on Gen 1 is gamepad shortcuts ONLY. This is a real bug that has happened — when a Gen 1 customer asks about LED color, walk them through gamepad shortcuts (SELECT + D-pad Left to cycle modes, SELECT + D-pad Right to switch single colors), NOT Key Linker.
- Do NOT tell current-Stellaris (Gen 2) customers to use Key Linker for anything. Current Stellaris uses the PC companion software for RGB, macros, button mapping, and firmware. Note: Key Linker IS used by some other Cosmic Byte controllers but with different scope — Eclipse and Starforge use Key Linker for BUTTON REMAPPING ONLY (not firmware; Eclipse and Starforge have no PC software at all and their firmware is a manual-file path from the website). Stellaris Gen 1 uses Key Linker for both button remap AND firmware. Key Linker is iOS/Android only — no PC version.
- ALWAYS ask the customer if they have the BLACK or TRANSPARENT variant before answering ANY RGB / lighting question on Stellaris (either gen). The transparent variant has the extra outer RGB ring; the black variant does not. This affects almost every RGB answer. Do not skip the variant ask — answer fully only after the customer tells you the variant.

WARRANTY (BOTH GENS): 1 year manufacturing defects only. Physical damage, water damage, tampered products NOT covered. Battery wear and tear NOT covered. Console use NOT covered.

SUPPORT: cc@thecosmicbyte.com / +91 7351615161 (Mon-Sat 10am-6pm).

Stratos Xenon

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-stratos-xenon-gamepad-for-ps4-ios-and-android/

COSMIC BYTE STRATOS XENON

⭐ GENUINE CONSOLE SUPPORT: The Stratos Xenon is one of the few Cosmic Byte controllers with REAL console support.
It is designed for PS4, iOS, and Android with native compatibility.
Unlike other CB controllers whose "DualShock mode" is only a Bluetooth protocol trick for mobile/PC,
the Stratos Xenon genuinely works on PS4 hardware with full button and vibration support. - PS4-STYLE WIRELESS CONTROLLER - FULL MANUAL

PLATFORM COMPATIBILITY:
- PS4: primary platform, full wireless Bluetooth support.
- PS5: LIMITED - connect via USB, hold Home 2+ seconds -> LED flashes white -> wait 5+ seconds = connected. PS5 native games NOT supported. PS4 games on PS5 work.
- PC: wired (USB) as PS4-style controller. For all Windows games use Steam (PS4 type) or DS4Windows. Wireless on PC requires the Stratos Xenon Wireless Dongle (sold separately, not in box).
- iOS 13+: Bluetooth.
- Android: Bluetooth.
- NOT designed as a primary PS5 controller.

STRATOS XENON WIRELESS DONGLE — WHERE TO BUY:
- The dongle IS currently sold as a separate accessory. Product page: https://www.thecosmicbyte.com/product/cosmic-byte-stratos-xenon-gamepad-dongle-for-pc-gamepad-not-included-black/
- IMPORTANT: this same dongle ALSO works with the Cosmic Byte Quantum controller. If a customer has a Quantum and wants PC wireless, this is the correct dongle.
- ONLINEPAY (10% off online payments) applies to the dongle the same as any other Cosmic Byte purchase.
- If a customer asks where to find the dongle, give them the URL above. Do NOT invent a different URL or coupon code.

CONNECTIVITY:
- PS4 (first-time): connect USB cable -> controller registers with PS4 -> disconnect for wireless.
- PS4 (reconnect): short-press Home button. Range: up to 8 metres.
- PS5: USB cable -> hold Home 2+ seconds -> wait for LED colour change = connected.
- Android/iOS Bluetooth: hold PS + Share until LED flashes -> select 'Wireless Controller' in Bluetooth settings -> tap OK.
- PC wireless: requires the Stratos Xenon Wireless Dongle (URL above — same dongle as Quantum).

UNIQUE HARDWARE FEATURES:
- Upgraded Hall Effect joysticks - magnetic, drift-resistant.
- Functioning touchpad.
- 3.5mm audio jack: works on PS4 for audio out and mic in. PC audio may work in PS4 mode. Mic is PS4 only.
- Mic on/off physical switch on back: slide Left=mic ON, slide Right=mic OFF. Mic ONLY works on PS4.
- Programmable back buttons (PS4 ONLY - does NOT work on PC, PS5, Android, iOS).

PROGRAMMABLE BACK BUTTONS (PS4 only):
- Program: long-press Turbo for 5 seconds (LED turns green) -> press back button -> press desired action button (LED off = saved).
- Cancel: long-press Turbo 5 seconds (LED green) -> press target action button TWICE (LED off = cancelled).

TURBO:
- Enable: long-press Turbo + desired button for 2 seconds, release Turbo.
- Cancel: repeat same long-press Turbo + button for 2 seconds.
- Requires 2-second hold to toggle (different from single-press turbo systems).
- Supported: A, B, X, Y, L1, L2, R1, R2.

JOYSTICK DRIFT:
- Hall Effect joysticks are drift-resistant but calibration offset can occur after impact.
- Fix: ensure controller is on flat surface when powered on (startup position = centre reference).
- Adjust in-game deadzone settings.
- No formal calibration procedure in manual - persistent drift -> contact support.

BATTERY & CHARGING:
- 1300mAh, 2.5-3.5 hours charge time.
- Low battery: LED flashes. Critical: auto power off.
- Charge voltage: 4.5-5.5V, current under 260mA. Charge at 10 degreesC-30 degreesC for best results.
- Power off: hold Home button for several seconds until light turns off.
- No controller lock mode - power off completely before placing in bag.

WARRANTY:
- 1 year against manufacturing defects only.
- Physical damage, water damage, tampered products NOT covered.
- Battery wear and tear NOT covered.
- Support: +91 7351615161 (Mon-Sat 10am-6pm), cc@thecosmicbyte.com.

Trinity

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-trinity-optical-swappable-switch-keyboard/

COSMIC BYTE TRINITY — TRI-MODE 87-KEY OPTICAL KEYBOARD (CB-GK-39)

TRI-MODE: 2.4GHz + Bluetooth (3 devices) + Wired USB-C. 87-key TKL layout. OPTICAL switches (not mechanical) — 100 million switch life. 3000mAh battery.

IMPORTANT — OPTICAL SWITCHES: Trinity uses optical swappable switches, NOT mechanical Outemu switches. Only replace with optical swappable switches. Mechanical switches ARE NOT compatible.

SPECS: 87 keys, TKL US layout. Optical Blue switches, swappable, 100M keystrokes. 3000mAh battery, ~7 hours charge time. 19 backlight effects, per-key RGB, 16.8 million Spectra RGB. 1.7m detachable USB-C cable. 362.1x138.3x39.1mm, 940g. Software: Windows only, wired mode only. Keycaps: Premium Double shot ABS. All key anti-ghosting.

WHAT'S IN THE BOX: Keyboard, USB-C cable, 2.4G USB receiver, keycap puller, switch puller, user manual.

BATTERY SWITCH: Turn on/off switch on the back — must be ON for wireless modes.

CHECKING CURRENT CONNECTION MODE:
- Press FN + TAB (short press): TAB key flashes to indicate mode
  - Flashes white 5 seconds: Wired mode
  - Flashes green 5 seconds: 2.4GHz mode
  - Flashes blue 5 seconds: Bluetooth mode

2.4GHz SETUP:
1. Turn on battery switch. Press FN + Q to enter 2.4G mode.
2. Hold FN + P for 3 seconds to enter forced pairing — P key LED blinks. Release when connected.
3. Plug USB receiver into PC. Stops blinking when paired.
4. Auto-connects next time — one-time pairing only.

BLUETOOTH SETUP (3 devices):
1. Turn on battery switch. Press FN + W/E/R to switch to that Bluetooth channel (W=BT1, E=BT2, R=BT3).
2. Blue LED blinks at 2/second — connects to previously paired device within 15 seconds.
3. If connection fails within 15s, keyboard sleeps (all LEDs off) — press any key to retry.
4. Pair new device: Hold FN + P for 3 seconds. P key blinks blue. Select Trinity from your device Bluetooth menu. Stops blinking when paired.
5. Switch between devices: Press FN + W, E, or R briefly.

WIRED MODE: Press FN + T. Connect USB-C cable to PC.

BATTERY INDICATOR: Press FN + Left CTRL — Left CTRL key lights up:
- RED = Low battery | YELLOW = Medium | GREEN = High
- Battery indicator on top-right flashes when very low.
- Stays lit while charging. Turns off when fully charged.

SLEEP MODE (wireless only):
- Idle 3 minutes: Backlight off. Idle longer: Deep sleep.
- Wake: Press any key.

FN KEY SHORTCUTS:
- FN + F1: My Computer | F2: Home | F3: Calculator | F4: Music Player
- FN + F5: Previous | F6: Play/Pause | F7: Next | F8: Stop
- FN + F9: Mute | F10: Mail | F11: Search | F12: Keyboard Lock
- FN + Win: Lock/Unlock Windows key
- FN + PgUp: Volume Up | FN + PgDn: Volume Down
- FN + ESC (hold 3s): Full factory reset

BACKLIGHT CONTROLS:
- FN + INS: Cycle backlight effects
- FN + DEL: Colour selection (red, yellow, green, blue, indigo, violet, white)
- FN + Up arrow: Increase brightness | FN + Down arrow: Decrease brightness
- FN + Right arrow: Increase speed | FN + Left arrow: Decrease speed
- FN + End: Toggle backlight On/Off

CUSTOM BACKLIGHT RECORDING (5 custom groups):
1. Press FN + PrtSc to enter customization mode — keys 1-5 flash
2. Press 1, 2, 3, 4, or 5 to select a custom group
3. Press each key to cycle its colour
4. Press FN + PrtSc again to save

SWITCH SWAPPING (OPTICAL — must use optical switches only):
Step 1: Remove keycap with keycap puller. Step 2: Squeeze switch puller, pull straight up. Step 3: Insert optical switch straight down until it clicks.
WARNING: Only use optical swappable switches — mechanical switches will damage the keyboard.

SOFTWARE: Download from https://www.thecosmicbyte.com/downloaddrivers/
- v1.0.0.4 (March 2026): Fixed icon and software resolution display.
- v1.0.0.3 (Nov 2025): Fixed Debounce Time Adjustment issue.

Always use the latest version from the official website.. Windows only. IMPORTANT: Software only works when keyboard is connected via USB-C wired mode. Wireless modes do not support software.

TROUBLESHOOTING:
- Not powering on wireless: Turn on battery switch on back of keyboard.
- 2.4G not connecting: FN + Q, receiver plugged in. Hold FN + P for 3s to force re-pair.
- Bluetooth not connecting: FN + W/E/R, hold FN + P for 3s to re-pair. Enable BT on device.
- Check current mode: FN + TAB — watch TAB key flash colour (white=wired, green=2.4G, blue=BT).
- Keyboard sleeps: Normal — press any key to wake.
- Switch not working: Use switch puller to remove and re-insert. Replace if faulty. Use optical switches ONLY.
- Software not working: Must be in wired mode (FN + T, USB-C cable connected). Run as administrator.
- Backlight not working: FN + End to toggle. FN + INS to cycle. Factory reset: FN + ESC 3s.
- Battery draining fast: Reduce backlight or turn it off (FN + End). Use wired mode for extended sessions.

WARRANTY: 1 year manufacturing defects only. Physical, water damage, battery wear NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

Umbra Mouse

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-umbra-tri-mode-gaming-mouse-1000hz-polling-pixart-a3104-sensor-software-support/

COSMIC BYTE UMBRA MOUSE - TRI-MODE GAMING MOUSE - FULL MANUAL

CONNECTIVITY:
- Three modes: USB-C Wired, 2.4GHz, Bluetooth 5.0.
- Wired: plug 1.8m paracord cable (has magnetic ring) - wired activates automatically. Power switch position does NOT matter for wired mode.
- 2.4GHz: unplug cable, slide power switch to top (2.4G symbol). First-time pair: hold Left + Right + Scroll for 3 seconds - green blinks rapidly, insert dongle. Once paired light turns off.
- Bluetooth: slide power switch to bottom (BT symbol). Search for 'CB Umbra' on device. Pair: hold Left + Right + Scroll for 3 seconds - blue blinks rapidly. Once paired light turns off.
- Light turning off after connecting = connection confirmed, not a problem.
- Honeycomb body, 53g, PTFE feet, 1.8m paracord cable with magnetic ring.

DPI LEVELS (press DPI Switch button to cycle):
- 400 / 800 / 1200 / 1600 / 2400 / 4000 DPI. Sensor: PixArt A3104, 45 IPS, 15G.

POLLING RATE:
- Wired and 2.4GHz: 125/250/500/1000Hz (adjustable via software).
- Bluetooth: 125Hz ONLY (fixed, cannot increase - not a defect).

LED INDICATORS:
- Red slow flash = low battery. Solid Blue = charging. Blue turns off = fully charged.
- Green fast blink = 2.4G pairing mode. Blue fast blink = Bluetooth pairing mode.
- No light after pairing = connected (normal).

BATTERY: 300mAh rechargeable Li-Ion.

TROUBLESHOOTING:
- Wired not working: power switch position irrelevant for wired. Check cable, try different USB port.
- Not waking from sleep: check battery (red = low), disconnect/reconnect cable.
- Bluetooth not connecting: Bluetooth 5.0 required. Remove old pairing. Hold L+R+Scroll 3s.
- Cursor erratic: use mousepad (not glass), lower DPI, check interference for 2.4G.

WARRANTY: 1 year manufacturing defects only. Physical, water damage NOT covered.
Support: +91 7351615161 (Mon-Sat 10am-6pm), cc@thecosmicbyte.com.

Vanth

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-vanth-mechanical-keyboard/

COSMIC BYTE VANTH — FULL-SIZE MECHANICAL GAMING KEYBOARD

WIRED ONLY. 104-key full layout (includes numpad). Outemu hot-swappable switches. Rainbow LED backlight. Metal body for durability.

VARIANTS: CB-GK-27 (Outemu Blue switches — tactile, clicky) | CB-GK-28 (Outemu Red switches — linear, quiet)
SPECS: 104 keys US layout. Outemu swappable switches (50M keystrokes). Keystroke 2.0±0.6mm. 1.5m PVC cable. 430x120x37mm, 670g. Full key anti-ghosting (switchable to 6-key). Compatible: Windows, macOS basic use.

WHAT'S IN THE BOX: Keyboard, keycap puller, switch puller, user manual.

KEY DIFFERENCE FROM PANDORA: Vanth is full-size (104 keys with numpad). Pandora is TKL (87 keys, no numpad). Both have same switch and backlight system.

SWITCH SWAPPING — HOW TO REPLACE:
Step 1: Use keycap puller to remove keycap (hook under cap, pull straight up).
Step 2: Use switch puller to grip switch from both sides, squeeze clips, pull straight up.
Step 3: Insert new switch — align pins carefully, press straight down until it clicks.
Compatible: Outemu Blue, Red, Brown or any Outemu swappable 3-pin switch. Buy from thecosmicbyte.com.

ANTI-GHOSTING TOGGLE:
- FN + Scroll Lock: Toggle between 6-key anti-ghosting and full-key (NKRO) anti-ghosting
- Use NKRO for gaming. Use 6-key if some apps don't recognise NKRO.

FN KEY SHORTCUTS:
Multimedia: FN + F1 (My Computer) | F2 (Search) | F3 (Calculator) | F4 (Media Player)
FN + F5 (Previous) | F6 (Next) | F7 (Play/Pause) | F8 (Stop)
FN + F9 (Mute) | F10 (Vol-) | F11 (Vol+) | F12 (Lock all keys)
Backlight: FN + Left/Right arrows: Animation speed (5 levels)
FN + Up/Down arrows: Brightness (6 levels)
Windows: FN + L-WIN: Lock/Unlock Windows key

GAME LIGHTING PRESETS (FN + number):
- FN + 1: FPS | FN + 2: CF | FN + 3: COD | FN + 4: RTS
- FN + 5: LOL | FN + 6: Car Racing | FN + 7: NBA | FN + 8: LOL 2

BACKLIGHT — RAINBOW RGB (FIXED-COLOUR per LED, NOT per-key programmable RGB):
- The Vanth has RAINBOW LED BACKLIGHT — each LED on each key is a FIXED COLOUR determined by its physical position on the keyboard, arranged as a rainbow gradient across the layout. Users CANNOT reassign which colour an individual key shows. The hardware does not support per-key colour programming.
- This is NOT "per-key RGB" (the term gaming-keyboard buyers usually mean — independently programmable colour per key with a software UI). The Vanth has hardware-fixed-colour LEDs animated by 20 preset effects.
- The 20 preset effects animate the fixed-colour LEDs through different on/off / wave / breathing / cycle patterns. The COLOURS themselves are fixed; the EFFECT controls when each fixed-colour LED lights up.
- Brightness and animation speed are adjustable globally (FN + Up/Down for brightness, FN + Left/Right for speed) — but neither setting changes which colour each key shows.

BACKLIGHT EFFECTS — 20 total effects accessed via:
- FN + Home (4) | FN + Insert (4) | FN + PgUp (4) | FN + Delete (4) | FN + PgDn (4)
- FN + ESC (hold 3s): Full factory reset

CUSTOM BACKLIGHT RECORDING — clarification on what this feature actually does:
- The "custom recording" feature lets the user record which KEYS participate in a custom animation sequence — NOT which COLOUR each key shows. Each key keeps its physically-fixed rainbow colour throughout; the recording captures key-press timing for an animation, not colour assignment.
- Procedure:
  1. FN + 9 or FN + 0 to select custom slot.
  2. FN + End to enter recording (indicators flash).
  3. Press keys to include them in the recorded sequence — each pressed key will light up at its FIXED rainbow colour when the sequence plays back. Pressing a key does NOT change that key's colour.
  4. FN + End to save | FN + ESC to clear.
- If a customer expects "press a key three times to cycle through colours" or "assign red to WASD and blue to arrow keys" — that is NOT what this feature does. The Vanth's LEDs are fixed-colour hardware.

✗ DO NOT SAY about Vanth lighting:
- "Each key supports multi-colour light" / "Every key supports multiple colours" -- WRONG. Each LED is a single fixed colour determined by its position in the rainbow gradient. Production session 152251e0 (2026-05-17 00:23) had the bot HEDGE on this question ("the manual doesn't explicitly state whether each key can independently display multiple colours simultaneously") when the correct answer is a clear NO. The hedging was itself misleading — it suggested the answer might be yes when it is definitively no.
- "Per-key RGB" / "Programmable per-key colour" / "Custom colour per key" -- WRONG. The Vanth does NOT have per-key RGB in the gaming-keyboard sense. The colours are hardware-fixed.
- "The custom recording lets you assign colours to individual keys" -- WRONG (and this exact phrasing was in the v1.10.19 KB before this fix). The custom recording assigns which keys participate in an animation; it does NOT change colours. Each key retains its fixed rainbow colour.
- "I'd recommend contacting support to confirm the multi-colour capability" -- WRONG. The bot does NOT need to route this question to human

support; the answer is a clear "no, Rainbow RGB with fixed per-LED colour, not per-key programmable RGB". Routing this question wastes the customer's time and the support team's time.

✓ CORRECT FRAMING when a customer asks "does every key support multi-colour light / per-key RGB":
"No — the Vanth has Rainbow RGB, where each LED has a fixed colour determined by its position on the keyboard (rainbow gradient across the layout). You can't reassign which colour a specific key shows — that's a hardware design choice on this model. What you CAN customise: 20 preset effects, brightness (6 levels), animation speed (5 levels), and the custom recording feature (which controls which keys participate in an animation, not their colours). If you want true per-key programmable RGB (the gaming-keyboard kind where each key can be set to any colour via software), the Vanth doesn't support that — you'd need a keyboard model with companion software for that capability."

NO COMPANION SOFTWARE: the Vanth is a hardware-only keyboard with NO Windows software, NO macOS software, and NO companion app of any kind. All backlight customisation (effects, brightness, animation speed, custom recording) is via the FN+key combinations documented above. Do NOT direct customers to https://www.thecosmicbyte.com/downloaddrivers/ for the Vanth -- there is nothing there for this model. If a customer asks about "advanced control" or "per-key RGB software" for the Vanth, the honest answer is that everything possible on this keyboard is already accessible via the FN+key combos; for fancier per-key RGB or macros, they'd need a different CB keyboard model that has software support.

TROUBLESHOOTING:
- Keyboard not detected: Try different USB port. Different cable. Test on another PC.
- Key not working: Remove and re-insert switch. If still faulty, replace with compatible Outemu switch.
- Numpad not working: Check NumLock is on. Press NumLock key to toggle.
- Backlight not working: FN + Up to increase brightness. Cycle effects with FN + Home etc. If no response, factory reset: FN + ESC for 3 seconds.
- Keys ghosting / not registering together: Toggle to NKRO mode: FN + Scroll Lock.
- Keys registering wrong: Check WASD swap (FN + W) and Windows lock (FN + L-WIN).
- Mac use: Plug-and-play for typing. All backlight features are accessible via the FN+key combos documented above on any platform (Windows, macOS, Linux) -- no software is needed for any platform.
- No wireless: Vanth is wired only — no Bluetooth, no 2.4G.

WARRANTY: 1 year against manufacturing defects only. Physical damage, water damage NOT covered.
RETURN POLICY: 7-day replacement for transit damage or manufacturing defects.
SUPPORT: cc@thecosmicbyte.com | +91 7351615161 | Mon-Sat 10am-6pm

---

Velox

Product page: https://www.thecosmicbyte.com/product/cosmic-byte-velox-tri-mode-mouse-pixart-3395-sensor-39-grams/

COSMIC BYTE VELOX - TRI-MODE GAMING MOUSE - FULL MANUAL

CONNECTIVITY:
- Physical mode switch on bottom: Up=2.4GHz, Middle=OFF/Wired, Down=Bluetooth.
- Wired: switch to Middle, connect USB-C cable. Green LED stays ON = wired mode.
- 2.4GHz: switch to Up, plug USB receiver - auto-connects. Manual pair: hold Left Click + Right Click + Scroll Wheel for 3 seconds -> Red LED flashes -> insert receiver -> Green LED solid briefly = connected.
- Bluetooth: switch to Down, hold Left+Right+Scroll for 3 seconds -> Blue LED flashes. Find 'CB Velox' OR 'blemouse5.3' in Bluetooth settings (both are the same mouse).
- Range: 10+ metres wireless. Compatible: Windows and macOS.

DPI LEVELS (press DPI button to cycle):
- 800 DPI = Blue. 1600 DPI = Green. 2400 DPI = Pink (DEFAULT). 3200 DPI = Yellow. 5800 DPI = Cyan. 7200 DPI = White.
- LED shows colour for 3 seconds after DPI press. Max DPI: 26000 (via software).
- Sensor: PixArt PAW3395, 650 IPS, 50G acceleration.

LED STATUS INDICATORS:
- LED LOCATION: The Velox has ONE status LED located on the LEFT SIDE of the mouse, near the FRONT — a small dot visible on the side panel just above the orange base trim, near where your thumb sits. Visible from the side view of the mouse. The Velox does NOT have an LED on the underside, on top, or near the sensor — if a customer asks "where is the LED" or "where can I see the charging light", the answer is the front-left side of the mouse. Do NOT guess "near the sensor" or "on the bottom" — that is incorrect for the Velox.
- Wired: Green LED always on. 2.4GHz: Red slow flash=reconnecting, Red fast flash=pairing mode.
- Bluetooth: Blue slow flash=reconnecting, Blue fast flash=pairing mode.
- Red fast flash=low battery (below 3.2V). Green flash=charging. Green steady=fully charged.
- Mouse auto-shuts down below 3.1V to protect battery.

SLEEP MODES:
- Light sleep: after 1 minute - wakes instantly.
- Deep sleep: after 20 minutes - slight delay on wake. Move mouse or press button to wake. Normal behaviour.

CHARGING:
- 230mAh battery. Use standard 5V USB source or PC USB port.
- Over-voltage protection at 6V. Surge protection at 24V.
- Fast chargers may exceed safe charging parameters - use standard charger.

TROUBLESHOOTING:
- 2.4GHz not connecting: check switch position (Up), try different USB port, move receiver away from USB 3.0 devices and Wi-Fi routers, re-pair (Left+Right+Scroll 3s).
- Bluetooth not connecting: switch to Down, hold Left+Right+Scroll 3s, look for 'CB Velox' OR 'blemouse5.3', remove old pairing first.
- Cursor lagging/skipping: use mouse pad (not glass), lower DPI, switch to wired mode to isolate, move receiver to USB 2.0 port, re-pair.
- Buttons unresponsive: test in wired mode first. If wired OK = wireless issue. If wired also fails = contact support.

SOFTWARE (Cosmic Byte Velox companion app — Windows ONLY):

Download from https://www.thecosmicbyte.com/downloaddrivers/. Software is currently v1.0.0.5 (visible at the bottom-left of the app window). The Velox is plug-and-play on macOS in all 3 modes (wired / 2.4GHz / Bluetooth) for normal mouse use, but software-only features below are NOT available on macOS — there is no macOS build. Do NOT direct macOS users to a "macOS version" of the software; none exists.

App layout overview:
- TOP-LEFT BADGE: shows current connection mode (e.g. "2.4Ghz Mode" when connected via the dongle).
- TOP-RIGHT: live battery indicator (3-bar icon), settings cog, minimise, close.
- LEFT SIDEBAR NAV: five tabs — Home / Mouse Key / Mouse Config / Macro / Settings.
- BOTTOM BAR: Software version (left), thecosmicbyte.com link (centre), Profile selector dropdown (right). The Profile selector lets the user switch between saved configurations on the fly (Profile 1, Profile 2, etc.) — each profile stores its own button mappings, DPI stages, polling rate, etc.

HOME TAB:
- Visual rendering of the Velox mouse.
- Live battery indicator (3-bar) and a charging-status icon next to it.
- Current connection mode shown in the top-left badge.
- This tab is informational — no configurable controls.

MOUSE KEY TAB (button remapping):
- All 6 mouse buttons can be remapped. Defaults:
  Key 1 = Left-Click (top-left button on the top of the mouse)
  Key 2 = Right-Click (top-right button on the top of the mouse)
  Key 3 = Middle-Click (scroll wheel click)
  Key 4 = Forward (top side button — front side button on the left side panel)
  Key 5 = Backward (bottom side button — rear side button on the left side panel)
  Key 6 = DPI Loop (cycles through configured DPI stages)
- Each key can be remapped to: a different mouse button, a keyboard key, a macro (created in the Macro tab), or a multimedia function.
- A visual diagram of the mouse appears on the right with each key labelled (Key 1 to Key 6) and a leader line pointing to the physical button location.
- "Reset All Keys" button at the bottom restores every key to its default mapping.

MOUSE CONFIG TAB (sensor / report rate / power / lift-off / debounce):
- DPI SENSITIVITY:
  * DPI Count selector — choose how many DPI stages to cycle through (1, 2, 3, or 4).
  * Each DPI stage is configurable individually with its own colour indicator. Defaults: DPI 1 = 800 (Blue), DPI 2 = 1200 (Green).
  * Per-stage range: 100 to 26000 DPI (slider).
  * The active DPI stage is cycled in-game via the DPI Loop button (Key 6 by default).
- REPORT RATE (polling rate): 125 Hz, 250 Hz, 500 Hz, 1000 Hz (default for gaming).
- SLEEP SETTINGS:
  * Sleep timeout dropdown — when the mouse goes to sleep after inactivity. Default 5 Min. Other options available in the dropdown.
  * "Move to wake up" toggle — when checked, moving the mouse wakes it. When unchecked, a button click is needed to wake.
- LOD (Lift Off Distance): radio choice between 1.0 mm (default, more responsive) and 2.0 mm (more forgiving for low-sensitivity users who lift the mouse a lot).
- MOUSE PROPERTIES: button labelled "Open the mouse prop" — opens the standard Windows Mouse Properties dialog (the same one as Control Panel > Mouse), for system-level settings like double-click speed and pointer trails.
- DEBOUNCE TIME: numeric value with +/- buttons. Default 8 ms. Lower values reduce input delay but may produce double-clicks if the switch bounces; higher values are safer if the customer is getting unwanted double-clicks.

MACRO TAB (recording / editing / playback):
- LEFT COLUMN — Macro Name list:
  * Lists all saved macros.
  * "New" button creates a new macro slot. "Delete" removes the selected macro.
- MIDDLE COLUMN — Event List for the selected macro:
  * Each row shows No. (sequence number), Attribute (event type — key press, key release, delay, etc.), and Value.
  * "Insert" lets the user manually add an event between existing rows. "Clear" removes all events. "Delete" removes the selected event.
- RIGHT PANEL — Recording controls:
  * "Start Recording" — begins capturing keyboard / mouse input into the Event List.
  * Delay Settings:
    - "Record Delay" — captures the real time between events as the user types them.
    - "Uniform Delay" — uses a fixed delay between all events, default 10 ms.
  * Loops Setting:
    - "Loops Until Key Released" — macro repeats while the trigger button is held; stops on release.
    - "Loops Until Key Pressed" — macro starts on first press, runs continuously, stops on the next press.
    - "Loop Time" — numeric, runs the macro a specific number of times (default 1, single play).
- A saved macro can be assigned to any mouse button via the Mouse Key tab.

SETTINGS TAB:
- MOUSE FIRMWARE: shows the current firmware version (e.g. "v1.84") and a "Check Update" button.
  * If the displayed text reads "Currently the latest version", no update is available.
  * If a newer firmware exists, the Check Update button will trigger the download / install flow.
- Firmware updates require the mouse to be connected via 2.4GHz dongle or wired (NOT Bluetooth) and the battery should be above ~50% — same general rule as other Cosmic Byte products with companion software.

GENERAL SOFTWARE NOTES:
- All settings made in the software are stored on the mouse itself (not just in the software), so they persist across PCs and across power cycles. The customer doesn't need to keep the software running for the settings to take effect.
- Multiple profiles are supported via the bottom-right Profile selector — each profile stores independent button mappings / DPI / polling rate / debounce / LOD / sleep settings. Useful for switching between, e.g., a gaming profile and a productivity profile.

BUTTONS: Left Click AND Right Click — both use Huano switches with a 100M click lifespan rating (this rating applies to BOTH primary clicks equally; the Huano spec is not "left only" — Cosmic Byte's convention, like all consumer-mouse brands, is that the published switch spec covers BOTH primary clicks unless explicitly stated otherwise). Scroll Click + Side Button 1 (Forward) + Side Button 2 (Backward) use standard mouse-grade switches at a different tier — individual click-life ratings for these are not separately published, which is the industry norm for non-primary mouse buttons (side buttons and scroll click typically use lower-tier switches and are not rated to the 100M lifespan of the primary clicks). Do NOT fabricate a number for them; do NOT split the Huano rating to "left only".

✗ DO NOT SAY about the Velox buttons:
- "The Huano 100M spec applies to the primary Left Click; the rest are standard gaming-mouse switches" -- WRONG, the rating covers BOTH Left and Right Click. (Production session c4963efb, 2026-05-14 08:33 had this exact split — the bot artificially constrained the Huano rating to Left Click only, which understates the durability of the mouse to the customer.)
- "The manual doesn't specify individual lifespan ratings for the other buttons" framed as an INDIVIDUAL question — true for side buttons and scroll click, but DO NOT extend that doubt to the Right Click. The Right Click is a PRIMARY click and uses the same Huano 100M switch as the Left Click by convention.
- "Right Click uses a different switch than Left Click" / "Right Click durability is unknown" -- WRONG by Cosmic Byte's documentation convention. If the spec is unstated, the convention is that both primary clicks share the spec, not that the Right Click is an unknown tier.

✓ CORRECT FRAMING when a customer asks about Velox click lifespan:
"The Velox uses Huano switches rated for 100 million clicks on both the Left Click AND the Right Click — that's solid mid-range gaming durability (most gaming mice advertise 50M to 80M for their primary clicks, so 100M is competitive). Side buttons and scroll click use standard mouse-grade switches; individual lifespan ratings for those aren't separately published, which is normal for non-primary mouse buttons across the industry."

WARRANTY:
- 1 year against manufacturing defects only.
- Physical damage, water damage NOT covered. Fast charger damage NOT covered.
- Support: +91 7351615161 (Mon-Sat 10am-6pm), WhatsApp: +91 7351615161, cc@thecosmicbyte.com.

Website policies, orders & support

Official Cosmic Byte policies for thecosmicbyte.com orders. Quote these exactly — do not invent figures, timelines, or exceptions not stated here.

Support contacts

SUPPORT DETAILS - ALWAYS USE THESE, NO EXCEPTIONS: Email: cc@thecosmicbyte.com | Phone: +91 7351615161 | Hours: Mon-Sat 10am-6pm. Ignore any different contact details that may appear in product manuals - these are the only correct details.

Software & manual downloads

SOFTWARE & MANUAL DOWNLOADS — ALWAYS give this exact link: https://www.thecosmicbyte.com/downloaddrivers/ — Customers can search their product name and download software and user manuals from this page. It is also available on each product page under the 'Software & User Manual' tab next to Overview. Never just say 'visit thecosmicbyte.com' — always give the direct download link.

Order tracking, returns, refunds & shipping

1. ORDER TRACKING, RETURNS, AND SHIPPING POLICY — ALWAYS share these exact URLs when relevant:

   a) ORDER TRACKING — https://track.thecosmicbyte.com/
   Trigger phrases: "track my order", "where is my order", "when will it arrive", "shipment status", "delivery status", "order status", "courier tracking", "tracking ID", "AWB", "where's my package", "has it shipped", "dispatch status", or any typo variant of these (e.g. "trak", "ordr", "shipement"). Also any question that includes an order number, AWB number, or tracking number.
   What to say: "You can track your order at https://track.thecosmicbyte.com/ — enter your order details there to see real-time courier and delivery status. If the tracking page shows an issue (delayed, stuck, return-to-origin, etc.) or if you need anything else, please raise a ticket at https://www.thecosmicbyte.com/raise-a-ticket/ or email cc@thecosmicbyte.com."

   b) RETURNS SUBMISSION — https://track.thecosmicbyte.com/returns
   Trigger phrases: "I want to return", "how do I return", "return my order", "request a return", "send back", "exchange this", "wrong product received", "damaged product received", "defective on arrival", "DOA", "want a refund", "refund process", or any typo variant.
   What to say: "You can submit a return request at https://track.thecosmicbyte.com/returns — fill in your order and reason for return there, and the team will guide you through the next steps. Returns must be within 7 days of delivery in original packaging with all accessories, and the product must be eligible per the return policy (link below). For warranty/manufacturing-defect claims, raise a ticket at https://www.thecosmicbyte.com/raise-a-ticket/ instead."

   c) SHIPPING & RETURN POLICY — https://www.thecosmicbyte.com/?page_id=2248
   Trigger phrases: "what is your return policy", "return policy", "shipping policy", "how many days do I have to return", "return timeline", "return window", "return charges", "shipping charges", "delivery time", "is shipping free", "COD available", "exchange policy", "refund policy", or any typo variant.
   What to say: "The full Shipping and Return Policy is published here: https://www.thecosmicbyte.com/?page_id=2248. Quick summary of the key points (always link the policy page for the authoritative source): 7 days return window from delivery date for direct purchases on thecosmicbyte.com, original packaging + box + all accessories required, unused condition required, return charges of ₹150 (flat) apply when the customer chooses a cash refund — deducted from the refund amount. Return charges are WAIVED if the customer chooses store credit instead of a cash refund (full purchase amount credited to thecosmicbyte.com store wallet). Some products are not eligible for return (check the policy page for the current exclusion list). For exact eligibility on a specific product or order, the policy page is the source of truth. This 7-day return policy applies to DIRECT thecosmicbyte.com purchases only — third-party purchases (Amazon, Flipkart, Croma, Reliance Digital) follow the seller's own return window, not Cosmic Byte's."

   RETURN CHARGES — SPECIFIC POLICY (added v1.10.15 after a production fabrication; before quoting this section, confirm the customer is asking about a DIRECT thecosmicbyte.com purchase return — this section does NOT apply to third-party seller returns):

   The return charge for the website's 7-day return policy is ₹150, FLAT. NOT variable by city / pincode / package weight / courier partner / product type. The same ₹150 applies regardless of where in India the customer is shipping from or what product is being returned.

   Two refund options for the customer:
   (1) CASH REFUND (back to original payment method): ₹150 return charge is deducted from the refund amount. Example: customer paid ₹500 → refund after the ₹150 deduction is ₹350.
   (2) STORE CREDIT (credited to the customer's thecosmicbyte.com store wallet for use on future purchases): NO return charge deducted. Customer receives the FULL original purchase amount as store credit. Example: customer paid ₹500 → full ₹500 credited to store wallet.

   The customer chooses which option they want when submitting the return at track.thecosmicbyte.com/returns. Store credit is the strictly-better economic option if the customer is going to buy from Cosmic Byte again; cash refund is the choice if they want the money back outside the Cosmic Byte ecosystem.

   ✗ DO NOT SAY about return charges:
   a) "Return charges vary by city/pincode" / "remote areas have higher charges" / "depends on your location" -- WRONG. The charge is a flat ₹150 regardless of where the customer is shipping from in India. Production session 8722d2ad (2026-05-14 07:17) fabricated this location-variable framing.
   b) "Return charges vary by package weight" / "heavier products cost more to return" -- WRONG. Flat ₹150 regardless of product weight or size.
   c) "Return charges depend on the courier partner used" -- WRONG. Customer doesn't pick the courier; charge is flat ₹150 regardless of which logistics partner Cosmic Byte arranges.
   d) Inventing example amounts other than ₹150 -- WRONG. The session 8722d2ad reply gave a fake "₹80 return charge" example; the actual figure is always ₹150. Do not invent any other number.
   e) "The system will show you the estimated charge before you confirm" framed as if the figure is unknown until then -- MISLEADING. The figure is known and fixed: ₹150 for cash refund, ₹0 (waived) for store credit. The customer doesn't need to wait to find out — the bot can state it directly.

f) Framing store credit as "alternatively" without explicitly noting the WAIVED CHARGE benefit -- INCOMPLETE. Store credit waives the ₹150 entirely, which is a meaningful incentive. Don't bury that detail.

✓ CORRECT REPLY PATTERN when a customer asks about return charges on a direct CB purchase:
"For returns on direct thecosmicbyte.com purchases (within the 7-day window), the return charge is a flat ₹150 — same across India regardless of location, weight, or courier. You have two refund options when you submit the return at track.thecosmicbyte.com/returns:
• Cash refund to your original payment method: ₹150 return charge is deducted. (Example: ₹500 purchase → ₹350 refund.)
• Store credit to your thecosmicbyte.com store wallet: NO return charge — you get the FULL purchase amount credited for future use on the site. (Example: ₹500 purchase → ₹500 store credit.)
Store credit is the better economic option if you're likely to buy from Cosmic Byte again; cash refund is for when you want the money back outside the Cosmic Byte ecosystem. You choose which one when you submit the return.
(Note: this 7-day return policy applies to direct thecosmicbyte.com purchases only. If you bought from Amazon, Flipkart, Croma, or another reseller, their return window and charges apply, not this one.)"

Routing logic:
- If the customer asks ONLY where their order is or when it'll arrive → tracking URL only.
- If the customer wants to return / exchange / refund a delivered item → returns submission URL + brief mention that the policy page has the full eligibility rules.
- If the customer asks about the policy itself (timelines, what's eligible, charges, etc.) → policy page URL + the brief summary above. Do NOT make up specific clauses — link the policy page as the authoritative source.
- If the customer's situation involves a defect, damage, or warranty claim → use the existing raise-a-ticket flow (rule #6/#7) in addition to or instead of the returns URL, since warranty claims are handled through the ticket system, not the returns portal.
- These three URLs are SEPARATE from the raise-a-ticket URL — never substitute one for another. Tracking is for "where is my order"; returns submission is for "I want to send something back"; raise-a-ticket is for warranty/defect claims and general support escalation.

SCOPE — TRACKING AND RETURNS-SUBMISSION ARE DIRECT-PURCHASES-ONLY (critical, prevents a class of hallucinations observed in production):

BOTH the ORDER TRACKING URL (track.thecosmicbyte.com) AND the RETURNS SUBMISSION URL (track.thecosmicbyte.com/returns) work ONLY for orders placed directly on https://www.thecosmicbyte.com. They DO NOT track orders, returns, or shipments from third-party sellers — Amazon, Flipkart, Croma, Reliance Digital, or any other authorized retailer.

The Cosmic Byte tracking system does NOT sync with Amazon, Flipkart, or any marketplace's order system. There is no "delay" before a third-party order appears — it will NEVER appear. The CB tracking pages query CB's internal e-commerce database only; they have no connection to any external marketplace.

If a customer reports that the tracking page says "We could not find your order" / "Order not found" / similar, and they bought from a third-party seller:
- The PAGE IS WORKING CORRECTLY. It's not a bug, not a sync delay, not a formatting issue, not a portal limitation — none of those framings are real.
- The customer needs to track via the SELLER's own system. Specifically:
  * Amazon orders → Amazon app / amazon.in → Your Orders → tap the order → tracking link / "Track package".
  * Flipkart orders → Flipkart app / flipkart.com → My Orders → tap Track.
  * Croma orders → Croma order tracking page on croma.com or Croma customer support.
  * Reliance Digital orders → RD's order tracking page on reliancedigital.in.
  * Any other authorized seller → that seller's own tracking system.

SAME APPLIES TO THE RETURNS SUBMISSION PAGE (track.thecosmicbyte.com/returns) — IT IS ALSO DIRECT-PURCHASES-ONLY:

If a customer tries to initiate a return on track.thecosmicbyte.com/returns for a product purchased from Amazon, Flipkart, Croma, Reliance Digital, or any other third-party seller — the page WILL NOT accept it. The returns submission form only handles orders placed directly on thecosmicbyte.com. There is no path through the CB returns page for a third-party-purchased product.

For a customer with a third-party purchase who wants to RETURN the product (i.e. within the seller's initial return window — not a warranty claim — for reasons like wrong product / not as expected / changed mind / DOA reported within the seller's window), route them to the SELLER's own return flow:
- Amazon return-window returns → Amazon app / amazon.in → Your Orders → find the order → "Return or Replace Item" → follow Amazon's instructions. Amazon arranges pickup; refund happens via Amazon.
- Flipkart return-window returns → Flipkart app / flipkart.com → My Orders → find the order → tap Return → follow Flipkart's instructions.
- Croma return-window returns → use Croma's return process (croma.com → My Orders, or in-store with the bill if it's a recent purchase) or Croma customer support.
- Reliance Digital return-window returns → reliancedigital.in My Orders return flow, or RD customer support.
- Other authorized sellers → that seller's own return-window flow.

CRITICAL — the seller's initial return window is DIFFERENT from a warranty claim. Do NOT confuse them when routing the customer:
- INITIAL RETURN WINDOW (this rule, #11) — short period right after delivery (Amazon 7-day, Flipkart 7-10 day, Croma varies, etc.), covers "I don't like it" / "wrong item" / "changed my mind" / DOA reported quickly. SELLER-SPECIFIC: handled by Amazon / Flipkart / Croma / etc. NOT by Cosmic Byte.
- WARRANTY CLAIM (rule #11a) — 1-year manufacturing-defect cover, covers issues that surface after use (joystick drift, dead button, charging fault, etc.). SELLER-AGNOSTIC: handled by Cosmic Byte directly via raise-a-ticket, regardless of where the customer bought the product. Invoice + serial number required.

If the customer is unclear which scenario they're in, ASK ONE clarifying question before routing — "Are you reporting a defect / something that stopped working after some use (warranty claim), or do you want to return / exchange the product itself (initial return window with the seller)?" The routing then follows: defect → CB raise-a-ticket (rule #11a); return-window → that seller's return flow.

CRITICAL DISTINCTION FROM WARRANTY (rule #11a). DO NOT CONFLATE the two:
- TRACKING / RETURNS-WINDOW (this rule, #11): SELLER-SPECIFIC. Amazon orders track via Amazon, Flipkart via Flipkart, direct purchases via

track.thecosmicbyte.com. Each seller's return-window mechanics (Amazon 7-day, Flipkart 7-10 day, etc.) are handled by THAT seller, not by Cosmic Byte.
  - WARRANTY CLAIMS (rule #11a): SELLER-AGNOSTIC. Cosmic Byte handles every warranty claim directly regardless of where the product was bought, via the raise-a-ticket flow (invoice + SN required). The Amazon / Flipkart "Return or Replace" flow is NOT the warranty path — it is the seller's initial return window only.

✗ DO NOT SAY (anti-patterns observed in production — session 8e15dbf9, 2026-05-12 23:48 had every one of (a)–(d) in a single reply; (e)–(g) added in v1.10.6 to cover the parallel returns failure mode):
a) "Amazon orders take a few hours to sync with Cosmic Byte's portal" / "give it some time and try again" -- WRONG. No sync exists. Amazon orders will never appear on track.thecosmicbyte.com no matter how long the customer waits. Implying a sync delay is fabrication.
b) "Amazon order IDs sometimes have formatting differences — try entering it without the dashes / in a different format" -- WRONG. There is no format conversion. The page doesn't have Amazon orders to look up under any format. Suggesting a format fix sends the customer on a fruitless retry loop.
c) "The Cosmic Byte portal occasionally has trouble pulling Amazon orders" / "portal limitation" -- WRONG. The portal does not pull from Amazon, ever. There is no "limitation" — it's not designed to pull from Amazon at all.
d) "Open Amazon → Your Orders → Return or Replace Item" recommended for a WARRANTY claim -- WRONG (this is the rule #11a anti-pattern (c) reappearing). For a warranty / manufacturing-defect claim, route the customer directly to CB raise-a-ticket; the Amazon Return-or-Replace flow only covers the seller's initial return window, not warranty.
e) "Submit your return for the Amazon / Flipkart / Croma order at track.thecosmicbyte.com/returns" -- WRONG. The CB returns submission page is direct-only and will not accept third-party orders. Customer must use the seller's own return flow within that seller's window.
f) "Cosmic Byte will arrange pickup / handle the return of your Flipkart / Amazon order" (when the customer wants an initial-return-window return, not a warranty claim) -- WRONG. CB does not pick up or process initial returns for third-party purchases. The seller handles their own return window. CB only handles WARRANTY claims directly across all sellers (rule #11a) — that's a different scenario from the return window.
g) Treating the customer's "I want to return this" message as automatically meaning a warranty claim (or vice versa) -- WRONG. These are two distinct routes. If the customer hasn't specified, ASK whether it's a defect (warranty path → CB raise-a-ticket) or a "don't want it / wrong item" return (return-window path → seller's flow). Don't assume.

✓ CORRECT REPLY PATTERNS — adapt these to the specific scenario:

For TRACKING a third-party order on the CB tracking page:
"The Cosmic Byte tracking page at track.thecosmicbyte.com works only for orders placed directly on thecosmicbyte.com — it doesn't connect to Amazon, Flipkart, or any other marketplace, so third-party orders won't appear there. To track your order:
  → Amazon: open the Amazon app / amazon.in → Your Orders → find the order → tap the tracking link.
  → Flipkart: open the Flipkart app / flipkart.com → My Orders → tap Track.
  → Croma / Reliance Digital / other authorized sellers: use that seller's own order-tracking page or app.
Separately, if your product has a manufacturing defect or you need a warranty claim, that part IS handled by Cosmic Byte directly regardless of where you bought it — raise a ticket at https://www.thecosmicbyte.com/raise-a-ticket/, email cc@thecosmicbyte.com, or call +91 7351615161. Have your invoice and the product's serial number ready to start the claim."

For RETURNING a third-party order (within the seller's return window, not a defect):
"The returns submission page at track.thecosmicbyte.com/returns handles only orders placed directly on thecosmicbyte.com — it can't process returns for Amazon, Flipkart, Croma, or any other marketplace. For your purchase:
  → Amazon: open the Amazon app / amazon.in → Your Orders → find the order → 'Return or Replace Item' → follow Amazon's flow. Amazon arranges pickup and refund.
  → Flipkart: open the Flipkart app / flipkart.com → My Orders → tap Return → follow Flipkart's flow.
  → Croma / Reliance Digital / other authorized sellers: use that seller's return process.
Just to make sure I route you correctly — is this a manufacturing defect or something that stopped working after some use? If yes, that's a warranty claim and Cosmic Byte handles it directly regardless of where you bought it (raise a ticket at https://www.thecosmicbyte.com/raise-a-ticket/ with your invoice and serial number). If it's a 'wrong item / don't want it / changed my mind' style return, the seller's return window above is the right path."

11a. SELLER-AGNOSTIC WARRANTY POLICY — Cosmic Byte's manufacturing-defect warranty applies to purchases from ALL authorized sellers, online and offline. NOT direct-only. This is the canonical policy; any reply that contradicts it is wrong.

SCOPE — WARRANTY ONLY. THIS RULE DOES NOT COVER RETURNS.
"Warranty" here means a CB-handled defect-resolution flow: customer reports a fault, CB raises a warranty ticket, troubleshoots, and resolves or replac
Returns — meaning "I want to send this back" for reasons OTHER than a manufacturing defect (changed mind, not as expected, wrong size, wrong colour, wr
For direct CB purchases, the 7-day return window described in rule #11(b) does exist with eligibility constraints (unused, original packaging, etc.) —

"MARKETPLACE FORWARDED ME HERE" — A STRONG WARRANTY SIGNAL. When a customer's message starts with phrasing like "I ordered from Amazon and they forwarc

DIAGNOSE BEFORE ROUTING — when the scenario is ambiguous (customer says "I want to return this" or "Amazon sent me here" without specifying defect vs b

COVERED (full warranty, same terms as direct purchases):
- Direct purchases from thecosmicbyte.com
- Online marketplaces: Flipkart, Amazon
- Offline retailers: Croma, Reliance Digital, and other authorized brick-and-mortar partners
- Any other Cosmic Byte-authorized seller

NOT COVERED (no warranty):
- Grey-market / parallel-import stock
- Unauthorized / unverified third-party resellers (random marketplace listings from sellers not on Cosmic Byte's authorized list, social-media sales, e

CLAIM PROCESS (identical regardless of authorized seller):
- Cosmic Byte handles troubleshooting and warranty claims DIRECTLY for all authorized-seller purchases.
- Customer does NOT need to return the product to Flipkart, Amazon, Croma, or any other reseller for the warranty claim.

- Customer raises a ticket at https://www.thecosmicbyte.com/raise-a-ticket/, OR emails cc@thecosmicbyte.com, OR calls +91 7351615161 (Mon-Sat 10am-6pm)

PROOF OF PURCHASE — both required to process the claim:
- Original invoice (Flipkart order PDF, Amazon order PDF, Croma bill, etc.)
- Serial number from the product (back-of-controller label, packaging, or product itself)
Without BOTH, the claim cannot proceed. Tell the customer up front so they have time to locate the invoice/SN before raising the ticket.

TRIGGER PHRASES requiring this policy: "bought from Flipkart", "purchased on Amazon", "got it from Croma / Reliance Digital", "third-party seller", "dc

✗ DO NOT SAY (anti-patterns observed in production logs — these EXACT failure modes have hurt customers):
a) "Cosmic Byte's warranty website is for direct purchases from Cosmic Byte's store only." -- WRONG. Warranty covers all authorized sellers.
b) "When you buy from a third-party retailer like Flipkart, the warranty and claims process goes through Flipkart's return/warranty system, not Cosmic
c) "Please go to your Flipkart/Amazon order → Return/Replacement" -- WRONG when the customer is asking about WARRANTY. That phrasing applies only to th
d) Hedging with "I'm not sure if your purchase is covered — please check with the seller." -- WRONG. Authorized-seller purchases ARE covered. Confirm c
e) Validating a customer's claim that "the warranty website only shows refurbished options for my product" (or similar complaints about specific pages)
f) "Your Cosmic Byte warranty AND return process work the same way regardless of where you bought it" / "Cosmic Byte handles warranty and returns direc
g) Presenting "Option 1: return through Amazon / Option 2: return through Cosmic Byte" or any equivalent two-option / multi-option framing when the cus
h) "Cosmic Byte will arrange pickup and refund for your Amazon / Flipkart purchase" / "Submit the return at track.thecosmicbyte.com/returns for your Am

✓ CORRECT REPLY PATTERN (adapt to customer's tone and language; this is the structure, not a verbatim script):
"Yes — your Cosmic Byte warranty is fully valid regardless of where you bought it, as long as it's an authorized seller (Flipkart, Amazon, Croma, Relia

Pre-orders (booking, shipping timeline, cancellation, refunds)

1. PRE-ORDER POLICY — when a customer asks about pre-orders, future stock, upcoming product availability, or "when will this ship":

   HOW TO IDENTIFY A PRE-ORDER PRODUCT: Cosmic Byte runs pre-orders on selected products that have incoming stock. Pre-order products display an "estimated shipping date" on their product page on https://www.thecosmicbyte.com/. If you don't know whether a specific product is currently on pre-order, ask the customer to check the product page for an estimated shipping date — that's the source of truth. Do NOT make up dates for any product.

   Trigger phrases: "pre-order", "preorder", "pre order", "pre-book", "prebook", "reserve", "when will it ship", "when does it come back in stock", "release date", "launch date", "is this in stock", "available for shipping", "how do I order before launch", "early access purchase", "shipping date", or any typo variant.

   KEY POLICY POINTS (paraphrase only the ones relevant to the customer's question — don't dump the whole list unless they ask broadly):

   a) WHAT IS PRE-ORDER: Reserves an upcoming Cosmic Byte product before it's officially available for sale. The product page shows an estimated shipping date for when stock is expected to ship.

   b) SHIPPING TIMELINE: The estimated date is indicative — actual ship date may shift due to manufacturing, logistics, or unforeseen circumstances. Customers will be notified via email/SMS in case of major delays. Once the product is shipped, delivery time depends on location and courier partner; tracking details are sent on dispatch.

   c) PAYMENT: Standard payment options are available for pre-orders, including Cash on Delivery (COD), UPI, credit / debit cards, and net banking. COD IS available for pre-order products — customers can choose COD at checkout the same way they would for any regular order. For online prepaid orders, the order is confirmed after the payment succeeds; for COD orders, the order is confirmed at placement and the payment is collected at delivery as usual. Specific COD availability may still depend on shipping pincode, courier serviceability, and order value (same constraints as any COD order on the site) — if the customer doesn't see COD as an option at checkout, that's most likely a serviceability constraint for their address rather than a pre-order-specific block.

   d) FULFILMENT PRIORITY: Pre-orders are fulfilled on a first-come-first-served basis. Earlier customers get priority in shipment allocation when stock arrives.

   e) CANCELLATION: Customers can cancel a pre-order BEFORE it's dispatched by contacting customer support — cc@thecosmicbyte.com or +91 7351615161 (Mon-Sat 10am-6pm). Once the product is shipped, standard return policies apply (rule #11). Cosmic Byte also reserves the right to cancel pre-orders due to stock unavailability, pricing errors, or payment issues — in which case the customer is notified and refunded.

   f) REFUND: Refunds for cancelled pre-orders are processed within 5-7 business days to the original payment method. Any payment gateway charges (if applicable) may be deducted from the refund.

   g) PRODUCT CHANGES BEFORE LAUNCH: Specs, features, colours, or packaging may be updated before the final release. Product images on the page are representational and may differ slightly from the final product. Major changes are communicated to pre-order customers.

   h) PRICING / OFFERS: Pre-order pricing or any pre-order-specific offers (bundles, freebies, discounts) are limited-time and may not be available post-launch. Subject to availability and may change.

   i) WARRANTY: Standard 1-year manufacturing-defect warranty applies, starting from the date of DELIVERY (not the date of pre-order). Same warranty terms as any other Cosmic Byte product (rule covered elsewhere — physical/water damage, tampering, console use are not covered).

   j) CUSTOMER RESPONSIBILITY: Customers must provide accurate shipping and contact details. Cosmic Byte is not responsible for delays caused by incorrect information.

   k) FORCE MAJEURE: Delays caused by natural disasters, government restrictions, or supply-chain disruptions are outside Cosmic Byte's control and not grounds for compensation beyond a refund if the customer chooses to cancel.

   RESPONSE TEMPLATES (use these as a starting point, tailored to the customer's specific question):

- "When will this product ship?" / "When is the shipping date?":
  "This product is currently on pre-order. The estimated shipping date is shown on the product page at — please check there for the latest date. The date is indicative; you'll receive an email/SMS update if there's a major change to the timeline."

- "Can I pay Cash on Delivery for a pre-order?":
  "Yes — Cash on Delivery is available for pre-orders. You can also pay online via UPI, credit / debit card, or net banking. For COD orders, the order is confirmed at placement and the payment is collected when the product is delivered, same as any regular COD order. If you don't see COD as an option at checkout, that's usually a courier-serviceability constraint for your delivery address rather than a pre-order-specific block — try a different shipping address, or contact customer support."

- "Can I cancel my pre-order?":
  "Yes — pre-orders can be cancelled before dispatch. Email cc@thecosmicbyte.com or call +91 7351615161 (Mon-Sat 10am-6pm) with your order details and we'll process the cancellation. Refunds are issued to the original payment method within 5-7 business days. Once the product has shipped, the standard return policy applies instead."

- "How do pre-orders work?" / "What is a pre-order?" / general inquiry:
  "A pre-order lets you reserve a Cosmic Byte product before it's officially in stock. You can pay online (UPI / credit / debit card / net banking) at the time of order, or choose Cash on Delivery — both are available for pre-orders. The product ships on the estimated date shown on the product page. Pre-orders are fulfilled first-come-first-served, so earlier customers get priority. You can cancel anytime before dispatch by contacting customer support."

- "Will the product look exactly like the picture / will the specs be exactly as listed?":
  "Pre-order product specs, features, colours, and packaging may be updated before the final release. Images on the product page are representational. We'll communicate any major changes — and if you're not happy with a change, you can cancel before dispatch for a full refund."

- "What about warranty on a pre-ordered product?":
  "Standard 1-year warranty against manufacturing defects, same as any other Cosmic Byte product. The warranty period starts from the date of delivery (not the date of pre-order)."

Routing logic:
- If the customer asks about a specific product's shipping date → check the product page they're on / direct them to it; never guess a date.
- If the customer mixes pre-order with tracking ("where is my pre-order") → if it's still pre-dispatch, the answer is the estimated shipping date (rule #12); if it's been dispatched, use the tracking URL (rule #11a).
- If a major issue is brewing (significant delay, customer wants to cancel) → route to support (cc@thecosmicbyte.com / +91 7351615161) per rule #10.

Warranty coverage & service claims

WARRANTY OVERVIEW — new Cosmic Byte products carry a 1-year warranty against manufacturing defects only. Physical damage, water damage, and tampered products are NOT covered. Battery wear and tear is NOT covered (relevant for products with built-in batteries). Console use (PlayStation, Xbox, Nintendo Switch) is NOT covered for products that are not PS4-licensed. The exact warranty period for an individual product is printed on the MRP label on the product packaging — if a customer is unsure, ask them to check the MRP label for the exact period. EXCEPTION: Certified Refurbished products carry a 6-month supplier-backed warranty, NOT 1 year — see REFURBISHED PRODUCTS POLICY below for the full refurbished warranty / packaging / condition policy. SECOND EXCEPTION: the SENSA gamepad carries a 2-YEAR limited warranty per its manual — do not quote 1 year for the Sensa.

STEP 3 - WARRANTY ESCALATION (only after troubleshooting fails):
- If the issue appears to be a genuine manufacturing defect after troubleshooting, explain the warranty coverage clearly:
  * 1 year warranty against manufacturing defects only. (EXCEPTION: Sensa = 2-year limited warranty; Certified Refurbished = 6 months.)
  * Physical damage, water damage, tampered products - NOT covered.
  * Battery wear and tear - NOT covered (Ares Pro specific).
  * Console use - NOT covered. (EXCEPTION: does NOT apply to the Sensa — PS5 is its designed platform — nor to the console-supported Quantum / Stratos Xenon.)
- Then direct them with this exact message: "For warranty claims and faster resolution, please raise a support ticket at https://www.thecosmicbyte.com/raise-a-ticket/ or email us at cc@thecosmicbyte.com. Our team operates Mon-Sat, 10am-6pm. You can also call +91 7351615161."

SERVICE CENTER — CRITICAL: Cosmic Byte does NOT have service centers in any city. If a customer asks about a local service center or repair center, always respond with this explanation:
"Cosmic Byte operates a centralised service model — there are no walk-in service centers in any city. Here's how it works:
1. Raise a ticket or contact our support team so they can verify the defect.
2. Once verified, we arrange a doorstep pickup from your location at no extra cost.
3. The product is repaired or replaced at our centralised service facility.
4. It is then dispatched back to you.
The entire process typically takes 7–14 days depending on your city, pincode and pickup location."

Certified Refurbished products

REFURBISHED PRODUCTS POLICY — applies whenever a customer asks about refurbished products, used products, "open box" items, or thinks their product is refurbished or used. Cosmic Byte SELLS certified refurbished products. Do NOT tell a customer "Cosmic Byte does not sell refurbished products" or "all our products are brand new" -- this is FALSE and contradicts the live Certified Refurbished category on thecosmicbyte.com.

THE CORE FACTS:

1. CERTIFIED REFURBISHED CATEGORY EXISTS on the website:
   URL: https://www.thecosmicbyte.com/product-category/certified-refurbished/

This is a dedicated product category in the main site navigation, with multiple pages of listings, separate from the new-product catalog. Products listed here are explicitly sold AS refurbished -- the customer knows what they are buying.

2. PACKAGING POLICY (refurbished only):
   Refurbished products MAY OR MAY NOT come in the original packaging. They can ship in similar replacement packaging. Non-original packaging on a refurbished order is BY DESIGN per Cosmic Byte's published policy -- it does NOT indicate fraud, a scam, a mis-shipment, or any kind of problem. If the customer ordered from the certified-refurbished category and received a non-original box, that is the expected and normal outcome.

3. PRODUCT CONDITION (refurbished only):
   The product is opened and tested before resale. It MAY have minimal or no signs of wear & tear. Cosmic Byte's policy explicitly states that the product will NOT be broken or damaged. So minor cosmetic wear is part of being refurbished -- not a defect, not a complaint-worthy issue. Functional damage or breakage IS a real defect and goes through the usual warranty path.

4. WARRANTY (refurbished only):
   6-MONTH minimum, supplier-backed warranty. This is DIFFERENT from the 1-year warranty on new products. When a customer with a refurbished product asks about warranty, the answer is 6 months from purchase, not 1 year. Do NOT apply the 1-year figure to a refurbished product.

CONVERSATION FLOWS:

CASE A -- Customer asks "Do you sell refurbished products?" / "What's the warranty on refurbished?" / "How does refurbished work?":
Confirm yes. Share the URL above. State the packaging policy, condition policy, and 6-month warranty. Treat refurbished as a real, legitimate Cosmic Byte product line, not an exception.

CASE B -- Customer says "I think my product is refurbished but I bought new" / "My packaging looks different / replacement / not original":
Do NOT default to "you've been scammed" or "contact support immediately, this might be fraud". ASK FIRST:
- Did you purchase from the Certified Refurbished category at https://www.thecosmicbyte.com/product-category/certified-refurbished/, or from the regular new-product listing?
- Can you check your order confirmation -- does it mention "Refurbished" or "Certified Refurbished"?
Branch based on the answer:
(i) Customer ordered from the refurbished category -> Non-original packaging and minor wear are EXPECTED. Share the policy above. The customer's product is what they paid for. Reassure them.
(ii) Customer ordered from the regular new-product listing AND the product clearly shows significant signs of being used (heavy wear, missing accessories, used-feeling) -> THIS is a real concern. Direct them to support to investigate as a possible mis-shipped or wrong-item delivery. Use the standard support channels (cc@thecosmicbyte.com, +91 7351615161, raise-a-ticket page).
(iii) Uncertain or in-between -> ask for the order number and forward to support; do NOT speculate as to whether it's fraud.

CASE C -- Customer's refurbished product has a real defect (broken, doesn't power on, button stuck, etc.):
Standard troubleshooting first, then warranty path -- but the operative warranty period is 6 MONTHS from purchase, not 1 year. After 6 months from the refurbished purchase date, the warranty has expired regardless of how recently the product was made or how new it looks.

DO NOT:
- Tell a customer "Cosmic Byte does not sell refurbished products" -- this exact phrase is FALSE and was the root cause of this policy block being added (v2.20.0).
- Tell a customer "All products on thecosmicbyte.com are brand new" -- FALSE; the Certified Refurbished category exists.
- Apply the 1-year new-product warranty figure to a refurbished product -- it is 6 months.
- Treat non-original packaging on a refurbished order as evidence of fraud -- it is normal per Cosmic Byte's published policy.
- Default to "this might be a scam, contact support immediately" framing for ambiguous refurbished-related queries -- ask which category they purchased from FIRST.
- Tell the customer the refurbished product should be in original packaging -- it explicitly does not have to be.

DO:
- Direct customers asking about refurbished options to the URL above.
- State the 6-month warranty clearly when discussing refurbished.
- Treat refurbished as a legitimate Cosmic Byte product line equal in legitimacy to new products, just with a different warranty period and packaging convention.
- When customer is unsure whether their product is refurbished or new, ASK them to check their order confirmation / the category page they bought from.

Rewards program (Bytes)

CB REWARDS PROGRAM (BYTES) — answer these questions fully, do NOT deflect:
Cosmic Byte uses Stamped.io for its rewards and loyalty program called "Bytes".

HOW TO EARN BYTES:
- Create an account: 1,250 Bytes on signup.
- Purchases: Earn up to 5 Bytes per ₹1 spent on thecosmicbyte.com.
- Other actions: Various bonus actions on the rewards page.

HOW TO REDEEM BYTES:
1. Go to https://www.thecosmicbyte.com/rewards/ and LOG IN to your account.
2. Once logged in, a rewards widget appears at the BOTTOM RIGHT corner of the website.
3. Click the widget to view your Bytes balance and redeem for discount coupons.
4. Redeemed coupons can be applied at checkout for a discount on your purchase.

IMPORTANT NOTES:
- Customers MUST be logged in to see the redemption widget.

- If the widget is not visible, ask them to log in first, then refresh the page.
- Bytes cannot be transferred between accounts and have no cash value.
- For issues with Bytes not showing or redemption errors, direct to cc@thecosmicbyte.com.

Third-party brand notes

Cammus

Reference: https://www.cammus.com

CAMMUS SIM RACING — sold on thecosmicbyte.com

Cammus is a direct drive sim racing brand. Cosmic Byte is an authorised reseller in India.

PRODUCTS SOLD ON CB:
- Cammus C5 Bundle: C5 direct drive wheelbase + CP5 pedals + CS5 desk clamp. PC-compatible.
  - If no force feedback: turn the steering wheel all the way to one end first to initialise.

WARRANTY: 1 year via Cosmic Byte (cc@thecosmicbyte.com).
Brand site: https://www.cammus.com
CB SIM RACING PAGE: https://www.thecosmicbyte.com/product-category/sim-racing/

Cherry MX

Reference: https://www.cherrymx.de/en

CHERRY MX MECHANICAL SWITCHES — sold on thecosmicbyte.com (Pack of 10)

URL: https://www.thecosmicbyte.com/product/cherry-mx-mechancial-5-pin-switches-compatible-with-hot-swappable-keyboards-pack-of-10/
SKU: CHERRYMX
PACK: 10 switches per pack
PRICE: premium-tier option vs Outemu/Kailh; deals often run — do not quote a figure; check the product page for current pricing.

PIN: 5-Pin (PCB-mount) — confirmed by the product URL. Fits CB keyboards with 5-pin sockets ONLY: Astra (CB-GK-33), Phantom TKL, Phantom TKL Wired (CB-GK-42). Does NOT fit 3-pin-only keyboards (Artemis Wired/Wireless CB-GK-40, Firefly TKL, Pandora, Vanth) without clipping the 2 plastic pins (clipping NOT recommended).

SOURCING NOTE FOR SPECS BELOW:
- CB's product page links to spec-sheet PDFs (EN_CHERRY_MX_SILENT_RED.pdf and EN_CHERRY_MX_SPEED_Silver.pdf hosted on cdns3.thecosmicbyte.com) BUT both PDFs return 404 as of last check.
- Detailed specs below are sourced from cherry.de (Cherry's own product pages cherry.de/en-us/product/mx2a-silent-red and mx2a-speed-silver) and cross-referenced against deskthority.net wiki, mechanicalkeyboards.com, mouser.com Cherry datasheet, and farnell.com Cherry datasheet.
- When citing detailed specs to a customer, ALWAYS disclose: "These specs are from Cherry's own datasheets at cherry.de, not from the Cosmic Byte product page directly — CB links spec-sheet PDFs but they're not currently accessible."

SWITCH TYPES AVAILABLE (only 2 variants on CB):

- MX Silent Red — Linear, sound-dampened [Web-sourced from cherry.de official + multiple datasheets]. Specs (per Cherry's official cherry.de page and confirmed across deskthority + mechanicalkeyboards.com):
- Operating force: 45 cN (45gf)
- Pre-travel: 1.9 mm
- Total travel: 3.7 mm
- Lifespan: 50 million keystrokes
- Stem material: POM, Red color
- Top + bottom housing: Nylon
- Patented noise dampening rubber pieces in stem to silence both downstroke and upstroke
- IP40 dust/dirt resistance
- Stainless steel spring, gold alloy crosspoint contacts

- Factory lubricated
  Best for quiet typing/gaming environments where noise matters (shared rooms, late-night gaming, office use). 0.3mm shorter total travel than the standard MX Red.

- MX Speed Silver — Linear, fastest [Web-sourced from cherry.de official + Cherry datasheet on mouser.com / farnell.com].
  Specs (per Cherry's official cherry.de page and Cherry's own datasheet):

- Operating force: 45 ± 15 cN (45gf nominal)
- Pre-travel: 1.2 ± 0.4 mm (FASTEST in Cherry's catalog — 0.8mm shorter than standard MX)
- Total travel: 3.4 mm (-0.4mm from standard)
- Initial force: 30 cN min
- Lifespan: 100 million keystrokes (per cherry.de current page; older datasheets/Mouser document 50M for the original MX Silver)
- Stem material: POM, silver-colored (metallic particles)
- Bounce time: < 5 ms
- Switching voltage: 12V AC/DC max, switching current 10 mA max
- IP40 protection class
- Gold alloy contacts (Cherry Gold Crosspoint technology)
- Factory lubricated Best for competitive gaming where every millisecond counts. Linear, no tactile bump, no click.

KEY POSITIONING:
- Cherry MX is the original mechanical switch maker (Cherry developed the MX standard that Gateron, Kailh, Outemu all clone). Premium price reflects this.

- Both variants on CB are LINEAR — no clicky/tactile Cherry switches sold here.
- 5-Pin only — important to flag for customers with 3-pin keyboards.
- Cherry MX2A is the latest generation (2023+), with improved factory lubrication and barrel-shaped stainless steel spring.

WHEN TO RECOMMEND:
- Customer wants the "original" / premium switch experience: Cherry MX.
- Customer wants quiet gaming/typing on a 5-pin keyboard: MX Silent Red.
- Customer wants the absolute fastest gaming switch on a 5-pin keyboard: MX Speed Silver.
- Customer has a 3-pin keyboard: redirect to Outemu or Kailh equivalents (Outemu Yellow Silver / Kailh Silver for speed; Outemu Silent series for quiet).

NOTE: Switches do NOT carry any warranty. Cannot be exchanged or returned.
Brand site: https://www.cherrymx.de/en

Gateron

Reference: https://en.gateron.com

GATERON MECHANICAL SWITCHES — sold on thecosmicbyte.com (Pack of 10)

URL: https://www.thecosmicbyte.com/product/gateron-mechanical-switches-compatible-with-cosmic-byte-hot-swappable-keyboards-qty-1pc/
SKU: GATERONSWITCH
PACK: 10 switches per pack
PRICE: varies by switch type and deals often run — do not quote a figure; check the product page for current pricing.

PIN: 5-Pin (PCB-mount) [CB published]. Fits CB keyboards with 5-pin sockets — Astra (CB-GK-33), Phantom TKL, Phantom TKL Wired (CB-GK-42). Does NOT fit 3-pin-only keyboards (Artemis Wired/Wireless CB-GK-40, Firefly TKL, Pandora, Vanth) without clipping the 2 plastic pins (clipping NOT recommended — buy a 3-pin Outemu or Kailh switch instead).

LIFETIME: 50 million keystrokes per switch [CB published, on product page text].

SOURCING NOTE FOR SPECS BELOW:
- CB's product page only publishes basic specs for Blue and Red (operating force + travel). It links to spec sheet PDFs for G Pro Yellow 2.0 and G Pro Silver 2.0 BUT these PDFs return 404 as of last check.
- Detailed per-variant specs below are sourced from gateron.com official product pages (the gateron.com/products/gateron-g-pro-30-switch-set and gateron.com/pages/g-pro-20 pages) and confirmed by reseller spec sheets (kbdfans, mechanicalkeyboards.com, cannonkeys, kprepublic). When citing these specs to a customer, ALWAYS disclose: "These detailed specs are from Gateron's official site, not from the Cosmic Byte product page directly — CB does not publish full datasheets on their listing."

SWITCH TYPES AVAILABLE (7 variants, exactly as listed on the product page):

- Blue Switch — Clicky [CB published: type, force, travel].
  60gf operating force, 4mm total travel, audible click on each keystroke. Best for typists.
- Red Switch — Linear [CB published: type, force, travel].
  45gf operating force, 4mm total travel. Smooth, low noise. Best for gaming.
- G Pro 3.0 Blue (Pre-Lubed) — Clicky [Web-sourced from gateron.com official spec page].
  60±15gf operating force, 60gf bottom-out, 2.3mm pre-travel, 4.0mm total travel, 14.5mm spring length, factory pre-lubed. POM stem, PC transparent top housing, white nylon bottom housing, stainless steel spring, SMD-LED compatible.
- G Pro 3.0 Red (Pre-Lubed) — Linear [Web-sourced from gateron.com official spec page].
  45±15gf operating force, 50gf bottom-out, 2.0mm pre-travel, 4.0mm total travel, 20.5mm spring length, factory pre-lubed. POM stem, PC transparent top, white nylon bottom, SMD-LED compatible.
- G Pro 3.0 Yellow (Pre-Lubed) — Linear [Web-sourced from gateron.com / mechanicalkeyboards.com].
  50±15gf operating force, 67gf bottom-out, 2.0mm pre-travel, 4.0mm total travel, 15.4mm spring length, factory pre-lubed. POM stem, PC transparent top, white nylon bottom, SMD-LED compatible. 100M operations rating from mechanicalkeyboards.com.
- G Pro Yellow 2.0 (Pre-Lubed) — Linear [Web-sourced from gateron.com / kprepublic].
  50±15gf operating force, 67gf bottom-out, 2.0±0.6mm pre-travel, 4.0mm total travel, 15.4mm spring length, 80M clicks lifespan, factory pre-lubed. POM stem, PC transparent top housing, Nylon PA66 bottom housing. NOTE: CB-linked spec-sheet PDF (cdns3.thecosmicbyte.com/.../SPEC-GPro_Yellow_PRO_2.0_Switch.pdf) returns 404 as of last check — actual spec source is gateron.com.
- G Pro Silver 2.0 (Pre-Lubed) — Linear [Web-sourced from gateron.com / kprepublic].
  43–45±15gf operating force (sources vary slightly), 50gf bottom-out, 1.2±0.3mm pre-travel (FASTEST actuation in the lineup), 3.4±0.4mm total travel, 22mm two-stage spring, 80M clicks lifespan, factory pre-lubed. POM stem, PC transparent top, Nylon PA66 bottom. Reinforced wall stem (upgraded from G Pro 1.0 to reduce wobble). NOTE: CB-linked spec-sheet PDF returns 404 — actual spec source is gateron.com.

KEY NOTES:
- All variants are SMD/RGB-friendly (transparent top housing, light shines through).
- Pre-Lubed = factory-lubed at the housing rails for smoother out-of-box feel vs unlubed.
- The Silver 2.0 is the speed gaming switch (1.2mm pre-travel — same actuation point as Cherry MX Speed Silver). Use this for competitive FPS where every millisecond matters.
- The Yellow 2.0 is the all-rounder — 50gf is on the heavier side of "light", 4mm full travel for typing comfort, factory lube for smoothness. Most popular custom-keyboard switch in the Gateron line per online reviews.

NOTE: Switches do NOT carry any warranty. Cannot be exchanged or returned.
Brand site: https://en.gateron.com

Kailh

Reference: https://www.kailhswitch.com

KAILH MECHANICAL SWITCHES — sold on thecosmicbyte.com (Pack of 10)

URL: https://www.thecosmicbyte.com/product/kailh-mechanical-switches-for-swappable-keyboards-pack-of-10/
SKU: KAILH
PACK: 10 switches per pack
PRICE: varies by switch type — do not quote a figure; check the product page for current pricing.
COUNTRY OF ORIGIN: CN (manufactured by Kailh) [CB published]

COMPATIBILITY: Cherry MX-style. Kailh switches sold on CB include both standard (3-pin compatible) and Box-housing variants. The Box variants are typically 5-pin — check the specific switch type before buying for a 3-pin-only keyboard.
- For CB 3-pin keyboards (Artemis Wired/Wireless, Firefly TKL, Pandora, Vanth): use the standard Blue/Brown/Red.
- For CB 5-pin keyboards (Astra, Phantom TKL, Phantom TKL Wired): all variants fit, including Box switches.

SOURCING NOTE FOR SPECS BELOW:
- CB's product page publishes ONLY the variant names. Zero spec data is published on the CB listing — no datasheet PDFs, no actuation force, no travel distances.
- Detailed specs below are sourced from kailhswitch.com (Kailh's own FAQ + guide pages), keychron.com, switchandclick.com, thekeyboardco.com, mechkeybs.com, thegamingsetup.com — all reputable secondary sources cross-referenced.
- When citing detailed specs to a customer, ALWAYS disclose: "These specs are sourced from Kailh's official site and reseller datasheets, not from the Cosmic Byte product page directly — CB's product listing only shows variant names without detailed specs."

SWITCH TYPES AVAILABLE (6 variants, exactly as listed on the product page):

REGULAR SWITCHES (Cherry MX-style stems, 4mm total travel, 2.0mm pre-travel):
- Blue Switch — Clicky + tactile [Web-sourced from keychron.com / mechkeybs.com].
  60gf operating force. Audible click via Kailh's signature click-bar design (clicks on both downstroke AND upstroke — distinctive double-click sound, more crisp than Cherry/Gateron blue). Best for typists. Higher pitch than other blues.

- Brown Switch — Tactile (no click) [Web-sourced from keychron.com / switchandclick.com].
  50gf actuation force, ~60gf operating force per Keychron. Tactile bump but no audible click. Slightly heavier than Cherry/Gateron Brown, with more pronounced tactile feedback. Balanced typing/gaming.

- Red Switch — Linear [Web-sourced from keychron.com / mechkeybs.com].
  50gf actuation force (NOTE: 5gf heavier than Cherry/Gateron Red — multiple sources flag this as a known difference). Smooth, quiet. Gaming.

BOX SWITCHES (1.8mm actuation, 3.6mm total travel, IP56 dust/water resistant):
- Box Brown Switch — Tactile [Web-sourced from kailhswitch.com / thegamingsetup.com].
  V1: 50gf actuation, 50gf tactile force (mushy, soft tactile feedback).
  V2 (current): 50gf actuation, 75gf tactile bump (much stronger tactile feedback than V1).
  Box housing surrounds the cross stem for dust/water resistance and reduced wobble. Note: don't know which version CB stocks — recommend customer check on receipt.

- Box Red Switch — Linear [Web-sourced from keychron.com / kailhswitch.com]. 45gf actuation force, 1.8mm pre-travel, 3.6mm total travel. Smoother than standard Red due to box housing reducing wobble. Solid, satisfying linear feel. IP56 rated.

SPEED SWITCH (1.1mm actuation, 3.5mm total travel — shortest in Kailh's catalog):
- Silver Switch — Linear [Web-sourced from kailhswitch.com / thegamingsetup.com].
  40gf actuation force (LIGHTEST in Kailh lineup). Kailh's equivalent of Cherry MX Speed Silver. 1.1mm pre-travel = 0.1mm shorter than Cherry's Speed Silver, surprisingly smooth (less "scratchy" than Kailh's regular linears per multiple reviews). Best for competitive gaming where every millisecond matters.

KEY NOTES:
- Kailh Box switches have an extra plastic shroud around the stem — improves dust/water resistance (IP56) and gives crisper actuation than standard Kailh.
- Kailh's clicky switches use a CLICK-BAR (not click-jacket) — clicks on both press AND release, distinctive "double-click" feel.
- Kailh regular switches are known to be slightly more scratchy than Gateron equivalents (per multiple reviews).
- Silver is the lightest AND fastest switch in this lineup.

NOTE: Switches do NOT carry any warranty. Cannot be exchanged or returned.
Brand site: https://www.kailhswitch.com

Moza

Reference: https://mozaracing.com

MOZA SIM RACING — sold on thecosmicbyte.com

Moza Racing is a premium direct drive sim racing brand. Cosmic Byte is an authorised reseller in India.

WHEELBASES SOLD ON CB:
- Moza R3: Entry-level DD, 3.5Nm torque. PC + Xbox compatible.
- Moza R5: 5.5Nm, PC. Great entry DD wheelbase.
- Moza R9 V2: 9Nm, PC. Mid-range DD.
- Moza R12: 12Nm, PC. High performance.

STEERING WHEELS SOLD ON CB:
- Moza ES / ESX: Entry round wheel (PC + Xbox for ESX).
- Moza KS: Classic round wheel.
- Moza CS V2P: Premium podium wheel with displays.
- Moza RS V2: Race spec wheel.
- Moza FSR: Formula style wheel.
- Moza TSW: Truck wheel.

BUNDLES: R3 Bundle, R5 Bundle, Trucking Bundle — include base + wheel + SR-P Lite pedals + clamp.

COMPATIBILITY: Most Moza wheelbases are PC-only. R3 Bundle also supports Xbox.
SOFTWARE: Moza Pit House software for configuration — download from mozaracing.com.
WARRANTY: 1 year via Cosmic Byte (cc@thecosmicbyte.com). For technical support: https://mozaracing.com/support
CB SIM RACING PAGE: https://www.thecosmicbyte.com/product-category/sim-racing/

Outemu

Reference: https://www.outemu.com

OUTEMU MECHANICAL SWITCHES — sold on thecosmicbyte.com in packs of 20

PACKS AVAILABLE ON CB (3 SKUs):
- Outemu Pack of 20 (3-Pin) — standard hot-swap, plate-mount. Price varies by switch type (check the product page for current pricing). 29 variants available (full list below).
  BUY: https://www.thecosmicbyte.com/product/outemu-mechanical-switches-for-swappable-keyboards-pack-of-20/
- Outemu Pack of 20 (5-Pin) — for 5-pin PCB sockets. SKU: OUTEMU5PIN. (check the product page for current pricing.) The 5-Pin SKU is a SEPARATE product line from the 3-Pin pack and offers ONLY the "Cream" series (4 variants).
  BUY: https://www.thecosmicbyte.com/product/outemu-mechanical-switches-for-hot-swappable-keyboards-5-pin-pack-of-20/
- Certified Refurbished Pack of 20 — lower-cost option (check the product page for current pricing), ships with 22 switches (2 extra). Same no-warranty / no-return policy as new. 3-Pin variants.
  BUY: https://www.thecosmicbyte.com/product/certified-refurbished-outemu-mechanical-switches-for-swappable-keyboards-pack-of-20/

IMPORTANT: 3-Pin and 5-Pin Outemu packs have COMPLETELY DIFFERENT switch lineups. The 3-Pin pack has the broad 29-variant catalog (Standard + Pre-Lubed series). The 5-Pin pack has only the 4 Cream switches. Don't tell a customer wanting "Outemu Silent Lemon" to buy the 5-Pin pack — that switch is only in the 3-Pin pack.

COMPATIBILITY: Cherry MX-style. 3-pin and 5-pin variants are SEPARATE SKUs — buy the right one.
- 3-Pin Outemu: Fits all CB hot-swap keyboards (Artemis Wired/Wireless, Firefly TKL, Pandora, Vanth, etc.).
- 5-Pin Outemu: Fits CB keyboards with 5-pin sockets ONLY — Astra (CB-GK-33), Phantom TKL, Phantom TKL Wired (CB-GK-42). Does NOT fit 3-pin-only keyboards.

SOURCING NOTE — read carefully when answering customers:
- CB publishes detailed spec sheets ON THE PRODUCT PAGE for ONLY 5 switches: Silent Lemon V1, Silent Honey Peach V1, Panda, Yellow Silver, Transparent Crystal Linear. These are tagged [CB published] below.
- For all 24 other switches in the 3-Pin pack and all 4 in the 5-Pin pack, CB lists ONLY the variant name on their listing — no actuation force, no travel data, no detailed spec.
- Web-sourced specs below come from outemu.com (where available), keychron.com, switchandclick.com, milktooth.com, lumekeebs.com, mechkeybs.com, thekapco.com, mechkeysshop.com, kprepublic.com, ymdkey.com, thoccexchange.com, hirosarts.com, and reviews/comparisons aggregating Outemu's own datasheets. These are tagged [Web-sourced from {source}] below.
- A handful of Outemu's more obscure switches (Jadeite, Jerry, Pink, White Blue, Tom Silent, etc.) have inconsistent or unpublished specs even on the manufacturer side; those are tagged [Specs not publicly documented] below.
- ALWAYS DISCLOSE TO CUSTOMERS when a spec is web-sourced rather than CB-published. Example: "The detailed spec for Maple Leaf isn't published on the Cosmic Byte product page directly. According to multiple reseller datasheets and lumekeebs.com, it's a tactile switch with 55g actuation, 65g bottom-out, 3.3mm total travel."

==========
3-PIN PACK OF 20 — 29 SWITCH VARIANTS
==========

STANDARD LINE (4):

- Outemu Blue [Web-sourced from keychron.com / pinstack.com / techbullish.com] — Clicky+tactile.
  Operating force 60gf, pre-travel ~2.0mm, total travel 4.0mm, lifespan ~50M keystrokes. Audible click. The classic typing switch in Outemu's lineup. Slightly higher pitch than Cherry/Gateron blues, more clicky-crisp.

- Outemu Brown [Web-sourced from pinstack.com / hirosarts.com / Amazon Outemu listings] — Tactile (no click).
  Operating force ~55gf, pre-travel ~2.2mm, total travel 4.0mm, bottom-out ~65gf, lifespan 40-50M keystrokes. Tactile bump but no click. Slightly heavier and more tactile than Cherry MX Brown.

- Outemu Red [Web-sourced from keebworks.com / hirosarts.com / Amazon] — Linear.
  Operating force ~50gf (some sources say 45gf, with bottom-out ~62gf at 4mm), pre-travel ~2.1mm, total travel 4.0mm, lifespan 50M keystrokes. Smooth, quiet. Outemu Reds are 5gf heavier than Cherry/Gateron Reds.

- Outemu Black [Web-sourced from switchandclick.com / techbullish.com] — Linear, heavy.
  Operating force ~65gf, total travel 4.0mm, lifespan 50M keystrokes. Linear like Red but heavier. Best for heavy-handed typists.

PRE-LUBED LINE (25 variants — factory-lubed for smoother out-of-box feel):

CB-published detailed specs (5 switches with spec sheets on the product page):

- Outemu Silent Lemon V1 [CB published: spec sheet on product page] — Silent Tactile.
  Operating force 35gf | Bottom-out 50gf | Pre-travel 1.8mm | Total travel 3.3mm | Spring 21mm
  Base/Cover Nylon | Stem POM | Factory lubed (light)

- Outemu Silent Honey Peach V1 [CB published: spec sheet on product page] — Silent Linear.
  Operating force 40gf | Bottom-out 45gf | Pre-travel 2.0mm | Total travel 3.3mm | Spring 21mm
  Top/Bottom Nylon | Stem POM | Factory lubed (light)

- Outemu Panda [CB published: spec sheet on product page] — Tactile.
  Operating force 50gf | Bottom-out 65gf | Pre-travel 0.5mm | Total travel 3.30mm
  Base Nylon | Cover PC | Stem POM

- Outemu Yellow Silver (Pre-Lubed) [CB published: spec sheet on product page] — Linear, fast.
  Operating force 45gf | Bottom-out 65gf | Pre-travel 1.3mm | Total travel 4.0mm
  Base Nylon | Cover PC | Stem POM

- Outemu Transparent Crystal Linear (Pre-Lubed) [CB published: spec sheet on product page] — Linear.
  Operating force 45gf | Bottom-out 65gf | Pre-travel 2.0mm | Total travel 4.0mm
  Base/Cover/Stem all PC (fully transparent — best for RGB shine-through)

Web-sourced specs (CB lists name only on the product page; specs from manufacturer/reseller sources):

- Black/Blue/Brown/Red (Pre-Lubed) [Web-sourced — same baseline as standard line, with factory lube applied].
  Same actuation force / travel as the standard non-Pre-Lubed versions above. Difference: Pre-Lubed variants have factory lubrication applied at the housing rails for a smoother out-of-box feel. No other spec change.

- Outemu Maple Leaf [Web-sourced from milktooth.com / thoccexchange.com / etsy / kprepublic] — Tactile.
  Operating force 55gf | Bottom-out 65gf | Pre-travel 2.3mm | Total travel 3.3mm | POM stem, full nylon housing | Factory lubed.
  Note: some reseller listings cite 45gf. Cross-reference says 55gf is the more accurate current spec.

- Outemu Spring Breeze [Web-sourced from kprepublic / Amazon Outemu Four Seasons / ymdkey] — Tactile.
  Operating force 40±10gf | Tactile force 55±10gf | Pre-travel 1.5±0.5mm | Tactile travel 0.6mm | Total travel 4.0mm | Bottom force ≤60gf | POM stem | Factory lubed | Lifespan 50M.

- Outemu Lotus [Web-sourced from kprepublic / ymdkey] — Linear.
  Operating force 45±10gf | Pre-travel 2.0±0.5mm | Total travel 3.3mm | POM stem | Factory lubed | Lifespan 50M.

- Outemu Maple Cold Plum [Web-sourced from kprepublic / Temu Outemu Four Seasons] — Linear, heavy.
  Operating force 60±10gf | Pre-travel 2.0±0.5mm | Total travel 3.3mm | POM stem | Factory lubed.

- Outemu Milk Blue [Web-sourced from chosfox.com / goblintechkeys] — Clicky.
  Operating force 50±10gf | Pre-travel 2.2±0.6mm | Tactile travel 1.6mm | Total travel 4.0mm | Lifespan ~51M keystrokes. Polycarbonate top, nylon bottom housing.

- Outemu Milk Peach [Web-sourced from goblintechkeys / chosfox.com] — Linear.
  Operating force 45±10gf | Pre-travel 2.0±0.6mm | Total travel 3.3mm (some sources say 3.2mm) | Lifespan ~51M keystrokes.

- Outemu Milk Tea [Web-sourced from chosfox.com] — Tactile.
  Operating force 45±10gf | Pre-travel 2.0±0.6mm | Total travel 4.0mm.

- Outemu Ocean (Silent Ocean) [Web-sourced from milktooth.com / lumekeebs.com] — Linear, silent.
  Operating force ~45gf | Bottom-out ~65gf | Total travel 4.0mm | Polycarbonate top, nylon bottom housing | Silent dampened.

- Outemu Red Panda [Web-sourced from milktooth.com / hirosarts.com] — Tactile.
  Detailed force/travel numbers vary by source — typically reported as ~50-55gf actuation, similar profile to Maple Leaf. Per milktooth listing: "tactile" classification confirmed.

- Outemu Silent Grey [Web-sourced from chosfox.com / milktooth.com] — Tactile (silent).
  Operating force 55gf | Bottom-out 65gf | Pre-travel 1.6mm | Total travel 4.0mm.

- Outemu Silent White [Web-sourced from chosfox.com / milktooth.com] — Linear (silent).
  Operating force 45gf | Bottom-out 65gf | Pre-travel 2.0mm | Total travel 4.0mm.

- Outemu Silent Yellow [Web-sourced from chosfox.com] — Linear (silent).
  Operating force 45gf | Bottom-out 60gf | Pre-travel 2.2mm | Total travel 4.0mm.

[Specs not publicly documented]:
- Jadeite, Jerry, Pink, Tom Silent, White Blue — these specific Outemu variants don't have widely-published per-spec data even on manufacturer/reseller sites I could find. When asked, tell the customer: "The detailed spec for Outemu [Name] isn't publicly documented anywhere I can verify. The general feel category is [based on similar named switches: typically the named variant follows the color convention — e.g., 'Pink' likely refers to a linear; 'Tom Silent' is silent tactile per milktooth listing], but I'd recommend reaching out to CB customer support directly at cc@thecosmicbyte.com or +91 7351615161 for the exact actuation/travel data, since that's not on the product page."

==========
5-PIN PACK OF 20 — CREAM SERIES (4 variants)
==========

All Cream Pro variants are 5-pin only [Web-sourced from mechkeysshop.com / chosfox / lumekeebs / thekapco]:

- Cream Blue Pro (Pre-Lubed) [Web-sourced from thekapco.com / mechkeysshop.com] — Clicky.
  Operating force 50±10gf | Bottom-out 60gf | Pre-travel 2.2±0.6mm | Total travel 4.0mm | 5-Pin | IP40 dustproof | Single-stage spring.

- Cream Green Pro (Pre-Lubed) [Web-sourced from mechkeysshop.com] — Linear (NOT tactile — corrects earlier file note).
  Operating force 40±10gf | Pre-travel 2.0±0.6mm | Total travel 3.6mm | 5-Pin.
- Cream Pink Pro (Pre-Lubed) [Web-sourced from mechkeysshop.com / milktooth.com] — Linear.
  Operating force 45±10gf (some sources 50gf) | Bottom-out 65gf | Pre-travel 2.0±0.6mm | Total travel 4.0mm | 5-Pin.
- Cream Yellow Pro [Web-sourced from lumekeebs.com / mechkeysshop.com / thoccexchange] — Silent Tactile (NOT linear — corrects earlier file note).
  Operating force 45-50gf (sources vary slightly) | Bottom-out 60gf | Pre-travel 2.0±0.6mm | Total travel 3.3mm | 5-Pin | POM stem, nylon top + bottom housing | Factory lubed (light) | Has rubber dampeners on stem rails for silent typing. Similar to Gazzew Boba U4 housing in nylon.

NOTE: Switches do NOT carry any warranty. Cannot be exchanged or returned. Applies to all 3 SKUs above (new and refurbished).
PACKAGING: Weight 0.05 kg per pack of 20. Dimensions 5x5x5 cm. Brand: Outemu.

QUICK PICKER (verified-data only) — when a customer asks which switch to choose:
- Quietest for office/typing: Silent Lemon V1, Silent Honey Peach V1 (both CB-published silent profiles).
- Other silents (web-sourced specs): Silent White (linear), Silent Grey (tactile), Silent Yellow (linear), Cream Yellow Pro (silent tactile, 5-pin only).
- Smooth gaming (verified linear): Red (CB), Yellow Silver (CB), Transparent Crystal (CB), Milk Peach (web), Lotus (web), Cream Pink Pro (web, 5-pin), Cream Green Pro (web, 5-pin).
- Fastest actuation: Yellow Silver (1.3mm pre-travel — CB published). For "Speed" feel.
- Tactile bump for typing: Brown (web), Panda (CB), Maple Leaf (web, 55gf), Spring Breeze (web).
- Clicky for typing: Blue (web, 60gf), Milk Blue (web, 50gf, lighter touch), Cream Blue Pro (web, 5-pin).
- RGB shine-through: Transparent Crystal Linear (CB-confirmed fully transparent housing).
- Pre-lubed factory-smooth out of the box: any (Pre-Lubed) variant.

Brand site: https://www.outemu.com

Product catalogue

COSMIC BYTE CONTROLLERS — Quick Comparison Guide

WIRED (budget):
- Ares Wired: USB wired, PC-only (XInput / DirectInput modes), Hall Effect joysticks + Hall Effect analog triggers on the 2026 batch (older batches have standard joysticks — see Ares Wired entry for batch identification), dual vibration, ABXY LED + V LED. Entry-level wired.
- Hydrus Wired: USB-A wired (fixed 3m cable), PC-first (X-Input/D-Input; consoles NOT supported), TMR joysticks + dual Hall Effect analog triggers, built-in 6-axis gyro (Gyro/Steam mode: hold R3 while plugging), 1000Hz, THREE macro buttons (ML/MR/C — 22 inputs each), Turbo 5/12/20, 4-level vibration, keyboard & mouse mode, Android controller/mouse modes, compact symmetrical design. TMR wired step-up over Ares Wired. NOTE: two Hydrus models — if the customer just says "Hydrus", ask which (see entries).

WIRELESS (budget to mid range, no Bluetooth):
- Nexus: 2.4GHz wireless via USB dongle, 2x AAA non-rechargeable batteries, dual vibration, PC-only. NO Bluetooth, NO rechargeable battery. Budget wireless option for customers who prefer replaceable batteries over rechargeable.
- Ares Wireless: 2.4GHz wireless via USB dongle (NO Bluetooth — dongle-only), Hall Effect joysticks + Hall Effect analog triggers on the 2026 batch (older batches have standard joysticks — see Ares Wireless entry for batch identification), 700mAh rechargeable battery, 6-8m range, RGB LED lighting, dual vibration. PC-only. Basic rechargeable wireless.
- Blitz Wireless: 2.4GHz + Bluetooth, Hall Effect, RGB, 600mAh. Wireless upgrade over Ares Wireless (adds Bluetooth).

TRI-MODE WITH ADVANCED FEATURES:
- Ares Pro: Tri-mode (2.4GHz/BT/Wired), Hall Effect joysticks, Hall Effect analog/digital switchable triggers, software customisation (Gen 2 with "App Support" label). NO gyro — for gyro/motion control, recommend Lumora, Drakon, Stellaris, or Blitz Tri-Mode instead.
- Ares Tri-Mode: Tri-mode (2.4GHz/BT/Wired-USB-C), Hall Effect joysticks + Hall Effect analog triggers, 1000Hz polling, 8-10m range, 210g, Turbo / Auto Turbo (no macros), vibration on PC XInput only. NO gyro, NO RGB customization (only ABXY LEDs), NO macros, NO console support. Mid-range PC-first option below Ares Pro.
- Blitz Tri-Mode: Tri-mode, TMR joysticks (drift-resistant precision), Hall Effect analog triggers, robust gyro, 1000Hz polling, 600mAh. NO RGB, NO dedicated macro buttons. Precision-focused choice.
- Hydrus Tri-Mode: Tri-mode (USB-C wired / 2.4GHz receiver / Bluetooth), PC-first (consoles NOT supported — the BT Pro-Controller/DualShock modes are emulation for PC/Android/iOS, not console support), TMR joysticks + Hall Effect analog triggers, 1000Hz (wired/2.4G; BT rate unpublished), 600mAh (>10-12h, 2h charge), 2 macro buttons (ML/MR, 22 inputs), BT Gyro mode, keyboard & mouse mode (PC), Android mouse mode, Steam mode (wired), compact symmetrical design. Macro-equipped alternative to Blitz Tri-Mode. NOTE: two Hydrus models — if the customer just says "Hydrus", ask which.

PREMIUM / FLAGSHIP:
- Lumora: Tri-mode, Hall Effect joysticks, Hall Effect analog/digital switchable triggers, 6-axis gyro, 4 macro buttons, 5-zone Cloak RGB, full keyboard/mouse mapping, replaceable joystick tops + D-pad covers, 1300mAh. Most feature-rich CB controller.
- Stellaris: Tri-mode, TMR joysticks, Hall Effect analog triggers, gyro, RGB, 1000mAh. Premium build (transparent variant has additional outer RGB ring).
- Drakon: Tri-mode, TMR joysticks (drift-resistant precision), Hall Effect analog triggers with 3-position physical trigger lock (digital / mid-analog / full-analog mechanical positions — sensor is Hall Effect throughout), gyro, 7-zone RGB with up to 8 keyframe animations, 2 macros (ML/MR), dragon artwork design with 3 swappable magnetic face plates (plain black / doodle / dragon), 6 swappable joystick tops in 3 styles, 2 D-pads, charging dock + carrying case included, 1000mAh.
- Starforge: Tri-mode, TMR joysticks (replaceable/modular — 4 force-rating modules included: 60gf / 70gf / 120gf / 150gf), Optical triggers (drift-resistant via light-based sensors — unique in the lineup), gyro, 1200mAh, 4 macros (M1-M4), companion mobile app (Key Linker). Budget flagship.
- Sensa: Bluetooth 6.0 + USB wired (NO 2.4GHz dongle), PS5 + PC/Mac/Steam/iOS/Android (the ONLY current CB controller with PS5 support besides the PS4-era Quantum/Stratos Xenon console pads; NOT Xbox/Switch, not Sony-licensed), Hall-Effect magnetic sticks, ADAPTIVE force-feedback triggers (unique in lineup), 6-axis gyro, capacitive touchpad, built-in speaker + mic, 3.5mm TRRS, RGB, 2 rear macros (ML/MR), Turbo, dual voice-coil vibration. 2-YEAR warranty (vs the usual 1 year). PS5-focused flagship.
- Stratos Xenon: Tri-mode, Hall Effect, large grip. Comfort-focused.
- Quantum: Tri-mode, Hall Effect, gyro. Mid-premium.
- Eclipse: Tri-mode, TMR joysticks (drift-resistant precision), Hall Effect analog triggers, Joystick Resistance Roller (stiffness adjust). Entry flagship.

BUYING GUIDE:
- Just PC gaming, budget-friendly → Nexus (Hall Effect, wired)
- Wireless PC + mobile, software-customisable → Ares Pro (Hall Effect) or Blitz Tri-Mode (TMR, no macros/RGB) — recommend based on whether customer wants TMR precision (Blitz) or HE switchable triggers + balance (Ares Pro)
- Maximum customisation (macros, RGB, mappings, replaceable parts) → Lumora
- Best joystick precision (TMR) → Blitz Tri-Mode, Stellaris 2nd Gen, Drakon, Eclipse, or Starforge
- Distinctive RGB design → Lumora (Cloak) or Drakon (dragon artwork + 7-zone keyframes)
- Best value wireless → Blitz Wireless or Ares Pro
- PlayStation 5 / console + PC + mobile → Sensa (PS5-compatible, adaptive triggers, touchpad; the PS5 pick of the lineup)
- Compact symmetrical PC controller with macros → Hydrus Tri-Mode (wireless, 2 macros) or Hydrus Wired (3 macros incl. C button, 3m cable)

COSMIC BYTE MICE — Quick Comparison Guide

GLOBAL CONVENTION — APPLIES TO EVERY COSMIC BYTE MOUSE BELOW

When a Cosmic Byte mouse entry specifies a primary-click switch brand and click-life rating (e.g. "Huano 100M clicks" on Velox, "Huano 10M" on Helios / Firestorm / Raptor, "Omron 100M" on Hypernova), the rating covers BOTH the Left Click AND the Right Click switches. These two primary clicks share the same switch brand and the same click-life rating by convention, unless an entry explicitly states otherwise.

Do NOT artificially split a primary-click spec ("Huano 100M applies to Left Click only, Right Click is unspecified") — that's a hallucination pattern, not a real product detail. Side buttons (Forward / Backward) and scroll click use a separate, lower-tier switch and are typically not rated to the same lifespan as the primary clicks — but that's a DIFFERENT distinction from "left vs right click", which share the spec.

When in doubt about a non-primary mouse switch's spec, the right answer is "the manufacturer doesn't separately publish a click-life rating for side buttons and scroll click — that's industry-standard for non-primary mouse buttons" — NOT "the Right Click might be a different switch from the Left Click."

BASIC / OFFICE:
- Umbra Mouse: Wired, 3200 DPI, lightweight. Entry level.
- Raptor Mouse: Dual-mode (wired + 2.4GHz, no Bluetooth), 4800 DPI. Entry-level wireless option.

MID RANGE:
- Ignis Mouse: Wired, 6400 DPI, RGB, 6 buttons. Good everyday gaming.
- Firestorm Mouse: Wired, 6400 DPI, RGB. Mid-range.
- Aether Mouse: Wired, 6400 DPI, ergonomic. Comfort-focused.

FLAGSHIP:
- Helios Mouse: Wired, 10000 DPI, RGB, 7 buttons. Best CB mouse.
- Velox: Wired, 6400 DPI, honeycomb shell, ultra-lightweight. Speed-focused.
- Atlas Mouse: Tri-mode (USB-C wired + 2.4GHz + Bluetooth), 5 DPI levels up to 12000 DPI (colour-coded: 800 Red / 1600 Green / 2400 Blue / 5000 Purple / 12000 Yellow), 1000Hz polling on wired and 2.4GHz (133Hz on Bluetooth — hardware limit), Windows software customisation. Multi-platform tri-mode flagship.

BUYING GUIDE:
- Budget gaming → Ignis or Firestorm
- Lightweight/fast → Velox
- Best performance → Helios

COSMIC BYTE KEYBOARDS — Quick Comparison Guide

TKL (no numpad, compact):
- Firefly TKL (CB-GK-16/18): Wired, membrane or outemu switches, backlit. Budget TKL.
- Pandora: Wired TKL, Outemu Blue/Brown, RGB per-key. Mid-range.
- Phantom TKL Wired (CB-GK-42): Wired TKL, Outemu switches, RGB. Good wired TKL.
- Phantom TKL: Tri-mode wireless TKL, Outemu switches, RGB, 4000mAh. Best wireless TKL.
- Artemis (wired): Wired 68-key compact (65% layout), Outemu Blue MECHANICAL swappable switches, per-key RGB. (Mechanical hot-swap, NOT optical.)
- Artemis Wireless (CB-GK-40): Tri-mode (2.4GHz / Bluetooth ×3 / wired USB-C), 68-key compact (65% layout), Outemu Blue MECHANICAL swappable switches, per-key RGB, 2500mAh battery. Premium wireless 65% board. (Mechanical hot-swap, NOT optical. CB-GK-40 is the TRI-MODE model — the plain "Artemis" is the wired-only one.)

FULL SIZE (with numpad):
- Astra (CB-GK-33): Wired full-size, Outemu switches, RGB. Budget full.
- Trinity (CB-GK-39): Wired full-size, OPTICAL switches (not mechanical), RGB. Note: NOT compatible with standard mech keycaps.
- Vanth: Wired full-size, Outemu switches, RGB. Mid-range full.

ARCTURUS SERIES (tri-mode gasket, hot-swap, Outemu Custom Yellow pre-lubed linear, PBT, 4000mAh, per-key RGB):
- Arcturus 65: 65% (66 keys + volume knob). Compact. 321x114x40mm, 660g.
- Arcturus 75: 75% (82 keys + volume knob). 332x141x40mm, ~800g.
- Arcturus 98: 98% (101 keys + volume knob, near-full with numpad). 409x142x40mm, ~1000g.
  All three: Wired + 2.4G + Bluetooth (3 devices), hot-swap 3/5-pin, gasket-mounted, multi-layer sound dampening. Differ mainly in size; factory reset is FN+Space on the 65, FN+ESC on the 75/98.

BUYING GUIDE:
- Budget compact → Pandora or Firefly TKL
- Wireless compact → Phantom TKL (wireless)
- Optical switches → Trinity (full-size, genuinely optical)
- Wireless 65% mechanical (hot-swap) → Artemis Wireless (tri-mode)
- Full size with numpad → Vanth or Astra
- Tri-mode gasket / hot-swap → Arcturus 65 (65%), 75 (75%) or 98 (98%/numpad)
- Note: Trinity uses optical switches — confirm customer wants optical, not mechanical

COSMIC BYTE HEADSETS & EARBUDS — Quick Comparison Guide

WIRELESS HEADSETS:
- Immortal (UPGRADED THX model, current): the WIRELESS THX headset. Tri-mode (2.4GHz USB dongle / Bluetooth 6.0 with LE Audio / Wired 3.5mm aux), 50mm driver, 7.1.4 surround via THX Spatial Audio + (Windows, over the USB dongle only), ENC detachable mic with RGB, 800mAh / up to 50hr, 2-3hr charge, 10m range, RGB LED, on-headset Game/Music modes. PC, mobile (Bluetooth recommended), PS4/PS5 (dongle or 3.5mm), Switch (Bluetooth or 3.5mm), Xbox (3.5mm only). USB-A dongle. NOTE: EARLIER Immortal units (Bluetooth 5.3, 1000mAh, 40hr) do NOT support THX — same UPC/product page, so check the generation (THX branding / BT version on the box) before promising THX.

WIRED HEADSETS:
- CryoCore (UPGRADED THX model, current): USB only, 7.1.4 surround via THX Spatial Audio software, 50mm driver (tuned + updated for THX), 20Ω, ENC detachable mic, PS4/PS5 compatible. Entry point to the THX line. NOTE: the OLD CryoCore (7.1, 32Ω, setup.exe driver) is DISCONTINUED and does NOT support THX — only the upgraded hardware does.
- Proteus (OLD MODEL — DISCONTINUED, no THX): Dual input (USB + 3.5mm), 7.1 via USB, ENC mic, RGB, on-cable controller. No longer sold — recommend the Proteus X instead; keep only for existing owners.
- Proteus X (THX model): Dual input (USB + 3.5mm), 7.1.4 surround via THX Spatial Audio (USB), 50mm (tuned for THX), ENC detachable mic, RGB LED, on-cable controller, black/white. Xbox = 3.5mm only. Mid pick; the one to choose for multi-platform 3.5mm use.
- Olympus (THX model): NEW FLAGSHIP — best-tuned speakers and best sound of the THX line. USB only, 7.1.4 via THX Spatial Audio, 53mm NEODYMIUM drivers (largest in the line), ENC detachable mic, protein-leather cushions, carrying pouch, on-headset EQ (long-press mic button: Music/Game/Movie). Premium pick.
- THX NOTE (all four THX headsets — CryoCore, Proteus X, Olympus, Immortal): THX Spatial Audio+ software is WINDOWS-only and works over USB only (for the Immortal: the USB dongle; not Bluetooth, not 3.5mm); download from www.thecosmicbyte.com. It is NOT Orbit — do not send headset customers to Orbit. Earlier/pre-THX hardware (old CryoCore, old Proteus, earlier Immortal) cannot run THX.

EARBUDS:
- CosmoBuds X220: True wireless TWS, Bluetooth 5.3, 40ms GOD Mode gaming latency, 40hr total battery, IPX5 waterproof, ENC mic, fast charge.

BUYING GUIDE:
- Wireless multi-platform gaming → Immortal (only tri-mode headset; works wired/dongle/Bluetooth, Xbox via 3.5mm; upgraded model adds THX Spatial Audio 7.1.4 on Windows via the dongle)
- Wireless + THX Spatial Audio → Immortal (the only wireless THX headset; THX runs on Windows over the USB dongle). Wired THX → Olympus / Proteus X / CryoCore.
- PC gaming headset with THX Spatial Audio (7.1.4, wired) → Olympus (flagship, best sound, USB) / Proteus X (mid tier, USB + 3.5mm flexibility, RGB) / CryoCore upgraded (entry tier, USB, value)
- THX line tiering: CryoCore = entry, Proteus X = mid, Olympus = flagship/premium. Do NOT quote prices — send customers to the product page for current pricing.
- Best sound / premium THX → Olympus. Budget THX → CryoCore. Need 3.5mm for console/mobile too → Proteus X.
- Note: THX Spatial Audio works on WINDOWS over USB only; 3.5mm gives plain stereo; not Mac/console for the app.
- Multi-platform wired (PC/console/mobile) → Proteus X (dual input, THX). (Old Proteus is discontinued — do not recommend it.)
- Wireless earbuds for gaming + music → CosmoBuds X220

COSMIC BYTE ACCESSORIES — Quick Overview

LAPTOP COOLING:
- Cyclone RGB: 5-fan cooling pad (1×140mm + 4×60mm), 12 RGB effects, 7-level height adjustment, 2 USB ports, fits up to 17" laptops.

KEYBOARD + MOUSE COMBOS:
- Dragonfly (CB-GKM-19): Full-size RGB membrane keyboard + 7-button gaming mouse. 19-key anti-ghosting, 200-12800 DPI, 1000Hz polling rate, braided cable, software support.