Nordvik Washing Machine

Model series WM-7

User Manual and Care Guide

Nordvik | Support: support@nordvik-support.example | 1-800-555-0188

Contents

1. Safety

2. Operation

3. Care

4. Error codes

5. Troubleshooting

6. Service and warranty

1. Safety

• Read all instructions before using the appliance.

• Keep this manual for future reference and for any later owner.

• Installation must follow local plumbing and electrical codes.

• Do not allow children to operate the appliance unsupervised.

• Use only genuine Nordvik parts and accessories.

• Disconnect power before any cleaning near electrical parts.

• Wipe up spills promptly to prevent staining and slipping.

• Check supply hoses for wear once a year.

Do not open the door while the drum is turning.

2. Operation

Read all instructions before using the appliance. Check supply hoses for wear once a year. Wipe up spills promptly to prevent staining and slipping. Installation must follow local plumbing and electrical codes.

Installation must follow local plumbing and electrical codes. Disconnect power before any cleaning near electrical parts. Wipe up spills promptly to prevent staining and slipping. Check supply hoses for wear once a year.

Use only genuine Nordvik parts and accessories. Check supply hoses for wear once a year. Keep this manual for future reference and for any later owner. Wipe up spills promptly to prevent staining and slipping.

Read all instructions before using the appliance. Use only genuine Nordvik parts and accessories. Disconnect power before any cleaning near electrical parts. Keep this manual for future reference and for any later owner.

3. Care

Clean the detergent drawer monthly and wipe the door seal after use.

Wipe up spills promptly to prevent staining and slipping. Disconnect power before any cleaning near electrical parts. Do not allow children to operate the appliance unsupervised. Use only genuine Nordvik parts and accessories.

Disconnect power before any cleaning near electrical parts. Use only genuine Nordvik parts and accessories. Do not allow children to operate the appliance unsupervised. Wipe up spills promptly to prevent staining and slipping.

4. Error codes

Code	Meaning	Action
F21	Drain fault: water not draining.	Pause, power off, clean the drain pump filter behind the lower right panel (have a towel ready), check the drain hose for kinks, restart.
E03	Water inlet fault.	Check the tap and inlet screen.
E10	Door lock fault.	Close door firmly.

5. Troubleshooting

Symptom	Cause	Solution
Water left in drum, F21	Blocked pump filter or hose	Clean pump filter, check hose
Loud spin	Unbalanced load	Redistribute laundry
Does not start	Door open	Close door

6. Service and warranty

See the warranty card supplied. Keep your receipt.

Use only genuine Nordvik parts and accessories. Read all instructions before using the appliance. Wipe up spills promptly to prevent staining and slipping. Installation must follow local plumbing and electrical codes.