Nordvik Dishwasher

Model series ADW-48xx

User Manual and Care Guide

Nordvik | Support: support@nordvik-support.example | 1-800-555-0188

Contents

1. Safety

2. Installation

3. Controls

4. Loading

5. Wash cycles

6. Care and filter cleaning

7. Error codes

8. Troubleshooting

9. Specifications

10. Service and warranty

1. Safety

Warning: risk of electric shock or injury. Follow these rules.

• Read all instructions before using the appliance.

• Keep this manual for future reference and for any later owner.

• Installation must follow local plumbing and electrical codes.

• Do not allow children to operate the appliance unsupervised.

• Use only genuine Nordvik parts and accessories.

• Disconnect power before any cleaning near electrical parts.

• Wipe up spills promptly to prevent staining and slipping.

• Check supply hoses for wear once a year.

Do not operate a dishwasher that is leaking. Turn off the water supply and unplug the unit.

Important: any user repair beyond the steps listed in this manual (for example opening the base, replacing internal parts, or bypassing sensors) will void the manufacturer warranty and any extended protection plan.

2. Installation

Installation overview

Installation must follow local plumbing and electrical codes. Use only genuine Nordvik parts and accessories. Read all instructions before using the appliance. Check supply hoses for wear once a year.

Keep this manual for future reference and for any later owner. Do not allow children to operate the appliance unsupervised. Wipe up spills promptly to prevent staining and slipping. Disconnect power before any cleaning near electrical parts.

Wipe up spills promptly to prevent staining and slipping. Check supply hoses for wear once a year. Keep this manual for future reference and for any later owner. Read all instructions before using the appliance.

Check supply hoses for wear once a year. Read all instructions before using the appliance. Do not allow children to operate the appliance unsupervised. Disconnect power before any cleaning near electrical parts.

Connection	Requirement
Water supply	Cold or hot, 0.1-0.8 MPa
Drain hose	Max height 40 in., no kinks
Electrical	120 V, 60 Hz, 15 A dedicated

3. Controls

Button	Function
Power	Turns the unit on or off
Cycle	Cycles through Auto, Heavy, Eco, Quick
Delay	Delays start 1-12 hours
Start/Cancel	Starts a cycle; hold 3 s to cancel and drain

Read all instructions before using the appliance. Disconnect power before any cleaning near electrical parts. Do not allow children to operate the appliance unsupervised. Installation must follow local plumbing and electrical codes.

Do not allow children to operate the appliance unsupervised. Use only genuine Nordvik parts and accessories. Read all instructions before using the appliance. Installation must follow local plumbing and electrical codes.

Read all instructions before using the appliance. Check supply hoses for wear once a year. Wipe up spills promptly to prevent staining and slipping. Use only genuine Nordvik parts and accessories.

4. Loading

Read all instructions before using the appliance. Do not allow children to operate the appliance unsupervised. Disconnect power before any cleaning near electrical parts. Keep this manual for future reference and for any later owner.

Wipe up spills promptly to prevent staining and slipping. Disconnect power before any cleaning near electrical parts. Read all instructions before using the appliance. Use only genuine Nordvik parts and accessories.

Do not allow children to operate the appliance unsupervised. Wipe up spills promptly to prevent staining and slipping. Check supply hoses for wear once a year. Disconnect power before any cleaning near electrical parts.

Do not block the spray arms. Load sharp items pointing down. Do not overload the lower rack.

5. Wash cycles

Cycle	Duration	Water	Best for
Auto	120 min	12 L	Mixed loads
Heavy	165 min	15 L	Pots and pans
Eco	210 min	9 L	Everyday loads
Quick	45 min	10 L	Light soil

Do not allow children to operate the appliance unsupervised. Installation must follow local plumbing and electrical codes. Keep this manual for future reference and for any later owner. Disconnect power before any cleaning near electrical parts.

Check supply hoses for wear once a year. Installation must follow local plumbing and electrical codes. Read all instructions before using the appliance. Do not allow children to operate the appliance unsupervised.

6. Care and filter cleaning

Cleaning the filter

Clean the filter assembly once a month, or when water remains in the tub after a cycle.

1. Turn off and unplug the dishwasher.

2. Remove the lower rack.

3. Twist the cylindrical filter counter-clockwise and lift it out.

4. Separate the coarse filter and the fine mesh filter.

5. Rinse under running water with a soft brush. Do not use abrasive pads.

6. Reassemble and lock the filter with a clockwise twist until it clicks.

7. Check the spray arms for blocked holes.

Run a cleaning cycle with dishwasher cleaner every three months.

Keep this manual for future reference and for any later owner. Check supply hoses for wear once a year. Disconnect power before any cleaning near electrical parts. Installation must follow local plumbing and electrical codes.

Keep this manual for future reference and for any later owner. Disconnect power before any cleaning near electrical parts. Installation must follow local plumbing and electrical codes. Use only genuine Nordvik parts and accessories.

7. Error codes

When the control detects a fault it shows a code and stops the cycle.

Code	Meaning	Action
E15	Water detected in the base pan. Leak protection has stopped the unit.	Turn off water, unplug, tilt unit slightly to drain base pan only if instructed, check door gasket and hose connections. If E15 returns, call service. Do not open the base.
E24	Drain fault. Water not draining within 5 minutes.	Clean the filter, check drain hose for kinks and the sink air gap, restart.
E09	Heater or temperature sensor fault.	Cancel the cycle, power off for 5 minutes, restart. If it repeats, call service.
E11	Fill fault. Insufficient water inlet.	Open the supply valve, check the inlet screen.
E31	Door latch not detected.	Close the door firmly and restart.

8. Troubleshooting

Symptom	Possible cause	Solution
Water leaks from door	Dirty gasket, overloading, too much detergent	Wipe gasket, reload, use less detergent
Puddle under unit, E15 shown	Water in base pan: loose hose, door gasket, or internal leak	Stop the unit, check hose clamps and gasket. Service call if the leak persists
Dishes not clean	Blocked spray arm or filter	Clean filter and spray arms
Cloudy glassware	Hard water, too much detergent	Use rinse aid, reduce detergent
Does not start	Door open or power off	Close door, check breaker

Note: repairs by the user beyond the steps listed above void the warranty. Contact Nordvik Support for service.

9. Specifications

Item	Value
Capacity	14 place settings
Noise	44 dB
Dimensions	24 x 24 x 34 in.
Power	1800 W

Wipe up spills promptly to prevent staining and slipping. Use only genuine Nordvik parts and accessories. Disconnect power before any cleaning near electrical parts. Keep this manual for future reference and for any later owner.

Use only genuine Nordvik parts and accessories. Installation must follow local plumbing and electrical codes. Check supply hoses for wear once a year. Do not allow children to operate the appliance unsupervised.

10. Service and warranty

The product is covered by the Nordvik Limited Warranty supplied separately. Keep your receipt and take a photo of the serial plate inside the door frame.

Wipe up spills promptly to prevent staining and slipping. Use only genuine Nordvik parts and accessories. Read all instructions before using the appliance. Do not allow children to operate the appliance unsupervised.

Do not allow children to operate the appliance unsupervised. Disconnect power before any cleaning near electrical parts. Check supply hoses for wear once a year. Wipe up spills promptly to prevent staining and slipping.