

MCHOSE

G3 / G3 A Wireless Mouse

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.


PRODUCT OVERVIEW






CONNECTION METHOD

For Charging / Wired Connection Use




• Insert the Type-C end of the standard - equipped USB cable into the corresponding port of the mouse, and insert the USB end into the corresponding port of the computer to use it.
• In 2.4G / wireless mode, plugging in the USB cable will switch to wired mode and charge the mouse simultaneously.

For 2.4G Connection Use



• Slide the switch to [ON], short - press to switch to [2.4G], take out the [USB receiver] from the bottom of the mouse and plug it into the computer's USB port for use.
• Manual pairing (factory - default paired): Long - press the [mode switch button] until the indicator light flashes rapidly to enter the pairing state. Plug the receiver into the computer's USB port, keep the mouse within 20 cm of the receiver. The indicator light will turn off after a successful connection.

For Wireless Connection Use (The connection methods for Wireless 1 and Wireless 2 are the same)



Short - press to switch to [Wireless 1]. Search for and connect to the device named [G3 Mouse]. If the connection fails, long - press until the indicator light flashes rapidly to enter the pairing state and try to connect again. The indicator light will turn off after a successful connection.

■ DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

DPI Adjustment

Level 1: Red Light 400DPI


Level 2: Green Light 800DPI

Level 3: Blue Light 1600DPI


Level 4: Cyan Light 3200DPI

Level 5: Yellow Light 6400DPI

Level 6: Purple Light 12000DPI



Battery Status Indication



The red indicator light is flashing:
Please charge immediately

Indicator light red and solid:
Charging

Indicator light green and solid:
Charging completed

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1. It is recommended to charge the mouse only via a computer USB port.
2. Avoid using substandard or non-compliant power adapters to charge the mouse.
3. Avoid using over-voltage or over-current power adapters for charging.
4. Keep the mouse away from high-temperature devices while charging.
5. Please turn off the power switch if the device will not be used for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).