

|       |      |    |    |              |              |     |       |            |         |     |         |
|-------|------|----|----|--------------|--------------|-----|-------|------------|---------|-----|---------|
| Model | Year | MG | SG | Illustration | Restrictions | UPD | 14:16 | 25.02.2010 | PORSCHE | PET | PORSCHE |
| 9442  | 1988 | 6  | 04 | 604-01       |              | 248 |       |            |         |     |         |

The diagram illustrates the assembly of a brake master cylinder. The main components are labeled as follows:

- 1**: Ventilation valve (small cylindrical part at the bottom left).
- 2**: Brake master cylinder (large central component with a reservoir).
- 3**: Sealing ring (small ring-shaped part next to the master cylinder).
- 4**: Expansion tank (reservoir part of the master cylinder).
- 5**: Lid (top cap of the expansion tank).
- 6**: Intermediate piece (flange-like part on the right).
- 7**: Gasket (square flange part between the master cylinder and the intermediate piece).
- 8**: Washer (small circular parts used for mounting).
- 9**: Lock nut (small cylindrical parts used for mounting).
- 10**: Ventilation valve (small cylindrical part at the bottom left, similar to 1).

| Pos | Part Number    | Description                                                       | Remark | Qty | Model |
|-----|----------------|-------------------------------------------------------------------|--------|-----|-------|
|     |                | brake master cylinder<br>brake booster<br>expansion tank<br>-ABS- |        |     | M593  |
| 1   | 951 355 011 01 | brake master cylinder<br>- ate -                                  |        | 1   |       |
| 2   | 944 355 023 11 | brake booster<br>- ate -                                          |        | 1   |       |
| 3   | 251 611 243    | sealing ring                                                      |        | 1   |       |
| 4 A | 951 355 303 02 | expansion tank                                                    |        | 1   |       |
| 4   | 951 355 303 02 | expansion tank                                                    |        | 1   |       |
| 5   | 951 355 351 00 | lid                                                               |        | 1   |       |
| 6   | 951 355 021 01 | intermediate piece                                                |        | 1   |       |
| 7   | 477 611 951    | gasket                                                            |        | 1   |       |
| 8   | N 011 525 13   | washer                                                            |        | 4   |       |
| 9   | N 022 146 1    | lock nut                                                          |        | 4   |       |
| 10  | 930 351 919 00 | ventilation valve                                                 |        | 1   |       |